



TECHNICAL SPECIFICATION

LTE;
Mission Critical Video (MCVideo) media plane control;
Protocol specification
(3GPP TS 24.581 version 18.6.0 Release 18)

get full document from standards.iteh.ai



Reference

RTS/TSGC-0124581 vi60

Keywords

LTE

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from the
[ETSI Search & Browse Standards](#) application.

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format on [ETSI deliver](#) repository.

Users should be aware that the present document may be revised or have its status changed, this information is available in the [Milestones listing](#).

If you find errors in the present document, please send your comments to the relevant service listed under [Committee Support Staff](#).

If you find a security vulnerability in the present document, please report it through our [Coordinated Vulnerability Disclosure \(CVD\)](#) program.

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2026.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the [ETSI IPR online database](#).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™**, **LTE™** and **5G™** logo are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found at [3GPP to ETSI numbering cross-referencing](#).

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	15
1 Scope	16
2 References	16
3 Definitions, symbols and abbreviations	17
3.1 Definitions	17
3.2 Symbols.....	18
3.3 Abbreviations	18
4 General	18
4.1 MCVideo media plane overview.....	18
4.1.1 Transmission Control.....	18
4.1.1.1 General	18
4.1.1.2 On-network transmission and reception control.....	19
4.1.1.3 Off-network transmission control	20
4.1.1.4 Determine on-network effective priority.....	21
4.1.1.5 Determine off-network effective priority	21
4.1.2 MBMS subchannel control	22
4.1.2.1 General	22
4.1.2.2 Start of a MCVideo transmission	22
4.1.2.3 During a media transmission.....	23
4.1.2.4 Ending the transmission	23
4.1.2.5 MBMS bearer announcement over an MBMS bearer	23
4.1.3 MBS subchannel control.....	23
4.2 Internal structure of media plane control entities	23
4.2.1 Controlling MCVideo function.....	23
4.2.2 MCVideo client	25
4.2.3 Participating MCVideo function.....	27
4.2.3.1 General	27
4.2.3.2 Internal structure of the participating MCVideo function	27
4.2.3.3 The roles of the participating MCVideo function	28
4.2.3.3.1 For the transmission control procedures.....	28
4.2.3.3.2 For the use of MBMS bearer procedures.....	28
4.2.4 Non-controlling MCVideo function of an MCVideo group	28
4.3 The media plane control channel.....	30
4.3.1 General.....	30
4.3.2 Control channel realization	30
4.3.3 Establishing a media plane control channel	30
4.3.3.1 General	30
5 Functional entities	31
5.1 General	31
5.2 MCVideo client	32
5.2.1 Introduction.....	32
5.2.2 Transmission participant in on-network mode.....	32
5.2.3 Transmission participant in off-network mode	32
5.3 Controlling MCVideo function	33
5.4 Participating MCVideo function	33
6 On-network transmission control	33
6.1 General	33
6.2 Transmission participant procedures	34
6.2.1 Transmission participant procedures at MCVideo session initialization	34

6.2.2	Transmission participant procedures at MCVideo call release	34
6.2.3	Transmission participant procedures at MCVideo call modification.....	34
6.2.4	Transmission participant state transition diagram for basic transmission control operation	34
6.2.4.1	General	34
6.2.4.2	State: 'Start-stop'.....	35
6.2.4.2.1	General	35
6.2.4.2.2	MCVideo call initiated, originating MCVideo user	36
6.2.4.2.3	MCVideo call established, terminating MCVideo user	36
6.2.4.3	State: 'U: has no permission to transmit'	36
6.2.4.3.1	General	36
6.2.4.3.2	Send Transmission Request message (Click Transmission send button)	36
6.2.4.3.3	Void.....	37
6.2.4.3.4	Void.....	37
6.2.4.4	State: 'U: pending request to transmit'	37
6.2.4.4.1	General	37
6.2.4.4.2	Receive Transmission rejected message (R: Transmission rejected)	37
6.2.4.4.3	Timer T100 (Transmission request) expired	37
6.2.4.4.4	Timer T100 (Transmission Request) expired N times.....	38
6.2.4.4.5	Receive Queue Position Info message (R: Queue Position Info)	38
6.2.4.4.6	Receive Transmission Granted message (R: Transmission Granted).....	38
6.2.4.4.7	Send Transmission end request message (Click Transmission end button)	38
6.2.4.5	State: 'U: has permission to transmit'	39
6.2.4.5.1	General	39
6.2.4.5.2	Send RTP media packets (S: RTP media)	39
6.2.4.5.3	Send Transmission end request message (Click Transmission end button)	39
6.2.4.5.4	Void.....	39
6.2.4.5.5	Receive Transmission Revoked message (R: Transmission Revoked)	39
6.2.4.5.6	Receive Media reception notification message (R: Media Reception notification).....	40
6.2.4.5.7	Receive Transmission End Request message (R: Transmission End Request).....	40
6.2.4.6	State: 'U: pending end of transmission'	40
6.2.4.6.1	General	40
6.2.4.6.2	Timer T101 (Transmission End Request) expired.....	40
6.2.4.6.3	Timer T101 (Transmission End Request) expired N times	40
6.2.4.6.4	Receive Transmission End Response message (R: Transmission end response)	41
6.2.4.6.5	Void.....	41
6.2.4.7	In any state	41
6.2.4.7.1	General	41
6.2.4.7.2	Receive MCVideo call release – step 1 (R: MCVideo call release - 1).....	41
6.2.4.8	State: 'Call releasing'	41
6.2.4.8.1	General	41
6.2.4.8.2	Receive MCVideo call release – step 2 (R: MCVideo call release - 2).....	41
6.2.4.9	State: 'U: queued transmission'.....	42
6.2.4.9.1	General	42
6.2.4.9.2	Receive Queue Position Info message (R: Queue Position Info)	42
6.2.4.9.3	Send Queue Position Request message (S: Queue Position Request)	42
6.2.4.9.4	Send Transmission end request message (Click Transmission end button)	42
6.2.4.9.5	void.....	43
6.2.4.9.6	Receive Transmission cancel request notify message (R: Transmission Cancel Request Notify)	43
6.2.4.9.7	Timer T102 (Transmission Queue Position Request) expired.....	43
6.2.4.9.8	Timer T102 (Transmission Queue Position Request) expired N times	43
6.2.4.9.9	Receive Transmission Granted message (R: Transmission Granted).....	43
6.2.5	Transmission participant state transition diagram for reception control operation.....	44
6.2.5.1	General	44
6.2.5.2	State: 'Start-stop'.....	45
6.2.5.2.1	General	45
6.2.5.2.2	MCVideo call established, terminating MCVideo user	45
6.2.5.2.3	MCVideo call initiated, originating MCVideo user	46
6.2.5.3	State: 'U: reception controller'.....	46
6.2.5.3.1	General	46
6.2.5.3.2	Receive Media transmission notification message (R: Media Transmission Notification)	46
6.2.5.3.3	Send Receive Media Request message (Click video receive button)	47

6.2.5.3.4	Receive Transmission end notify message (R: Transmission end notify)	47
6.2.5.3.5	Receive MCVideo call release – step 1 (R: MCVideo call release - 1)	47
6.2.5.4	State: 'U: pending request to receive'	47
6.2.5.4.1	General	47
6.2.5.4.2	Reception of Receive media response (rejected) message (R: RM response (rejected))	47
6.2.5.4.3	Timer T103 (Receive media request) expired	48
6.2.5.4.4	Timer T103 (Receive Media Request) expired N times	48
6.2.5.4.5	Reception of Receive media response (granted) message (R: RM response (granted))	48
6.2.5.4.6	Media reception request cancel (Click video reception end button)	49
6.2.5.5	State: 'U: has permission to receive'	49
6.2.5.5.1	General	49
6.2.5.5.2	Receive RTP media packets (R: RTP media)	49
6.2.5.5.3	Media reception end request message (Click video reception end button)	49
6.2.5.5.4	Receive Media reception override notify message (R: Media Rx override notify)	50
6.2.5.5.5	Receive Media reception end request message (R: MRE request)	50
6.2.5.5.6	Void	50
6.2.5.6	State: 'U: pending reception release'	50
6.2.5.6.1	General	50
6.2.5.6.2	Timer T104 (Receive Media Release) expired	50
6.2.5.6.3	Timer T104 (Receive media release) expired N times	51
6.2.5.6.4	Receive Media Reception End Response message (R: MRE response)	51
6.2.5.6.5	Void	51
6.2.5.7	Void	51
6.2.5.7.1	Void	51
6.2.5.7.2	Void	51
6.2.5.7.3	Void	51
6.2.5.7.4	Void	51
6.2.5.8	State: 'U: terminated'	51
6.2.5.8.1	General	51
6.2.5.9	State: 'Call releasing'	52
6.2.5.9.1	General	52
6.2.5.9.2	Receive MCVideo call release – step 2 (R: MCVideo call release - 2)	52
6.3	Transmission control server procedures	52
6.3.1	General	52
6.3.2	Controlling MCVideo function procedures at MCVideo call initialization	52
6.3.2.1	General	52
6.3.2.2	Initial procedures	52
6.3.2.3	Switching from a non-controlling MCVideo function mode to a controlling MCVideo function mode	53
6.3.3	MCVideo transmission control procedures at MCVideo call release	53
6.3.4	Transmission control server state transition diagram for general transmission control operation	54
6.3.4.1	General	54
6.3.4.2	State: 'Start-stop'	55
6.3.4.2.1	General	55
6.3.4.2.2	MCVideo call initialization	56
6.3.4.3	State: 'G: Transmit Idle'	56
6.3.4.3.1	General	56
6.3.4.3.2	Enter the 'G: Transmit Idle' state	56
6.3.4.3.3	Receive Transmission Media Request message (R: Transmission Media Request)	57
6.3.4.3.4	Timer T2 (Transmit Idle) expired	57
6.3.4.3.5	Timer T1 (Inactivity) expired	58
6.3.4.3.6	Receive an implicit Transmission request (R: Implicit Transmission request)	58
6.3.4.4	State: 'G: Transmit Taken'	58
6.3.4.4.1	General	58
6.3.4.4.2	Enter the 'G: Transmit Taken' state	59
6.3.4.4.5	Receive RTP media packets (R: RTP media)	59
6.3.4.4.6	Receive Transmission End Request message (R: Transmission End Request)	59
6.3.4.4.7A	Receive Transmission Media Request message without pre-emptive priority (R: Transmission Media Request)	60
6.3.4.4.7	Receive Transmission Media Request message with pre-emptive priority (R: pre-emptive Transmission Media Request)	60

6.3.4.4.8	Receive Transmission request message from permitted transmission participant (R: Transmission Media Request)	61
6.3.4.4.9	Timer T4 (Transmission Grant) expired.....	61
6.3.4.4.10	Timer T4 (Transmission Grant) expired N times	62
6.3.4.4.11	Permitted MCVidéo client release (R: client release).....	62
6.3.4.4.12	Receive an implicit Transmission request (R: Implicit Transmission request)	62
6.3.4.4.13	Send Transmission End Request message (S: Transmission End Request)	62
6.3.4.5	State: 'G: pending Transmission Revoke'.....	63
6.3.4.5.1	General	63
6.3.4.5.2	Enter the 'G: pending Transmission Revoke' state.....	63
6.3.4.5.3	Receive RTP media packets (R: RTP media).....	63
6.3.4.5.4	Receive Transmission End Request message (R: Transmission End Request)	63
6.3.4.5.5	Void.....	64
6.3.4.5.6	Void.....	64
6.3.4.5.7	Receive Transmission End Response message (R: Transmission End Response)	64
6.3.4.6	In any state	64
6.3.4.6.1	General	64
6.3.4.6.2	Receive MCVidéo call release - 1	64
6.3.4.7	State: 'Releasing'	65
6.3.4.7.1	General	65
6.3.4.7.2	Receive MCVidéo call release - 2	65
6.3.5	Transmission control server state transition diagram for basic transmission control operation towards the transmission participant	65
6.3.5.1	General	65
6.3.5.2	State: 'Start-stop'.....	67
6.3.5.2.1	General	67
6.3.5.2.2	SIP Session initiated	67
6.3.5.3	State: 'U: not permitted and Transmit Idle'.....	70
6.3.5.3.1	General	70
6.3.5.3.2	Enter state 'U: not permitted and Transmit Idle'	70
6.3.5.3.3	Void.....	70
6.3.5.3.4	Receive Transmission Media Request message (R: Transmission Media Request).....	70
6.3.5.3.5	Send Transmission Grant message (S: Transmission Grant).....	70
6.3.5.3.6	Send Transmission Reject message (S: Transmission Reject).....	71
6.3.5.3.7	Receive Transmission End Request message (R: Transmission End Request)	71
6.3.5.3.8	Receive RTP media packets (R: media)	71
6.3.5.3.9	Receive an implicit Transmission request (R: Implicit Transmission request)	72
6.3.5.3.10	Send Transmission Idle message (S: Transmit Idle)	72
6.3.5.4	State 'U: not permitted and transmit taken'.....	72
6.3.5.4.1	General	72
6.3.5.4.2	Enter state 'U: not permitted and Transmit Taken'	72
6.3.5.4.3	Send Transmission Idle message (S: Transmit Idle)	73
6.3.5.4.4	Receive Transmission Media Request message (R: Transmission Media Request).....	73
6.3.5.4.5	Receive Transmission End Request message (R: Transmission End Request)	76
6.3.5.4.6	Receive RTP media packets (R: media)	78
6.3.5.4.7	Send Transmission Queue Position Info message (R: Transmission Queue Position Request)	78
6.3.5.4.8	Receive an implicit Transmission request (R: Implicit Transmission request)	78
6.3.5.4.9	Send Transmission Grant message (S: Transmission Grant).....	78
6.3.5.4.10	Send Media Transmission Notification message (S: Media Transmission Notification)	79
6.3.5.5	State: 'U: permitted'	79
6.3.5.5.1	General	79
6.3.5.5.2	Enter state 'U: permitted'	79
6.3.5.5.3	Receive Transmission End Request message (R: Transmission End Request)	79
6.3.5.5.3a	Send Transmission End Response message (S: Transmission End Response).....	80
6.3.5.5.4	Send Transmission Idle message (S: Transmit Idle)	80
6.3.5.5.5	Send Transmission Revoke message (S: Transmission Revoke).....	80
6.3.5.5.6	Receive RTP media packets (R: media)	80
6.3.5.5.7	Receive Transmission Media Request message (R: Transmission Media Request).....	80
6.3.5.5.8	Send RTP Media (S: media).....	80
6.3.5.5.9	Send Media Transmission Notification message (S: Media Transmission Notification)	80
6.3.5.5.10	Send Transmission End Request message (S: Transmission End Request)	81
6.3.5.6	State: 'U: pending Transmit Revoke'.....	81

6.3.5.6.1	General	81
6.3.5.6.2	Enter state 'U pending Transmit Revoke'	81
6.3.5.6.3	Timer T3 (Transmission Revoke) expired	81
6.3.5.6.4	Receive RTP media packets (R: media)	81
6.3.5.6.5	Receive Transmission End Request message (R: Transmission End Request)	82
6.3.5.6.5a	Send Transmission End Response message (S: Transmission End Response)	82
6.3.5.6.6	Send Transmission Idle message (S: Transmit Idle)	82
6.3.5.6.7	Send Media Transmission Notification message (S: Media Transmission Notification)	82
6.3.5.6.8	Receive Transmission End Response message (R: Transmission End Response)	83
6.3.5.7	State 'U: not permitted but sends media'	83
6.3.5.7.1	General	83
6.3.5.7.2	Enter state 'U: not permitted but sends media'	83
6.3.5.7.3	Timer T3 (Transmission Revoke) expired	83
6.3.5.7.4	Receive Transmission End Request message (R: Transmission End Request)	84
6.3.5.8	In any state	84
6.3.5.8.1	General	84
6.3.5.8.2	Receive MCVideo call release – 1	85
6.3.5.9	State: 'Releasing'	85
6.3.5.9.1	General	85
6.3.5.9.2	Receive MCVideo call release - 2	85
6.3.6	Transmission control server state transition for general reception control	85
6.3.6.1	General	85
6.3.6.2	State: 'Start-stop'	86
6.3.6.2.1	General	86
6.3.6.2.2	MCVideo call initialization	87
6.3.6.3	State: 'Gr: Reception Idle'	87
6.3.6.3.1	General	87
6.3.6.3.2	Enter the 'Gr: Reception Idle' state	87
6.3.6.3.3	Receive Media Transmission Notification message (R: Media Transmission Notification)	87
6.3.6.3.4	Void	88
6.3.6.3.5	Timer T5 (Reception Inactivity) expired	88
6.3.6.3.6	Reception of Receive Media Request message (R: Receive Media Request)	88
6.3.6.3.7	Receive RTP media (R: RTP media)	89
6.3.6.3.8	Receive Transmission End Notify message (R: Transmission End Notify)	89
6.3.6.3.9	Timer T11(Stream Reception Idle) expired	89
6.3.6.4	State: 'Gr: Reception accepted'	89
6.3.6.4.1	General	89
6.3.6.4.2	Enter the 'Gr: Reception Accepted' state	89
6.3.6.4.3	Reception of Receive Media Request message (R: Receive Media Request)	89
6.3.6.4.4	Reception of Receive Media End Request message (R: Receive Media End Request)	90
6.3.6.4.5	Reception of Receive Media End Response message (R: Receive Media End Response)	90
6.3.6.4.6	Void	91
6.3.6.4.7	Receive RTP media (R: RTP media)	91
6.3.6.4.8	Timer T6 (Reception Granted) expires	91
6.3.6.4.9	Timer T6 (Reception Granted) expired N times	91
6.3.6.4.10	Receive Media Transmission Notification message (R: Media Transmission Notification)	91
6.3.6.4.11	Receive Transmission End Notify message (R: Transmission End Notify)	92
6.3.6.4.12	Timer T11(Stream Reception Idle) expired	92
6.3.6.5	State: 'Gr: Any state'	92
6.3.6.5.1	General	92
6.3.6.5.2	Receive MCVideo call release - 1	92
6.3.6.6	State: 'Gr: Releasing'	93
6.3.6.6.1	General	93
6.3.6.6.2	Receive MCVideo call release - 2	93
6.3.7	Transmission control server state transition for basic reception control operations towards the transmission participant	93
6.3.7.1	General	93
6.3.7.2	State: 'Start-stop'	95
6.3.7.2.1	General	95
6.3.7.2.2	SIP Session initiated	95
6.3.7.3	State: 'U: not permitted to receive'	96
6.3.7.3.1	General	96

6.3.7.3.2	Enter state 'U: not permitted to receive'	96
6.3.7.3.3	Send Media Transmission Notification message (S: Media Transmission Notification)	96
6.3.7.3.4	Reception of Receive Media Request message (R: Receive Media Request)	97
6.3.7.3.5	Receive Media Reception End Response message (R: Media Reception End Resonse).....	97
6.3.7.3.6	Send Receive Media Response (Granted) message (S: Receive Media Response (Granted))	98
6.3.7.3.7	Send Transmission End Notify message (S: Transmission End Notify)	98
6.3.7.4	State: 'U: permitted to receive'	98
6.3.7.4.1	General	98
6.3.7.4.2	Enter state 'U: permitted to receive'.....	98
6.3.7.4.3	Send RTP media packets (S: RTP media)	98
6.3.7.4.4	Receive Media Reception End Request message (R: Media Reception End Request).....	99
6.3.7.4.5	Send Media Transmission Notification message (S: Media Transmission Notification)	99
6.3.7.4.6	Send Media Reception Override Notify message (S: Media Reception Override Notify)	99
6.3.7.4.7	Send Transmission End Notify message (S: Transmission End Notify)	99
6.3.7.4.8	Send Media Reception End Request message (S: Media Reception End Request).....	100
6.3.7.4.9	Send Media Reception End Response message (S: Media Reception End Response).....	100
6.3.7.4.10	Reception of Receive Media Request message (R: Receive Media Request)	100
6.3.7.4.11	Send Receive Media Response (Granted) message (S: Receive Media Response (Granted))	101
6.3.7.4.12	Receive Media Reception End Response message (R: Media Reception End Response).....	101
6.4	Participating MCVideo function transmission control procedures.....	102
6.4.1	General.....	102
6.4.2	Receive transmission control messages	102
6.4.3	Receive RTP media packets (R: RTP Media).....	102
6.4.4	Release of session	103
6.5	Non-controlling MCVideo function of an MCVideo group.....	103
6.5.1	General.....	103
6.5.2	The MCVideo call initialization procedure in the non-controlling MCVideo function of an MCVideo group.....	103
6.5.2.1	General	103
6.5.2.2	Initial procedures when a new SIP session is establishing a group session	104
6.5.2.3	Switching from a controlling MCVideo function mode to a non-controlling MCVideo function mode.....	104
6.5.2.3.1	Overview	104
6.5.2.3.2	Preparing for the switch to non-controlling MCVideo function (Step 1)	104
6.5.2.3.3	Start acting as a non-controlling MCVideo function (Step 2)	105
6.5.3	The MCVideo call release procedure in the non-controlling MCVideo function of an MCVideo group.....	105
6.5.4	Floor control server interface procedures	106
6.5.4.1	General	106
6.5.4.2	Receiving a Transmission Request message	106
6.5.4.3	Receive Transmission Release message.....	106
6.5.4.4	Receive Queue Position Request message	107
6.5.4.5	Receive Transmission Control Ack message	107
6.5.4.6	Receive Transmission Granted message	107
6.5.4.7	Receive Transmission Rejected message	108
6.5.4.8	Receive Transmission Idle message.....	108
6.5.4.9	Receive Media Transmission Notification message.....	109
6.5.4.10	Receive Transmission Revoked message.....	110
6.5.4.11	Receive Queue Position Info message	110
6.5.4.12	Receive RTP media packets from controlling MCVideo function.....	110
6.5.4.13	Receive RTP media packets from an MCVideo client.....	111
6.5.4.14	MCVideo session release step 1.....	111
6.5.4.15	MCVideo session release step 2.....	111
6.5.4.16	Receiving a split instruction (R: Split)	111
6.5.5	Floor participant interface procedures	111
6.5.5.1	General	111
6.5.5.2	State: 'Start-Stop'	112
6.5.5.2.1	General	112
6.5.5.2.2	Participant invited to session	112
6.5.5.3	State: 'P: has no permission'	113
6.5.5.3.1	General	113
6.5.5.3.2	Receive Transmission Idle message (R: Transmission Idle)	113

6.5.5.3.3	Receive Media Transmission Notification message (R: Media Transmission Notification).....	113
6.5.5.3.4	Receive Transmission Request message (R: Transmission Request).....	113
6.5.5.3.5	Receive Transmission Granted message (R: Transmission Granted).....	113
6.5.5.3.6	Receive Transmission Rejected message (R: Transmission Rejected).....	113
6.5.5.3.7	Receive Queue Position Info message (R: Queue Position Info).....	114
6.5.5.3.8	Receive Queue Position Request message (R: Queue Position Request).....	114
6.5.5.3.9	Receive RTP media packets (R: RTP media).....	114
6.5.5.3.10	Receive Transmission Release message (R: Transmission Release).....	114
6.5.5.3.11	Receive split instruction (R: Split).....	115
6.5.5.4	State: 'P: has permission'.....	115
6.5.5.4.1	General.....	115
6.5.5.4.2	Receive RTP media packets.....	115
6.5.5.4.3	Receive Transmission Release message.....	115
6.5.5.4.4	Receive Transmission Ack message.....	115
6.5.5.4.5	Receive Transmission Idle message.....	116
6.5.5.4.6	Receive Media Transmission Notification message.....	116
6.5.5.4.7	Receive Transmission Revoked message.....	116
6.5.5.4.8	Receive split instruction (R: Split).....	116
6.5.5.5	In any state.....	117
6.5.5.5.1	General.....	117
6.5.5.5.2	Receive Transmission Ack message (R: Transmission Ack).....	117
6.5.5.5.3	MCVideo session release step 1 (MCVideo call release - 1).....	117
6.5.5.6	State: 'P: Releasing'.....	117
6.5.5.6.1	General.....	117
6.5.5.6.2	MCVideo session release step 2 (MCVideo call release - 2).....	117
7	Off-network MCVideo service media plane procedures.....	118
7.1	General.....	118
7.2	Transmission participant procedures for single arbitrator approach.....	118
7.2.1	Transmission participant procedures at MCVideo session initialisation.....	118
7.2.1.2	Determine off-network transmission priority.....	119
7.2.2	Transmission participant procedures at MCVideo call release.....	120
7.2.3	Transmission participant state diagram – basic operation.....	120
7.2.3.1	General.....	120
7.2.3.2	State: 'Start-stop'.....	121
7.2.3.2.1	General.....	121
7.2.3.2.2	MCVideo call established – originating MCVideo user.....	122
7.2.3.2.3	MCVideo group call established – terminating MCVideo user.....	122
7.2.3.2.4	MCVideo private call established – terminating MCVideo user.....	122
7.2.3.2.5	Send Transmission Request message (click video transmission send button).....	122
7.2.3.2.6	Receive Transmission Arbitration Taken message (R: Transmission Arbitration Taken).....	123
7.2.3.2.7	Receive Transmission Granted message (R: Transmission Granted to other).....	123
7.2.3.2.8	Receive RTP media (R: RTP media).....	123
7.2.3.2.9	MCVideo broadcast call established – terminating MCVideo user.....	123
7.2.3.3	State: 'O: silence'.....	123
7.2.3.3.1	General.....	123
7.2.3.3.2	Send Transmission Request message (click video transmission send button).....	124
7.2.3.3.3	Receive RTP media (R: RTP media).....	124
7.2.3.3.4	Receive Transmission Granted message (R: Transmission Granted to other).....	124
7.2.3.3.5	Receive Transmission Request message (R: Transmission Request).....	124
7.2.3.3.6	Receive Transmission Arbitration Taken message (R: Transmission Arbitration Taken).....	125
7.2.3.3.7	Timer T230 (Inactivity) expired.....	125
7.2.3.4	State: 'O: has no permission'.....	125
7.2.3.4.1	General.....	125
7.2.3.4.2	Sending Transmission Request message (click video transmission send button).....	125
7.2.3.4.3	Receive Transmission Release message (R: Transmission Release).....	126
7.2.3.4.4	Receive Transmission Arbitration Release message (R: Transmission Arbitration Release).....	126
7.2.3.4.5	Timer T203 (End of RTP media) expired.....	126
7.2.3.4.6	Receive Transmission Granted message (R: Transmission Granted to other).....	126
7.2.3.4.7	Receive RTP media (R: RTP media).....	127
7.2.3.4.8	Receive Transmission Arbitration Taken message (R: Transmission Arbitration Taken).....	127
7.2.3.4.9	Receive Transmission Revoked message (R: Transmission Revoked).....	127

7.2.3.5	State: 'O: transmission arbitration'	128
7.2.3.5.1	General	128
7.2.3.5.2	Send RTP Media packets (S: RTP Media)	128
7.2.3.5.3	Receive Transmission Release message (R: Transmission Release)	128
7.2.3.5.4	Receive Transmission Request message (R: Transmission Request)	128
7.2.3.5.5	Send Transmission Arbitration Release message (click video transmission end button with empty transmitter list)	129
7.2.3.5.6	Send Transmission Arbitration Release message (click video transmission end button with non-empty transmitter list)	129
7.2.3.5.7	Receive Transmission Request message with pre-emption indication and revoking self (R: Transmission Request with pre-emption)	129
7.2.3.5.8	Receive Transmission Request message with pre-emption indication and revoking a transmitter (R: Transmission Request with pre-emption)	130
7.2.3.5.9	Transmission time limit warning (Timer T206 expires)	131
7.2.3.5.10	Transmission time limit reached with transmitter(s) in transmitter list (Timer T207 expires with transmitter(s))	131
7.2.3.5.11	Transmission time limit reached with no transmitter in transmitter list (Timer T207 expires with no transmitter)	131
7.2.3.5.12	Receive RTP media (R: RTP media)	131
7.2.3.5.13	Timer T205 (Transmission Granted) expired (timer T205 expired)	132
7.2.3.5.14	Timer T205 (Transmission Granted) expired N times (Timer T205 expired N times)	132
7.2.3.5.15	Timer T203 (End of RTP media) expired	132
7.2.3.6	State: 'O: has permission'	132
7.2.3.6.1	General	132
7.2.3.6.2	Send RTP Media packets (S: RTP Media)	133
7.2.3.6.3	Receive Transmission Release message (R: Transmission Release)	133
7.2.3.6.4	Send Transmission Release message (click video transmission end button)	133
7.2.3.6.5	Receive RTP media (R: RTP media)	133
7.2.3.6.6	Transmission time limit warning (Timer T206 expires)	134
7.2.3.6.7	Transmission time limit (Timer T207 expires)	134
7.2.3.6.8	Timer T203 (End of RTP media) expired	134
7.2.3.6.9	Receive Transmission Granted message (R: Transmission Granted to other)	134
7.2.3.6.10	Receive Transmission Arbitration Taken message (R: Transmission Arbitration Taken)	134
7.2.3.6.11	Receive Transmission Arbitration Release message with next arbitrator to me (R: Transmission Arbitration Release with next arbitrator to me)	135
7.2.3.6.12	Receive Transmission Revoked message (R: Transmission Revoked)	135
7.2.3.6.13	Receive Transmission Arbitration Release message with next arbitrator to other (R: Transmission Arbitration Release with next arbitrator to other)	135
7.2.3.7	State: 'O: pending request'	135
7.2.3.7.1	General	135
7.2.3.7.2	Receive RTP media (R: RTP media)	135
7.2.3.7.3	Receive Transmission Rejected message (R: Transmission Rejected)	136
7.2.3.7.4	Send Transmission Release message (click video transmission end button with no transmitter)	136
7.2.3.7.5	Send Transmission Release message (click video transmission end button with transmitter)	136
7.2.3.7.6	Send Transmission Arbitration Taken message (Timer T201 expired N times)	137
7.2.3.7.7	Receive Transmission Granted message (R: Transmission Granted to me)	137
7.2.3.7.8	Receive Transmission Granted message with next arbitrator (R: Transmission Granted with next arbitrator to me)	137
7.2.3.7.9	Receive Transmission Granted message (R: Transmission Granted to other)	138
7.2.3.7.10	Timer T201 (Transmission Request) expired (Timer T201 expired)	138
7.2.3.7.11	Receive Transmission Request message (R: Transmission request)	138
7.2.3.7.12	Receive Transmission Arbitration Taken message (R: Transmission Arbitration Taken)	138
7.2.3.7.13	Receive Transmission Release message (R: Transmission Release)	139
7.2.3.7.14	Receive Transmission Revoked message (R: Transmission Revoked)	139
7.2.3.8	State: 'O: pending delegated'	139
7.2.3.8.1	General	139
7.2.3.8.2	Receive RTP media (R: RTP Media)	139
7.2.3.8.3	Timer T205 (Transmission Granted) expired (timer T205 expired)	140
7.2.3.8.4	Timer T205 (Transmission Granted) expired N times with transmitter(s) in the transmitter list (Timer T205 expired N times and transmitter in transmitter list)	140

7.2.3.8.5	Timer T205 (Transmission Granted) expired N times with no transmitter in the transmitter list (Timer T205 expired N times and no transmitter in transmitter list)	140
7.2.3.8.6	Click Video transmission send button	141
7.2.3.8.7	Receive Transmission Release message (R: Transmission Release)	141
7.2.3.8.8	Receive Transmission Request message (R: Transmission Request)	141
7.2.3.8.9	Receive Transmission Arbitration Taken message (R: Transmission Arbitration Taken)	141
7.2.3.8.10	Timer T208 (Transmission Arbitration Release) expired (timer T208 expired).....	141
7.2.3.8.11	Timer T208 (Transmission Arbitration Release) expired N times with transmitter(s) in the transmitter list (Timer T208 expired N times and transmitter in transmitter list).....	142
7.2.3.8.12	Timer T208 (Transmission Arbitration Release) expired N times with no transmitter in the transmitter list (Timer T208 expired N times and no transmitter in transmitter list).....	142
7.2.3.9	In any state	143
7.2.3.9.1	General	143
7.2.3.9.2	Receive MCVideo call release (R: MCVideo call release)	143
8	Communication release media plane procedures	143
9	Coding	143
9.1	Introduction	143
9.1.1	General.....	143
9.1.2	RTCP: APP message format.....	143
9.1.3	Application specific data field.....	145
9.1.4	Handling of unknown messages and fields.....	146
9.2	Transmission control	146
9.2.1	Introduction.....	146
9.2.2	Transmission control messages.....	146
9.2.2.1	General	146
9.2.3	Transmission control specific fields	147
9.2.3.1	Introduction.....	147
9.2.3.2	Transmission Priority field.....	148
9.2.3.3	Duration field	149
9.2.3.4	Reject Cause field	149
9.2.3.5	Queue Info field	150
9.2.3.6	User Id of the Transmitting User field	150
9.2.3.7	Permission to Request the Transmission field	151
9.2.3.8	User ID field.....	151
9.2.3.9	Message Sequence Number field	152
9.2.3.10	Message Type field	152
9.2.3.11	Transmission Indicator field.....	152
9.2.3.12	Source field	153
9.2.3.13	Track Info field	154
9.2.3.14	Queued User ID field	154
9.2.3.15	Queue Size field.....	155
9.2.3.16	Audio SSRC of Transmitting Participant field.....	155
9.2.3.17	Result	156
9.2.3.18	Message Name field.....	156
9.2.3.19	Reception Priority field.....	156
9.2.3.20	MCVideo Group Identity field.....	157
9.2.3.21	Functional Alias field.....	157
9.2.3.22	Reception Mode Field.....	158
9.2.3.23	Video SSRC of the Transmitting User field.....	158
9.2.4	Transmission Request message.....	159
9.2.5	Transmission Granted message.....	160
9.2.6	Transmission Rejected message	162
9.2.6.1	General	162
9.2.6.2	Rejection cause codes and rejection cause phrase.....	163
9.2.7	Transmission Release message.....	163
9.2.8	Transmission Arbitration Taken message.....	164
9.2.9	Transmission Arbitration Released message	166
9.2.10	Transmission Revoked message	167
9.2.10.1	General	167
9.2.10.2	Transmission revoked cause codes and revoked cause phrases	168

9.2.11	Queue Position Request message.....	169
9.2.12	Queue Position Info message.....	169
9.2.13	Media transmission notification.....	171
9.2.14	Receive media request	172
9.2.15	Receive media response.....	174
9.2.15.1	General	174
9.2.15.2	Rejection cause codes and rejection cause phrase.....	175
9.2.16	Media reception notification	176
9.2.17	Void	177
9.2.18	Void	177
9.2.19	Transmission cancel request notify.....	177
9.2.20	Transmission end request.....	178
9.2.21	Transmission end response	179
9.2.22	Remote Transmission request	180
9.2.23	Remote Transmission response.....	181
9.2.24	Remote Transmission cancel request.....	181
9.2.25	Remote Transmission cancel response	182
9.2.26	Media reception end request	183
9.2.27	Media reception end response.....	184
9.2.28	Media reception override notification.....	185
9.2.29	Transmission end notify.....	186
9.2.30	Transmission idle.....	187
9.2.31	Transmission control ack	188
9.3	MBMS subchannel control.....	189
9.3.1	Introduction.....	189
9.3.2	MBMS subchannel control messages	189
9.3.3	MBMS subchannel control specific fields.....	189
9.3.3.1	Introduction.....	189
9.3.3.2	MCVideo Group ID field.....	189
9.3.3.3	MBMS Subchannel field.....	190
9.3.3.4	TMGI field	191
9.3.3.5	Monitoring state	191
9.3.4	Map Group To Bearer message	191
9.3.5	Unmap Group To Bearer message.....	192
9.3.6	Application Paging message.....	193
9.3.7	Bearer Announcement message.....	193
9.4	MBMS notifications	194
9.4.1	Introduction.....	194
9.4.2	MBMS notifications control messages	194
9.4.3	MBMS notifications control specific fields.....	195
9.4.3.1	Introduction.....	195
9.4.3.2	Status field.....	195
9.4.3.3	Status changing MCVideo User Identity field	195
9.4.3.4	Group call ongoing field	196
9.4.3.5	Group broadcast alias field.....	196
9.4.3.6	Group regroup alias field	197
9.4.4	Group Dynamic Data Notify message	198
9.5	MBS subchannel control	199
9.5.1	Introduction.....	199
9.5.2	MBS subchannel control messages.....	199
9.5.3	MBS subchannel control specific fields.....	199
9.5.3.1	Introduction.....	199
9.5.3.2	MCVideo Group ID field.....	199
9.5.3.3	MBS Subchannel field	200
9.5.3.4	MBS Session ID field.....	201
9.5.3.5	Monitoring state	201
9.5.4	MapGroupToSessionStream message.....	201
9.5.5	UnMapGroupFromSessionStream message	202
9.5.6	MBS Application Paging message.....	203
9.5.7	Session Announcement message	204
10	Media plane handling for MBMS	204

10.1	General	204
10.2	MBMS subchannel control procedure for the participating MCVideo function	205
10.2.1	General	205
10.2.2	State: 'Start-stop'	206
10.2.2.1	General	206
10.2.2.2	Send Map Group To Bearer message (R: Transmission Request, Media Transmission Notification)	206
10.2.3	State: 'M: A transmission is active'	206
10.2.3.1	General	206
10.2.3.2	Send Transmission Idle message (R: Transmission Idle)	207
10.2.3.3	Send Media Transmission Notification message (R: Media Transmission Notification)	207
10.2.3.4	Send any other transmission control message (R: Any other message)	207
10.2.3.5	Send RTP media packet over the MBMS subchannel (R: RTP packet)	207
10.2.3.7	Timer T300 (Transmission) expired	208
10.2.3.8	Timer T301 (Map Group To Bearer) expired	208
10.2.3.9	Timer T302 (Unmap Group To Bearer) expired	208
10.2.3.10	Timer T302 (Unmap Group To Bearer) expired Nth time	209
10.2.3.11	End transmission over the MBMS bearer (End transmission)	209
10.2.3.12	Group call released	209
10.2.3.13	Move conversation to unicast	209
10.3	MBMS subchannel control procedure for the MCVideo client	209
10.3.1	General	209
10.3.2	Transmission over a pre-activated MBMS bearer is started	210
10.3.3	Receive transmission control messages, RTP media packets and FEC repair packets over a MBMS subchannel	210
10.3.4	Transmission ended	210
10.3.5	Receive Application Paging message	210
10.3.6	Receive MBMS bearer announcement over MBMS bearer	210
10.4	Forward error correction	210
10.4.1	General	210
10.4.2	Participating MCVideo function procedure for FEC	211
10.4.3	MCVideo client procedure for FEC	211
10.5	Additional MBMS procedures	211
10.5.1	Group dynamic data notifications	211
10A	Media plane handling for MBS	211
11	Configurable parameters	212
11.1	Timers	212
11.1.1	Timers in the on-network transmission participant	212
11.1.2	Timers in the off-network transmission participant	215
11.1.3	Timers in the transmission control server	218
11.1.4	Timers in the participating MCVideo function	221
11.2	Counters	222
11.2.1	Counters in the on-network transmission participant	222
11.2.2	Counters in the off-network transmission participant	223
11.2.3	Counters in the controlling MCVideo function	223
11.2.4	Counters in the participating MCVideo function	224
12	Extensions within the present document	225
12.1	Session description types defined within the present document	225
12.1.1	General	225
12.1.2	SDP "fmtp" attribute for MCVideo	225
12.1.2.1	General	225
12.1.2.2	Semantics	225
12.1.2.3	Syntax	226
13	Media plane security	227
13.1	General	227
13.2	Derivation of SRTP/SRTCP master keys	229
13.3	Media plane encryption and decryption	229
13.3.1	General	229
13.3.2	The participating MCVideo function	229

13.3.3	The MCVideo client	230
13.3.4	The controlling MCVideo function	234
14	SDP offer/ answer procedures	236
14.1	General	236
14.2	Generating an SDP offer	236
14.2.1	General	236
14.2.2	"mc_queueing" fmp attribute	236
14.2.3	"mc_priority" fmp attribute	236
14.2.4	"mc_granted" fmp attribute	236
14.2.5	"mc_implicit_request" fmp attribute	236
14.2.6	"mc_reception_priority" fmp attribute	237
14.2.7	"mc_transmission_src" fmp attribute	237
14.3	Generating the SDP answer	237
14.3.1	General	237
14.3.2	"mc_queueing" fmp attribute	237
14.3.3	"mc_priority" fmp attribute	237
14.3.4	"mc_granted" fmp attribute	238
14.3.5	"mc_implicit_request" fmp attribute	238
14.3.6	"mc_reception_priority" fmp attribute	238
14.3.7	"mc_audio_src" fmp attribute	238
14.3.8	"mc_video_src" fmp attribute	238
14.3.9	"mc_transmission_src" fmp attribute	239
14.4	Offerer processing of the SDP answer	239
14.5	Modifying the media plane control channel	239
14.6	The use of SDP offer / answer procedures in off-network mode	239
14.6.1	General	239
14.6.2	fmp attribute "mc_queueing"	239
Annex A (Informative): Mapping of MBMS terms to MBS		241
Annex B (informative): Change history		242
History		245