
International Standard



4575

INTERNATIONAL ORGANIZATION FOR STANDARDIZATION • МЕЖДУНАРОДНАЯ ОРГАНИЗАЦИЯ ПО СТАНДАРТИЗАЦИИ • ORGANISATION INTERNATIONALE DE NORMALISATION

Plastics — Polyvinyl chloride pastes — Determination of apparent viscosity using the Severs rheometer

Plastiques — Pâtes de polychlorure de vinyle — Détermination de la viscosité apparente au rhéomètre Severs

Second edition — 1985-08-15

ITEH STANDARD PREVIEW
(standards.iteh.ai)

[ISO 4575:1985](https://standards.iteh.ai/catalog/standards/sist/aca3daba-da60-4da0-8cea-8ace327210fc/iso-4575-1985)

<https://standards.iteh.ai/catalog/standards/sist/aca3daba-da60-4da0-8cea-8ace327210fc/iso-4575-1985>

UDC 678.743.22 — 404.9 : 532.13

Ref. No. ISO 4575-1985 (E)

Descriptors : plastics, polyvinyl chloride, pastes, tests, determination, viscosity, test equipment, rheometers.

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work.

Draft International Standards adopted by the technical committees are circulated to the member bodies for approval before their acceptance as International Standards by the ISO Council. They are approved in accordance with ISO procedures requiring at least 75 % approval by the member bodies voting.

International Standard ISO 4575 was prepared by Technical Committee ISO/TC 61, *Plastics*.

ISO 4575 was first published in 1978. This second edition cancels and replaces the first edition, of which it constitutes a minor revision.

Plastics — Polyvinyl chloride pastes — Determination of apparent viscosity using the Severs rheometer

1 Scope and field of application

This International Standard specifies a method for determining the apparent viscosity, at high shear, of polyvinyl chloride pastes prepared from PVC paste polymers and plasticizers, using the Severs rheometer.

It applies in particular to "standard pastes" prepared according to ISO 4612, *Plastics — PVC paste resins — Preparation of a paste*.

2 Principle

Placing of a sample of the paste in a Severs rheometer and setting of the jacket to a defined temperature.

Measurement of the flow rate of the paste through a calibrated die at different pressures.

Calculation of the shear rate and apparent viscosity for each flow rate corresponding to each of the pressures applied.

Optionally, preparation of a graph of apparent viscosity as a function of the corresponding shear rate.

3 Apparatus

3.1 Severs rheometer, of capacity 500 to 1 000 ml, of one of the two basic designs shown in figure 1, and consisting essentially of:

3.1.1 Measuring vessel, for example a stainless steel or bronze cylinder with polished internal surfaces to which can be fixed both a base having an orifice in which can be placed a die, and a cover which can be connected to the source of pressure or to the atmosphere. The whole must be airtight.

3.1.2 Jacket, connected to a system for temperature control which allows the contents of the body of the measuring vessel to be maintained at the temperature of $23 \pm 0,5$ °C.

3.1.3 Non-deformable die, for example of stainless steel or PTFE, consisting of a cylindrical tube which can be fitted air-

tight to the bottom of the measuring vessel. The outer and internal surfaces of the tube are polished. The die is defined by the diameter and the height of the tube. Two dies, A and B, are specified in the application of this International Standard:

Dimension	Die A	Die B
Radius of tube, mm	$1,5 \pm 0,05$	$1,5 \pm 0,05$
Height, mm	$45 \pm 0,5$	$22,5 \pm 0,5$

3.1.4 Piston, if necessary, of rigid plastic material with a diameter slightly less than that of the measuring vessel to prevent the fluid, under pressure, from passing directly through the die in the case of pastes which cavitate. (Furthermore, its use simplifies the cleaning of the instrument.) A sketch of the piston is given in figure 2.

3.1.5 Pressurizing device, consisting of a cylinder of pressurized nitrogen, an expansion chamber with pressure gauges, and a number of valves. An example is shown in figure 3.

3.2 Beakers, of capacity about 50 ml.

3.3 Timer, accurate to 0,1 s.

3.4 Balance, accurate to $\pm 0,5$ g.

3.5 Thermometer, to measure a temperature of $23 \pm 0,5$ °C.

4 Conditioning

The paste may be tested immediately after its preparation or after conditioning at a temperature of 23 °C. The conditioning time shall be indicated in the test report.

5 Procedure

5.1 Choice of test pressures and die

Depending on the test paste and its intended use, choose at least four pressures in the following list of preferred numbers:

100, 160, 250, 400, 630, 1 000, 1 600, 2 500 kPa*

Conduct a test with die A and pressure 2 500 kPa; from the measured flow q_m (6.1), calculate according to 6.2 the corresponding shear rate.

- If the shear rate is more than $1\ 000\ s^{-1}$, tests shall be carried out with die A.
- If the shear rate is less than or equal to $1\ 000\ s^{-1}$, the tests shall be carried out with die B.

5.2 Introduction of paste, and temperature control

Position the base together with the appropriate die (3.1.3) and introduce the paste to be tested into the measuring vessel (3.1.1). If necessary, place the piston (3.1.4) on the paste.

Bring the temperature of the paste to $23 \pm 0,5\ ^\circ C$ by circulating water maintained at that temperature in the jacket (3.1.2) (generally 5 min is sufficient).

Screw down the lid and connect it to the pressurizing device (3.1.5).

5.3 Regulation of the test pressure

Start the tests with the lowest pressure. Regulate the pressure to $\pm 10\ kPa$ according to the device used. In the case of the example given in figure 3, proceed in the following manner:

Close valves E and F, open valves C and D, and operate the pressure reduction valve L progressively until the pressure reading on the gauge having the higher scale range (C) is practically equal to the desired value. Then read the pressure on the gauge having the lower scale range (D) and carefully regulate the pressure to the desired value to the nearest $\pm 10\ kPa$.

Operate in the same way for regulating the other test pressures, but without opening valve D for pressure above its maximum gauge reading.

5.4 Determination

5.4.1 Weight three 50 ml beakers (3.2) to the nearest 0,5 g.

Clean the exit orifice of the die and open valve E to admit nitrogen under pressure to the rheometer. Under pressure, the paste will pass through the die. Make sure that the pressure does not vary; regulate, if necessary, by operating the pressure reduction valve L.

Place a weighed beaker under the emerging paste stream and at the same time start the timer (3.3).

When the mass of paste obtained is at least 10 g, remove the beaker and stop the timer simultaneously; note the time of flow t_1 , in seconds to the nearest $\pm 0,1\ s$. (If the amount is insufficient at the end of 2 min, abandon the test at this pressure and carry it out under greater pressure.)

Repeat the measurements with the other two weighed beakers in turn, designating the corresponding flow times t_2 and t_3 .

Close the pressurized nitrogen inlet valve E and open the valve to atmosphere F in order to arrest the flow of paste.

Weigh the containers, determining the masses of paste, m_1 , m_2 and m_3 , in grams, to the nearest 0,5 g.

5.4.2 Close the valve to atmosphere F and regulate the pressure to its new value. Repeat the test under the conditions specified in 5.4.1.

5.4.3 After testing, clean the rheometer, avoiding the use of fluffy materials.

6 Calculations

6.1 Calculation of flows

For each one of the test pressures, calculate the flows q_{m1} , q_{m2} and q_{m3} , in grams per second, corresponding to the measurements using the formulae

$$q_{m1} = \frac{m_1}{t_1} \quad q_{m2} = \frac{m_2}{t_2} \quad q_{m3} = \frac{m_3}{t_3}$$

where m_1 , m_2 and m_3 , and t_1 , t_2 and t_3 have the same meaning as given in 5.4.1.

Calculate the arithmetic mean of the three values, designating q_m as the flow, in grams per second corresponding to the test pressure.

6.2 Calculation of shear rates and apparent viscosities

For each of the values of flow q_m (calculated according to 6.1), calculate the shear rate and apparent viscosity using the formulae shown in the following table (see notes 1 and 2):

Quantity	Any die	Die A	Die B
Shear rate, ϵ s^{-1}	$\frac{4 q_m}{\pi r^3 \rho}$	$377 \frac{q_m}{\rho}$	
Apparent viscosity, η_{app} Pa·s	$10^3 \frac{\pi r^4 p \rho}{8 h q_m}$	$44 \times 10^{-3} \frac{p \rho}{q_m}$	$88 \times 10^{-3} \frac{p \rho}{q_m}$

* 1 kPa = 1 kN/m²

where

r is the radius of the cylindrical tube of the die, in centimetres;

h is the height of the cylindrical tube of the die, in centimetres;

p is the test pressure in kilopascals;

q_m is the paste flow at pressure p , in grams per second (calculated according to 6.1);

ρ is the density of the paste at 23 °C, in grams per cubic centimetre.

NOTES

1 Strictly these formulae are applicable to Newtonian fluids. Nevertheless they have been applied to PVC pastes because they are easy to use and the values determined are sufficiently accurate for the purpose intended. The exact formulae are given in the annex for information.

2 The shear force σ is equal to $\eta\epsilon$ and can be calculated for each test pressure using the formulae $\sigma = pr/2h$.

7 Expression of results

Indicate the apparent viscosities for the corresponding shear rate in the form of a table (see figure 4).

Plot a graph showing the apparent viscosity (ordinate) versus the shear rate (abscissa). An example of the curve is given in figure 4.

8 Test report

The test report shall include the following particulars:

- a) reference to this International Standard;
- b) complete identification of the PVC paste polymer and plasticizer;
- c) the formula of the paste;
- d) the density of the paste;
- e) the die used;
- f) the conditioning time at 23 °C before measurement;
- g) a table of apparent viscosities at the various shear rates used;
- h) optionally, a graph of apparent viscosity versus shear rate.

iTech STANDARD PREVIEW
(standards.iteh.ai)

ISO 4575:1985

<https://standards.iteh.ai/catalog/standards/sist/aca3daba-da60-4da0-8cca-8ace327210fc/iso-4575-1985>

Annex

Formulae for non-Newtonian fluids

The exact formulae for non-Newtonian fluids include the term m , the reciprocal of the non-Newtonian symbol n , and are as follows:

Quantity	Any die
Shear rate, ϵ s ⁻¹	$\frac{(m+3) q_m}{\pi r^3 \rho}$
Apparent viscosity, η_{app} Pa·s	$10^3 \frac{\pi r^4 p \rho}{2 h (m+3) q_m}$

in which the symbols (other than m) have the same meaning and are expressed in the same units as given in 6.2.




Figure 1 — Diagram showing basic principles of two types of Severs rheometer

Dimensions in millimetres





Figure 2 — Piston



ISO 4575:1985
<https://standards.iteh.ai/catalog/standards/sist/aca3daba-da60-4da0-8cca-8ace327210fc/iso-4575-1985>

- (C) Valves
- (D) Valves
- (E) Pressurized nitrogen inlet valve
- (F) Valve to atmosphere
- (G) Pressure gauges (with different scales)
- (H) Severs rheometer
- (I) Die
- (J) Expansion chamber
- (K) Nitrogen cylinder
- (L) Pressure reduction valve

Figure 3 — Example of pressurizing device

Test with Severs rheometer

PVC paste "100 and 50"

$$\rho_{23} = 1,22 \text{ g/cm}^3$$

Die A

Immediate measurement

p	kPa	100	400	630	1 000
q_m	g/s	0,32	1,40	2,38	4,44
ϵ	s^{-1}	98	430	730	1 360
η_{app}	Pa·s	16,9	15,4	14,3	12,2




Figure 4 — Examples of presentation in tabular form and graphically of results obtained using the Severs rheometer