



SLOVENSKI STANDARD
SIST ETS 300 974 E11:2003

01-december-2003

8 [[[HJb]`W] b]`hY`Y_ca i b]_UW`g_]`g]ghYa `fZuU&Zk/`E`GdYWZ_ UW`UXY`UnU
a cV]`bY`Ud`]_UW`Y`fA5 DL`f] GA `\$-`\$&zfUn`]]WU) "%) "%z]nXUU%- * Ł

Digital cellular telecommunications system (Phase 2+) (GSM); Mobile Application Part (MAP) specification (GSM 09.02 version 5.15.1 Release 1996)

iteh STANDARD PREVIEW
(standards.iteh.ai)

Ta slovenski standard je istoveten z: ^{SIST ETS 300 974 E11:2003} **ETS 300 974 Edition 11**
<https://standards.iteh.ai/catalog/standards/sist/53e2579f-abc2-4a5b-83a2-e801b9b64a16/sist-ets-300-974-e11-2003>

ICS:

33.070.50	Globalni sistem za mobilno telekomunikacijo (GSM)	Global System for Mobile Communication (GSM)
-----------	---	--

SIST ETS 300 974 E11:2003

en

iTeh STANDARD PREVIEW
(standards.iteh.ai)

[SIST ETS 300 974 E11:2003](https://standards.iteh.ai/catalog/standards/sist/33e2579f-abe2-4a3b-83a2-e801b9b64a16/sist-ets-300-974-e11-2003)

<https://standards.iteh.ai/catalog/standards/sist/33e2579f-abe2-4a3b-83a2-e801b9b64a16/sist-ets-300-974-e11-2003>



EUROPEAN
TELECOMMUNICATION
STANDARD

ETS 300 974

December 2000

Eleventh Edition

Source: SMG

Reference: RE/TSGN-040902QR10

ICS: 33.020

Key words: Digital cellular telecommunications system, Global System for Mobile communications (GSM)



**Digital cellular telecommunications system (Phase 2+);
Mobile Application Part (MAP) specification
(GSM 09.02 version 5.15.1 Release 1996)**

ETSI

European Telecommunications Standards Institute

ETSI Secretariat

Postal address: F-06921 Sophia Antipolis CEDEX - FRANCE

Office address: 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

Internet: secretariat@etsi.fr - <http://www.etsi.org>

Tel.: +33 4 92 94 42 00 - Fax: +33 4 93 65 47 16

Copyright Notification: No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2000. All rights reserved.

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ETS 300 974 E11:2003

<https://standards.iteh.ai/catalog/standards/sist/33e2579f-abe2-4a3b-83a2-e801b9b64a16/sist-ets-300-974-e11-2003>

Contents

Intellectual Property Rights.....	19
Foreword.....	19
1 Scope	21
1.1 Normative references.....	21
1.2 Abbreviations	27
2 Configuration of the mobile network.....	27
2.1 The entities of the mobile system	27
2.1.1 The Home Location Register (HLR)	27
2.1.2 The Visitor Location Register (VLR).....	28
2.1.3 The Mobile-services Switching Centre (MSC)	28
2.1.4 The Base Station System (BSS)	28
2.1.5 The Gateway MSC (GMSC).....	28
2.1.6 The SMS Gateway MSC	28
2.1.7 The SMS Interworking MSC.....	29
2.1.8 The VBS/VGCS Anchor MSC	29
2.1.9 The Equipment Identity Register (EIR).....	29
2.1.10 The GSM Service Control Function (gsmSCF)	29
2.1.11 The Group Call Register (GCR)	29
2.2 Configuration of a Public Land Mobile Network (PLMN)	29
2.3 Interconnection between PLMNs.....	29
2.4 The interfaces within the mobile service.....	29
2.4.1 Interface between the HLR and the VLR (D-interface)	29
2.4.2 Interface between the HLR and the gsmSCF (J-interface)	30
2.4.3 Interface between the VLR and its associated MSC(s) (B-interface).....	30
2.4.4 Interface between VLRs (G-interface).....	30
2.4.5 Interface between the HLR and the MSC (C-interface)	30
2.4.6 Interface between MSCs (E-interface)	30
2.4.7 Interface between the MSC and Base Station Systems (A-interface)	30
2.4.8 Interface between MSC and EIR (F-interface)	30
2.4.9 Interface between VBS/VGCS Anchor MSC and GCR (I-interface)	31
2.5 Splitting of the data storage	31
3 Overload and compatibility overview.....	33
3.1 Overload control.....	33
3.1.1 Overload control for MSC (outside MAP).....	33
3.1.2 Overload control for MAP entities.....	33
3.1.3 Congestion control for Signalling System No. 7.....	36
3.2 Compatibility.....	36
3.2.1 General	36
3.2.2 Strategy for selecting the Application Context (AC) version	36
3.2.2.1 Proposed method	36
3.2.2.2 Managing the version look-up table.....	37
3.2.2.3 Optimizing the method.....	38
4 Requirements concerning the use of SCCP and TC.....	38
4.1 Use of SCCP.....	38
4.1.1 SCCP Class.....	38
4.1.2 Sub-System Number (SSN)	38
4.1.3 SCCP addressing	38
4.1.3.1 Introduction	38
4.1.3.2 The Mobile-services Switching Centre (MSC).....	39
4.1.3.2.1 MSC interaction during handover	39
4.1.3.2.2 MSC for short message routing	40

	4.1.3.3	The Home Location Register (HLR).....	40
	4.1.3.3.1	During call set-up	40
	4.1.3.3.2	Before location updating completion	40
	4.1.3.3.3	After location updating completion	41
	4.1.3.3.4	VLR restoration	41
	4.1.3.4	The Visitor Location Register (VLR)	41
	4.1.3.4.1	Inter-VLR information retrieval	41
	4.1.3.4.2	HLR request	41
	4.1.3.5	The Interworking MSC (IWMSC) for Short Message Service	41
	4.1.3.6	The Equipment Identity Register (EIR)	41
	4.1.3.7	Summary table	42
4.2	Use of TC		43
5	General on MAP services		45
5.1	Terminology and definitions		45
5.2	Modelling principles		45
5.3	Common MAP services		45
	5.3.1	MAP-OPEN service	46
	5.3.2	MAP-CLOSE service	49
	5.3.3	MAP-DELIMITER service	50
	5.3.4	MAP-U-ABORT service	50
	5.3.5	MAP-P-ABORT service	51
	5.3.6	MAP-NOTICE service	52
5.4	Sequencing of services		52
5.5	General rules for mapping of services onto TC.....		54
	5.5.1	Mapping of common services	54
	5.5.2	Mapping of user specific services	56
5.6	Definition of parameters		57
	5.6.1	Common parameters	59
	5.6.1.1	Invoke Id	59
	5.6.1.2	Linked Id	59
	5.6.1.3	Provider error 74.E11:2003	59
	5.6.1.4	User error 74.E11:2003	59
	5.6.2	Numbering and identification parameter	61
	5.6.2.1	IMSI	61
	5.6.2.2	TMSI	61
	5.6.2.3	IMEI	61
	5.6.2.4	Previous location area Id	62
	5.6.2.5	Stored location area Id	62
	5.6.2.6	Current location area Id	62
	5.6.2.7	Target location area Id	62
	5.6.2.8	Target cell Id	62
	5.6.2.9	[Spare]	62
	5.6.2.10	Originating entity number	62
	5.6.2.11	MSC number	62
	5.6.2.12	Target MSC number	62
	5.6.2.13	HLR number	62
	5.6.2.14	VLR number	62
	5.6.2.15	HLR Id	62
	5.6.2.16	LMSI	62
	5.6.2.17	MS ISDN	62
	5.6.2.18	OMC Id	62
	5.6.2.19	Roaming number	63
	5.6.2.20	[Spare]	63
	5.6.2.21	Handover number	63
	5.6.2.22	Forwarded-to number	63
	5.6.2.23	Forwarded-to subaddress	63
	5.6.2.24	Called number	63
	5.6.2.25	Calling number	63
	5.6.2.26	Originally dialled number	63
	5.6.2.27	Service centre address	63
	5.6.2.28	Zone Code	63

ETS 300 974: December 2000 (GSM 09.02 version 5.15.1)

	5.6.2.29	MSIsdn-Alert	63
	5.6.2.30	Location Information	63
	5.6.2.31	GMSC Address	63
	5.6.2.32	VMSC Address	63
	5.6.2.33	Group Id	63
5.6.3		Subscriber management parameters	64
	5.6.3.1	Category	64
	5.6.3.2	Equipment status	64
	5.6.3.3	Extensible Bearer service	64
	5.6.3.4	Extensible Teleservice	64
	5.6.3.5	Extensible Basic Service Group	64
	5.6.3.6	GSM bearer capability	64
	5.6.3.7	Subscriber Status	64
	5.6.3.8	CUG Outgoing Access indicator	64
	5.6.3.9	Operator Determined Barring General Data	64
	5.6.3.10	ODB HPLMN Specific Data	65
	5.6.3.11	Regional Subscription Data	65
	5.6.3.12	Regional Subscription Response	65
	5.6.3.13	Roaming Restriction Due To Unsupported Feature	65
	5.6.3.14	Extensible SS-Info	65
	5.6.3.15	Extensible Forwarding information	65
	5.6.3.16	Extensible Forwarding feature	65
	5.6.3.17	Extensible SS-Status	66
	5.6.3.18	Extensible Forwarding Options	66
	5.6.3.19	Extensible No reply condition timer	66
	5.6.3.20	Extensible Call barring information	66
	5.6.3.21	Extensible Call barring feature	66
	5.6.3.22	CUG info	66
	5.6.3.23	CUG subscription	66
	5.6.3.24	CUG interlock	66
	5.6.3.25	CUG index	66
	5.6.3.26	CUG feature	67
	5.6.3.27	Inter CUG options	67
	5.6.3.28	Intra CUG restrictions	67
	5.6.3.29	Extensible SS-Data	67
	5.6.3.30	Subscriber State	67
	5.6.3.31	Requested Info	67
	5.6.3.32	Suppression of Announcement	67
	5.6.3.33	Suppress T-CSI	68
	5.6.3.34	GMSC CAMEL Subscription Info	68
	5.6.3.35	VLR CAMEL Subscription Info	68
	5.6.3.36	Supported CAMEL Phases	68
	5.6.3.37	CUG Subscription Flag	68
	5.6.3.38	CAMEL Subscription Info Withdraw	68
	5.6.3.39	Voice Group Call Service (VGCS) Data	68
	5.6.3.40	Voice Broadcast Service (VBS) Data	68
5.6.4		Supplementary services parameters	68
	5.6.4.1	SS-Code	68
	5.6.4.2	SS-Status	68
	5.6.4.3	SS-Data	69
	5.6.4.4	Override Category	69
	5.6.4.5	CLI Restriction Option	69
	5.6.4.6	Forwarding Options	69
	5.6.4.7	No reply condition timer	69
	5.6.4.8 - 5.6.4.14	[Spare]	69
	5.6.4.15	Forwarding information	69
	5.6.4.16	Forwarding feature	69
	5.6.4.17	[Spare]	70
	5.6.4.18	Call barring information	70
	5.6.4.19	Call barring feature	70
	5.6.4.20	New password	70
	5.6.4.21	Current password	70
	5.6.4.22	Guidance information	70

iTeh STANDARDS PREVIEW
 (standards.tch.ai)

https://standards.csi.catalog/standards/ets-300-974-2002-4a3b-83a2-
 6636964a16/sis-ets-300-974-2003

	5.6.4.23	[Spare].....	70
	5.6.4.24	SS-Info	70
	5.6.4.25 - 5.6.4.35	[Spare]	71
	5.6.4.36	USSD Data Coding Scheme	71
	5.6.4.37	USSD String	71
	5.6.4.38	Bearer service	71
	5.6.4.39	Teleservice	71
	5.6.4.40	Basic Service Group	71
	5.6.4.41	eMLPP information.....	71
5.6.5	Call parameters.....		71
	5.6.5.1	Call reference number.....	71
	5.6.5.2	Interrogation type	71
	5.6.5.3	OR interrogation.....	72
	5.6.5.4	OR capability.....	72
	5.6.5.5	Forwarding reason	72
	5.6.5.6	Forwarding interrogation required.....	72
	5.6.5.7	O-CSI	72
5.6.6	Radio parameters		72
	5.6.6.1 - 5.6.6.6	[Spare].....	72
	5.6.6.7	HO-Number Not Required.....	72
5.6.7	Authentication parameters.....		72
	5.6.7.1	Authentication set list	72
	5.6.7.2	Rand.....	72
	5.6.7.3	Sres	72
	5.6.7.4	Kc	72
	5.6.7.5	[Spare].....	72
	5.6.7.6	Cksn	72
	5.6.7.7	Ciphering mode	73
5.6.8	Short message parameters		73
	5.6.8.1	SM-RP-DA	73
	5.6.8.2	SM-RP-OA	73
	5.6.8.3	MWD status.....	73
	5.6.8.4	SM-RP-UI.....	73
	5.6.8.5	SM-RP-PR.....	73
	5.6.8.6	SM-Delivery Outcome	73
	5.6.8.7	More Messages To Send.....	73
	5.6.8.8	Alert Reason	74
	5.6.8.9	Absent Subscriber Diagnostic SM	74
5.6.9	Access and signalling system related parameters		74
	5.6.9.1	BSS-apdu	74
	5.6.9.2	CM service type	74
	5.6.9.3	Access connection status.....	74
	5.6.9.4	External Signal Information	74
	5.6.9.5	Access signalling information.....	74
	5.6.9.6	Location update type.....	74
	5.6.9.7	Protocol ID.....	74
	5.6.9.8	Network signal information.....	75
5.6.10	System operations parameters.....		75
	5.6.10.1	Network resources	75
	5.6.10.2	Trace reference.....	76
	5.6.10.3	Trace type	76
5.7	Representation of a list of a basic parameter in service-primitives.....		76
6	Mobility services.....		76
6.1	Location management services.....		76
6.1.1	MAP_UPDATE_LOCATION_AREA service.....		76
	6.1.1.1	Definition	76
	6.1.1.2	Service primitives	76
	6.1.1.3	parameter definitions and use.....	76
6.1.2	MAP_UPDATE_LOCATION service.....		77
	6.1.2.1	Definition	77
	6.1.2.2	Service primitives	78
	6.1.2.3	Parameter definitions and use	78

6.1.3	MAP_CANCEL_LOCATION service	79
6.1.3.1	Definition	79
6.1.3.2	Service primitives	79
6.1.3.3	Parameter definitions and use	79
6.1.4	MAP_SEND_IDENTIFICATION service	79
6.1.4.1	Definition	79
6.1.4.2	Service primitives	80
6.1.4.3	Parameter definitions and use	80
6.1.5	MAP_DETACH_IMSI service	80
6.1.5.1	Definition	80
6.1.5.2	Service primitives	81
6.1.5.3	Parameter definitions and use	81
6.1.6	MAP_PURGE_MS service	81
6.1.6.1	Definition	81
6.1.6.2	Service primitives	81
6.1.6.3	Parameter definitions and use	81
6.2	Paging and search	82
6.2.1	MAP_PAGE service	82
6.2.1.1	Definition	82
6.2.1.2	Service primitives	82
6.2.1.3	Parameter definitions and use	82
6.2.2	MAP_SEARCH_FOR_MS service	83
6.2.2.1	Definition	83
6.2.2.2	Service primitives	83
6.2.2.3	Parameter definitions and use	83
6.3	Access management services	84
6.3.1	MAP_PROCESS_ACCESS_REQUEST service	84
6.3.1.1	Definition	84
6.3.1.2	Service primitives	84
6.3.1.3	Parameter definitions and use	84
6.4	Handover services	85
6.4.1	MAP_PREPARE_HANOVER service	85
6.4.1.1	Definition	85
6.4.1.2	Service primitives	86
6.4.1.3	Parameter use	86
6.4.2	MAP_SEND_END_SIGNAL service	86
6.4.2.1	Definition	86
6.4.2.2	Service primitives	87
6.4.2.3	Parameter use	87
6.4.3	MAP_PROCESS_ACCESS_SIGNALLING service	87
6.4.3.1	Definition	87
6.4.3.2	Service primitives	87
6.4.3.3	Parameter use	87
6.4.4	MAP_FORWARD_ACCESS_SIGNALLING service	87
6.4.4.1	Definition	87
6.4.4.2	Service primitives	88
6.4.4.3	Parameter use	88
6.4.5	MAP_PREPARE_SUBSEQUENT_HANOVER service	88
6.4.5.1	Definition	88
6.4.5.2	Service primitives	88
6.4.5.3	Parameter use	88
6.4.6	MAP_ALLOCATE_HANOVER_NUMBER service	89
6.4.6.1	Definition	89
6.4.6.2	Service primitives	89
6.4.6.3	Parameter use	89
6.4.7	MAP_SEND_HANOVER_REPORT service	90
6.4.7.1	Definition	90
6.4.7.2	Service primitives	90
6.4.7.3	Parameter use	90
6.5	Authentication management services	90
6.5.1	MAP_AUTHENTICATE service	90
6.5.1.1	Definition	90
6.5.1.2	Service primitives	90

	6.5.1.3	Parameter use.....	91
6.5.2		MAP_SEND_AUTHENTICATION_INFO service	91
	6.5.2.1	Definition	91
	6.5.2.2	Service primitives	91
	6.5.2.3	Parameter use.....	92
6.6		Security management services	92
6.6.1		MAP_SET_CIPHERING_MODE service.....	92
	6.6.1.1	Definitions.....	92
	6.6.1.2	Service primitives	92
	6.6.1.3	Parameter use.....	93
6.7		International mobile equipment identities management services	93
6.7.1		MAP_CHECK_IMEI service.....	93
	6.7.1.1	Definition	93
	6.7.1.2	Service primitives	93
	6.7.1.3	Parameter use.....	93
6.7.2		MAP_OBTAIN_IMEI service.....	94
	6.7.2.1	Definition	94
	6.7.2.2	Service primitives	94
	6.7.2.3	Parameter use.....	94
6.8		Subscriber management services	95
6.8.1		MAP-INSERT-SUBSCRIBER-DATA service.....	95
	6.8.1.1	Definition	95
	6.8.1.2	Service primitives	95
	6.8.1.3	Parameter use.....	96
		Supported CAMEL Phases	101
	6.8.1.4	Basic service information related to supplementary services	101
6.8.2		MAP-DELETE-SUBSCRIBER-DATA service.....	102
	6.8.2.1	Definition	102
	6.8.2.2	Service primitives	102
	6.8.2.3	Parameter use.....	102
6.9		Identity management services.....	104
6.9.1		MAP-PROVIDE-IMSI service.....	104
	6.9.1.1	Definition	104
	6.9.1.2	Service primitives	104
	6.9.1.3	Parameter use.....	104
6.9.2		MAP-FORWARD-NEW-TMSI service	104
	6.9.2.1	Definition	104
	6.9.2.2	Service primitives	104
	6.9.2.3	Parameter use.....	104
6.10		Fault recovery services	105
6.10.1		MAP_RESET service.....	105
	6.10.1.1	Definition	105
	6.10.1.2	Service primitives	105
	6.10.1.3	Parameter definition and use	105
6.10.2		MAP_FORWARD_CHECK_SS_INDICATION service.....	105
	6.10.2.1	Definition	105
	6.10.2.2	Service primitives	105
	6.10.2.3	Parameter definition and use	106
6.10.3		MAP_RESTORE_DATA service.....	106
	6.10.3.1	Definition	106
	6.10.3.2	Service primitives	106
	6.10.3.3	Parameter definitions and use	106
		MS Not Reachable Flag.....	107
6.11		Subscriber Information services	107
6.11.1		MAP-ANY-TIME-INTERROGATION service	107
	6.11.1.1	Definition	107
	6.11.1.2	Service primitives	107
	6.11.1.3	Parameter definition and use	107
6.11.2		MAP-PROVIDE-SUBSCRIBER-Info service	108
	6.11.2.1	Definition	108
	6.11.2.2	Service primitives	108
	6.11.2.3	Parameter definition and use	108

7	Operation and maintenance services.....	109
7.1	Subscriber tracing services.....	109
7.1.1	MAP-ACTIVATE-TRACE-MODE service.....	109
	7.1.1.1 Definition.....	109
	7.1.1.2 Service primitives.....	109
	7.1.1.3 Parameter use.....	109
7.1.2	MAP-DEACTIVATE-TRACE-MODE service.....	110
	7.1.2.1 Definition.....	110
	7.1.2.2 Service primitives.....	110
	7.1.2.3 Parameter use.....	110
7.1.3	MAP-TRACE-SUBSCRIBER-ACTIVITY service.....	110
	7.1.3.1 Definition.....	110
	7.1.3.2 Service primitives.....	111
	7.1.3.3 Parameter use.....	111
7.2	Other operation and maintenance services.....	111
7.2.1	MAP-SEND-IMSI service.....	111
	7.2.1.1 Definition.....	111
	7.2.1.2 Service primitives.....	111
	7.2.1.3 Parameter use.....	112
8	Call handling services.....	112
8.1	MAP_SEND_ROUTING_INFORMATION service.....	112
	8.1.1 Definition.....	112
	8.1.2 Service primitives.....	112
	8.1.3 Parameter use.....	113
8.2	MAP_PROVIDE_ROAMING_NUMBER service.....	116
	8.2.1 Definition.....	116
	8.2.2 Service primitives.....	116
	8.2.3 Parameter use.....	116
8.3	MAP_RESUME_CALL_HANDLING service.....	118
	8.3.1 Definition.....	118
	8.3.2 Service primitives.....	118
	8.3.3 Parameter use.....	118
	https://standards.iteh.ai/catalog/standards/sist/33e2579f-abe2-4a3b-83a2-300-974-e11-2003	
9	Supplementary services related services.....	119
9.1	MAP_REGISTER_SS service.....	119
	9.1.1 Definition.....	119
	9.1.2 Service primitives.....	119
	9.1.3 Parameter use.....	119
9.2	MAP_ERASE_SS service.....	120
	9.2.1 Definition.....	120
	9.2.2 Service primitives.....	121
	9.2.3 Parameter use.....	121
9.3	MAP_ACTIVATE_SS service.....	122
	9.3.1 Definition.....	122
	9.3.2 Service primitives.....	122
	9.3.3 Parameter use.....	122
9.4	MAP_DEACTIVATE_SS service.....	123
	9.4.1 Definitions.....	123
	9.4.2 Service primitives.....	124
	9.4.3 Parameter use.....	124
9.5	MAP_INTERROGATE_SS service.....	125
	9.5.1 Definitions.....	125
	9.5.2 Service primitives.....	125
	9.5.3 Parameter use.....	125
9.6	MAP_INVOKE_SS service.....	127
	9.6.1 Definitions.....	127
	9.6.2 Service primitives.....	127
	9.6.3 Parameter use.....	127
9.7	MAP_REGISTER_PASSWORD service.....	128
	9.7.1 Definitions.....	128
	9.7.2 Service primitives.....	128
	9.7.3 Parameter use.....	128

9.8	MAP_GET_PASSWORD service.....	128
9.8.1	Definitions	128
9.8.2	Service primitives.....	129
9.8.3	Parameter use	129
9.9	MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service.....	129
9.9.1	Definitions	129
9.9.2	Service primitives.....	129
9.9.3	Parameter use	130
9.10	MAP_UNSTRUCTURED_SS_REQUEST service.....	130
9.10.1	Definitions	130
9.10.2	Service primitives.....	130
9.10.3	Parameter use	131
9.11	MAP_UNSTRUCTURED_SS_NOTIFY service.....	131
9.11.1	Definitions	131
9.11.2	Service primitives.....	131
9.11.3	Parameter use	132
10	Short message service management services.....	132
10.1	MAP-SEND-ROUTING-INFO-FOR-SM service.....	132
10.1.1	Definition	132
10.1.2	Service primitives.....	133
10.1.3	Parameter use	133
10.2	MAP-MO-FORWARD-SHORT-MESSAGE service	134
10.2.1	Definition	134
10.2.2	Service primitives.....	134
10.2.3	Parameter use	134
10.3	MAP-REPORT-SM-DELIVERY-STATUS service.....	135
10.3.1	Definition	135
10.3.2	Service primitives.....	135
10.3.3	Parameter use	135
10.4	MAP-READY-FOR-SM service.....	136
10.4.1	Definition	136
10.4.2	Service primitives.....	137
10.4.3	Parameter use	137
10.5	MAP-ALERT-SERVICE-CENTRE service.....	137
10.5.1	Definition	137
10.5.2	Service primitives.....	138
10.5.3	Parameter use	138
10.6	MAP-INFORM-SERVICE-CENTRE service.....	138
10.6.1	Definition	138
10.6.2	Service primitives.....	139
10.6.3	Parameter use	139
10.7	MAP-SEND-INFO-FOR-MT-SMS service.....	139
10.7.1	Definition	139
10.7.2	Service primitives.....	139
10.7.3	Parameter use	139
10.8	MAP-SEND-INFO-FOR-MO-SMS service	140
10.8.1	Definition	140
10.8.2	Service primitives.....	140
10.8.3	Parameter use	140
10.9	MAP-MT-FORWARD-SHORT-MESSAGE service.....	141
10.9.1	Definition	141
10.9.2	Service primitives.....	141
10.9.3	Parameter use	141
11	General.....	142
11.1	Overview.....	142
11.2	Underlying services	142
11.3	Model.....	143
11.4	Conventions.....	143
12	Elements of procedure.....	143
12.1	Dialogue establishment	143

12.1.1	Handling of unknown operations	144
12.1.2	Receipt of a MAP-OPEN request primitive	144
12.1.3	Receipt of a TC-BEGIN indication	145
12.1.4	Receipt of a MAP-OPEN response	147
12.1.5	Receipt of the first TC-CONTINUE ind.....	147
12.1.6	Receipt of a TC-END ind.....	148
12.1.7	Receipt of a TC-U-ABORT ind	148
12.1.8	Receipt of a TC-P-ABORT ind	148
12.2	Dialogue continuation	148
12.2.1	Sending entity.....	148
12.2.2	Receiving entity	149
12.3	Dialogue termination	149
12.3.1	Receipt of a MAP-CLOSE request	149
12.3.2	Receipt of a TC-END indication	149
12.4	User Abort	149
12.4.1	MAP-U-ABORT request	149
12.4.2	TC-U-ABORT ind.....	149
12.5	Provider Abort	149
12.5.1	MAP PM error situation	150
12.5.2	TC-P-ABORT ind.....	150
12.5.3	TC-U-ABORT ind.....	150
12.6	Procedures for MAP specific services	150
12.6.1	Service invocation	151
12.6.2	Service invocation receipt	151
12.6.3	Service response.....	152
12.6.4	Receipt of a response	152
12.6.4.1	Receipt of a TC-RESULT-NL indication	152
12.6.4.2	Receipt of a TC-RESULT-L indication.....	153
12.6.4.3	Receipt of a TC-U-ERROR indication	153
12.6.4.4	Receipt of a TC-INVOKE indication.....	153
12.6.4.5	Receipt of a TC-U-REJECT indication	154
12.6.4.6	Receipt of a TC-L-REJECT indication	154
12.6.4.7	Receipt of a TC-L-CANCEL indication	154
12.6.4.8	Receipt of a TC-NOTICE indication.....	155
12.6.5	Other events.....	155
12.6.5.1	Receipt of a TC-U-REJECT	155
12.6.5.2	Receipt of a TC-R-REJECT indication	155
12.6.5.3	Receipt of a TC-L-REJECT indication	155
12.6.6	Parameter checks.....	156
12.6.7	Returning state machines to idle	156
12.6.8	Load control.....	156
13	Mapping on to TC services.....	156
13.1	Dialogue control	156
13.1.1	Directly mapped parameters	157
13.1.2	Use of other parameters of dialogue handling primitives	157
13.1.2.1	Dialogue Id.....	157
13.1.2.2	Application-context-name	157
13.1.2.3	User information	157
13.1.2.4	Component present	157
13.1.2.5	Termination	157
13.1.2.6	P-Abort-Cause	157
13.1.2.7	Quality of service	157
13.2	Service specific procedures	158
13.2.1	Directly mapped parameters	158
13.2.2	Use of other parameters of component handling primitives.....	158
13.2.2.1	Dialogue Id.....	158
13.2.2.2	Class	158
13.2.2.3	Linked Id	158
13.2.2.4	Operation	158
13.2.2.5	Error	159
13.2.2.6	Parameters	159
13.2.2.7	Time out.....	160

	13.2.2.8	Last component.....	160
	13.2.2.9	Problem code	160
	13.2.2.9.1	Mapping to MAP User Error	160
	13.2.2.9.2	Mapping to MAP Provider Error parameter	160
	13.2.2.9.3	Mapping to diagnostic parameter	161
13.3		SDL descriptions	161
14		Abstract syntax of the MAP protocol	187
14.1		General.....	187
	14.1.1	Encoding rules	187
	14.1.2	Use of TC.....	187
	14.1.2.1	Use of Global Operation and Error codes defined outside MAP.....	188
	14.1.3	Use of information elements defined outside MAP.....	188
	14.1.4	Compatibility considerations	189
	14.1.5	Structure of the Abstract Syntax of MAP	189
	14.1.6	Application Contexts	190
14.2		Operation packages	192
	14.2.1	General aspects.....	192
	14.2.2	Packages specifications	193
	14.2.2.1	Location updating.....	193
	14.2.2.2	Location cancellation.....	193
	14.2.2.3	Roaming number enquiry.....	193
	14.2.2.4	Information retrieval	193
	14.2.2.5	Inter-VLR information retrieval	193
	14.2.2.6	IMSI retrieval.....	194
	14.2.2.7	Call control transfer	194
	14.2.2.8 - 14.2.2.9	[Spare]	194
	14.2.2.10	Interrogation.....	194
	14.2.2.11	[Spare].....	194
	14.2.2.12	Handover Control	194
	14.2.2.13	Subscriber Data management stand alone.....	195
	14.2.2.14	Equipment management	195
	14.2.2.15	Subscriber data management	195
	14.2.2.16	Location register restart	195
	14.2.2.17	Tracing stand-alone	196
	14.2.2.18	Functional SS handling	196
	14.2.2.19	Tracing	196
	14.2.2.20	Binding	196
	14.2.2.21	Unstructured SS handling	197
	14.2.2.22	MO Short message relay services	197
	14.2.2.23	Short message gateway services	197
	14.2.2.24	MT Short message relay services.....	198
	14.2.2.25	[Spare].....	198
	14.2.2.26	Message waiting data management	198
	14.2.2.27	Alerting	198
	14.2.2.28	Data restoration.....	198
	14.2.2.29	Purging	198
	14.2.2.30	Subscriber information enquiry	199
	14.2.2.31	Any time information enquiry.....	199
14.3		Application contexts	200
	14.3.1	General aspects.....	200
	14.3.2	Application context definitions	201
	14.3.2.1	[Spare].....	201
	14.3.2.2	Location Updating	201
	14.3.2.3	Location Cancellation.....	201
	14.3.2.4	Roaming number enquiry.....	201
	14.3.2.5	[Spare].....	202
	14.3.2.6	Location Information Retrieval	202
	14.3.2.7	Call control transfer	202
	14.3.2.8 - 14.3.2.10	[Spare]	202
	14.3.2.11	Location registers restart.....	202

	14.3.2.12	Handover control	202
	14.3.2.13	IMSI Retrieval	203
	14.3.2.14	Equipment Management.....	203
	14.3.2.15	Information retrieval	203
	14.3.2.16	Inter-VLR information retrieval.....	203
	14.3.2.17	Stand Alone Subscriber Data Management	203
	14.3.2.18	Tracing.....	204
	14.3.2.19	Network functional SS handling.....	204
	14.3.2.20	Network unstructured SS handling	204
	14.3.2.21	Short Message Gateway	204
	14.3.2.22	Mobile originating Short Message Relay	205
	14.3.2.23	[Spare]	205
	14.3.2.24	Short message alert.....	205
	14.3.2.25	Short message waiting data management	205
	14.3.2.26	Mobile terminating Short Message Relay.....	205
	14.3.2.27	MS purging.....	206
	14.3.2.28	Subscriber information enquiry	206
	14.3.2.29	Any time information enquiry	206
	14.3.3	ASN.1 Module for application-context-names.....	207
14.4		MAP Dialogue Information	208
14.5		MAP operation and error codes	211
14.6		MAP operation and error types	216
	14.6.1	Mobile Service Operations	216
	14.6.2	Operation and Maintenance Operations	220
	14.6.3	Call Handling Operations	222
	14.6.4	Supplementary service operations	224
	14.6.5	Short message service operations	228
	14.6.6	Errors	231
14.7		MAP constants and data types	236
	14.7.1	Mobile Service data types	236
	14.7.2	Operation and maintenance data types	246
	14.7.3	Call handling data types	247
	14.7.4	Supplementary service data types	250
	14.7.5	Supplementary service codes	253
	14.7.6	Short message data types	255
	14.7.7	Error data types	257
	14.7.8	Common data types	261
	14.7.9	Teleservice Codes.....	265
	14.7.10	Bearer Service Codes	267
	14.7.11	Extension data types	269
15		General on MAP user procedures.....	270
	15.1	Introduction	270
	15.2	Common aspects of user procedure descriptions	270
	15.2.1	General conventions.....	270
	15.2.2	Naming conventions	270
	15.2.3	Convention on primitives parameters.....	272
	15.2.3.1	Open service.....	272
	15.2.3.2	Close service	272
	15.2.4	Version handling at dialogue establishment.....	272
	15.2.4.1	Behaviour at the initiating side.....	272
	15.2.4.2	Behaviour at the responding side	272
	15.2.5	Abort Handling.....	273
	15.2.6	SDL conventions	273
	15.3	Interaction between MAP Provider and MAP Users.....	273
16		Mobility procedures	274
	16.1	Location management Procedures.....	274
	16.1.1	Location updating	279
	16.1.1.1	General	279
	16.1.1.2	Detailed procedure in the MSC.....	283
	16.1.1.3	Detailed procedure in the VLR	287
	16.1.1.4	Detailed procedure in the HLR	299