



Designation: F2078 – 22

# Standard Terminology Relating to Hydrogen Embrittlement Testing<sup>1</sup>

This standard is issued under the fixed designation F2078; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reappraisal. A superscript epsilon ( $\epsilon$ ) indicates an editorial change since the last revision or reappraisal.

## 1. Scope

1.1 This terminology covers the principal terms, abbreviations, and symbols relating to mechanical methods for hydrogen embrittlement testing. These definitions are published to encourage uniformity of terminology in product specifications.

1.2 *This international standard was developed in accordance with internationally recognized principles on standardization established in the Decision on Principles for the Development of International Standards, Guides and Recommendations issued by the World Trade Organization Technical Barriers to Trade (TBT) Committee.*

## 2. Referenced Documents

2.1 *ASTM Standards:*<sup>2</sup>

- C904 Terminology Relating to Chemical-Resistant Nonmetallic Materials
- D4848 Terminology Related to Force, Deformation and Related Properties of Textiles
- E6 Terminology Relating to Methods of Mechanical Testing
- E8/E8M Test Methods for Tension Testing of Metallic Materials
- E631 Terminology of Building Constructions
- E1823 Terminology Relating to Fatigue and Fracture Testing
- F109 Terminology Relating to Surface Imperfections on Ceramics
- F1624 Test Method for Measurement of Hydrogen Embrittlement Threshold in Steel by the Incremental Step Loading Technique
- G193 Terminology and Acronyms Relating to Corrosion

## 3. Significance and Use

3.1 The terms used in describing hydrogen embrittlement have precise definitions. The terminology and its proper usage

<sup>1</sup> This terminology standard is under the jurisdiction of ASTM Committee F07 on Aerospace and Aircraft and is the direct responsibility of Subcommittee F07.04 on Hydrogen Embrittlement.

Current edition approved May 1, 2022. Published May 2022. Originally approved in 2001. Last previous edition approved in 2015 as F2078 – 15. DOI: 10.1520/F2078-22.

<sup>2</sup> For referenced ASTM standards, visit the ASTM website, [www.astm.org](http://www.astm.org), or contact ASTM Customer Service at [service@astm.org](mailto:service@astm.org). For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

must be completely understood to communicate and transfer information adequately within the field.

3.2 The terms defined in other terminology standards are respectively identified in parentheses following the definition.

## 4. Terminology

4.1 *Definitions:*

**baking**—heating to a temperature, not to exceed 50 °F (27.8 °C) below the tempering or aging temperature of the metal or alloy, in order to remove hydrogen before embrittlement occurs by the formation of microcracks.

DISCUSSION—No metallurgical changes take place as a result of baking.

**brittle**—see **brittleness**.

**brittleness**—the tendency of a material to break at a very low strain, elongation, or deflection, and to exhibit a clean fracture surface with no indications of plastic deformation. (E631)

**crack**—line of fracture without complete separation. (F109)

**crack strength**—the maximum value of the nominal stress that a cracked specimen is capable of sustaining. (E1823)

**ductile**—see **ductility**.

**ductility**—the ability of a material to deform plastically before fracturing. (E6)

**embrittle**—see **embrittlement**.

**embrittlement**—the severe loss of ductility or toughness, or both, of a material, usually a metal or alloy. (G193)

**environmental hydrogen embrittlement (EHE)**—hydrogen embrittlement caused by hydrogen introduced into a steel/metallic alloy from an environmental source coupled with stress either residual or externally applied.

DISCUSSION—Produces a clean intergranular fracture and is not reversible. For the subtle differences between EHE and IHE, see Table X1.1.

**environmentally assisted cracking (EAC)**—see **stress corrosion cracking**.

**fast fracture strength (FFS)**—the load at which a sample fractures when loaded at a rate consistent with Test Methods E8/E8M

**fracture strength**—the normal stress at the beginning of fracture.

**gaseous hydrogen embrittlement (GHE)**—a distinct form of EHE caused by the presence of external sources of high pressure hydrogen gas; cracking initiates on the outer surface.

**heat treatment**—heating and cooling processes that produce metallurgical changes in the metallic alloy which alter the mechanical properties and microstructure of the metal.

**hydrogen-assisted stress cracking (HASC)**—crack growth as a result of the presence of hydrogen, which can be either IHE or EHE and sometimes is referred to as hydrogen stress cracking (HSC).

**hydrogen embrittlement (HE)**—a permanent loss of ductility in a metal or alloy caused by absorption of hydrogen in combination with stress, either an externally applied or an internal residual stress.

**hydrogen embrittlement relief**—see **baking**.

**hydrogen-induced stress cracking**—see **hydrogen-assisted stress cracking**.

**hydrogen stress cracking**—crack growth as a result of the presence of hydrogen, which can be either IHE or EHE; also see **hydrogen-assisted stress cracking**.

**hydrogen susceptibility ratio (Hsr)**—the ratio of the threshold for the onset of hydrogen-assisted cracking to the tensile strength of the material.

**internal hydrogen embrittlement (IHE)**—hydrogen embrittlement caused by absorbed atomic hydrogen into the steel/metallic alloy from an industrial hydrogen emitting process coupled with stress, either residual or externally applied.

DISCUSSION—For the subtle differences between IHE and EHE, see **Table X1.1**.

**notched tensile strength (NTS)**—the maximum nominal (net section) stress that a notched tensile specimen is capable of sustaining. **(E1823)**

**process**—a defined event or sequence of events in plating or coating that may include pretreatments and posttreatments.

**reaction hydrogen embrittlement (RHE)**—irreversible embrittlement caused by the reaction of hydrogen with metal to form a stable hydride.

**residual stress**—stress in a metal in the absence of external forces.

**sharp-notch strength**—the maximum nominal (net section) stress that a sharply notched specimen is capable of sustaining. **(E1823)**

**strain**—deformation of a material caused by the application of an external force. **(D4848)**

**strain rate**—the rate of relative length deformation with time due to an applied stress. **(C904)**

**stress**—the resistance to deformation developed within a material subjected to an external force. **(D4848)**

**stress concentration factor ( $k_t$ )**—the ratio of the greatest stress in the region of a notch or other stress concentrator, as determined by the theory of elasticity or by experimental procedures that give equivalent values, to the corresponding nominal stress. **(E1823)**

**stress corrosion cracking (SCC)**—a cracking process that requires the simultaneous action of a corrodent and sustained tensile stress.

DISCUSSION—This excludes corrosion-reduced sections that fail by fast fracture. It also excludes intercrystalline or transcrystalline corrosion, which can disintegrate an alloy without either applied or residual stress **(G193)**. In essence, the process of SCC and EAC are equivalent.

**stress-intensity factor,  $K$** —the magnitude of the mathematically ideal crack-tip stress field (stress field singularity) for a particular mode in a homogeneous linear-elastic body. **(E1823)**

DISCUSSION— $K_I$ —for a Mode I (opening mode) loading condition that displaces the crack faces in a direction normal to the crack plane.

$K_{II}$ —for a Mode II (sliding mode) loading condition where the crack faces are displaced in shear sliding in the crack plane and in the primary crack propagation direction.

$K_{III}$ —for a Mode III (tearing mode) loading condition where the crack faces are displaced in shear tearing in the crack plane but normal to the primary crack propagation direction.

**susceptibility to hydrogen embrittlement**—a material property that is measured by the threshold stress intensity parameter for hydrogen induced stress cracking,  $K_{Isc}$ ,  $K_{IHE}$ , or  $K_{EHE}$ , which is a function of hardness and microstructure.

**threshold (th)**—a point, separating conditions that will produce a given effect, from conditions that will not produce the effect; the lowest load at which subcritical cracking can be detected.

**threshold stress ( $\sigma_{th}$ )**—a stress below which no hydrogen stress cracking will occur and above which time-delayed fracture will occur.

**threshold stress intensity ( $K_{th}$ )**—a stress intensity below which no hydrogen stress cracking will occur and above which, time-delayed fracture will occur.

**time-delayed embrittlement**—see **internal hydrogen embrittlement**.

#### 4.2 Symbols:

$K$ —stress-intensity factor

$K_{EHE}$ —Environmental Hydrogen Embrittlement (EHE) threshold stress intensity at a specified loading rate—test conducted in a specified hydrogen charging environment — not geometry dependent.

$K_{IHE}$ —Internal Hydrogen Embrittlement (IHE) threshold stress intensity at a specified loading rate — test conducted in air — not geometry dependent.

$K_{Isc}$ —threshold stress intensity for stress corrosion cracking

$k_t$ —stress concentration factor

$K_{th}$ —threshold stress intensity

**$P$** —applied load  
 **$P_c$** —critical load required to rupture a specimen using a continuous loading rate  
 **$P_i$** —crack initiation load for a given loading and environmental condition using an incrementally increasing load under displacement control  
 **$P_{th}$** —threshold load in which  $P_i$  is invariant with respect to loading rate;  $P_{th}$  is the basis for calculating the threshold stress or the threshold stress intensity  
 **$R_{nsb}$** —ratio of specimen notched strength to yield strength in bending  
 **$R_{sb}$** —ratio of specimen crack strength to yield strength in bending  
 **$th$** —threshold  
 **$\sigma$** —applied stress  
 **$\sigma_{net}$** —net stress based on area at minimum diameter of notched round bar  
 **$\sigma_i$** —stress at crack initiation  
 **$\sigma_{th-EHE}$** —threshold stress—test conducted in a specified environment—geometry dependent  
 **$\sigma_{th-IHE}$** —threshold stress—test conducted in air—geometry dependent  
 **$\Sigma_{th}$** —threshold stress

#### 4.3 Abbreviations:

**EAC**—environmentally assisted cracking

**EHE**—environmental hydrogen embrittlement

**ETUL**—extended time under load

**FFS**—fast fracture strength

**GHE**—gaseous hydrogen embrittlement

**HASC**—hydrogen-assisted stress cracking

**HE**—hydrogen embrittlement

**HSC**—hydrogen stress cracking

**Hsr**—hydrogen susceptibility ratio

**IHE**—internal hydrogen embrittlement

**ISL**—incremental step load

**ISL<sub>th</sub>**—threshold from an incremental step-load test

**NFS(B)**—notched fracture strength in bending

**NFS(T)**—notched fracture strength in tension

**NTS**—notched tensile strength

**RA**—reduction of area

**RHE**—reaction hydrogen embrittlement

**SCC**—stress corrosion cracking

**SCE**—saturated calomel electrode

**SLT**—sustained load test

iTech Standards  
 (https://standards.iteh.ai)  
 Document Preview

## ANNEX

### (Mandatory Information)

#### A1. DEFINITIONS OF SYMBOLIC EXPRESSIONS

A1.1 The following abbreviations and symbols are included as separate sections in this standard because they evolved specifically from tests conducted on fasteners, which inherently have all of the ingredients necessary to create hydrogen embrittlement problems.

A1.2 Fasteners are generally (1) a notched, high-strength structural element that in service is always torqued to a high percentage of the fracture strength, (2) chemically cleaned, (3) coated with a sacrificial anodic coating that is generally electrochemically deposited producing a hydrogen charging condition, and (4) placed in service under cathodic charging conditions when exposed to an aqueous environment—all of the conditions necessary to cause classical hydrogen embrittlement (IHE) or environmentally induced hydrogen embrittlement (EHE).

A1.3 *Test Methods E8/E8M Loading Rates*—These results are independent of any residual hydrogen concentration because the tests are performed at a rate that does not allow sufficient time for the diffusion of hydrogen to occur.

##### A1.3.1 Tensile Test Symbols:

$TS(T)$  = tensile strength (tension), ksi; calculated from the minimum specified tensile strength (mst) and minor diameter of the fastener.

$FS(T)$  = fracture strength (tension), ksi; calculated from the measured fracture or ultimate tensile load of the fastener, or notched or precracked test sample.

$R_{nst}$  = notched strength ratio in tension; calculated from  $FS(T)/TS(T)$ .

##### A1.3.2 Bend Test Symbols:

$YS(B)$  =  $TS(T)$ .

$FS(B)$  = fracture strength (bend), ksi; calculated from the measured fracture or ultimate bend of the fastener, or notched or precracked test sample.

$R_{nsb}$  = notched strength ratio in bending.

A1.4 *Test Method F1624 Loading Rates*—These abbreviations are used for the terms for results that are dependent on the residual hydrogen concentration. The tests are performed at a rate that allows sufficient time for the diffusion of hydrogen to occur.