



Designation: F 1997 – 99

## Standard Test Method for Determining the Sensitivity (Teasing) of a Tactile Membrane Switch<sup>1</sup>

This standard is issued under the fixed designation F 1997; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reappraisal. A superscript epsilon ( $\epsilon$ ) indicates an editorial change since the last revision or reappraisal.

### 1. Scope

1.1 This test method establishes procedures for depressing and releasing a tactile membrane switch to determine the amount of switch teasing, if any.

1.2 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.*

### 2. Referenced Documents

#### 2.1 ASTM Standards:<sup>2</sup>

F 1570 Test Method for Determining the Tactile Ratio of a Membrane Switch

F 1597 Test Method for Determining the Actuation Force and Contact Force of a Membrane Switch

### 3. Terminology

3.1 *Definitions:* Refer to Figs. 1 and 2 for the following terms.

3.1.1 *actuation force ( $F_{max}$  or  $F_a$ )*—maximum force measured prior to or including point at which contact closure is achieved (see Test Method F 1597).

3.1.2 *break force ( $F_b$ )*—the force at contact break.

3.1.3 *break travel ( $T_b$ )*—the travel at contact break.

3.1.4 *circuit resistance*—electrical resistance as measured between two terminations whose internal contacts, when held closed, complete a circuit.

3.1.5 *contact break*—point at which circuit resistance is higher than specified resistance.

3.1.6 *contact closure (make)*—point at which specified resistance is achieved.

3.1.7 *contact force ( $F_c$ )*—the force at contact closure (see Test Method F 1597).

3.1.8 *contact travel ( $T_c$ )*—the travel at contact closure.

3.1.9  *$F_{min}$* —minimum force seen between  $F_{max}$  and point at which probe movement ceases.

3.1.10 *force-displacement curve*—relationship between force applied and displacement of a membrane switch. Sometimes referred to as “force-travel curve”.

3.1.10.1 *Discussion*—usually expressed as a line graph.

3.1.11 *force-resistance curve*—the relationship between force applied and resistance of a membrane switch.

3.1.11.1 *Discussion*—usually expressed as a line graph.

3.1.12 *membrane switch*—a momentary switching device in which at least one contact is on, or made of, a flexible substrate.

3.1.13 *nontactile switch*—a switch assembly that has a tactile ratio equal to zero.

3.1.14 *return force ( $F_{rmin}$ )*—minimum force seen during return cycle before reaching  $F_{rmax}$ .

3.1.15 *return max force ( $F_{rmax}$ )*—maximum force measured during return cycle after achieving  $F_{rmin}$ .

3.1.16 *specified resistance*—maximum allowable resistance as measured between two terminations whose internal switch contacts, when held closed, complete a circuit.

3.1.17 *switch teasing (break)*—the travel measurement on the force-displacement curve between contact break ( $F_b$ ) and return force ( $F_{rmin}$ ).

3.1.18 *switch teasing (make)*—the travel measurement on the force-displacement curve between contact force ( $F_c$ ) and minimum force ( $F_{min}$ ).

3.1.19 *tactile ratio*—a measure of tactile response (see Test Method F 1570).

3.1.20 *tactile response*—a sudden collapse or snapback of a membrane switch prior to contact closure or after contact break.

3.1.21 *tactile switch*—a switch assembly that provides a tactile ratio greater than zero.

3.1.22  *$T_b$* —travel at contact break.

3.1.23  *$T_{fm}$* —travel at  $F_{min}$ .

3.1.24  *$T_r$* —travel at  $F_r$ .

<sup>1</sup> This test method is under the jurisdiction of ASTM Committee F-1 on Electronics, and is the direct responsibility of Subcommittee F01.18 on Membrane Switches.

Current edition approved Dec. 10, 1999. Published February 2000.

<sup>2</sup> For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.