

### SLOVENSKI STANDARD SIST ISO 8584-1:1995

01-november-1995

## Plastomerne cevi za industrijske cevovode pod tlakom - Določanje faktorja kemične odpornosti in osnovne napetosti - 1. del: Poliolefinske cevi

Thermoplastics pipes for industrial applications under pressure -- Determination of the chemical resistance factor and of the basic stress -- Part 1: Polyolefin pipes

## iTeh STANDARD PREVIEW

Tubes en thermoplastiques pour les applications industrielles sous pression --Détermination du facteur de résistance chimique et de la contrainte de base -- Partie 1: Tubes en polyoléfines

https://standards.iteh.ai/catalog/standards/sist/665b7b62-88a0-4346-820f-7305bd297058/sist-iso-8584-1-1995 Ta slovenski standard je istoveten z: ISO 8584-1:1990

ICS:

23.040.20 Cevi iz polimernih materialov Plastics pipes

SIST ISO 8584-1:1995

en

SIST ISO 8584-1:1995

## iTeh STANDARD PREVIEW (standards.iteh.ai)

<u>SIST ISO 8584-1:1995</u> https://standards.iteh.ai/catalog/standards/sist/665b7b62-88a0-4346-820f-7305bd297058/sist-iso-8584-1-1995

## INTERNATIONAL STANDARD



First edition 1990-03-01

Thermoplastics pipes for industrial applications under pressure — Determination of the chemical resistance factor and of the basic stress —

#### Part 1: iTeh Spolyolefin pipes PREVIEW (standards.iteh.ai)

Tubes en thermoplastiques pour les applications industrielles sous pression – Détermination du facteur de résistance chimique et de la contrainte de base – https://standards.ieh.a/catalog/standards/sist/665b7b62-88a0-4346-820f-Partie 1: Tubes en polyolétines /305bd29/058/sist-iso-8584-1-1995



Reference number ISO 8584-1 : 1990 (E)

#### Contents

	Pa	ge
Fore	eword	iv
Intr	oduction	v
1	Scope	1
2	Normative references	1
3	Definitions	1
4	Principle	3
5	Apparatus	<b>F</b> VIEW
6	Test pieces (standards.iteh.a	aj)
7	Test fluids <u>SIST ISO 8584-1:1995</u>	4
8	https://standards.iteh.ai/catalog/standards/sist/665b7b Test temperatures	62-88a0-4346-820f- 995
9	Choice of test stress and calculation of the test pressure	4
10	Test procedure	5
11	Basic curves of long-term creep strength with water	5
12	Determination of the basic stress function with a given fluid at the operating temperature $T_{\rm S}$ and of the basic stress for a given time to failure	5
13	Choice of the pipe series	7
14	Test report	7
An	nexes	
Α	Laboratory apparatus	8
в	Examples of calculation	9

© ISO 1990

All rights reserved. No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the publisher.

International Organization for Standardization

Case postale 56 • CH-1211 Genève 20 • Switzerland

Printed in Switzerland

С	Tables showing examples of basic stresses as a function of the operating temperature $T_{\rm S}$ , the time to failure <i>t</i> and the chemical resistance factor $f_{\rm CR}$	12
D	Examples of basic stress curves with water for polyethylene pipes with a nominal stress $\sigma_{\rm N}=5{\rm MPa}\ldots$	16
E	Examples of basic stress curves with water for polybutene pipes with a nominal stress $\sigma_{\rm N}=8{\rm MPa}\ldots$	17
F	Examples of basic stress curves with water for propylene homopolymer pipes with a nominal stress $\sigma_{\rm N}=$ 6,3 MPa	18
G	Examples of basic stress curves with water for propylene copolymer pipes with a nominal stress $\sigma_{\rm N}=5{\rm MPa}\ldots$	19

## iTeh STANDARD PREVIEW (standards.iteh.ai)

<u>SIST ISO 8584-1:1995</u> https://standards.iteh.ai/catalog/standards/sist/665b7b62-88a0-4346-820f-7305bd297058/sist-iso-8584-1-1995

#### SIST ISO 8584-1:1995

#### Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

Draft International Standards adopted by the technical committees are circulated to the member bodies for approval before their acceptance as International Standards by the ISO Council. They are approved in accordance with ISO procedures requiring at VIEW least 75 % approval by the member bodies voting.

#### (standards.iteh.ai)

International Standard ISO 8584-1 was prepared by Technical Committee ISO/TC 138, *Plastics pipes, fittings and valves for the transport of fluids*, ST ISO 8584-1:1995

https://standards.iteh.ai/catalog/standards/sist/665b7b62-88a0-4346-820F ISO 8584 consists of the following parts, under the general title *Thermoplastics pipes* for industrial applications under pressure — Determination of the chemical resistance factor and of the basic stress:

- Part 1: Polyolefin pipes
- Part 2: Pipes of halogenated polymers [Technical Report]

Annex A forms an integral part of this part of ISO 8584. Annexes B to G are for information only.

#### Introduction

The design and the calculation of dimensions of pressure pipes intended for the transportation of liquids or gases is a complex task. It is necessary to take into consideration the influence of both the hydraulic properties of the liquid or gas and the material characteristics, both of which are more or less well defined and depend to a certain extent on one another. Application techniques use simplified rules which, by iterative methods, permit the best choice of the type of material and of the dimensions of the pipes, and provide an estimate of the permissible continuous pressures in the pipeline.

The resistance of a pipe to the fluids being transported by it may be expressed as a long-term chemical resistance under constant operating conditions (e.g. the type and concentration of the fluids, the temperature and the pressure).

in accordance with ISO 16121, this part of ISO 8584 defines the development in time *t* of the permissible stress in the pipe wall, due to the action of a static internal pressure, as the "basic stress function":

https://standards.itehorijcatalog/standards/sist/665±7/p(1)-88a0-4346-820f-7305bd297058/sist-iso-8584-1-1995

The materials suitable for pressure pipes are divided into classes according to their nominal stress  $\sigma_N$ . This nominal stress corresponds to the basic stress  $\sigma_B$ , extrapolated to 50 years, for the case where the fluid is water at 20 °C, under nominal pressure (PN):

 $\sigma_{\rm N}$  =  $\sigma_{\rm B, 50, water, 20 \ ^{\circ}C, PN}$ 

In addition to their designation according to the material and the nominal stress, pipes may be designated by a pipe series number S which corresponds to the series of wall thicknesses given in the table in ISO 4065. The definition of S is as follows:

$$S = \frac{d_e - \delta}{2\delta} = \frac{\sigma}{p}$$

where

 $d_{\rm P}$  is the nominal outside diameter;

 $\delta$  is the nominal wall thickness;

*p* is the operating pressure.

Using the nominal values, this equation then becomes

$$\sigma_{\rm N} = {\rm PN} \times {\rm S}$$

or

$$PN = \frac{\sigma_N}{S}$$

v

For example, a polyethylene-based pipe designated by  $\sigma_{\rm N}$  = 5 MPa and S5 has a nominal pressure

PN = 5/5 = 1 (corresponding to 1 MPa or 10 bar).

The design of a pressure pipe system is determined according to the differences in level, the maximum rate of discharge of fluid and other requirements of the design. The flow speed may, as a general rule and within certain limits, be chosen freely. The appropriate choice of the cross-section of the pipes (the cross-section multiplied by the speed gives the discharge of fluid), i.e. the inside diameter of the pipes in a system, enables the determination of the necessary pressure and thus the requirements for the long-term resistance of the pipes.

Once the operating pressure *p* as required by the hydraulic conditions, valid for all diameters, has been determined it is recommended that one chooses the series of pipe wall thicknesses which is likely to be suitable. Following this assumption, and according to the formula given above, the operating stress  $\sigma_{\rm S}$  has the following value:

 $\sigma_{\rm S} = p S$ 

The requirements of the material itself are then defined according to the operating stress. This stress shall be admissible for the fluid being transported at the given temperature and for the given period of time, and it is the essential criterion for the choice of the material.

The pipe series and the type of material chosen are suitable for carrying out a given V F where the operating stress  $\sigma_S$  is equal to or less than the basic stress  $\sigma_B$ , as determined under the conditions specified in this part of ISO 8584 ard sites.

 $\sigma_{\rm S} \leq \sigma_{\rm B}$ 

#### SIST ISO 8584-1:1995

If this inequality is not satisfied, it means, initially, that the choice of the pipe series is 88a0-4346-820fincorrect. 7305bd297058/sist-iso-8584-1-1995

It is also possible to make other assumptions, starting from the basis of different data. One may make selections, for example, on the basis of the pipe series as well as on the material, or one may increase the pipe diameter so that the pipe system works at a lower pressure.

The long-term creep strength (or resistance) of thermoplastics pipes subject to internal pressure due to water has been the subject of very detailed investigation for decades. As the results show, the long-term creep strength may be represented mathematically by a regression curve of the form

 $\lg \sigma = a - b \lg t$ 

In this case, the regression curve is a straight line. If the tests are performed over a long period of time at high temperatures and/or under the action of aggressive fluids, the slope of the regression curve becomes steeper. This part of ISO 8584 is applicable to the case where the long-term creep strength can be represented by a bilinear model, i.e. by a curve consisting of two straight line portions with different gradients, where each of the two straight line portions of the curve may be represented mathematically by a regression line of the form:

 $\lg \sigma = a_i - b_i \lg t$ 

The first straight line portion has constants  $a_1$  and  $b_1$  and the second portion, with a steeper gradient, has constants  $a_2$  and  $b_2$ . If the temperature of the water is taken as a parameter, a group of regression curves is obtained which enables one to determine the creep strength as a function of time for a given pipe material (see figure 1).



#### (standards.iteh.ai)

The curve which connects the points of change in gradient or "transition points" of the group of regression curves, called the transition curve, represents the development of these transition points with time and temperature. The transition point is therefore located at longer times for lower temperatures.

The basic stress for an industrial application is determined from the group of rupture stress curves  $\sigma_R$  found by experimental tests. The corresponding values are extrapolated by taking into account the lower dispersion limit and safety factors which are fixed by agreement. The field of industrial applications (the shaded area in figure 1) is situated below the transition curve. Furthermore, it is limited by oxidation phenomena which may occur during long periods of usage at high temperatures <sup>1</sup>).

By way of example, diagrams of such basic stresses of pipes are shown in annexes D to G. These types of long-term hoop stresses are necessary for the choice of the pipe series and the calculation of the dimensions of the pipes.

As the observed scatter of test results is high, the tests, extrapolations and classifications of each type of pipe are performed using statistical methods. A suitable method is the "standard extrapolation method", which will form the subject of ISO/TR 9080. Within the temperature ranges for each type of material, it is necessary to carry out tests at several temperatures, where any two temperatures are separated by 10 K to 20 K, for at least five stresses and for at least five test pieces per test, so that some time periods are at least  $10^4$  h.

<sup>1)</sup> See GAUBE, GEBLER, MÜLLER, GONDRO, Zeitstandfestigkeit und Alterung von Rohren aus HDPE, *Kunstoffe* **75** (1985) p. 7.

ISO 4433 describes a method of determining the resistance of polyolefin pipes to industrial products and other chemical fluids using an immersion test and provides a system for preliminary classification. The results only apply directly to non-pressure pipes. For pipes containing fluids under pressure, this method only enables one to reveal the incompatibilities between the fluid and the pipes. The resulting classification of "satisfactory resistance" or "limited resistance" shall be confirmed by tests of the long-term creep strength under pressure.

The present test method, intended for the determination of the chemical resistance factor  $f_{CR}$ , gives examples of characteristic values of creep strength which express, for a given stress and temperature, the resistance of a pipe to the fluid considered in comparison with its resistance to water.

The aim of this test method is

- a) to determine the chemical resistance factor  $f_{\rm CR}$  and the basic stress function
- $\sigma_{\rm B} = f(t, T)$  with fluids more aggressive than water;
- b) to make test periods as short as possible and to keep costs as low as possible.

In view of the countless number of fluids, concentrations and mixtures used in various industries, it is absolutely essential to have a test method and a method of extrapolation simpler than those given in ISO 1167 and by the "standard extrapolation method" respectively which are valid for water and other wide-ranging applications.

The reduction in the cost of a test is not achieved by a reduction in the number of NEW necessary statistical tests or by applying high stresses in the area situated above the transition curve for water. The simplification sought is achieved

- by carrying out the tests at high temperatures, and

 by determining the median of the time to failure (this method consists of stopping the tests as soon as half the test pieces have failed) standards/sist/665b7b62-88a0-4346-820f-7305bd297058/sist-iso-8584-1-1995

The function of the basic stress with water is to enable extrapolation of the  $f_{CR}$  values. Examples of diagrams of such basic stresses are given, for information, in annexes D to G. When the results are applied to pipes of greater wall thickness, the differences in the structure and the internal stresses induced in the walls of such pipes are taken into account.

The basic stress  $\sigma_B$  estimated from the tests and extrapolation serves as a basis for the calculation of the permissible stress. By definition,  $\sigma_B$  does not take into account

 additional loads and various influences due to the fluids and temperatures which, depending on the case in hand, may exert a stress in addition to that of the pressure;

b) the physical or chemical influence of the environment, or any special safety requirements.

It is up to experts to estimate the influence of these additional factors and to introduce them into the calculations.

# Thermoplastics pipes for industrial applications under pressure — Determination of the chemical resistance factor and of the basic stress —

## **Part 1** : Polyolefin pipes

#### 1 Scope

tables.

**1.1** This part of ISO 8584 defines the basic stress  $\sigma_B$  as the reference value for determining the series S of polyolefin pressure pipes and makes use of the classification of pipes according to their nominal stress  $\sigma_N$ .

**1.2** For applications in the water industry, this part of ISO 8584 (standards.

gives examples of the possible basic stress as a func-

2 Normative references

The following standards contain provisions which, through reference in this text, constitute provisions of this part of ISO 8584. At the time of publication, the editions indicated were valid. All standards are subject to revision, and parties to agreements based on this part of ISO 8584 are encouraged to investigate the possibility of applying the most recent editions of the standards indicated below. Members of IEC and ISO maintain registers of currently valid International Standards.

ISO 3:1973, Preferred numbers — Series of preferred numbers.

tion of time and temperature for polyolefin pipes and ISO 8584-1:1995 https://standards.iteh.ai/catalog/standards/sisISO 16151:21978. Thermoplastics pipes for the transport of — provides the design engineer with a method to (study<sub>s1-iso</sub>-*fluids*) - Nominal outside diameters and nominal pressures the field of application of each class of pipes and how the Part 1: Metric series. basic stress can develop, with the aid of diagrams and

ISO 1167:1973, Plastics pipes for the transport of fluids – Determination of the resistance to internal pressure.

ISO 3126: 1974, Plastics pipes - Measurement of dimensions.

ISO 4065:1978, Thermoplastic pipes — Universal wall thickness table.

ISO 4433:1984, Polyolefin pipes – Resistance to chemical fluids – Immersion test method – System for preliminary classification.

ISO/TR 9080:  $-^{1}$ , Plastics pipes for the transport of fluids – Standard extrapolation method for the long term resistance to constant internal pressure.

#### 3 Definitions

**3.1** basic stress,  $\sigma_B$ : Stress sustained in continuous operation, without failure and with an appropriate safety factor, during a given period by the wall of a pipe exposed to a fluid under static pressure.

**1.3** As far as applications in the chemical industry are concerned, this part of ISO 8584

- defines the chemical resistance factor  $f_{\rm CR}$ ,
- specifies the test method to determine  $f_{CR}$ ,

 specifies a method of extrapolation to estimate the development of the basic stress in the case of an aggressive fluid, and

 — illustrates in annex A a simplified laboratory apparatus, resistant to corrosion, for use on pipes of 12 mm and 8 mm in diameter.

**1.4** This part of ISO 8584 may be applied in a similar manner to pipes made of other materials whose regression curves can be represented by a bilinear model. The method of extrapolation assumes knowledge of the basic stress function  $\sigma_{\rm B} = f(t, T)$  with water.

1) To be published.