

Designation: D 3822 - 96

Standard Test Method for Tensile Properties of Single Textile Fibers¹

This standard is issued under the fixed designation D 3822; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

- 1.1 This test method covers the measurement of tensile properties of natural and man-made single textile fibers of sufficient length to permit mounting test specimens in a tensile testing machine.
- 1.2 This test method is also applicable to continuous (filament) and discontinuous (staple) fibers or filaments taken from yarns or tow. When the fibers to be tested contain crimp, or if the tow or yarns have been subjected to bulking, crimping, or texturing process, the tensile properties are determined after removal of the crimp.
- Note 1—Testing of filaments taken from yarns or tow, included in this test method was originally covered in Test Method D 2101, that is discontinued.
- 1.3 The words "fiber" and "filament" are used interchangeably throughout this test method.
- 1.4 This test method is also applicable to fibers removed from yarns, or from yarns processed further into fabrics. It should be recognized that yarn and manufacturing processes can influence or modify the tensile properties of fibers. Consequently, tensile properties determined on fibers taken from yarns, or from yarns that have been processed into fabrics, may be different than for the same fibers prior to being subjected to yarn or fabric manufacturing processes.
- 1.5 This test method provides directions for measuring the breaking force and elongation at break of single textile fibers and for calculating breaking tenacity, initial modulus, chord modulus, tangent modulus, tensile stress at specified elongation, and breaking toughness.
- 1.6 Procedures for measuring the tensile properties of both conditioned and wet single fibers are included. The test method is applicable to testing under a wide range of conditions.
- 1.7 As the length of the test specimen decreases, the tensile strength is likely to increase, but the accuracy of the tensile properties determined may decrease, which may require the need to increase the number of test specimens. This is particularly true for those properties dependent on the measurement of elongation, since the shorter lengths increase the

relative effect of slippage and stretching of the test specimens within the jaws of either clamp.

- 1.8 The values stated in either acceptable metric units or in other units shall be regarded separately as standard. The values stated in each system may not be exact equivalents; therefore, each system must be used independently of the other, without combining values in any way.
- 1.9 This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.

2. Referenced Documents

- 2.1 ASTM Standards:
- D 76 Specification for Tensile Testing Machine for Textiles²
- D 123 Terminology Relating to Textiles²
- D 578 Specification for Glass Fiber Yarns²
- D 629 Test Methods for Quantitative Analysis of Textiles²
- D 1577 Test Methods for Linear Density of Textile Fibers²
- D 1776 Practice for Conditioning Textiles for Testing²
- D 2101 Test Method for Tensile Properties of Single Man-Made Fibers Taken from Yarns and Tow³
- D 2258 Practice for Sampling Yarn for Testing²
- D 3333 Practice for Sampling Man-Made Staple Fibers, Sliver, or Tow for Testing⁴
- D 4848 Terminology Relating to Force and Deformation Properties of Textiles⁴
- E 178 Practice for Dealing with Outlying Observations⁵

3. Terminology

- 3.1 Definitions:
- 3.1.1 *breaking force*, *n*—the maximum force applied to a material carried to rupture.
- 3.1.1.1 *Discussion*—The observed breaking force for fibers and filaments is generally expressed as millinewton (mN) or gram-force (gf).
- 3.1.2 *breaking tenacity*, *n*—the tenacity at the breaking force.

¹ This test method is under the jurisdiction of ASTM Committee D-13 on Textiles and is the direct responsibility of Subcommittee D13.57 on Fiber Test Methods, General.

Current edition approved Sept. 10, 1996. Published January 1997. Originally published as D 3822 - 79. Last previous edition D 3822 - 95a.

² Annual Book of ASTM Standards, Vol 07.01.

³ Discontinued; see 1995 Annual Book of ASTM Standards, Vol 07.01.

⁴ Annual Book of ASTM Standards, Vol 07.02.

⁵ Annual Book of ASTM Standards, Vol 14.02.

- 3.1.2.1 *Discussion*—Breaking tenacity is commonly expressed as centinewton per tex (cN/tex) or gram-force per denier (gf/den). The breaking tenacity is calculated from the breaking force and the linear density of the unstrained specimen or obtained directly from tensile testing machines that can be suitably adjusted to indicate tenacity instead of force for specimens of known linear density.
- 3.1.3 *breaking toughness*, *n*—toughness up to the breaking force.
- 3.1.3.1 *Discussion*—Breaking toughness is proportional to the area under the force-elongation curve from the origin to the breaking force. In textile strands, it is expressed as work (joules) per unit linear density.
- 3.1.4 *chord modulus*, *n*—*in a stress-strain curve*, the ratio of the change in stress to the change in strain between two specified points on the curve.
- 3.1.4.1 *Discussion*—The chord modulus is expressed in centinewton per tex (cN/tex), or in gram-force per denier (gf/den).
- 3.1.5 *corresponding elongation*, *n*—see elongation at specified force.
- 3.1.6 corresponding force, n—see force at specified elongation.
- 3.1.7 *elongation*, *n*—the ratio of the extension of a material to the length of the material prior to stretching, expressed as a percent.
- 3.1.7.1 *Discussion*—Elongation may be measured at any specified force or at rupture.
- 3.1.8 *elongation at break*, *n*—the elongation corresponding to the breaking force. (Syn. *breaking elongation*.)
- 3.1.9 elongation at specified force, (EASF) n—the elongation associated with a specified force on the force-extension curve. (Syn. corresponding elongation.)
- 3.1.10 *fiber*, *n*—*in textiles*, a generic term for any one of the various types of matter that form the basic elements of a textile and that is characterized by having a length at least 100 times its diameter.
- 3.1.10.1 *Discussion*—Refer to D 123 definitions for manmade fiber and natural fiber, and Annex A1 and Annex A2 for additional information.
- 3.1.11 *filament*, *n*—*in textiles*, continuous fiber of indefinite length.
- 3.1.12 *filament yarn*, *n*—a yarn composed of (continuous) filaments assembled with or without twist.
- 3.1.13 force at specified elongation (FASE), n—the force associated with a specific elongation on the force-extension or force-elongation curve. (Syn. corresponding force.)
- 3.1.14 *initial modulus*, *n*—*in a stress-strain curve*, the slope of the initial straight portion of the curve.
- 3.1.14.1 *Discussion*—The modulus is the ratio of the change in stress, expressed in centinewton per tex (cN/tex) or gram-force per denier (gf/den), to the change in strain, expressed as a fraction of the original length.
- 3.1.15 *linear density*, *n*—mass per unit length; the quotient obtained by dividing the mass of a fiber or yarn by its length.
- 3.1.15.1 *Discussion*—The tex unit (gram per kilometre) is preferred over the denier unit (gram per 9 kilometres).

- 3.1.16 *secant modulus*, *n*—deprecated term in textile terminology. Use the preferred term *chord modulus*.
- 3.1.17 tangent modulus, n—in a stress-strain curve, the ratio of change in stress to change in strain derived from the tangent to any point on the curve.
- 3.1.18 *tenacity*, *n*—*in a tensile test*, the force exerted on the specimen based on the linear density of the unstrained material.
- 3.1.18.1 *Discussion*—Tenacity is commonly expressed as centinewton per tex (cN/tex) or gram-force per denier (gf/d).
- 3.1.19 *tow*, *n*—*in man-made fibers*, a twistless multifilament strand suitable for conversion into staple fibers or sliver, or for direct spinning into yarn.
- 3.1.20 *yield point*, *n*—*in a stress-strain curve*, the point beyond which work is not completely recoverable and permanent deformation takes place.
- 3.1.20.1 Discussion—In textile fibers, an exact proportionality does not exist between force and extension and there is not a true yield point. The point on the force-extension curve beyond which the force-extension ratio changes from that existing during the first essentially straight line portion of the curve is frequently called the yield point of a textile strand or fiber. With animal fibers, permanent deformation does not occur until the extension reaches about 30 %, or when the rate of extension is extremely slow or the fiber is held under tension for a long time. In fact, if animal fiber is stretched in water, or at high humidity conditions, to as much as 30 % of the original length and allowed to relax for 24 h, the original force-extension curves may be reproduced.
- 3.1.21 Refer to Terminology D 123 for definitions of other textile terms and Terminology D 4848 for definitions of terms related to force and deformation used in this test method.

4. Summary of Test Method

4.1 Single-fiber specimens are broken on a constant-rate-of-extension (CRE) type tensile testing machine at a predetermined gage length and rate of extension. Using the force-extension curve, the breaking force and elongation at break are determined. The force-elongation curve and linear density are used to calculate breaking tenacity, initial modulus, chord modulus, tangent modulus, tensile stress at specified elongation, and breaking toughness.

5. Significance and Use

- 5.1 Test Method D 3822 using test specimens having gage lengths of 10 mm (0.4 in.) or greater is considered satisfactory for acceptance testing of commercial shipments since the test method has been used extensively in the trade for acceptance testing. Critical differences noted in Tables 1 and 2 were obtained on man-made fibers having a gage length of 25.4 mm (1.0 in.) and 254 mm (10 in.). Natural fibers or fibers having lesser or greater gage lengths may provide different values and may require comparative testing. (See 5.1.1.)
- 5.1.1 In cases of a dispute arising from differences in reported test results when using Test Method D 3822 for acceptance testing of commercial shipments, the purchaser and the supplier should conduct comparative tests to determine if there is a statistical bias between their laboratories. Competent statistical assistance is recommended for the investigation of bias. As a minimum, the two parties should take a group of test



TABLE 1 Fiber Tensile Properties Using 25.4 mm (1 in.) Gage Length Critical Differences for the Conditions Noted^A

TABLE 2 Fiber Tensile Properties Using a 254 mm (10 in.) Gage Length Critical Differences for the Conditions Noted^A

Properties, Limits of Measure and Materials	Number of Observations in Each Average	Single- Operator Precision	Within- Laboratory Precision			Number of Observations in Each Average	Single- Operator Precision	Within- Laboratory Precision	Between- Laboratory Precision
Breaking Tenacity, gf/tex:					Breaking Tenacity, gf/tex				
Acetate	1	0.17	0.18	0.24	Acetate	1	0.19	0.21	0.23
7.001010	10	0.05	0.08	0.18	71001010	10	0.06	0.10	0.13
	20	0.03	0.07	0.18		20	0.04	0.09	0.13
	40	0.04	0.07	0.18		40	0.04	0.09	0.13
Aramid	1	14.05	14.05	14.05	Aramid	1	8.73	9.27	9.68
Alamid	10	4.44	4.44	4.44	Alamid	10	2.76	4.15	5.01
	20	3.14	3.14	3.14		20	1.95	3.67	4.61
	40	2.22	2.22	2.22	N. I	40	1.38	3.40	4.40
Nylon	1	0.78	0.78	0.82	Nylon	1	0.69	0.74	0.83
	10	0.24	0.27	0.37		10	0.22	0.33	0.51
	20	0.17	0.21	0.32		20	0.15	0.29	0.49
	40	0.12	0.17	0.30		40	0.11	0.27	0.47
Polyester	1	0.53	0.53	0.57	Polyester	1	0.69	0.78	0.79
	10	0.17	0.17	0.28		10	0.22	0.42	0.43
	20	0.12	0.12	0.25		20	0.15	0.39	0.40
	40	0.08	0.08	0.24		40	0.11	0.38	0.39
nitial Madulus of/tax					Initial Madulus of/tax				
Initial Modulus, gf/tex		7.00	44.04	10.01	Initial Modulus, gf/tex		4.00	4.00	F 00
Acetate	1	7.32	11.01	16.64	Acetate	1	4.02	4.82	5.29
	10	2.31	8.55	15.12		10	1.27	2.95	3.67
	20	1.64	8.39	15.03		20	0.90	2.81	3.56
	40	1.16	8.31	14.99		40	0.64	2.74	3.50
Aramid	1	266.1	283.8	367.1	Aramid	1	191.8	191.8	243.7
	10	84.2	129.5	266.5		10	60.6	60.6	162.2
	20	59.5	115.1	259.7		20	42.9	42.9	156.4
	40	42.1	107.1	256.3		40	30.3	30.3	153.5
Nylon	1	6.26	8.47	15.54	Nylon	1	4.85	7.08	10.71
•	10	1.98	6.04	14.36	1 1 1	10	1.53	5.38	9.67
	20	1.40	5.88	14.29		20	1.08	5.27	9.60
	40	0.99	5.79	14.26		40	0.77	5.21	9.58
Polyester	1	21.84	28.52	38.99	Polyester	1	12.25	15.66	17.11
. Olycoloi	10	6.91	21.35	33.03	nt Proviow	10	3.87	10.50	12.56
	20	4.88	18.99	32.66		20	2.74	10.13	12.26
	40	3.45	18.67	32.48		40	1.94	9.95	12.20
	40	0.40	10.07	02.40		40	1.34	3.33	12.11
Elongation at Break, %					Elongation at Break, %				
Acetate	1	7.29	7.65	8.64	Acetate	1	8.23	8.65	8.82
	toh 10	2.30	3.28	5.18		10 155	2.60	3.72	4.10
	11011. a ₂₀ ata	1.63	2.84	4.92		20	1.84	3.24	3.66
	40	1.15	2.60	4.78		40	1.30	2.96	3.42
Aramid	1	1.25	1.25	1.53	Aramid	1	0.64	0.73	0.77
	10	0.39	0.39	0.97		10	0.20	0.41	0.48
	20	0.28	0.28	0.93		20	0.14	0.39	0.46
	40	0.20	0.20	0.91		40	0.10	0.37	0.45
Nylon	1	17.93	18.36	22.43	Nylon	1	14.80	16.20	16.20
,	10	5.67	6.92	14.63		10	4.68	8.09	8.09
	20	4.01	5.64	14.01		20	3.31	7.38	7.38
	40	2.84	4.87	13.78		40	2.34	7.00	7.00
Polyester	1	14.97	15.09	17.82	Polyester	1	13.77	13.87	15.35
Fulyestel					Folyestel				
	10	4.73	5.10	10.76		10	4.36	4.65	8.05
	20 40	3.35 2.37	3.85 3.04	10.23 9.95		20 40	3.08 2.18	3.49 2.72	7.44 7.11

 $^{^{\}rm A}$ The critical differences were calculated using t = 1.960, which is based on infinite degrees of freedom.

specimens which are as homogeneous as possible and which are from a lot of material of the type in question. The test specimens should then be randomly assigned in equal numbers to each laboratory for testing. The average results from the two laboratories should be compared using Student's t-test for unpaired data and an acceptable probability level chosen by the two parties before the testing begins. If a bias is found, either its cause must be found and corrected or the purchaser and the supplier must agree to interpret future test results in view of test results with consideration to the known bias.

5.2 The breaking tenacity, calculated from the breaking force and the linear density, and the elongation are fundamental properties that are widely used to establish limitations on fiber processing or conversion and on their end-use applications. Initial modulus is a measure of the resistance of the fiber to extension at forces below the yield point. The tangent modulus and tensile stress at specified elongation may be used to differentiate between the probable performance of fibers in processing and end-use performance. The breaking toughness is an indication of the durability of materials produced from the fiber.

 $^{^{}A}$ The critical differences were calculated using t = 1.960, which is based on infinite degrees of freedom.

- 5.3 It is recognized that computerized results are used extensively in the industry. When comparing results from two laboratories using computerized tensile testers, the algorithms used to derive results must be examined for parity, that is, how the maximum slope and specimen failure or rupture are determined.
- 5.4 The breaking strength of wet fibers tested in air may be different from wet fibers tested while immersed.
- 5.4.1 Tests on wet specimens are usually made only on fibers which show a loss in breaking force when wet or when exposed to high humidity, for example, yarns made from animal fibers and man-made fibers based on regenerated and modified cellulose. Wet tests are made on flax fiber to detect adulteration by failure to show a gain in breaking force.

6. Apparatus and Reagents

6.1 Constant-Rate-of-Extension (CRE) Type Tensile Testing Machine, conforming to Specification D 76, having adequate response characteristics to properly record the characteristics of the force-elongation curve, or the stress-strain curve of the fibers under test at the rate of extension specified in Table 3. The capacity of the machine must be selected for the break on the recorded curve to fall within 20 to 90 % of full scale, preferably within 50 to 90 % of full scale. It is permissible to use tensile testing machines that have a means of calculating and displaying the required results without the use of an autographic recorder. The tensile testing machine must be equipped with a tank to provide for breaking fibers immersed in a liquid, if tests on wet immersed specimens are required.

Note 2—Special force-measuring systems may be used to directly record the tenacity in cN/tex.

- 6.2 *Clamps*, with flat jaws for gripping the fiber specimens and designed to minimize slippage in the clamps during the test.
- 6.2.1 *Tabs*, when required, of thin plastic or other material for use with cementing techniques (See Annex A1); and
- 6.2.2 *Cement or Adhesive*—The adhesive must be capable of binding the tabs to the fibers without affecting the moisture content of the specimen.

Note 3—For wet testing, the tabs and adhesive must be waterproof.

- 6.3 *Container*, separate from the testing machine for wetting out specimens to be tested without immersion.
- 6.4 Auxiliary Equipment—The testing machine may be equipped with auxiliary equipment to permit the automatic recording of data or the calculation of any required tensile property. The auxiliary equipment must be capable of recording data and performing calculations in a manner consistent with the definitions and instructions for calculations as described in this test method.

TABLE 3 Rate of Extension^A

_		
	Estimated Elongation at Break of Specimen, %	Rate of Extension, % of Initial Specimen Length/min
	Under 8	10
	8 to 100, incl.	60
	Over 100	240

^A For the optimum degree of comparability, tensile properties of filaments should be measured at the same rate of extension.

- 6.5 Area-Measuring Device—An integrating accessory to the tensile testing machine or a planimeter. The device shall measure area with an accuracy of ± 1 %.
- 6.6 *Jig*, to aid in accurately mounting test specimens on tabs at the specified gage length.
- 6.7 Distilled or Deionized Water, for use in wet specimen testing.
- 6.8 Wetting Agent, Nonionic—For wet specimen testing, for example, Triton X-100⁶ to make 0.1 % aqueous solution using water described in 6.7.

7. Sampling

7.1 Lot Sampling—As a lot sample for acceptance testing, take at random the number of shipping containers directed in the applicable material specification or other agreement between the purchaser and supplier, such as an agreement to use Practice D 3333 or Practice D 2258. Consider shipping containers to be the primary sampling units.

Note 4—An adequate specification or other agreement between the purchaser or supplier requires taking into account the variability between shipping units, between packages, ends or other laboratory sampling unit within a shipping unit if applicable, and with specimens from a single package, end or other laboratory sampling unit to provide a sampling plan with a meaningful producer's risk, consumer's risk, acceptable quality level, and limiting quantity level.

- 7.2 Laboratory Sample—As a laboratory sample for acceptance testing, take at random from each shipping container in the lot sample the number of laboratory sampling units as directed in an applicable material specification or other agreement between purchaser and supplier such as an agreement to use Practice D 3333 or Practice D 2258. Preferably, the same number of laboratory sampling units are taken from each shipping container in the lot sample. If differing numbers of laboratory sampling units are to be taken from shipping containers in the lot sample, determine at random which shipping containers are to have each number of laboratory units drawn.
- 7.2.1 *For Staple Fiber*—Take 50 g samples from laboratory sampling units.
- 7.2.2 For Sliver (or Top) or Tow—Take 1 m (1 yd) from the leading end which has a clean, uniform appearance from each laboratory sampling unit.
- 7.2.3 For Yarns—Take at least a 1 m (1 yd) length from each laboratory sampling unit.
- 7.3 Test Specimens—From each laboratory sampling unit, take 20 fiber specimens at random. If the standard deviation determined for the 20 specimens is more than a value agreed upon between the purchaser and supplier prior to testing, continue testing in groups of 20 specimens from the same laboratory sampling unit until the standard deviation for all specimens tested is not more than the agreed-to value or, by agreement, stop testing after a specified number.
- 7.3.1 Carefully remove twist before taking specimens from yarn. Using tweezers and grasping each specimen at one end, gently remove the required number of specimens from the

⁶ Triton-X 100 is a registered trademark of Rohm & Haas.



laboratory sampling units for testing. In some cases, if specimens are not to be tested immediately, place them on a short-pile or plush surface for storage until ready to test.

8. Preparation of Test Specimens

- 8.1 Measure the linear density of each specimen as directed in Test Methods D 1577.
- 8.2 If fibers are to be tabbed, select a technique from Annex A1 or some other technique agreed upon by the purchaser and supplier.
- 8.3 For testing wet specimens without immersion, place the specimens in a container and submerge in a 0.1% aqueous solution of a nonionic wetting agent in distilled or deionized water at ambient temperature until thoroughly soaked. (See 8.3.1 and 8.3.2.)
- 8.3.1 The time of immersion must be sufficient to completely wet out the specimens, as indicated by no significant changes in breaking force, or elongation at break when followed by longer periods of immersion.
- 8.3.2 When desizing treatments are specified prior to wet testing, use desizing treatments that will not effect the normal physical property of the material as directed in Test Methods D 629.
- 8.4 For wet specimens tested while immersed, proceed as directed in 11.2.2.

9. Preparation of Test Apparatus

- 9.1 Select the appropriate force range for the fiber to be tested.
- 9.2 Verify that the tensile tester is within calibration as specified in the manufacturer's instructions.
- 9.3 Adjust the distance between the clamps to obtain the selected nominal gage length of at least 10 mm (0.4 in.) and, when applicable, 250 mm (10 in.) or more. The most common gage lengths are 10, 20, 25, and 250 mm (0.4, 0.4, 1.0 and 10 in.).
- Note 5—The results obtained are normally subject to less error if the gage length is selected to be as large as possible, consistent with the length of fibers to be tested. When comparisons are to be made between different fibers or where it is necessary to obtain comparable results in different laboratories, it is advisable to use the same gage length for all tests, selecting it to accommodate the shortest fibers of interest.
- 9.3.1 If the fiber specimen is mounted on tabs before being placed in the testing machine, the distance between tabs defines the nominal gage length (See Annex A1).
- 9.4 Set the extension speed to provide the rate of elongation specified in Table 3 for the gage length selected.
- 9.5 When using microprocessor automatic data gathering systems, set the appropriate parameters as defined in the manufacturer's instruction.

10. Conditioning

- 10.1 Precondition the specimens by bringing them to approximate moisture equilibrium in the standard atmosphere for preconditioning textiles as directed in Practice D 1776.
- 10.2 After preconditioning, bring the test specimens to moisture equilibrium for testing in the standard atmosphere for

testing textiles as directed in Practice D 1776 or, if applicable, in the specified atmosphere in which the testing is to be performed.

11. Procedure

- 11.1 Test the conditioned specimens in the standard atmosphere for testing textiles, which is 21 \pm 1°C (70 \pm 2°F) and 65 \pm 2 % relative humidity.
- 11.2 Mount a test specimen in the jaws of the clamps, removing slack without stretching the specimen. The specimen must be straight within the jaws and extreme care must be taken to ensure that the fiber specimen lies on the line of action between the force-measuring device and the point where the fiber leaves the moving jaw face. Any misalignment that tends to produce transverse motion of the clamps and jaws will introduce errors in measurements of elongation and may contribute to premature fiber failure.
- 11.2.1 For testing wet specimens without immersion, remove a specimen from the water and immediately mount it in the clamps as directed in 11.1 and 11.2. Perform the test within two minutes after removal of the specimen from the water.
- 11.2.2 For testing wet specimens while immersed, secure the specimens into the clamps of the tensile tester and submerge in the tank containing a 0.1 % aqueous solution of a nonionic wetting agent in distilled or deionized water at ambient temperature until thoroughly soaked. (See 8.3.1 and 8.3.2.). Test while the specimens are immersed in the water bath
- Note 6—In general, it will be found that no one type of fiber mounting will be suitable for all types and sizes of fibers and experience may show that some mounting techniques are much more efficient than others. Experience and operator preferences have been found to be of importance in selecting the most satisfactory mounting methods for a given laboratory.
- 11.3 For specimens having crimp, use a pretension of 0.3 to 1.0 cN/tex (0.03 to 0.11 gf/d) to remove the crimp while the fiber is placed in the clamps. If certain fibers with a high degree of crimp require greater pretensioning than the amount specified, determine the minimum pretension as directed in Appendix XI of Test Method D 1577. If, by visual examination, the crimp is not completely removed even at these greater force applications, record this fact.
- 11.4 Start the tensile testing machine and any associated auxiliary equipment, extending the fiber specimen to break at the selected extension speed and record the data of interest. For fibers of low stiffness, it may be advisable to first back off the moving jaw of the testing machine to allow the fiber to be slack at the time the testing machine is started.
- 11.5 After breaking the specimen, return the testing machine to its starting condition and remove all remains of the broken specimen from the clamp faces. Pieces of broken fiber remaining in the jaws may adversely affect the ability of the jaws to properly hold the succeeding specimens.
- 11.6 Test successive specimens as directed in 11.1-11.5 until the remaining specimens have been broken. If the number of fiber specimens failing at the jaw-fiber interface exceeds 5 % of the number tested, repeat the test after adjusting the jaw faces and clamping mechanism as described in 11.6.1-11.6.3.

- 11.6.1 If a specimen slips in the jaws, breaks at the edge or in the jaws, or, if for any reason attributable to faulty machine operation the result falls $20\,\%$ below the average of the breaking force for the set of specimens, discard the result and test another specimen. Continue until the required number of acceptable breaks have been obtained.
- 11.6.2 The decision to discard the results of a break shall be based on observation of the specimen during the test and upon the inherent variability of the fiber. It is difficult to determine the precise reason for certain specimens breaking near the edge of the jaws. If a jaw break is caused by damage to the specimen by the jaws, then the results should be discarded. If, however, it is merely due to randomly distributed weak places, it is a perfectly legitimate result. Refer to Practice E 178 for treatment of outlying data points.
- 11.6.3 If a fiber manifests any slippage in the jaws or if more than 25 % of the specimens break at a point within 3 mm ($\frac{1}{8}$ in.) of the edge of the jaw, then (I) the jaws may be padded, (2) the fiber may be coated under the jaw face area, or (3) the surface of the jaw face may be modified. If any of the modifications listed above are used, state the method of modification in the report.
- 11.7 Obtain the elongation data by means of a suitable recording device, or computer, at the same time as the breaking force is determined unless otherwise agreed upon, as provided for in an applicable material specification.

12. Calculation

- 12.1 Breaking Force—Record the breaking force of individual specimens to three significant digits as read directly from the tension testing machine expressed in cN (gf).
- 12.2 Breaking Tenacity—Calculate the breaking tenacity of individual specimens to three significant digits, using Eq 1:

$$Y = F/D_L \tag{1}$$

where:

Y = breaking tenacity in mN/tex (gf/den),

F = breaking force in cN (gf), and

 D_L = linear density in tex (denier).

12.3 Effective Specimen Length—Calculate the effective specimen length of individual specimens to three significant digits, using Eq 2: (See Annex A2 and Figs. X1.1 and X1.2.)

$$L_e = L_i + \Delta L_c \tag{2}$$

where:

 L_e = effective specimen length, mm (in.),

 L_i = initial distance between clamps (gage length), mm

(in.), and

 ΔL_c = additional specimen length corresponding to the clamp error as determined in A2.2, when required.

12.4 *Elongation*—From XY type recorders, calculate the elongation at break, or other specified elongation, of individual specimens to three significant digits using Eq 3:

$$\epsilon_s = (\Delta L \times R_s \times 100) / (C_s \times L_e) \tag{3}$$

where:

 ϵ_s = elongation percent, at the specified force,

 ΔL = distance along the zero-stress axis from the point corresponding to the point where the tangent line to the initial straight-line section of the stress-strain curve intersects the zero-stress axis, to a point corresponding to the breaking stress, or other specified stress, mm (in.),

 R_s = testing speed rate, mm/min (in./min),

 C_s = recording chart speed, mm/min (in./min), and

 L_e = effective specimen length, mm (in.).

12.5 Initial Modulus—Locate the maximum slope and draw a line tangent to the stress-strain curve between the tangent point for this tangent line and the proportional elastic limit and through the zero-stress axis. Measure the stress and the corresponding elongation with respect to the stress axis. Calculate initial modulus in cN/tex (gf/d) to three significant digits, using Eq 4 (see Appendix X2 and Figs. X1.1 and X1.2):

$$J_i = S/\epsilon_n \tag{4}$$

where:

 J_i = initial modulus, cN/tex (gf/den),

S = determined stress on the drawn tangent line cN/tex (gf/den), and

 ϵ_p = corresponding strain with respect to the drawn tangent line and determined stress.

12.6 Chord Modulus—Determine the stress for a specified elongation, such as 10 %, and label that point on the stress-strain curve as P_2 . Likewise, label a second point, P_1 at a specified elongation, such as 0 % elongation. Draw a straight line through points P_1 and P_2 intersecting the zero-stress axis. Other elongation values may be used, for example, when provided for in an applicable material specification. Calculate chord modulus in cN/tex (gf/d) to three significant digits, using Eq 5 (see Appendix X2 and Fig. X2.1):

5-75ae-434f-ba89-214
$$g_{ch} = g_{ep} = 1/astm-d3822-96$$
 (5)

where:

 J_{ch} = chord modulus between specified elongations, cN/tex (gf/den),

S = determined stress on the constructed line, cN/tex (gf/den), and

 ϵ_p = corresponding strain with respect to the constructed line and determined stress.

- 12.7 Breaking Toughness—When using the stress-strain curves, draw a line from the point of breaking force of each specimen perpendicular to the extension axis. Measure the area bounded by the curve, the perpendicular and the extension axis by means of an integrator or a planimeter, or cut out the area of the chart under the stress-strain curve, weigh it, and calculate the area under the curve using the mass of the unit area.
- 12.7.1 When determining the breaking toughness of fibers that exhibit slack caused by crimp or design, the area under the stress-strain curve which precedes the initial modulus line represents the work to remove this slack. Automatic area measuring equipment may or may not include this area in measuring breaking toughness, and therefore, such information should be reported along with the value obtained for the breaking toughness.