



# SLOVENSKI STANDARD

## SIST EN 29318-3:1997

01-december-1997

---

### Information technology - Intelligent Peripheral Interface - Part 3: Device generic command set for magnetic and optical disk drives (ISO/IEC 9318:1990)

Information technology - Intelligent Peripheral Interface - Part 3: Device generic command set for magnetic and optical disk drives (ISO/IEC 9318:1990)

Informationstechnik - Intelligente Peripherie-Schnittstelle - Teil 3: Allgemeiner Befehlssatz für magnetische und optische Plattenlaufwerke (ISO/IEC 9318-3:1990)

Technologies de l'information - Interface pour les périphériques intelligents - Partie 3: Jeu de commandes génériques appareils pour les disques magnétiques et optiques (ISO/IEC 9318-3:1990)

<https://standards.iteh.ai/catalog/standards/sist/84d08123-0518-42bd-9bff-a9c03117534f/sist-en-29318-3-1997>

**Ta slovenski standard je istoveten z: EN 29318-3:1993**

---

#### **ICS:**

35.180	Terminalska in druga periferna oprema IT	IT Terminal and other peripheral equipment
35.200	Vmesniška in povezovalna oprema	Interface and interconnection equipment

**SIST EN 29318-3:1997**

**en**

**iTeh STANDARD PREVIEW**  
**(standards.iteh.ai)**

SIST EN 29318-3:1997

<https://standards.iteh.ai/catalog/standards/sist/84d08123-0518-42bd-9bff-a9c03117534f/sist-en-29318-3-1997>

EUROPEAN STANDARD

EN 29318-3:1993

NORME EUROPÉENNE

EUROPÄISCHE NORM

October 1993

UDC 681.327.6

Descriptors: Data processing, information interchange, network interconnection, computer interfaces, magnetic disks, optical disks, computer peripheral equipment

English version

**Information technology - Intelligent Peripheral  
Interface - Part 3: Device generic command set for  
magnetic and optical disk drives (ISO/IEC  
9318-3:1990)**

Technologies de l'information - Interface pour  
les périphériques intelligents - Partie 3: Jeu  
de commandes génériques appareils pour les  
disques magnétiques et optiques (ISO/IEC  
9318-3:1990)

Informationstechnik - Intelligente  
Peripherie-Schnittstelle - Teil 3: Allgemeiner  
Befehlssatz für magnetische und optische  
Plattenlaufwerke (ISO/IEC 9318-3:1990)

**STANDARD PREVIEW**  
standards.itech.it



REPUBLIKA SLOVENIJA  
MINISTRSTVO ZA ZNANOST IN TEHNOLOGIJO  
Urad RS za standardizacijo in meroslovje  
LJUBLJANA

SIST. EN 29318-3

PREVZET PO METODI RAZGLASITVE

-12- 1997

This European Standard was approved by CEN on 1993-10-20. CEN members are bound to comply with the CEN/CENELEC Internal Regulations which stipulate the conditions for giving this European Standard the status of a national standard without any alteration.

Up-to-date lists and bibliographical references concerning such national standards may be obtained on application to the Central Secretariat or to any CEN member.

The European Standards exist in three official versions (English, French, German). A version in any other language made by translation under the responsibility of a CEN member into its own language and notified to the Central Secretariat has the same status as the official versions.

CEN members are the national standards bodies of Austria, Belgium, Denmark, Finland, France, Germany, Greece, Iceland, Ireland, Italy, Luxembourg, Netherlands, Norway, Portugal, Spain, Sweden, Switzerland and United Kingdom.

**CEN**

European Committee for Standardization  
Comité Européen de Normalisation  
Europäisches Komitee für Normung

Central Secretariat: rue de Stassart, 36 B-1050 Brussels

### Foreword

On the proposal of the CEN Central Secretariat, the Technical Board decided to submit the International Standard:

"Information technology - Intelligent Peripheral Interface - Part 3: Device generic command set for magnetic and optical disk drives (ISO/IEC 9318-3:1990)"

to the formal vote.

The result of the formal vote was positive.

For the time being, this document exists only in English.

This European Standard shall be given the status of a national standard, either by publication of an identical text or by endorsement, at the latest by April 1994, and conflicting national standards shall be withdrawn at the latest by April 1994.

In accordance with the CEN/CENELEC Internal Regulations, the following countries are bound to implement this European Standard:

Austria, Belgium, Denmark, Finland, France, Germany, Greece, Iceland, Ireland, Italy, Luxembourg, Netherlands, Norway, Portugal, Spain, Sweden, Switzerland and United Kingdom.

### Endorsement notice

<https://standards.iteh.ai/catalog/standards/sist/84d08123-0518-42bd-9bff>

The text of the International Standard ISO/IEC 9318-3:1990 was approved by CEN as a European Standard without any modification.



# INTERNATIONAL STANDARD

# ISO/IEC 9318-3

First edition  
1990-12-15

---

---

## Information technology — Intelligent Peripheral Interface

### Part 3:

Device generic command set for magnetic and optical  
disk drives

iTeh STANDARD PREVIEW  
(standards.iteh.ai)

*Technologies de l'information — Interface pour les périphériques intelligents —*

*Partie 3: Jeu de commandes génériques appareil pour les disques magnétiques et optiques*



Reference number  
ISO/IEC 9318-3 : 1990 (E)

## ISO/IEC 9318-3 : 1990 (E)

## Contents

	Page
Foreword .....	xxvii
Introduction .....	xxviii
1 Scope .....	1
2 Normative reference .....	2
3 Definitions and conventions .....	3
3.1 Definitions .....	3
3.2 Conventions .....	5
4 Logical interface characteristics .....	6
4.1 Operations .....	6
4.1.1 Commands .....	6
4.1.1.1 Command types .....	6
4.1.1.2 Command stacking .....	6
4.1.1.2.1 Individual .....	6
4.1.1.2.2 Queued .....	7
4.1.1.3 Command execution order .....	7
4.1.2 Operation responses .....	8
4.1.2.1 Interrupts .....	8
4.1.2.2 Response types .....	9
4.1.2.2.1 Command completion response .....	9
4.1.2.2.2 Transfer Notification Response (optional) .....	9
4.1.2.2.3 Asynchronous response .....	9
4.1.2.2.4 Imbedded data response (optional) .....	9
4.1.2.3 Response handling .....	9
4.1.3 Physical interface error recovery considerations .....	10
4.1.3.1 Recovery from unsuccessful Slave Status octet .....	10
4.1.3.2 Recovery from bad parity on the Slave Status octet .....	10
4.1.3.3 Recovery from bad parity on the Slave Status octet .....	10
4.2 Operation sequences .....	11
4.2.1 Slave procedures .....	11
4.2.2 Basic steps .....	11
4.2.2.1 Transmit Command packet to slave .....	11
4.2.2.2 Poll interrupts .....	12
4.2.2.3 Receive Response packet from slave .....	12
4.2.2.4 Transfer of data between master and slave .....	12
4.2.3 Operation sequence examples .....	13
4.2.3.1 Example of facility selection and individual commands .....	13
4.2.3.2 Example of facility selection and queued commands .....	13
4.2.3.3 Example of slave selection .....	14
4.2.3.4 Example of slave selection and slave control of Bus .....	14
4.3 Multiplexed data transfers (optional) .....	15
4.3.1 Physical interface Pause and Continue (optional) .....	15
4.3.2 Slave pause and master Continue .....	15
4.3.2.1 Implicit continue .....	16
4.3.2.2 Explicit continue .....	16
4.3.3 Slave control of Pause and Continue .....	16
4.3.4 Master control of Pause and Continue .....	16
4.3.5 Uses of multiplexing .....	17
4.3.5.1 One paused transfer per facility .....	17

© ISO/IEC 1990

All rights reserved. No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the publisher.

ISO/IEC Copyright Office • Case postale 56 • CH-1211 Genève 20 • Switzerland

Printed in Switzerland

4.3.5.2 One paused transfer per slave	17
4.3.5.3 Multiple paused transfers per slave	17
4.3.6 Anticipated pause	17
4.3.6.1 Master stays selected	17
4.3.6.2 Master deselects	18
4.3.7 Unanticipated pauses by the slave	18
4.3.8 Unanticipated pauses by the master	18
4.3.9 Multiplexed transfer mode identification	18
4.4 Data groupings	18
4.4.1 PhysicalBlocks	19
4.4.2 DataBlocks	19
4.4.3 Extents	19
4.4.4 Partitions	19
4.4.4.1 Slave-defined partitions	20
4.4.4.1.1 Data partition	20
4.4.4.1.2 Maintenance partitions	20
4.4.4.2 Master-defined partitions	20
4.4.4.2.1 Data partitions	20
4.4.4.2.2 Maintenance partitions	20
4.4.5 Alternate data areas	20
4.4.6 Physical groups	20
4.5 Media addressing definitions	21
4.5.1 Absolute addressing	21
4.5.2 Physical addressing	21
4.5.3 Logical addressing	22
4.5.4 Media defect management considerations	22
4.6 Interface addressing definitions	23
4.6.1 Actual Addresses	23
4.6.2 Selection Addresses	23
4.6.3 Command Addresses	23
4.6.4 Facility Address	24
4.6.5 Synonym Addresses (optional)	24
4.6.6 Alias Addresses (optional)	24
4.6.7 Partition parameters	25
4.6.8 Communication addresses (optional)	25
4.6.9 Address examples	26
4.7 Slave and facility conditions	26
4.7.1 Interface conditions	27
4.7.1.1 P-Available	27
4.7.1.2 Not P-Available	27
4.7.1.3 Operational	27
4.7.1.4 Not Operational	28
4.7.1.5 P-Busy	28
4.7.1.6 Not P-Busy	28
4.7.1.7 L-Available	28
4.7.1.8 Not L-Available	28
4.7.1.9 L-Busy	28
4.7.1.10 Not L-Busy	28
4.7.2 General conditions	28
4.7.2.1 Active	28
4.7.2.2 Inactive	28
4.7.2.3 Status Pending	29
4.7.2.4 Reset	29
4.7.3 Operating status	29
4.8 Multiple ports (optional)	30
4.8.1 Slave switching	30
4.8.1.1 Physical switch	31
4.8.1.2 Logical switch	31
4.8.1.3 Mixed switch types	32
4.8.2 Facility switching	32

## ISO/IEC 9318-3 : 1990 (E)

4.8.3	Slave static switching	33
4.8.3.1	Disabling a slave port	33
4.8.3.2	Enabling a slave port	33
4.8.4	Facility static switching	33
4.8.4.1	Disabling a facility	34
4.8.4.1.1	Disabling a facility at a slave port	34
4.8.4.1.2	Disabling a facility at a facility port	34
4.8.4.2	Enabling a facility	34
4.8.4.2.1	Enabling a facility at a slave port	34
4.8.4.2.2	Enabling a facility at a facility port	35
4.8.5	Slave dynamic switching	35
4.8.5.1	Neutral Mode	35
4.8.5.2	Switched Mode	35
4.8.5.3	Implicitly switched	35
4.8.5.4	Explicitly switched	36
4.8.6	Facility dynamic switch	36
4.8.6.1	Facility neutral mode	36
4.8.6.1.1	Facility neutral mode at the slave port	36
4.8.6.1.2	Facility neutral mode at the facility port	36
4.8.6.2	Facility switched mode	36
4.8.6.2.1	Facility switched mode at a slave port	37
4.8.6.2.2	Facility switched mode at a facility port	37
4.8.6.3	Implicitly switched facilities	37
4.8.6.3.1	Implicitly switched facilities at a slave port	37
4.8.6.3.2	Implicitly switched facility at a facility port	37
4.8.6.4	Explicitly switched facilities	37
4.8.6.4.1	Explicitly switched facilities at a slave port	38
4.8.6.4.2	Explicitly switched facilities at a facility port	38
4.8.7	Allegiances	38
4.8.7.1	Multiple allegiances	38
4.8.7.2	Explicit group allegiance	38
4.8.8	Alternate port notification of changes	38
4.9	Reset	38
4.9.1	External reset	38
4.9.2	Internal reset	39
4.10	Bus octets	39
4.10.1	Facility selection & request facility interrupts octets	39
4.10.2	Bus Control octet	39
4.10.3	Bus Acknowledge octet	39
4.10.4	Master Status octet	40
4.10.4.1	Bit definitions	40
4.10.4.2	Valid combinations	40
4.10.5	Slave Status octet	41
4.10.5.1	Bit definitions	41
4.10.5.2	Valid combinations	42
4.10.6	Request interrupts octet	42
4.10.7	Selective Reset Control octet	42
4.11	ATTENTION IN signal	43
4.12	Information transfers	43
4.12.1	Packet transfer conventions	43
4.12.2	Bit significance conventions	44
4.12.3	Octet significance conventions	44
4.12.4	Command and Response packet conventions	44
4.12.5	Data transfer conventions	45
5	Message packet structure	46
5.1	Conventions	46
5.1.1	General organization	46
5.1.2	Parameters	46
5.1.2.1	Parameter documentation	46



5.1.2.2	Parameter length	47
5.1.2.3	Parameter ID	47
5.1.3	Message packet representation in the document	47
5.2	Operation Command packets	48
5.2.1	Fields in Command packets	48
5.2.1.1	Packet Length	48
5.2.1.2	Command Reference Number	48
5.2.1.3	Slave Address	48
5.2.1.4	Facility Address	49
5.2.1.5	Opcode	49
5.2.1.6	Modifier octet	50
5.2.1.7	Parameters	50
5.2.2	Basic Command Message packet	50
5.2.3	Command packet parameter requirements	52
5.2.3.1	Control Command packet	52
5.2.3.2	Position Command packet	52
5.2.3.3	Transfer and Other Transfer Command packet	52
5.2.3.4	Combination Transfer Command packet (optional)	52
5.2.3.5	Diagnostic Command packet	52
5.2.4	Transferring parameters as data	52
5.2.4.1	Writing	52
5.2.4.2	Reading	52
5.2.4.3	Example	53
5.2.4.3.1	General	53
5.2.4.3.2	Specific	54
5.3	Operation Response Message packets	54
5.3.1	Fields In Response packets	54
5.3.1.1	Packet Length	54
5.3.1.2	Command Reference Number	54
5.3.1.3	Slave address	54
5.3.1.4	Facility address	54
5.3.1.5	Opcode	55
5.3.1.6	Modifier	55
5.3.1.7	Response Type	55
5.3.1.8	Major Status	55
5.3.1.9	Parameters	55
5.3.2	Basic Response packet	56
5.3.3	Response packet parameter requirements	56
5.3.3.1	Control Response packet	56
5.3.3.2	Position Response packet	56
5.3.3.3	Transfer and Other Transfer Response packet	56
5.3.3.4	Combination Transfer Response packet (optional)	56
5.3.3.5	Diagnostic Response packet	56
5.3.3.6	Asynchronous Response packet	56
5.3.3.7	Transfer Notification packet (optional)	57
5.3.3.8	Imbedded Data Response packet (optional)	57
5.4	Status	58
5.4.1	Major Status	58
5.4.2	Substatus	58
5.4.2.1	Intervention Required (ID='x4')	59
5.4.2.1.1	Not P-Available	59
5.4.2.1.2	Not Ready	59
5.4.2.1.3	Not P-Available transition	59
5.4.2.1.4	Not Ready transition	59
5.4.2.1.5	Physical Link failure	59
5.4.2.1.6	Attribute Table may be corrupted	59
5.4.2.1.7	Addressee Busy	60
5.4.2.2	Alternate Port exception (ID='x5')	60
5.4.2.2.1	Priority Reserve issued	60
5.4.2.2.2	Attributes updated	60

## ISO/IEC 9318-3 : 1990 (E)

5.4.2.2.3	Initialization completed	60
5.4.2.2.4	Format completed	60
5.4.2.2.5	Facility switched to another port	60
5.4.2.2.6	Slave Diagnostic in progress	61
5.4.2.2.7	Slave Diagnostic terminated	61
5.4.2.3	Machine Exception (ID='x6')	61
5.4.2.3.1	Addressee no longer busy	61
5.4.2.3.2	P-Available transition	62
5.4.2.3.3	Ready transition	62
5.4.2.3.4	Operation timeout	62
5.4.2.3.5	Physical Interface check	62
5.4.2.3.6	Slave-Initiated reset	62
5.4.2.3.7	Environmental error	62
5.4.2.3.8	Power fail alert	62
5.4.2.3.9	Data Check (on raw data)	62
5.4.2.3.10	Uncorrectable Data Check (on perfect data)	62
5.4.2.3.11	Fatal error	62
5.4.2.3.12	Hardware write protected	63
5.4.2.3.13	Queue full	63
5.4.2.3.14	Command failure	63
5.4.2.3.15	Read access violation	63
5.4.2.3.16	Write access violation	63
5.4.2.3.17	Data overrun	63
5.4.2.3.18	Reallocation space exhausted	63
5.4.2.3.19	End of media detected	63
5.4.2.3.20	End of extent detected	63
5.4.2.3.21	Unexpected master action	63
5.4.2.3.22	Error Log full	64
5.4.2.3.23	Defect Directory full	64
5.4.2.3.24	Logical link failure	64
5.4.2.3.25	Position lost	64
5.4.2.4	Command Exception (ID='x7')	64
5.4.2.4.1	Invalid Packet length	65
5.4.2.4.2	Invalid Command Reference Number	65
5.4.2.4.3	Invalid Slave Address	65
5.4.2.4.4	Invalid Facility Address	65
5.4.2.4.5	Invalid selection address	65
5.4.2.4.6	Invalid Opcode	65
5.4.2.4.7	Invalid Modifier	65
5.4.2.4.8	Invalid Extent	65
5.4.2.4.9	Out of context	65
5.4.2.4.10	Invalid parameter(s)	65
5.4.2.4.11	Missing parameter(s)	66
5.4.2.4.12	Reserved value not equal to zero	66
5.4.2.4.13	Invalid combination	66
5.4.2.4.14	Not at initial position	66
5.4.2.5	Command Aborted (ID='x8')	66
5.4.2.5.1	Command Aborted	66
5.4.2.5.2	Command sequence terminated	66
5.4.2.5.3	Unexecuted command from terminated sequence	67
5.4.2.5.4	Command chain terminated	67
5.4.2.5.5	Unexecuted command from terminated chain	67
5.4.2.5.6	Command order terminated	67
5.4.2.5.7	Unexecuted command from terminated order	67
5.4.2.6	Conditional Success (ID='x9')	68
5.4.2.6.1	Logging data appended	68
5.4.2.6.2	ABORT received: No Command Active	69
5.4.2.6.3	ABORT received: Status Pending	69
5.4.2.6.4	ABORT received: Not Operational	69
5.4.2.6.5	Anticipated error	69

5.4.2.6.6	Anticipated data error	69
5.4.2.6.7	Reallocation required	69
5.4.2.6.8	Reallocation discontinuity	69
5.4.2.6.9	Defect Directory threshold exceeded	69
5.4.2.6.10	Error retry performed	69
5.4.2.6.11	Data retry performed	69
5.4.2.6.12	Motion retry performed	70
5.4.2.6.13	Data correction performed	70
5.4.2.6.14	Soft error	70
5.4.2.6.15	Release of an unreserved addressee	70
5.4.2.6.16	Request Diagnostic Control command	70
5.4.2.6.17	Error Log request	70
5.4.2.6.18	Non-Interchange volume	70
5.4.2.6.19	Retention required	70
5.4.2.6.20	End of Media Warning (EMW)	70
5.4.2.6.21	Statistics update requested	71
5.4.2.6.22	Parameter update requested	71
5.4.2.6.23	Asynchronous event occurrence	71
5.4.2.6.24	Master-Terminated transfer	71
5.4.2.7	Incomplete (ID='xA')	71
5.4.2.7.1	Command may be resumed	71
5.4.2.7.2	COPY source space empty	72
5.4.2.7.3	Response packet truncated	72
5.4.2.7.4	Select Subservient slave	72
5.4.2.7.5	Connect unsuccessful	72
5.4.2.7.6	Disconnect unsuccessful	72
5.4.2.7.7	Connect Identifier already assigned	72
5.4.2.7.8	Link not connected	72
5.4.2.7.9	Beginning of Media (BOM) detected	72
5.4.2.7.10	End of Media Warning (EMW)	72
5.4.2.7.11	End of extent detected	72
5.4.2.7.12	Block length difference	73
5.4.2.7.13	Unrecorded media	73
5.4.2.7.14	Data length difference	73
5.4.2.7.15	Block not found	73
5.4.2.8	Successful	73
5.4.2.9	Message/Microcode Exception (ID='x3')	73
5.4.2.9.1	Microcode Data not accepted	74
5.4.2.9.2	Request Master to IML Slave	74
5.4.2.9.3	Slave Unable to IML	74
5.4.2.9.4	Message	74
5.4.2.9.5	Microcode Execution error	74
5.4.2.9.6	Failure message	74
5.4.2.9.7	Port Disable pending	74
5.4.2.9.8	Port Response	74
5.4.2.9.9	Facility status	74
5.4.3	Extended substatus	75
5.5	Common parameters	75
5.5.1	Transfer Notification parameter (optional)	75
5.5.2	Command Extent parameter	76
5.5.2.1	Count	76
5.5.2.2	Data Address	76
5.5.3	Response Extent parameter	76
5.5.3.1	Residual Count	77
5.5.3.2	Data Address	77
5.5.4	Combination Command Extent parameter (optional)	77
5.5.4.1	Slave address	78
5.5.4.2	Facility address	78
5.5.4.3	Modifiers	78
5.5.4.4	Count	78

## ISO/IEC 9318-3 : 1990 (E)

5.5.4.5 Data Address .....	78
5.5.5 Combination Response Extent parameter (optional) .....	79
5.5.5.1 Slave address .....	79
5.5.5.2 Facility address .....	79
5.5.5.3 Modifiers .....	79
5.5.5.4 Residual Count .....	79
5.5.5.5 Data Address .....	79
5.5.5.6 Major Status .....	80
5.5.5.7 Substatus .....	80
5.5.6 Access Key parameter (optional) .....	80
5.5.7 Reserved .....	80
5.5.8 Reserved .....	80
5.5.9 Invalid Parm parameter (optional) .....	80
5.5.9.1 Displacement of parameter in error .....	80
5.5.9.2 Displacement of field in error .....	81
5.5.10 Missing Parm parameter (optional) .....	81
5.5.11 Data Address parameter (optional) .....	81
5.5.12 Block Size parameter (optional) .....	82
5.5.13 Transfer .....	82
5.5.13.1 Verify .....	82
5.5.13.2 Volume .....	83
5.5.13.3 Certify .....	83
5.5.13.4 Stop on Data Error .....	83
5.5.13.5 Compare .....	83
5.5.13.6 Threshold .....	83
5.5.13.7 Suppress Incorrect Length Indication .....	84
5.5.13.8 Response conditions (octet 3 bits 7-4) .....	84
5.5.14 Encapsulation parameter (optional) .....	84
5.5.15 Partition parameter (optional) .....	84
5.5.15.1 Disk Partitions .....	85
5.5.15.2 Tape Partitions .....	85
5.5.16 Stop On Discontinuity parameter (optional) .....	87
5.5.16.1 Cylinders .....	87
5.5.16.2 Tracks .....	87
5.5.16.3 Access boundary .....	87
5.5.16.4 Discontiguous Defect reallocation .....	87
5.5.16.5 Bands .....	87
5.5.16.6 Time .....	87
5.5.16.7 Discontinuity Time .....	87
5.5.17 Imbedded Data parameter (optional) .....	88
6 Control commands .....	89
6.1 NOP .....	89
6.1.1 Command packet .....	89
6.1.2 Response packet .....	89
6.1.3 Description .....	89
6.2 FACILITY OPERATION .....	90
6.2.1 Command packet .....	90
6.2.2 Response packet .....	90
6.2.3 Description .....	90
6.2.4 Parameter 3D - Encapsulation parameter .....	90
6.3 ATTRIBUTES .....	91
6.3.1 Command packet .....	91
6.3.2 Response packet .....	91
6.3.3 Description .....	91
6.3.4 Parameters .....	93
6.3.4.1 Parameters 3A, 3E, 50 .....	93
6.3.4.1.1 Data Address (common) parameter .....	94
6.3.4.1.2 Partition (common) parameter .....	94
6.3.4.1.3 Vendor ID parameter .....	94

6.3.4.2 Parameters 51-58 .....	95
6.3.4.2.1 Size of Disk DataBlocks parameter .....	95
6.3.4.2.2 Size of Disk PhysicalBlocks parameter .....	95
6.3.4.2.3 Total Number of Disk DataBlocks parameter .....	96
6.3.4.2.4 Total Number of Disk PhysicalBlocks parameter .....	96
6.3.4.2.5 DataBlock Sizes Supported parameter .....	96
6.3.4.2.6 PhysicalBlock Sizes Supported parameter .....	96
6.3.4.2.7 Size of Physical Groups parameter .....	96
6.3.4.2.8 Hard Disk Formats parameter .....	96
6.3.4.3 Parameters 59-5A .....	97
6.3.4.3.1 Attributes Table conditions parameter .....	97
6.3.4.3.2 Pad with Fill Characters parameter .....	97
6.3.4.4 Parameters 5B-5D .....	98
6.3.4.4.1 Disk Partition Definition parameter .....	98
6.3.4.4.2 Synonym Definition parameter .....	98
6.3.4.4.3 Alias Definition parameter .....	98
6.3.4.5 Parameters 5E-5F .....	99
6.3.4.5.1 Multi-Port Characteristics parameter .....	99
6.3.4.5.2 Physical Disk Configuration parameter .....	99
6.3.4.6 Parameters 60-63 .....	100
6.3.4.6.1 DataBlock Interleave parameter .....	100
6.3.4.6.2 Transfer Rate parameter .....	101
6.3.4.6.3 PhysicalBlock Performance Characteristics Supported parameter .....	101
6.3.4.6.4 Current PhysicalBlock Performance Settings parameter .....	101
6.3.4.7 Parameters 64-65 .....	102
6.3.4.7.1 Physical Interface Attributes parameter .....	102
6.3.4.7.2 Addressee Configuration parameter .....	102
6.3.4.8 Parameter 66 - Slave Configuration (bit significant) .....	103
6.3.4.9 Parameter 67 - Slave Configuration (fields) .....	105
6.3.4.10 Parameter 68 - Facilities Attached to Slave .....	106
6.3.4.11 Parameters 69-6A .....	108
6.3.4.11.1 Parameter 69 .....	108
6.3.4.11.2 Command Supported parameter .....	108
6.3.4.12 Parameter 6B - Masks of octets supported .....	109
6.3.4.13 Parameters 6C-6D .....	110
6.3.4.13.1 Request Parm parameter .....	110
6.3.4.13.2 Parm Length parameter .....	111
6.3.4.14 Parameter 6E - Slave Reconfiguration (bit-significant) .....	111
6.3.4.15 Parameter 6F - .....	113
6.4 REPORT ADDRESSEE STATUS .....	114
6.4.1 Command packet .....	114
6.4.2 Response packet .....	114
6.4.3 Description .....	114
6.4.4 Parameters 50-53 .....	115
6.4.4.1 Port Mask parameter .....	115
6.4.4.2 Condition parameter .....	116
6.4.4.3 Media Status parameter .....	116
6.4.4.4 Vendor Unique Status parameter .....	116
6.5 PORT ADDRESS .....	116
6.5.1 Command packet .....	116
6.5.2 Response packet .....	116
6.5.3 Description .....	116
6.6 PATH CONTROL .....	118
6.6.1 Command packet .....	118
6.6.2 Response packet .....	118
6.6.3 Description .....	118
6.6.4 Parameters 50-51 .....	119
6.6.4.1 Port Mask parameter .....	119
6.6.4.2 Path Control Mask parameter .....	119
6.7 ATTENTION CONTROL .....	119

## ISO/IEC 9318-3 : 1990 (E)

6.7.1	Command packet	119
6.7.2	Response packet	120
6.7.3	Description	120
6.7.4	Interrupts Mask parameter	120
6.8	OPERATING MODE	121
6.8.1	Command packet	121
6.8.2	Response packet	121
6.8.3	Description	121
6.8.4	Parameters 3E, 50-51	122
6.8.4.1	Partition (common) parameter	122
6.8.4.2	Response Conditions parameter	122
6.8.4.3	Disk Modes parameter	122
6.9	ABORT	123
6.9.1	Command packet	123
6.9.2	Response packet	123
6.9.3	Description	123
6.9.4	Parameters 50-54	124
6.9.4.1	Command Reference Number parameter	124
6.9.4.2	Alternate Port Commands parameter	124
6.9.4.3	Facility Address parameter	125
6.9.4.4	Alternate Port parameter	125
6.9.4.5	Facility Reset parameter	125
6.10	ACCESS PERMITS	125
6.10.1	Command packet	125
6.10.2	Response packet	126
6.10.3	Description	126
6.10.4	Parameters 31-32, 35, 3A, 3E, 50-51	127
6.10.4.1	Command Extent (common) parameter	127
6.10.4.2	Response Extent (common) parameter	128
6.10.4.3	Access Key (common) parameter	128
6.10.4.4	Data Address (common) parameter	128
6.10.4.5	Partition (common) parameter	128
6.10.4.6	Port Mask parameter	128
6.10.4.7	Access Protection parameter - protection modifiers	128
6.11	RESUME	129
6.11.1	Command packet	129
6.11.2	Response packet	129
6.11.3	Description	129
6.11.4	Parameters 50-51	130
6.11.4.1	Command Reference Number parameter	130
6.11.4.2	Alternate Port Commands parameter	130
6.12	PORT RESPONSE	130
6.12.1	Command packet	130
6.12.2	Response packet	131
6.12.3	Description	131
6.12.4	Parameters 50-51	131
6.12.4.1	Port Mask parameter	131
6.12.4.2	Response Information Transfer parameter	131
6.13	ANTICIPATED ACTION	131
6.13.1	Command packet	131
6.13.2	Response packet	132
6.13.3	Description	132
6.13.4	Parameters 3D, 50	132
6.13.4.1	Expected Conditions parameter	132
6.13.4.2	Encapsulation parameter	132
6.14	OPERATOR DISPLAY	133
6.14.1	Command packet	133
6.14.2	Response packet	133
6.14.3	Description	133
6.14.4	Parameters 50-53	134

6.14.4.1	Identifier parameter .....	135
6.14.4.2	Length parameter .....	135
6.14.4.3	Mode parameter .....	135
6.14.4.4	Timing parameter .....	136
6.14.4.5	Normal message parameter .....	137
6.14.4.6	Alternate message parameter .....	137
7	Position commands .....	138
7.1	Reserved .....	138
7.2	POSITION CONTROL .....	138
7.2.1	Command packet .....	138
7.2.2	Response packet .....	138
7.2.3	Description .....	138
7.2.4	Parameters 31, 32, 35, 3A, 3E .....	139
7.2.4.1	Command Extent (common) parameter .....	139
7.2.4.2	Response Extent (common) parameter .....	139
7.2.4.3	Access Key (common) parameter .....	139
7.2.4.4	Data Address (common) parameter .....	139
7.2.4.5	Partition (common) parameter .....	139
7.3	REPORT POSITION .....	140
7.3.1	Command packet .....	140
7.3.2	Response packet .....	140
7.3.3	Description .....	140
7.3.4	Parameters 32, 35, 3A, 3E .....	140
7.3.4.1	Response Extent (common) parameter .....	140
7.3.4.2	Access Key (common) parameter .....	141
7.3.4.3	Data Address (common) parameter .....	141
7.3.4.4	Partition (common) parameter .....	141
7.4	Reserved .....	141
7.5	REPORT DISCONTINUITY .....	141
7.5.1	Command packet .....	141
7.5.2	Response packet .....	141
7.5.3	Description .....	141
7.5.4	Parameters 31-32, 35, 3A, 3E-3F, 6C-6D .....	142
7.5.4.1	Command Extent (common) parameter .....	142
7.5.4.2	Response Extent (common) parameter .....	142
7.5.4.3	Access Key (common) parameter .....	143
7.5.4.4	Data Address (common) parameter .....	143
7.5.4.5	Partition (common) parameter .....	143
7.5.4.6	Stop on Discontinuity (common) parameter .....	143
7.5.4.7	Request Parm parameter .....	143
7.5.4.8	Parm Length parameter .....	143
8	Transfer commands .....	144
8.1	READ .....	144
8.1.1	Command packet .....	144
8.1.2	Response packet .....	144
8.1.3	Description .....	144
8.1.4	Parameters .....	146
8.1.4.1	Parameters 31-32, 35, 3A, 3C, 3E-3F .....	146
8.1.4.1.1	Command Extent (common) parameter .....	146
8.1.4.1.2	Response Extent (common) parameter .....	146
8.1.4.1.3	Access Key (common) parameter .....	146
8.1.4.1.4	Data Address (common) parameter .....	146
8.1.4.1.5	Transfer (common) parameter .....	146
8.1.4.1.6	Partition (common) parameter .....	147
8.1.4.1.7	Stop on Discontinuity (common) parameter .....	147
8.1.4.2	Parameters 50-53 .....	147
8.1.4.2.1	Skip Mask parameter .....	147
8.1.4.2.2	Information Transfer Size Override parameter .....	147