

INTERNATIONAL  
STANDARD

**ISO/IEC  
9316**

Second edition  
1995-11-01

---

---

---

**Information technology — Small  
Computer System Interface-2**

**iTeh STANDARD PREVIEW**  
*Technologies de l'information — Interface «Small Computer System-2»*  
**(standards.iteh.ai)**

[ISO/IEC 9316:1995](#)

[https://standards.iteh.ai/catalog/standards/sist/ce56cdf8-0f40-4cab-ac76-  
3fffd15e093/iso-iec-9316-1995](https://standards.iteh.ai/catalog/standards/sist/ce56cdf8-0f40-4cab-ac76-3fffd15e093/iso-iec-9316-1995)



Reference number  
ISO/IEC 9316:1995(E)

## Contents

	Page
1 Scope . . . . .	1
2 Normative references . . . . .	2
3 Definitions, symbols and abbreviations . . . . .	3
3.1 Definitions . . . . .	3
3.2 Symbols and abbreviations . . . . .	5
4 General . . . . .	6
4.1 Overview . . . . .	6
4.2 Conventions . . . . .	7
5 Physical characteristics . . . . .	8
5.1 Physical description . . . . .	8
5.2 Cable requirements . . . . .	8
5.2.1 Single-ended cable . . . . .	8
5.2.2 Differential cable . . . . .	9
5.2.3 Cable requirements for fast synchronous data transfer . . . . .	9
5.3 Connector requirements . . . . .	9
5.3.1 Non-shielded connector requirements . . . . .	9
5.3.1.1 Non-shielded connector alternative 1 - A cable . . . . .	9
5.3.1.2 Non-shielded connector alternative 2 - A cable . . . . .	10
5.3.1.3 Non-shielded connector - B cable . . . . .	10
5.3.2 Shielded connector requirements . . . . .	15
5.3.2.1 Shielded connector alternative 1 - A cable . . . . .	15
5.3.2.2 Shielded connector alternative 2 - A cable . . . . .	15
5.3.2.3 Shielded connector - B cable . . . . .	15
5.3.3 Connector contact assignments . . . . .	20

© ISO/IEC 1995

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the publisher.

ISO/IEC Copyright Office • Case postale 56 • CH-1211 Genève 20 • Switzerland

Printed in Switzerland

5.4 Electrical description . . . . .	25
5.4.1 Single-ended alternative . . . . .	25
5.4.1.1 Output characteristics . . . . .	25
5.4.1.2 Input characteristics . . . . .	25
5.4.2 Differential alternative . . . . .	26
5.4.2.1 Output characteristics . . . . .	26
5.4.2.2 Input characteristics . . . . .	26
5.4.3 Terminator power . . . . .	26
5.4.4 RESERVED lines . . . . .	29
5.5 SCSI bus . . . . .	30
5.6 SCSI bus signals . . . . .	32
5.6.1 Signal values . . . . .	33
5.6.2 OR-tied signals . . . . .	33
5.6.3 Signal sources . . . . .	33
5.7 SCSI bus timing . . . . .	34
5.7.1 Arbitration delay . . . . .	35
5.7.2 Assertion period . . . . .	35
5.7.3 Bus clear delay . . . . .	35
5.7.4 Bus free delay . . . . .	35
5.7.5 Bus set delay . . . . .	36
5.7.6 Bus settle delay . . . . .	36
5.7.7 Cable skew delay . . . . .	36
5.7.8 Data release delay . . . . .	36
5.7.9 Deskew delay . . . . .	36
5.7.10 Disconnection delay . . . . .	36
5.7.11 Hold time . . . . .	36
5.7.12 Negation period . . . . .	36
5.7.13 Power-on to selection time . . . . .	36
5.7.14 Reset to selection time . . . . .	36
5.7.15 Reset hold time . . . . .	37
5.7.16 Selection abort time . . . . .	37
5.7.17 Selection time-out delay . . . . .	37
5.7.18 Transfer period . . . . .	37
5.8 Fast synchronous transfer option . . . . .	37
5.8.1 Fast assertion period . . . . .	37
5.8.2 Fast cable skew delay . . . . .	37
5.8.3 Fast deskew delay . . . . .	37
5.8.4 Fast hold time . . . . .	37
5.8.5 Fast negation period . . . . .	38
6 Logical characteristics . . . . .	39
6.1 SCSI bus phases . . . . .	39
6.1.1 BUS FREE phase . . . . .	39
6.1.2 ARBITRATION phase . . . . .	40
6.1.3 SELECTION phase . . . . .	40
6.1.3.1 SELECTION time-out procedure . . . . .	41
6.1.4 RESELECTION phase . . . . .	41
6.1.4.1 RESELECTION . . . . .	41
6.1.4.2 RESELECTION time-out procedure . . . . .	42
6.1.5 Information transfer phases . . . . .	42
6.1.5.1 Asynchronous information transfer . . . . .	43
6.1.5.2 Synchronous data transfer . . . . .	43
6.1.5.3 Wide data transfer . . . . .	44

6.1.6 COMMAND phase . . . . .	46
6.1.7 Data phase . . . . .	46
6.1.7.1 DATA IN phase . . . . .	46
6.1.7.2 DATA OUT phase . . . . .	46
6.1.8 STATUS phase . . . . .	46
6.1.9 Message phase . . . . .	46
6.1.9.1 MESSAGE IN phase . . . . .	46
6.1.9.2 MESSAGE OUT phase . . . . .	46
6.1.10 Signal restrictions between phases . . . . .	47
6.2 SCSI bus conditions . . . . .	47
6.2.1 Attention condition . . . . .	47
6.2.2 Reset condition . . . . .	48
6.2.2.1 Hard reset alternative . . . . .	49
6.2.2.2 Soft reset alternative . . . . .	49
6.3 SCSI bus phase sequences . . . . .	50
6.4 SCSI pointers . . . . .	51
6.5 Message system description . . . . .	52
6.6 Messages . . . . .	55
6.6.1 ABORT . . . . .	55
6.6.2 ABORT TAG . . . . .	55
6.6.3 BUS DEVICE RESET . . . . .	56
6.6.4 CLEAR QUEUE . . . . .	56
6.6.5 COMMAND COMPLETE . . . . .	56
6.6.6 DISCONNECT . . . . .	56
6.6.7 IDENTIFY . . . . .	57
6.6.8 IGNORE WIDE RESIDUE . . . . .	58
6.6.9 INITIATE RECOVERY . . . . .	58
6.6.10 INITIATOR DETECTED ERROR . . . . .	59
6.6.11 LINKED COMMAND COMPLETE . . . . .	59
6.6.12 LINKED COMMAND COMPLETE (WITH FLAG) . . . . .	59
6.6.13 MESSAGE PARITY ERROR . . . . .	59
6.6.14 MESSAGE REJECT . . . . .	59
6.6.15 MODIFY DATA POINTER Message . . . . .	60
6.6.16 NO OPERATION . . . . .	60
6.6.17 Queue tag messages . . . . .	60
6.6.17.1 HEAD OF QUEUE TAG . . . . .	61
6.6.17.2 ORDERED QUEUE TAG . . . . .	61
6.6.17.3 SIMPLE QUEUE TAG . . . . .	61
6.6.18 RELEASE RECOVERY . . . . .	61
6.6.19 RESTORE POINTERS . . . . .	61
6.6.20 SAVE DATA POINTER . . . . .	62
6.6.21 SYNCHRONOUS DATA TRANSFER REQUEST . . . . .	62
6.6.22 TERMINATE I/O PROCESS . . . . .	64
6.6.23 WIDE DATA TRANSFER REQUEST . . . . .	64
7 SCSI commands and status . . . . .	67
7.1 Command implementation requirements . . . . .	67
7.1.1 Reserved . . . . .	67
7.1.2 Operation code types . . . . .	67
7.2 Command descriptor block . . . . .	68
7.2.1 Operation code . . . . .	69
7.2.2 Logical unit number . . . . .	70
7.2.3 Logical block address . . . . .	70

7.2.4 Transfer length . . . . .	70
7.2.5 Parameter list length . . . . .	70
7.2.6 Allocation length . . . . .	70
7.2.7 Control field . . . . .	71
7.3 Status . . . . .	71
7.4 Command examples . . . . .	73
7.4.1 Single command example . . . . .	73
7.4.2 Disconnect example . . . . .	73
7.4.3 Linked command example . . . . .	74
7.5 Command processing considerations and exception conditions . . . . .	74
7.5.1 Programmable operating definition . . . . .	74
7.5.2 Incorrect initiator connection . . . . .	75
7.5.3 Selection of an invalid logical unit . . . . .	75
7.5.4 Parameter rounding . . . . .	76
7.5.5 Asynchronous event notification . . . . .	76
7.5.6 Unexpected reselection . . . . .	77
7.6 Contingent allegiance condition . . . . .	78
7.7 Extended contingent allegiance condition . . . . .	78
7.8 Queued I/O processes . . . . .	79
7.8.1 Untagged queuing . . . . .	79
7.8.2 Tagged queuing . . . . .	79
7.8.3 Example of queued I/O process . . . . .	80
7.8.3.1 Typical sequences for tagged queuing . . . . .	81
7.8.3.2 Example of tagged queuing . . . . .	81
7.9 Unit attention condition . . . . .	83

8 All device types . . . . .	<a href="https://standards.iteh.ai/catalog/standards/sist/ce56cdf8-0f40-4cab-ac76-3ffdb15e093/iso-iec-9316-1995">ISO/IEC 9316:1995 https://standards.iteh.ai/catalog/standards/sist/ce56cdf8-0f40-4cab-ac76-3ffdb15e093/iso-iec-9316-1995</a>	84
8.1 Model for all device types . . . . .		84
8.1.1 SCSI addresses . . . . .		84
8.1.1.1 SCSI device address . . . . .		84
8.1.1.2 Logical units . . . . .		84
8.1.1.3 Target routines . . . . .		84
8.1.2 Commands implemented by all SCSI devices . . . . .		84
8.1.2.1 Using the INQUIRY command . . . . .		85
8.1.2.2 Using the REQUEST SENSE command . . . . .		85
8.1.2.3 Using the SEND DIAGNOSTIC command . . . . .		85
8.1.2.4 Using the TEST UNIT READY command . . . . .		85
8.2 Commands for all device types . . . . .		85
8.2.1 CHANGE DEFINITION command . . . . .		86
8.2.2 COMPARE command . . . . .		88
8.2.3 COPY command . . . . .		89
8.2.3.1 Errors detected by the managing SCSI device . . . . .		90
8.2.3.2 Errors detected by a target . . . . .		91
8.2.3.3 COPY function code 00h and 01h . . . . .		91
8.2.3.4 COPY function code 02h . . . . .		92
8.2.3.5 COPY function code 03h . . . . .		93
8.2.3.6 COPY function code 04h . . . . .		94
8.2.3.7 Copies with unequal block lengths . . . . .		94
8.2.4 COPY AND VERIFY command . . . . .		95
8.2.5 INQUIRY command . . . . .		96
8.2.5.1 Standard INQUIRY data . . . . .		97
8.2.5.2 Vital product data . . . . .		100
8.2.6 LOG SELECT command . . . . .		101

8.2.7 LOG SENSE command . . . . .	103
8.2.8 MODE SELECT(6) command . . . . .	104
8.2.9 MODE SELECT(10) command . . . . .	106
8.2.10 MODE SENSE(6) command . . . . .	106
8.2.10.1 Current values . . . . .	107
8.2.10.2 Changeable values . . . . .	108
8.2.10.3 Default values . . . . .	108
8.2.10.4 Saved values . . . . .	108
8.2.10.5 Initial responses . . . . .	108
8.2.11 MODE SENSE(10) command . . . . .	109
8.2.12 READ BUFFER command . . . . .	109
8.2.12.1 Combined header and data mode (000b) . . . . .	110
8.2.12.2 Vendor-specific mode (001b) . . . . .	110
8.2.12.3 Data mode (010b) . . . . .	110
8.2.12.4 Descriptor mode (011b) . . . . .	111
8.2.13 RECEIVE DIAGNOSTIC RESULTS command . . . . .	112
8.2.14 REQUEST SENSE command . . . . .	112
8.2.14.1 Sense-key specific . . . . .	116
8.2.14.2 Deferred errors . . . . .	117
8.2.14.3 Sense key and sense code definitions . . . . .	119
8.2.15 SEND DIAGNOSTIC command . . . . .	125
8.2.16 TEST UNIT READY command . . . . .	126
8.2.17 WRITE BUFFER command . . . . .	127
8.2.17.1 Combined header and data mode (000b) . . . . .	128
8.2.17.2 Vendor-specific mode (001b) . . . . .	128
8.2.17.3 Data mode (010b) . . . . .	128
8.2.17.4 Download microcode mode (100b) . . . . .	129
8.2.17.5 Download microcode and save mode (101b) . . . . .	129
8.3 Parameters for all device types . . . . .	129
8.3.1 Diagnostic parameters . . . . .	129
8.3.1.1 Supported diagnostic pages . . . . .	130
8.3.2 Log parameters . . . . .	131
8.3.2.1 Buffer over-run/under-run page . . . . .	134
8.3.2.2 Error counter pages . . . . .	135
8.3.2.3 Last n error events page . . . . .	136
8.3.2.4 Non-medium error page . . . . .	136
8.3.2.5 Supported log pages . . . . .	136
8.3.3 Mode parameters . . . . .	137
8.3.3.1 Control mode page . . . . .	140
8.3.3.2 Disconnect-reconnect page . . . . .	142
8.3.3.3 Peripheral device page . . . . .	144
8.3.4 Vital product data parameters . . . . .	144
8.3.4.1 ISO/IEC 646 implemented operating definition page . . . . .	145
8.3.4.2 ISO/IEC 646 information page . . . . .	146
8.3.4.3 Implemented operating definition page . . . . .	146
8.3.4.4 Supported vital product data pages . . . . .	148
8.3.4.5 Unit serial number page . . . . .	149
9 Direct-access devices . . . . .	150
9.1 Direct-access device model . . . . .	150
9.1.1 Removable medium . . . . .	150
9.1.2 Logical blocks . . . . .	150
9.1.3 Ready state . . . . .	151

9.1.4 Initialization . . . . .	151
9.1.5 Medium defects . . . . .	151
9.1.6 Data cache . . . . .	152
9.1.7 Reservations . . . . .	153
9.1.8 Seek and rezero . . . . .	154
9.1.9 Notched drives . . . . .	154
9.1.10 Rotational position locking . . . . .	154
9.1.11 Relative addressing . . . . .	154
9.1.12 Error reporting . . . . .	154
9.1.13 Examples . . . . .	155
9.1.13.1 Rotating media . . . . .	155
9.1.13.2 Sequential media . . . . .	156
9.1.13.3 Memory media . . . . .	156
9.2 Commands for direct-access devices. . . . .	157
9.2.1 FORMAT UNIT command . . . . .	158
9.2.1.1 Defect list formats . . . . .	162
9.2.1.2 Initialization pattern option . . . . .	163
9.2.2 LOCK UNLOCK CACHE command . . . . .	165
9.2.3 PRE-FETCH command . . . . .	166
9.2.4 PREVENT ALLOW MEDIUM REMOVAL command . . . . .	167
9.2.5 READ(06) command . . . . .	168
9.2.6 READ(10) command . . . . .	168
9.2.7 READ CAPACITY command . . . . .	169
9.2.8 READ DEFECT DATA command . . . . .	171
9.2.9 READ LONG command . . . . .	173
9.2.10 REASSIGN BLOCKS command . . . . .	174
9.2.11 RELEASE command . . . . .	175
9.2.11.1 Logical unit release . . . . .	176
9.2.11.2 Extent release . . . . .	176
9.2.11.3 Third-party release . . . . .	176
9.2.12 RESERVE command . . . . .	177
9.2.12.1 Logical unit reservation . . . . .	177
9.2.12.2 Extent reservation . . . . .	177
9.2.12.3 Third-party reservation . . . . .	179
9.2.12.4 Superseding reservations . . . . .	180
9.2.13 REZERO UNIT command . . . . .	180
9.2.14 SEARCH DATA commands . . . . .	181
9.2.14.1 SEARCH DATA EQUAL command . . . . .	183
9.2.14.2 SEARCH DATA HIGH command . . . . .	183
9.2.14.3 SEARCH DATA LOW command . . . . .	183
9.2.15 SEEK(06) and SEEK(10) commands . . . . .	183
9.2.16 SET LIMITS command . . . . .	184
9.2.17 START STOP UNIT command . . . . .	185
9.2.18 SYNCHRONIZE CACHE command . . . . .	186
9.2.19 VERIFY command . . . . .	187
9.2.20 WRITE(06) command . . . . .	188
9.2.21 WRITE(10) command . . . . .	188
9.2.22 WRITE AND VERIFY command . . . . .	189
9.2.23 WRITE LONG command . . . . .	190
9.2.24 WRITE SAME command . . . . .	191
9.3 Parameters for direct-access devices . . . . .	192
9.3.1 Diagnostic parameters . . . . .	192
9.3.1.1 Translate address page - SEND DIAGNOSTIC . . . . .	192

9.3.1.2 Translate address page - RECEIVE DIAGNOSTIC . . . . .	193
9.3.2 Log parameters . . . . .	194
9.3.3 Mode parameters . . . . .	194
9.3.3.1 Caching page . . . . .	196
9.3.3.2 Flexible disk page . . . . .	199
9.3.3.3 Format device page . . . . .	202
9.3.3.4 Medium types supported page . . . . .	205
9.3.3.5 Notch and partition page . . . . .	206
9.3.3.6 Read-write error recovery page . . . . .	207
9.3.3.7 Rigid disk drive geometry page . . . . .	214
9.3.3.8 Verify error recovery page . . . . .	215
9.4 Definitions specific to direct-access devices . . . . .	217
10 Sequential-access devices . . . . .	218
10.1 Sequential-access device model . . . . .	218
10.1.1 Physical elements . . . . .	218
10.1.2 Data storage characteristics . . . . .	219
10.1.3 Partitions within a volume . . . . .	221
10.1.4 Logical elements within a partition . . . . .	222
10.1.5 Data buffering . . . . .	223
10.1.6 Recorded object descriptors (block identifiers) . . . . .	224
10.1.7 Direction and position definitions . . . . .	224
10.1.8 Error reporting . . . . .	225
10.2 Command descriptions for sequential-access devices . . . . .	226
10.2.1 ERASE command . . . . .	227
10.2.2 LOAD UNLOAD command . . . . .	228
10.2.3 LOCATE command . . . . .	229
10.2.4 READ command . . . . .	230
10.2.5 READ BLOCK LIMITS command . . . . .	232
10.2.6 READ POSITION command . . . . .	233
10.2.7 READ REVERSE command . . . . .	235
10.2.8 RECOVER BUFFERED DATA command . . . . .	236
10.2.9 RELEASE UNIT command . . . . .	237
10.2.9.1 Third-party release . . . . .	237
10.2.10 RESERVE UNIT command . . . . .	238
10.2.10.1 Third-party reservation . . . . .	238
10.2.10.2 Superseding reservations . . . . .	239
10.2.11 REWIND command . . . . .	239
10.2.12 SPACE command . . . . .	240
10.2.13 VERIFY command . . . . .	242
10.2.14 WRITE command . . . . .	243
10.2.15 WRITE FILEMARKS command . . . . .	244
10.3 Parameters for sequential-access devices . . . . .	246
10.3.1 Diagnostic parameters . . . . .	246
10.3.2 Log parameters . . . . .	246
10.3.3 Mode parameters . . . . .	246
10.3.3.1 Device configuration page . . . . .	250
10.3.3.2 Medium partition page(1) . . . . .	253
10.3.3.3 Medium partition page(2-4) . . . . .	254
10.3.3.4 Read-write error recovery page . . . . .	254
10.4 Definitions specific to sequential access devices . . . . .	256
11 Commands for printer devices . . . . .	257

11.1 Model for printer devices . . . . .	257
11.2 Commands for printer devices . . . . .	258
11.2.1 FORMAT command . . . . .	259
11.2.2 PRINT command . . . . .	260
11.2.3 RECOVER BUFFERED DATA command . . . . .	260
11.2.4 SLEW AND PRINT command . . . . .	261
11.2.5 STOP PRINT command . . . . .	262
11.2.6 SYNCHRONIZE BUFFER command . . . . .	262
11.3 Parameters for printer devices . . . . .	263
11.3.1 Diagnostic parameters . . . . .	263
11.3.2 Log parameters . . . . .	263
11.3.3 Mode parameters . . . . .	263
11.3.3.1 Parallel printer interface page . . . . .	264
11.3.3.2 Printer options page . . . . .	266
11.3.3.3 Serial printer interface page . . . . .	269
12 Processor devices . . . . .	271
12.1 Model for processor devices . . . . .	271
12.1.1 Host-to-host communication, SEND only . . . . .	272
12.1.2 Host-to-host communication, SEND and RECEIVE . . . . .	272
12.1.3 Host-to-special-output peripheral . . . . .	272
12.1.4 Host-to-special-input peripheral . . . . .	272
12.2 Commands for processor devices . . . . .	273
12.2.1 RECEIVE command . . . . .	273
12.2.2 SEND command . . . . .	274
12.3 Parameters for processor devices . . . . .	275
12.3.1 Diagnostic parameters . . . . .	275
12.3.2 Log parameters . . . . .	275
12.3.3 Mode parameters . . . . .	275
12.4 Definitions specific to processor devices . . . . .	275
13 Write-once devices . . . . .	276
13.1 Model for write-once devices . . . . .	276
13.1.1 Logical blocks . . . . .	276
13.1.2 Initialization . . . . .	276
13.1.3 Physical medium defects . . . . .	276
13.1.4 Error reporting . . . . .	276
13.2 Commands for write-once devices . . . . .	277
13.3 Parameters for write-once devices . . . . .	279
13.4 Definitions specific to write-once devices . . . . .	279
14 CD-ROM devices . . . . .	280
14.1 Model for CD-ROM devices . . . . .	280
14.1.1 CD-ROM media organization . . . . .	280
14.1.2 CD-ROM physical data format . . . . .	283
14.1.2.1 Frame format for audio . . . . .	283
14.1.2.2 Sector format for data . . . . .	283
14.1.2.3 Sub-channel information formats . . . . .	284
14.1.3 CD Audio error reporting . . . . .	285
14.1.4 CD-ROM ready condition/not ready condition . . . . .	285
14.1.5 CD-ROM address reporting formats (MSF bit) . . . . .	285
14.1.6 Sensing support for CD-audio commands . . . . .	286
14.1.7 Error reporting . . . . .	286
14.2 Commands for CD-ROM devices . . . . .	287

14.2.1 PAUSE RESUME command . . . . .	288
14.2.2 PLAY AUDIO(10) command . . . . .	289
14.2.3 PLAY AUDIO(12) command . . . . .	290
14.2.4 PLAY AUDIO MSF command . . . . .	290
14.2.5 PLAY AUDIO TRACK INDEX command . . . . .	292
14.2.6 PLAY AUDIO TRACK RELATIVE(10) command . . . . .	293
14.2.7 PLAY AUDIO TRACK RELATIVE(12) command . . . . .	294
14.2.8 READ CD-ROM CAPACITY command . . . . .	294
14.2.9 READ HEADER command . . . . .	296
14.2.10 READ SUB-CHANNEL command . . . . .	297
14.2.10.1 Sub-Q channel data format . . . . .	298
14.2.10.2 CD-ROM current position data format . . . . .	302
14.2.10.3 Media catalogue number data format . . . . .	302
14.2.10.4 Track international standard recording code data format . . . . .	303
14.2.11 READ TOC command . . . . .	305
14.3 Parameters for CD-ROM devices . . . . .	307
14.3.1 Diagnostic parameters . . . . .	307
14.3.2 Log parameters . . . . .	307
14.3.3 Mode parameters . . . . .	307
14.3.3.1 CD-ROM audio control parameters . . . . .	309
14.3.3.2 CD-ROM device parameters . . . . .	311
14.3.3.3 Read error recovery parameters . . . . .	312
14.3.3.4 Verify error recovery parameters . . . . .	318
14.4 Definitions specific to CD-ROM devices . . . . .	318
15 Scanner devices . . . . .	321
15.1 Model for scanner devices . . . . .	321
15.2 Commands for scanner devices . . . . .	322
15.2.1 GET DATA BUFFER STATUS command . . . . .	323
15.2.2 GET WINDOW command . . . . .	325
15.2.3 OBJECT POSITION command . . . . .	329
15.2.4 READ command . . . . .	331
15.2.5 SCAN command . . . . .	332
15.2.6 SEND command . . . . .	332
15.2.7 SET WINDOW command . . . . .	333
15.3 Parameters for scanner devices . . . . .	334
15.3.1 Diagnostic parameters . . . . .	334
15.3.2 Log parameters . . . . .	334
15.3.3 Mode parameters . . . . .	335
15.3.3.1 Measurement units page . . . . .	335
15.4 Definitions specific to scanner devices . . . . .	337
16 Optical memory devices . . . . .	338
16.1 Model for optical memory devices . . . . .	338
16.1.1 Defect management . . . . .	339
16.1.2 Error reporting . . . . .	339
16.2 Commands for optical memory devices . . . . .	340
16.2.1 ERASE(10) command . . . . .	341
16.2.2 ERASE(12) command . . . . .	342
16.2.3 MEDIUM SCAN command . . . . .	342
16.2.4 READ(12) command . . . . .	344
16.2.5 READ DEFECT DATA(12) command . . . . .	345
16.2.6 READ GENERATION command . . . . .	346

16.2.7 READ UPDATED BLOCK(10) command . . . . .	347
16.2.8 SEARCH DATA(12) commands . . . . .	348
16.2.9 SET LIMITS(12) command . . . . .	348
16.2.10 UPDATE BLOCK command . . . . .	349
16.2.11 VERIFY(10) command . . . . .	350
16.2.12 VERIFY(12) command . . . . .	351
16.2.13 WRITE(10) command . . . . .	352
16.2.14 WRITE(12) command . . . . .	353
16.2.15 WRITE AND VERIFY(10) command . . . . .	353
16.2.16 WRITE AND VERIFY(12) command . . . . .	354
16.3 Parameters for optical memory devices . . . . .	355
16.3.1 Diagnostic parameters . . . . .	355
16.3.2 Log parameters . . . . .	355
16.3.3 Mode parameters . . . . .	355
16.3.3.1 Optical memory page . . . . .	357
16.4 Definitions specific to write-once and optical memory devices . . . . .	358
17 Medium-changer devices . . . . .	359
17.1 Medium-changer device model . . . . .	359
17.1.1 Medium-changer elements . . . . .	359
17.1.1.1 Medium transport elements . . . . .	359
17.1.1.2 Storage elements . . . . .	360
17.1.1.3 Import export elements . . . . .	360
17.1.1.4 Data transfer element . . . . .	360
17.1.2 SCSI addressing of medium changer devices . . . . .	360
17.1.3 Data access operations using a medium changer device . . . . .	361
17.1.4 Element status maintenance requirements . . . . .	361
17.1.5 Volume tags . . . . .	361
<a href="https://standards.ieee.org/catalog/standards/sis/ce36cd18-0f40-4cab-ac76-31mb01fe093/iso-iec-9316-1995">https://standards.ieee.org/catalog/standards/sis/ce36cd18-0f40-4cab-ac76-31mb01fe093/iso-iec-9316-1995</a> . . . . .	362
17.1.5.1 Volume tag format . . . . .	362
17.1.5.2 Primary and alternate volume tag information . . . . .	362
17.2 Commands for medium changer devices . . . . .	363
17.2.1 EXCHANGE MEDIUM command . . . . .	364
17.2.2 INITIALIZE ELEMENT STATUS command . . . . .	365
17.2.3 MOVE MEDIUM command . . . . .	366
17.2.4 POSITION TO ELEMENT command . . . . .	367
17.2.5 READ ELEMENT STATUS command . . . . .	368
17.2.5.1 Element status data . . . . .	369
17.2.5.2 Element status page . . . . .	371
17.2.5.3 Medium transport element descriptor . . . . .	372
17.2.5.4 Storage element descriptor . . . . .	373
17.2.5.5 Import export element descriptor . . . . .	374
17.2.5.6 Data transfer element descriptor . . . . .	375
17.2.6 REQUEST VOLUME ELEMENT ADDRESS command . . . . .	376
17.2.7 RELEASE command . . . . .	378
17.2.7.1 Logical unit release . . . . .	378
17.2.7.2 Element release (optional) . . . . .	378
17.2.7.3 Third party release . . . . .	378
17.2.8 RESERVE command . . . . .	379
17.2.8.1 Logical unit reservation . . . . .	379
17.2.8.2 Element reservation (optional) . . . . .	379
17.2.8.3 Third party reservation . . . . .	380
17.2.8.4 Superseding reservations . . . . .	381
17.2.9 SEND VOLUME TAG command . . . . .	381

17.3 Parameters for medium changer devices . . . . .	383
17.3.1 Diagnostic parameters . . . . .	383
17.3.2 Log parameters . . . . .	384
17.3.3 Mode parameters . . . . .	384
17.3.3.1 Device capabilities page . . . . .	385
17.3.3.2 Element address assignment page . . . . .	386
17.3.3.3 Transport geometry parameters page . . . . .	388
17.4 Definitions specific to medium changer devices . . . . .	389
 18 Communications devices . . . . .	390
18.1 Communications device model . . . . .	390
18.1.1 Implementation examples . . . . .	391
18.1.1.1 Host-to-host communications . . . . .	391
18.1.1.2 Host-to-device communications . . . . .	391
18.1.1.3 Multiple role communications . . . . .	391
18.2 Command descriptions for communications devices . . . . .	392
18.2.1 GET MESSAGE(06) command . . . . .	393
18.2.2 GET MESSAGE(10) command . . . . .	393
18.2.3 GET MESSAGE(12) command . . . . .	394
18.2.4 SEND MESSAGE(06) command . . . . .	394
18.2.5 SEND MESSAGE(10) command . . . . .	395
18.2.6 SEND MESSAGE(12) command . . . . .	395
18.3 Parameters for communication devices . . . . .	396
18.3.1 Diagnostic parameters . . . . .	396
18.3.2 Log parameters . . . . .	396
18.3.3 Mode parameters . . . . .	397
18.4 Definitions specific to communications devices . . . . .	398
 Index . . . . .	420

**iTeh STANDARD PREVIEW**

**(standards.iteh.ai)**

<https://standards.iteh.ai/catalog/standards/sist/ce56cdf8-0f40-4cab-ac76-3ffdb15e093/iso-iec-9316-1995>

## Annexes

A	SCSI signal sequence example . . . . .	399
B	SCSI skew time . . . . .	403
C	Other SCSI standardization activities . . . . .	405
D	Numeric order codes . . . . .	406
E	Vendor identification . . . . .	416

**Tables**

1 - Cross-reference to connector contact assignments .....	20
2 - Single-ended contact assignments - A cable .....	20
3 - Single-ended contact assignments - B cable .....	21
4 - Differential contact assignments - A cable .....	22
5 - Differential contact assignments - B cable .....	23
6 - Signal sources .....	33
7 - SCSI bus timing values .....	34
8 - Information transfer phases .....	42
9 - Message format .....	52
10 - Message codes .....	52
11 - Extended message format .....	53
12 - Extended message codes .....	54
13 - IDENTIFY message format .....	57
14 - IGNORE WIDE RESIDUE message format .....	58
15 - Ignore field definition .....	58
16 - MODIFY DATA POINTER .....	60
17 - Queue tag message format .....	60
18 - SYNCHRONOUS DATA TRANSFER REQUEST .....	62
19 - WIDE DATA TRANSFER REQUEST .....	64
20 - Operation code type .....	67
21 - Typical command descriptor block for six-byte commands .....	68
22 - Typical command descriptor block for ten-byte commands .....	68
23 - Typical command descriptor block for twelve-byte commands .....	68
24 - Operation code .....	70
25 - Control field .....	71
26 - Status byte .....	71
27 - Status byte code ISO/IEC 9316:1995 .....	72
28 - Commands in order received by target 1995 .....	81
29 - Commands in order of execution .....	81
30 - Modified by HEAD OF QUEUE TAG message .....	82
31 - Commands for all device types .....	85
32 - CHANGE DEFINITION command .....	86
33 - Definition parameter field .....	86
34 - COMPARE command .....	88
35 - COPY command .....	89
36 - COPY parameter list .....	89
37 - COPY function codes .....	90
38 - Segment descriptor for COPY function codes 00h and 01h .....	91
39 - Segment descriptor for COPY function code 02h .....	92
40 - Segment descriptor for COPY function code 03h .....	93
41 - Segment descriptor for COPY function code 04h .....	94
42 - Pad and Cat bit definition .....	94
43 - COPY AND VERIFY command .....	95
44 - INQUIRY command .....	96
45 - Standard INQUIRY data format .....	97
46 - Peripheral qualifier .....	97
47 - Peripheral device type .....	98
48 - ISO-approved version .....	98
49 - LOG SELECT command .....	101
50 - Page control field .....	101
51 - LOG SENSE command .....	103
52 - MODE SELECT(6) command .....	104

53 - MODE SELECT(10) command .....	106
54 - MODE SENSE(6) command .....	106
55 - Page control field .....	107
56 - Mode page code usage for all devices .....	107
57 - MODE SENSE(10) command .....	109
58 - READ BUFFER command .....	109
59 - READ BUFFER mode field .....	110
60 - READ BUFFER header .....	110
61 - READ BUFFER descriptor .....	111
62 - Buffer offset boundary .....	111
63 - RECEIVE DIAGNOSTIC RESULTS command .....	112
64 - REQUEST SENSE command .....	112
65 - Error codes 70h and 71h sense data format .....	113
66 - Field pointer bytes .....	116
67 - Actual retry count bytes .....	116
68 - Format progress indication bytes .....	117
69 - Sense key (0h-7h) descriptions .....	119
70 - Sense key (8h-Fh) descriptions .....	120
71 - ASC and ASCQ assignments .....	121
72 - SEND DIAGNOSTIC command .....	125
73 - TEST UNIT READY command .....	126
74 - Preferred TEST UNIT READY responses .....	126
75 - WRITE BUFFER command .....	127
76 - WRITE BUFFER mode field .....	128
77 - Diagnostic page format .....	129
78 - Diagnostic page codes .....	130
79 - Supported diagnostic pages .....	130
80 - Log page format .....	131
81 - Log parameter .....	131
82 - Threshold met criteria .....	133
83 - Log page codes .....	134
84 - Parameter code field for buffer over-run/under-run counters .....	134
85 - Count basis definition .....	135
86 - Cause field definition .....	135
87 - Parameter codes for error counter pages .....	135
88 - Non-medium error event parameter codes .....	136
89 - Supported log pages .....	136
90 - Mode parameter list .....	137
91 - Mode parameter header(06) .....	137
92 - Mode parameter header(10) .....	137
93 - Mode parameter block descriptor .....	138
94 - Mode page format .....	139
95 - Mode page codes .....	140
96 - Control mode page .....	140
97 - Queue algorithm modifier .....	140
98 - Disconnect-reconnect page .....	142
99 - Data transfer disconnect control .....	143
100 - Peripheral device page .....	144
101 - Interface identifier codes .....	144
102 - Vital product data page codes .....	144
103 - ISO/IEC 646 implemented operating definition .....	145
104 - ISO/IEC 646 information page .....	146
105 - Implemented operating definition page .....	147

106 - Supported vital product data pages . . . . .	148
107 - Unit serial number page . . . . .	149
108 - Commands for direct-access devices . . . . .	157
109 - FORMAT UNIT command . . . . .	158
110 - FORMAT UNIT parameter list . . . . .	159
111 - Defect list header . . . . .	159
112 - FORMAT UNIT defect descriptor format and requirements . . . . .	160
113 - Defect descriptor - Block format . . . . .	162
114 - Defect descriptor - Bytes from index format . . . . .	162
115 - Defect descriptor - Physical sector format . . . . .	163
116 - Initialization pattern descriptor . . . . .	163
117 - Initialization pattern modifier . . . . .	164
118 - Initialization pattern type . . . . .	164
119 - LOCK UNLOCK CACHE command . . . . .	165
120 - PRE-FETCH command . . . . .	166
121 - PREVENT ALLOW MEDIUM REMOVAL command . . . . .	167
122 - READ(06) command . . . . .	168
123 - READ(10) command . . . . .	168
124 - READ CAPACITY command . . . . .	169
125 - READ CAPACITY data . . . . .	170
126 - READ DEFECT DATA command . . . . .	171
127 - READ DEFECT DATA defect list . . . . .	172
128 - READ LONG command . . . . .	173
129 - REASSIGN BLOCKS command . . . . .	174
130 - REASSIGN BLOCKS defect list . . . . .	174
131 - RELEASE command . . . . .	175
132 - RESERVE command . . . . .	177
133 - Data format of extent descriptors . . . . .	178
134 - Reservation types . . . . .	178
135 - REZERO UNIT command . . . . .	180
136 - SEARCH DATA commands . . . . .	181
137 - SEARCH DATA parameter list . . . . .	182
138 - SEEK(06) command . . . . .	183
139 - SEEK(10) command . . . . .	183
140 - SET LIMITS command . . . . .	184
141 - START STOP UNIT command . . . . .	185
142 - SYNCHRONIZE CACHE command . . . . .	186
143 - VERIFY command . . . . .	187
144 - WRITE(06) command . . . . .	188
145 - WRITE(10) command . . . . .	188
146 - WRITE AND VERIFY command . . . . .	189
147 - WRITE LONG command . . . . .	190
148 - WRITE SAME command . . . . .	191
149 - Diagnostic page codes . . . . .	192
150 - Translate address page - SEND DIAGNOSTIC . . . . .	192
151 - Translate address page - RECEIVE DIAGNOSTIC . . . . .	193
152 - Log page codes . . . . .	194
153 - Direct-access medium-type codes . . . . .	194
154 - Device specific parameter . . . . .	195
155 - Mode page codes . . . . .	196
156 - Caching page . . . . .	196
157 - Demand read and write retention priority . . . . .	197
158 - Flexible disk page . . . . .	199