



**SLOVENSKI STANDARD**  
**SIST ISO 16000-2:2004**

**01-december-2004**

---

BčlfUbŋ'nfU\_!'&"XY. GlfUHY[ ]Uj ncf Yb'UZ:fa UXYŋ ]XU

Indoor air - Part 2: Sampling strategy for formaldehyde

**iTeh STANDARD PREVIEW**

Air intérieur - Partie 2: Stratégie d'échantillonnage du formaldéhyde  
(standards.iteh.ai)

Ta slovenski standard je istoveten z: **ISO 16000-2:2004**  
SIST ISO 16000-2:2004  
<https://standards.iteh.ai/catalog/standards/sist/727515b-1d14-4dc7-8678-9cf91dac23b/sist-iso-16000-2-2004>

**ICS:**

13.040.20      Kakovost okoljskega zraka      Ambient atmospheres

**SIST ISO 16000-2:2004**

**en**

**iTeh STANDARD PREVIEW**  
**(standards.iteh.ai)**

SIST ISO 16000-2:2004

<https://standards.iteh.ai/catalog/standards/sist/727315f3-fd14-4dc7-8678-9cf91dac23b/sist-iso-16000-2-2004>

INTERNATIONAL  
STANDARD

ISO  
16000-2

First edition  
2004-07-01

---

---

Indoor air —

Part 2:  
Sampling strategy for formaldehyde

*Air intérieur —*

*Partie 2: Stratégie d'échantillonnage du formaldéhyde*

iTeh STANDARD PREVIEW  
(standards.iteh.ai)

[SIST ISO 16000-2:2004](https://standards.iteh.ai/catalog/standards/sist/727315f3-fd14-4dc7-8678-9cf91dac23b/sist-iso-16000-2-2004)

<https://standards.iteh.ai/catalog/standards/sist/727315f3-fd14-4dc7-8678-9cf91dac23b/sist-iso-16000-2-2004>



Reference number  
ISO 16000-2:2004(E)

© ISO 2004

**ISO 16000-2:2004(E)****PDF disclaimer**

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.

## iTeh STANDARD PREVIEW (standards.iteh.ai)

[SIST ISO 16000-2:2004](https://standards.iteh.ai/catalog/standards/sist/727315f3-fd14-4dc7-8678-9cfe91dac23b/sist-iso-16000-2-2004)

<https://standards.iteh.ai/catalog/standards/sist/727315f3-fd14-4dc7-8678-9cfe91dac23b/sist-iso-16000-2-2004>

© ISO 2004

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office  
Case postale 56 • CH-1211 Geneva 20  
Tel. + 41 22 749 01 11  
Fax + 41 22 749 09 47  
E-mail [copyright@iso.org](mailto:copyright@iso.org)  
Web [www.iso.org](http://www.iso.org)

Published in Switzerland

## Contents

Page

Foreword .....	iv
Introduction .....	v
1 Scope .....	1
2 Normative references .....	1
3 Sources and occurrence of formaldehyde .....	1
4 Measurement techniques .....	3
4.1 General .....	3
4.2 Short-term monitoring .....	4
4.3 Long-term monitoring .....	4
4.4 Methods for screening tests .....	4
5 Sampling strategy .....	4
5.1 General .....	4
5.2 Objectives of the measurement and conditions .....	4
5.3 Time of sampling .....	6
5.4 Duration of sampling and frequency of measurement .....	6
5.5 Sampling location .....	6
5.6 Reporting on results and uncertainties .....	6
5.7 Quality assurance .....	7
Annex A (informative) Properties of formaldehyde .....	8
Annex B (informative) Overview of important sources and typical concentrations .....	9
Annex C (informative) Correlation of formaldehyde concentrations in naturally ventilated rooms depending on ventilation .....	10
Annex D (informative) Dependence of the confidence interval on the number of samples .....	11
Annex E (informative) Examples of screening tests .....	12
Bibliography .....	14

## ISO 16000-2:2004(E)

## Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 16000-2 was prepared by Technical Committee ISO/TC 146, *Air quality*, Subcommittee SC 6, *Indoor air*.

ISO 16000 consists of the following parts, under the general title *Indoor air*:

- *Part 1: General aspects of sampling strategy*
- *Part 2: Sampling strategy for formaldehyde*
- *Part 3: Determination of formaldehyde and other carbonyl compounds — Active sampling method*
- *Part 4: Determination of formaldehyde — Diffusive sampling method*
- *Part 6: Determination of volatile organic compounds in indoor and test chamber air by active sampling on Tenax TA sorbent, thermal desorption and gas chromatography using MS/FID*

The following parts of ISO 16000 are under preparation:

- *Part 5: Sampling strategy for volatile organic compounds (VOCs)*
- *Part 7: Sampling strategy for determination of airborne asbestos fibre concentrations*
- *Part 8: Ventilation rate measurement*
- *Part 9: Determination of the emission of volatile organic compounds — Emission test chamber method*
- *Part 10: Determination of the emission of volatile organic compounds — Emission test cell method*
- *Part 11: Determination of the emission of volatile organic compounds — Sampling, storage of samples and preparation of test specimens*

## Introduction

This part of ISO 16000 describes basic aspects to be considered when working out a sampling strategy for the analysis of formaldehyde in indoor air.

NOTE The term “formaldehyde” is used in this International Standard instead of the term “methanal”, as specified by IUPAC regulations.

It is intended to be a link between Part 1 of ISO 16000, which describes a measurement strategy, and Parts 3 and 4 of ISO 16000, which describe the analytical procedures dealing with active or diffusive sampling of formaldehyde respectively. This part of ISO 16000 presupposes knowledge of Part 1 of ISO 16000.

The sampling strategy procedure is based on VDI 4300, Part 3<sup>[1]</sup>.

VOC measurements in different fields of air pollution are described in ISO 16017, *Indoor, ambient and workplace air — Sampling and analysis of volatile organic compounds by sorbent tube/thermal desorption/capillary gas chromatography*

— Part 1: Pumped sampling

— Part 2: Diffusive sampling

**ITEH STANDARD PREVIEW**  
**(standards.iteh.ai)**

[SIST ISO 16000-2:2004](https://standards.iteh.ai/catalog/standards/sist/727315f3-fd14-4dc7-8678-9cf91dac23b/sist-iso-16000-2-2004)

<https://standards.iteh.ai/catalog/standards/sist/727315f3-fd14-4dc7-8678-9cf91dac23b/sist-iso-16000-2-2004>

**iTeh STANDARD PREVIEW**  
**(standards.iteh.ai)**

[SIST ISO 16000-2:2004](#)

<https://standards.iteh.ai/catalog/standards/sist/727315f3-fd14-4dc7-8678-9cf91dac23b/sist-iso-16000-2-2004>



## Indoor air —

### Part 2: Sampling strategy for formaldehyde

#### 1 Scope

This part of ISO 16000 is intended as an aid to planning formaldehyde indoor pollution measurements. In the case of indoor air measurements<sup>1)</sup>, the careful planning of sampling and the entire measurement strategy are of particular significance, since the result of the measurement can have far-reaching consequences, for example, with regard to the need for remedial action or the success of such an action.

#### 2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

*ISO Guide to the expression of uncertainty in measurement (GUM)*, published jointly by BIPM/IEC/IFCC/ISO/IUPAC/IUPAP/OIML, first edition 1995

ISO 6879:1995, *Air quality — Performance characteristics and related concepts for air quality measuring methods*

ISO 16000-3, *Indoor air — Part 3: Determination of formaldehyde and other carbonyl compounds — Active sampling method*


ISO 16000-4, *Indoor air — Part 4: Determination of formaldehyde — Diffusive sampling method*

#### 3 Sources and occurrence of formaldehyde

The occurrence of formaldehyde in indoor air is often due to the use of certain wood-based board material for construction and for work on the interior and furnishing of a room. Increased concentrations may also be caused by other products, including use of certain disinfectants and paints. Tobacco smoke is an additional important intermittent source of formaldehyde. Details are given in Table B.1.

Whereas an intermittent emission source (e.g. the use for a limited period of time of disinfectant spray containing formaldehyde) will cause an increased formaldehyde concentration in indoor air for only a short period of time during and after use, a continuous emission source (e. g. a particleboard used for indoor furnishings) will contribute to the formaldehyde concentration over a longer period. Figure 1 shows the influence of humidity and temperature on the emission rate of formaldehyde from particleboard; by increasing humidity and temperature, formaldehyde emission increases considerably.

1) This part of ISO 16000 uses the definition for indoor environment [2], [3] defined in ISO 16000-1.

**Key**X relative humidity,  $H$ , in percentY factor  $K$ 

- 1 temperature = 15 °C
- 2 temperature = 20 °C
- 3 temperature = 25 °C
- 4 temperature = 30 °C

iTeh STANDARD PREVIEW  
(standards.iteh.ai)

<https://standards.iteh.ai/catalog/standards/sist/727315f3-fd14-4dc7-8678-9cfe91dac23b/sist-iso-16000-2-2004>


NOTE 1 Parameter for  $K = 1$ : temperature, 23 °C; relative humidity, 45 %; air exchange rate, 1 h<sup>-1</sup>; loading, 1 m<sup>2</sup>/m<sup>3</sup>.

NOTE 2  $C_{t/H} = C_{23/45} \cdot K$ , expressed in millilitres per cubic metre (ppm).

**Figure 1 — Plot of rate of emission of formaldehyde from particleboards in relation to temperature and relative humidity<sup>[1]</sup>, <sup>[4]</sup>**

Figure 2 presents the formaldehyde equilibration concentration as a function of the air exchange rate after placing a 23-m<sup>2</sup> particleboard emitting 2,3 mg/h formaldehyde into a room of 23 m<sup>3</sup><sup>[1]</sup>, <sup>[5]</sup>. Curves A, B and C show the outcome with ventilation rates of > 0,5 h<sup>-1</sup>, 0,5 h<sup>-1</sup> and < 0,5 h<sup>-1</sup>, respectively.

The recommended World Health Organization (WHO) guideline value for formaldehyde for indoor/ambient air quality is 0,1 mg/m<sup>3</sup>, expressed as the 30 min average concentration<sup>[6]</sup>.

**Key**

X time, expressed in hours

Y formaldehyde concentration, expressed in milligrams per cubic metre

A ventilation rate  $> 0,5 \text{ h}^{-1}$

B ventilation rate  $= 0,5 \text{ h}^{-1}$

C ventilation rate  $< 0,5 \text{ h}^{-1}$

STANDARD PREVIEW  
(standards.iteh.ai)

SIST ISO 16000-2:2004

Figure 2 — Formaldehyde equilibration concentration in relation to the ventilation rate

Generally, outdoor sources of formaldehyde are not significant sources of formaldehyde in indoor air. Outdoor air may be contributory only if strong formaldehyde sources (e.g. heavy road traffic) are nearby.

In a study of 300 typical households in Germany during 1985/86, the median level of formaldehyde in indoor air was found to be  $55 \mu\text{g}/\text{m}^3$ <sup>[7]</sup>. In a few per cent of the cases, concentrations were above  $100 \mu\text{g}/\text{m}^3$ . Other, more recent studies in the UK, Sweden and Australia found median formaldehyde concentrations of about  $25 \mu\text{g}/\text{m}^3$  (see Table B.2). Table B.2 compares the median and the range of concentrations measured indoors with concentrations observed in outdoor air.

## 4 Measurement techniques

### 4.1 General

There are several methods for measuring formaldehyde. Basically, they meet different demands and can be divided into short-term measurements with active sampling, long-term measurements with active or diffusive samplers, continuous measurements, and screening tests with direct-reading detection tubes. High concentrations of interfering gases (in special cases ozone,  $\text{NO}_2$  etc.) shall be taken into account.

Analytical methods for the determination of formaldehyde in the air that can be used to determine compliance with the WHO guideline are described in ISO 16000-3.