

---

---

**Corrosion of metals and alloys —  
Electrochemical potentiokinetic  
reactivation measurement using the  
double loop method (based on Čihal's  
method)**

**iTeh STANDARD PREVIEW**  
*Corrosion des métaux et alliages — Mesurage de la réactivation  
électrochimique potentiocinétique par la méthode de la double boucle  
(dérivée de la méthode de Čihal)*  
**(standard iTeh only)**

ISO 12732:2006

<https://standards.itih.ai/catalog/standards/sist/cc8f330e-765b-4be8-bf27-06cdd1c19b11/iso-12732-2006>



**PDF disclaimer**

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.

**iTeh STANDARD PREVIEW**  
**(standards.iteh.ai)**

ISO 12732:2006

<https://standards.iteh.ai/catalog/standards/sist/cc8f330e-765b-4be8-bf27-06cdd1c19b11/iso-12732-2006>

© ISO 2006

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office  
Case postale 56 • CH-1211 Geneva 20  
Tel. + 41 22 749 01 11  
Fax + 41 22 749 09 47  
E-mail [copyright@iso.org](mailto:copyright@iso.org)  
Web [www.iso.org](http://www.iso.org)

Published in Switzerland

## Contents

Page

Foreword.....	iv
1 Scope .....	1
2 Normative references .....	1
3 Terms and definitions.....	1
4 Principle.....	2
5 Apparatus.....	3
6 Test solutions.....	5
7 Test specimen preparation .....	5
8 Procedure .....	5
9 Metallographic inspection .....	6
10 Evaluation of results.....	6
11 Test report .....	7
Annex A (informative) Flushed port cell and flushed electrode holder.....	9
Annex B (informative) Potential of selected reference electrodes at 25 °C with respect to the standard hydrogen electrode (SHE) .....	12
Annex C (informative) Suggested method for sensitizing test specimens .....	13
Annex D (informative) Correlation of $I_{p1}$ with the degree of grain-boundary sensitization, $P_a$ (ASTM G108), $Q_{GBA}$ and $Q_{GBL}$ .....	14

## Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 12732 was prepared by Technical Committee ISO/TC 156, *Corrosion of metals and alloys*.

## iTeh STANDARD PREVIEW (standards.iteh.ai)

ISO 12732:2006

<https://standards.iteh.ai/catalog/standards/sist/cc8f330e-765b-4be8-bf27-06cdd1c19b11/iso-12732-2006>

# Corrosion of metals and alloys — Electrochemical potentiokinetic reactivation measurement using the double loop method (based on Čihal's method)

**WARNING** — This International Standard may involve hazardous materials, operations and equipment. It is the responsibility of whoever uses this standard to consult and establish appropriate safety and health practices, and determine the applicability of regulatory limitations prior to use.

## 1 Scope

This International Standard specifies the method for measuring the degree of sensitization (DOS) in stainless steel and nickel-based alloys using the Double Loop Electrochemical Potentiokinetic Reactivation (DL-EPR) test (based on Čihal's method).

The method may be used for the quantitative assessment of deleterious thermal effects resulting in the formation of alloy-element-depleted zones at grain boundaries or in the matrix. However, attention should be paid when testing heat-affected weld zones, due to possible non-uniform distribution of sensitized zones along the fusion lines.

The results of the test can be used as an index to identify the potential susceptibility of stainless steel and nickel-based alloys to intergranular corrosion, pitting corrosion, and intergranular-stress corrosion cracking, but prediction of these corrosion modes depends on complementary specific testing.

This International Standard describes the general methodology and, in Annex C, gives examples of suitable test exposure conditions for specific alloys.

## 2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 8044:1999, *Corrosion of metals and alloys — Basic terms and definitions*

ISO 643:2003, *Steels — Micrographic determination of the apparent grain size*

## 3 Terms and definitions

For the purposes of this document, the terms and definitions in ISO 8044 and the following apply.

### 3.1 integrated charge

$Q$

charge measured during passivation ( $Q_p$ ) and reactivation ( $Q_r$ ), given by the time integral of current below the passivation and reactivation peak of the curve


## 4 Principle

Heat treatment (including welding) of corrosion-resistant alloys can lead to formation of particles, such as chromium carbide in the case of 304 SS or  $\sigma$ -phase (FeCrMo) in duplex stainless steels. This will lead to local depletion of alloying elements, unless replenished by matrix diffusion, the extent of which will be temperature dependent. This process is commonly referred to as sensitization, because depleted zones have an intrinsic lower resistance to localized corrosion and, where appropriate, to stress corrosion cracking. The extent to which these damage mechanisms develop and propagate will depend on the extent of depletion and the density of depleted zones. There was a need for a simple laboratory test to rapidly identify potentially deleterious thermal effects on stainless steels and nickel-based alloys. The EPR test was developed for that purpose. Although two methods have been used in laboratory testing, the single loop and the double loop, the former, which involves polarization scanning from the passive to the active state, has the disadvantage that the method can be sensitive to surface finish. The EPR test may also be applied to in-field testing, provided some adaptation be made to the cell and assembly.

The double loop version of this method is preferred. Here, the specimen is immersed in an acid solution such that it is in the active state under freely corroding conditions, but then anodically polarized into the passive domain. As surface features are dissolved during initial immersion under active corrosion conditions, the likelihood of surface preparation having an impact diminishes. From the passive state, the specimen is polarized at a controlled scan rate in the cathodic direction. A schematic illustration is shown in Figure 1. In the absence of active depleted zones, the passive film can become unstable as the potential becomes less positive and can start to dissolve (e.g. by reductive dissolution). However, the rate of dissolution is small and, with the sweep rate employed, the anodic current is not able to rise substantially, so that only a modest anodic peak current is measured. The process of anodic dissolution during the cathodic scan is referred to as reactivation. Occasionally, the current may go transiently cathodic on lowering the potential, as the passive current density may be less than the cathodic current at the potentials of relevance.

When a depleted zone is present, the passive film is locally less protective and is more easily reduced. Hence, active dissolution of the depleted zones will occur more readily whilst adjacent material still retains some passive film, albeit a gradually thinning passive film. Thus significant active dissolution occurs. The reason for the gradual rise in current is probably a reflection of the spread in activity associated with a spread of the extent of depletion and corresponding variations in the passive film properties (some sections reduced at higher potentials and some at lower potentials). Gradually, as the activity of all the sites build up, this begins to be counteracted by the decrease in potential reducing the current of the active regions because of Tafel behaviour; thus a reactivation peak is observed. The peak in the current density, and the charge passed associated with that peak, depend on the extent of alloy depletion.

The ratio of the reactivation peak to the activation peak, or the reactivation charge to the activation charge, when compared with the values for the solution-annealed specimen, gives an index of sensitization. However, for sensitized grain boundaries, these values have to be normalized to the grain size. At the end of the test, the specimen is examined to confirm the nature of the localized corrosion process.

**Key**

X potential  
Y log of current

1 anodic scan

2 reactivation scan

**iTeh STANDARD PREVIEW**  
**(standards.iteh.ai)**

[ISO 12732:2006](https://standards.iteh.ai/catalog/standards/sist/cc8f330e-765b-4be8-bf27-06cdd1c19b11/iso-12732-2006)

<https://standards.iteh.ai/catalog/standards/sist/cc8f330e-765b-4be8-bf27-06cdd1c19b11/iso-12732-2006>

**Figure 1 — Schematic polarization curves of the double loop EPR test method**

## 5 Apparatus

The apparatus necessary for obtaining EPR data consists of electronic instruments and a test cell. The electronic instruments may be integrated into one instrument package or may be individual components. Either form of instrumentation can provide acceptable data.

### 5.1 Scanning potentiostat

The potentiostat should be capable of controlling the potential to within  $\pm 1$  mV accuracy, over the range of potential and current encountered in the EPR measurements. The potentiostat should have a potential range of  $-2\ 000$  to  $+2\ 000$  mV and a current range of  $1\ \mu\text{A}$  to  $1\ \text{A}$ .

### 5.2 Electrode potential-measuring instrument

The electrode potential-measuring circuit should have a high input impedance of the order of  $10^{11}\ \Omega$  to  $10^{14}\ \Omega$ , to minimize current drawn from the system during measurements. Such circuits are provided with most potentiostats. Instruments should have sufficient sensitivity and accuracy to detect a change of  $1,0$  mV over a potential range between  $-2\ 000$  and  $+2\ 000$  mV.

### 5.3 Current-measuring instruments

The current in the circuit is evaluated from the potential drop measured across a known resistor. In many potentiostats, this measurement is made internally but measurements can also be made externally by locating a resistor in the current line from the counter electrode to the auxiliary connection on the potentiostat. The current intensities encountered in an EPR test are usually in the range of  $1 \mu\text{A}\cdot\text{cm}^{-2}$  to  $100 \text{mA}\cdot\text{cm}^{-2}$ . An instrument that is capable of measuring a current accuracy to within 1 % of the absolute value over a current density range between  $1,0 \mu\text{A}\cdot\text{cm}^{-2}$  and  $105 \mu\text{A}\cdot\text{cm}^{-2}$ , for a specimen with a surface area of approximately  $1,0 \text{cm}^2$  to  $5,0 \text{cm}^2$ , is recommended.

### 5.4 EPR test cell

The test cell should contain the working electrode (the metal to be polarized), a reference electrode for measuring the electrode potential and counter electrode(s). The test cell shall be constructed of materials that will not corrode, deteriorate, or otherwise contaminate the test solution. Borosilicate glass and polytetrafluoroethylene (PTFE) have been successfully used.

The counter electrode/s should be positioned so that the current distribution about the specimen is symmetrical.

The reference electrode may be inserted directly into the main cell. To avoid mutual contamination, a double-junction reference electrode may be used or the reference electrode may be located in a separate chamber and linked to the main cell by a salt bridge. To minimize the potential drop between the reference electrode and the working electrode, a Luggin capillary should be used. The tip of the capillary probe shall be positioned so that it is at a minimum distance from the working electrode of 2 times the diameter of the tip.

The volume of solution in the test cell shall be such as to reduce to insignificance any change in the solution chemistry, as a consequence of the reaction processes. Typically 250 ml is sufficient, with a minimum requirement of  $100 \text{ml}\cdot\text{cm}^{-2}$  of working electrode.

**5.4.1 Electrode holder.** The working electrodes shall be mounted in such a way that the holder and mounting material have no influence on the measurement. An example of an electrode-mounting assembly is shown in Figure A.2. For steels with a protective oxide film, the seal of the test specimen to the holder can sometimes lead to undesired crevice attack of the steel at the interface. A method of preventing such crevice attack for certain applications, using a flushed port cell or using a flushed specimen holder, is outlined in Annex A.

**5.4.2 Working-electrode material.** The working electrode is prepared from the test material of interest, usually in the form of a rod or sheet. See Clause 7 for surface finish and cleaning of the working electrode.

**5.4.3 Reference electrode.** The type of reference electrode used will depend on the application, e.g. temperature and environment. Commonly used electrodes include the saturated calomel electrode and silver/silver chloride electrode. The potential of these electrodes at 25 °C, relative to the standard hydrogen electrode at 25 °C, is given in Annex B.

**5.4.4 Counter-electrode preparation.** The counter electrode shall be free of any product that would contaminate the solution. The counter electrode is commonly prepared from high-purity platinum. For platinum electrodes, dipping in concentrated HCl and thoroughly rinsing in distilled water is usually sufficient. Other materials may be used, provided they are inert. The area of the counter electrode should be at least the area of the working electrode.

**NOTE** Graphite may be used as a counter electrode but care must be taken to avoid contamination; desorption of species retained in the graphite may be necessary prior to usage. This contamination can be avoided by routinely replacing the graphite electrode.



## 6 Test solutions

The test solution most often consists of a mixture of sulfuric acid ( $H_2SO_4$ ) and potassium thiocyanate (KSCN), prepared from analytical reagent-grade chemicals and distilled water (the solution can be made up in bulk in a large quantity and stored for 1 month at room temperature). The composition of the test solution is chosen depending on the tested material and varies between 0,5 M to 2,5 M  $H_2SO_4$  and 0,001 M to 0,05 M KSCN.

NOTE KSCN is deliquescent. For super-duplex stainless steel, 3,0 M HCl without KSCN has been shown to be an effective test solution.

Fresh solution should be used for each test.

## 7 Test specimen preparation

Specimens to be given a thermal sensitizing treatment prior to DL-EPR testing should be treated according to the procedure given in Annex C.

The shape of the specimens should not allow crevice corrosion and be without sharp edges. Care should be taken to avoid overheating of specimens when machining or grinding.

Although corrosion in the active state should limit the influence of the surface state, it is advisable to prepare specimens to a well-defined surface finish, for example to  $R_a$  less than 0,25  $\mu m$ . The specimen shall then be cleaned. Ultrasonic cleaning in distilled water, washing with alcohol and rinsing with acetone is usually adequate. The time between grinding and exposing the specimen may have some effect on the rate of subsequent dissolution in the active state. This delay should be limited to 1 h. After grinding, specimens shall be stored in a dessicator cabinet when possible.

Specimens should be pre-treated according to the procedure given in Annex C.

The use of control specimens with a known degree of sensitization is recommended. These can be used to confirm the performance of new cells for field applications, and the quality of the apparatus and reagents used.

## 8 Procedure

Place the specimen, counter electrode, salt bridge probe, and other components in the test cell. Add the solution, ensuring that the Luggin capillary is filled with the test solution and contains no air bubbles, particularly in the restricted space within the tip region.

Record the open circuit (rest or corrosion) potential of the test specimen after 1 min to 2 min. If the rest potential does not register normal for the class of alloys being evaluated ( $-350$  mV to  $-450$  mV vs. SCE for Cr18 Ni9 type steel), cathodically polarize the specimen so as to remove any existing oxide layer, for instance to  $-700$  mV vs. SCE for 0,1 min to 1 min, and recheck the rest potential.

Expose the specimen for about 5 min. at the free corrosion potential, then polarize anodically into the passive region at a controlled scan rate. Typically, the potential will be about 200 mV to 600 mV (SCE). As soon as this potential is reached, the scanning direction is reversed and the potential is decreased at the same rate to the initial free corrosion value  $E_{corr}$ . The scan rate chosen is designed to give a clear distinction between the activation and reactivation process and will be alloy sensitive. Initial tests should be undertaken to establish the optimum rate. Values in the range 2 000  $mV \cdot hr^{-1}$  to 15 000  $mV \cdot hr^{-1}$  are typical. The sequence of the polarization steps should be performed at least three times.

For types 304, 321, and 347, the following test conditions shall be used:

- test solution composition: 0,5 M H<sub>2</sub>SO<sub>4</sub> +0,01 M KSCN;
- scan rate: 6 V/h;
- polarization range from  $E_{\text{corr}}$  (about -400) up to +300 mV/SCE;
- temperature: 25 °C (however, acceptable temperature range for field applications requires experimental justification).

## 9 Metallographic inspection

At the end of the test, the specimen surface shall be examined to ensure that there are no other factors, such as pitting, that might have influenced the results.

A grain size measurement is required when normalizing the data obtained to the grain size. This should be done using ISO grids on micrographs of the sample for determination of the grain size number, and dividing the data by the grain-boundary area per unit of specimen area, or by the length of grain boundary per unit of specimen area.

## 10 Evaluation of results

Measure the peak current for the reactivation scan ( $I_r$ ) and for the activation scan ( $I_p$ ), and take their ratio. Do likewise for the charge ( $Q_r$  and  $Q_p$  respectively) by integrating the current under the peak over the time. The ratio, when compared with results from tests of a solution-annealed specimen, will give an index of the extent of depletion. When depletion is homogeneous, this index provides a sufficient criteria for ranking the impact of different heat treatments.

[https://standards.iteh.ai/catalog/standards/sist/cc8f330e-765b-4be8-bf27-](https://standards.iteh.ai/catalog/standards/sist/cc8f330e-765b-4be8-bf27-06cdd1c19b11/iso-12732-2006)

For sensitized grain boundaries, divide the activation peak current by the area of the specimen and divide the reactivation peak by the area of the grain boundary, in order to account for specimens with different grain sizes. This assumes that the reactivation peak is associated with the grain-boundary sensitization only, and not depleted zones or other active corrosion regions in the matrix. The exercise is repeated for the charge. The relevant relationships are:

$$(I_r/I_p)_{\text{GBA}} = \frac{I_r}{S_{\text{GBA}}/A_s} = \frac{I_r}{S_A A_s} \frac{A_s}{I_p} = \frac{I_r}{S_A I_p} = \frac{I_r}{I_p 10^{-3} \sqrt{2}^{G+5}} \quad (1)$$

$$(Q_r/Q_p)_{\text{GBA}} = \frac{Q_r}{S_{\text{GBA}}/A_s} = \frac{Q_r}{S_A A_s} \frac{A_s}{Q_p} = \frac{Q_r}{S_A Q_p} = \frac{Q_r}{Q_p 10^{-3} \sqrt{2}^{G+5}} \quad (2)$$

where

$Q_r$  is the charge for the reactivation loop (in coulombs);

$Q_p$  is the charge for the anodic loop (in coulombs);

$I_r$  is the maximum current for the reactivation loop ( $\mu\text{A}\cdot\text{cm}^{-2}$ );

$I_p$  is the maximum current for the anodic loop ( $\mu\text{A}\cdot\text{cm}^{-2}$ );

$S_A$  is the grain-boundary area per unit of specimen area;

$$S_A = 4 \times 10^{-3} \sqrt{2^{G+1}};$$

$A_s$  is the specimen area (cm<sup>2</sup>);

$S_{\text{GBA}}$  is the grain-boundary area (cm<sup>2</sup>);

$$S_{\text{GBA}} = S_A \times A_s;$$

$G$  is the grain-size number (see ISO 643).

For convenience purposes,  $(I_r/I_p)_{\text{GBA}}$  and  $(Q_r/Q_p)_{\text{GBA}}$  ratios can be multiplied by 100 to be expressed as percentage values.

An alternative approach is to normalize the reactivation currents or charge to the grain-boundary length, to provide a dimensional ratio defined by:

$$(I_r/I_p)_{\text{GBL}} = \frac{I_r}{L_{\text{GBL}}} \Big/ \frac{I_p}{A_s} = \frac{I_r}{10L_A A_s} \Big/ \frac{I_p}{A_s} = \frac{I_r}{10L_A I_p} = \frac{I_r}{I_p 10\sqrt{2^{G+5}}} \text{ (cm)} \quad (3)$$

$$(Q_r/Q_p)_{\text{GBL}} = \frac{Q_r}{L_{\text{GBL}}} \Big/ \frac{Q_p}{A_s} = \frac{Q_r}{10L_A A_s} \Big/ \frac{Q_p}{A_s} = \frac{Q_r}{10L_A Q_p} = \frac{Q_r}{Q_p 10\sqrt{2^{G+5}}} \text{ (cm)} \quad (4)$$

where

**iTeh STANDARD PREVIEW**

$L_A$  is the length of grain boundary per unit of specimen area (mm<sup>-1</sup>);

$$L_A = \sqrt{2^{G+5}};$$

ISO 12732:2006  
<https://standards.iteh.ai/catalog/standards/sist/cc8f330e-765b-4be8-bf27-06cdd1c19b11/iso-12732-2006>

$A_s$  is the specimen area (cm<sup>2</sup>);

$L_{\text{GBL}}$  is the grain-boundary length (cm);

$$L_{\text{GBL}} = 10 \times L_A \times A_s$$

The ratios can be used as a relative index for comparing the relative effect of different heat treatments on sensitization. The degree of sensitization can only be confirmed by separate complementary measurements but Annex D provides preliminary guidelines.

## 11 Test report

The test report shall include the following information:

- a full description of the test material from which the specimens were taken, including UNS number, composition, heat treatment, type of product;
- method of manufacture of the specimens and details of the surface preparation;
- number of test repeats and whether the sample surface is reprepared after each test;
- the solution composition, pH, volume and temperature and any variations with time;
- area of the specimen exposed to the test solution;