



SLOVENSKI STANDARD SIST ETS 300 838 E1:2003

01-december-2003

Digitalno omrežje z integriranimi storitvami (ISDN) – Usklajeni programirljivi komunikacijski vmesnik (HPCI) za ISDN

Integrated Services Digital Network (ISDN); Harmonized Programmable Communication Interface (HPCI) for ISDN

iTeh STANDARD PREVIEW
(standards.iteh.ai)

Ta slovenski standard je istoveten z: **ETS 300 838 Edition 1**
<https://standards.iteh.ai/catalog/standards/sist/51aba759-d754-4199-b07c-303f90de1a8c/sist-ets-300-838-e1-2003>

ICS:

33.080	Digitalno omrežje z integriranimi storitvami (ISDN)	Integrated Services Digital Network (ISDN)
35.200	Vmesniška in povezovalna oprema	Interface and interconnection equipment

SIST ETS 300 838 E1:2003

en

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ETS 300 838 E1:2003

<https://standards.iteh.ai/catalog/standards/sist/31aba739-d754-4199-b07c-303f90de1a8c/sist-ets-300-838-e1-2003>



EUROPEAN
TELECOMMUNICATION
STANDARD

ETS 300 838

May 1998

Source: MTA

Reference: RE/MTA-002040

ICS: 33.020

Key words: API, ISDN, PCI

iTeh STANDARD PREVIEW
Integrated Services Digital Network (ISDN);
Harmonized Programmable Communication Interface (HPCI)

for ISDN
<https://standards.iteh.ai/catalog/standards/sist/300-838-e1-2003>
<https://standards.iteh.ai/catalog/standards/sist/300-838-e1-2003>

ETSI

European Telecommunications Standards Institute

ETSI Secretariat

Postal address: F-06921 Sophia Antipolis CEDEX - FRANCE

Office address: 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

Internet: secretariat@etsi.fr - <http://www.etsi.fr> - <http://www.etsi.org>

Tel.: +33 4 92 94 42 00 - Fax: +33 4 93 65 47 16

Copyright Notification: No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 1998. All rights reserved.

iTeh STANDARD PREVIEW (standards.iteh.ai)

SIST ETS 300 838 E1:2003

<https://standards.iteh.ai/catalog/standards/sist/31aba739-d754-4199-b07c-303f90de1a8c/sist-ets-300-838-e1-2003>

Contents

Foreword	23
Introduction	23
1 Scope	25
2 Normative references	26
3 Definitions and abbreviations	27
3.1 Definitions	27
3.2 Abbreviations	28
4 General	29
4.1 Overview	29
4.2 Requirements	30
4.3 Reader's guide	31
5 Profile A	31
5.1 Reader's guidance and overview	31
5.1.1 Reader's guide	31
5.1.2 How to use this profile	32
5.1.3 Functional overview	33
5.1.4 Connection management	33
5.1.5 The planes	33
5.1.6 Properties	33
5.1.7 External equipment (e.g. telephony)	34
5.1.8 ISDN accesses and the multi-applications environment	34
5.1.9 Exchange mechanism	34
5.2 Message overview	34
5.2.1 Functional model	34
5.2.1.1 Introduction	34
5.2.1.2 Architecture	34
5.2.1.2.1 Profile A and its components	35
5.2.1.2.2 Profile A architecture	36
5.2.1.2.3 Co-ordination cases	36
5.2.1.3 Functionality	37
5.2.1.3.1 Introduction	37
5.2.1.3.2 Resource management	37
5.2.1.3.2.1 Attribute sets	37
5.2.1.3.2.2 Network Connection Objects	38
5.2.1.3.2.3 Support of external equipment	38
5.2.1.3.2.4 Support of security features	40
5.2.1.3.2.5 Support of manufacturer specific features	40
5.2.1.3.3 Connection management	41
5.2.1.3.3.1 Connection set-up and removal	41
5.2.1.3.3.2 Support of supplementary services	41
5.2.1.3.4 Data management	41
5.2.1.4 Relating functionality to planes	42
5.2.1.4.1 Optional features	42
5.2.1.4.2 Administration Plane	42
5.2.1.4.3 Control Plane	43
5.2.1.4.4 User Plane	43
5.2.1.5 PUF NAF interactions	43
5.2.1.6 Total interaction overview	45
5.2.1.7 Identifiers	47
5.2.1.8 Error handling	48
5.2.1.8.1 Overview	48
5.2.1.8.2 Function error handling	48

	5.2.1.8.3	Message error handling	49
5.2.2		Information encoding	49
5.2.3		Conventions	50
	5.2.3.1	Address conventions	50
	5.2.3.2	Provision of information	50
	5.2.3.3	Message conventions	50
	5.2.3.4	Parameter conventions	51
		5.2.3.4.1	Parameter ordering
		5.2.3.4.2	Parameter repetition
		5.2.3.4.3	Parameter checking
	5.2.3.5	Default philosophy	51
5.2.4		User Plane particularities	51
5.3		Exchange method	52
	5.3.1	Registration phase	52
		5.3.1.1	Overview
		5.3.1.2	PciGetHandles
		5.3.1.3	PciGetProperty
		5.3.1.4	PciRegister
	5.3.2	Deregistration phase	57
		5.3.2.1	PciDeregister
	5.3.3	Conversation phase	57
		5.3.3.1	Sending messages
		5.3.3.2	Receiving messages
		5.3.3.3	Receiving messages using the polling method
		5.3.3.4	Receiving messages using signal method
		5.3.3.5	PCI Message Parameter Block (PCIMPB)
		5.3.3.6	PciPutMessage
		5.3.3.7	PciGetMessage
		5.3.3.8	PciSetSignal
5.4		Administration Plane messages	61
	5.4.1	ACreateNCOREq	62
	5.4.2	NCOType and conditional parameter specification	63
	5.4.3	ACreateNCOCnf	64
	5.4.4	ADestroyNCOREq	65
	5.4.5	ADestroyNCOCnf	65
	5.4.6	AGetNCOInfoReq	65
	5.4.7	AGetNCOInfoCnf	66
	5.4.8	AErrorInd	66
	5.4.9	ASecurityReq	67
	5.4.10	ASecurityCnf	67
	5.4.11	AManufacturerReq	68
	5.4.12	AManufacturerInd	68
	5.4.13	AChangeNCOREq	68
	5.4.14	AChangeNCOCnf	69
5.5		Control Plane messages	69
	5.5.1	Introduction	69
		5.5.1.1	Control Messages classes
		5.5.1.2	Sequencing of Control Plane messages
	5.5.2	CAlertReq	74
	5.5.3	CAlertInd	75
	5.5.4	CConnectReq	75
	5.5.5	CConnectInd	76
	5.5.6	CConnectRsp	77
	5.5.7	CConnectCnf	78
	5.5.8	CDisconnectReq	78
	5.5.9	CDisconnectInd	78
	5.5.10	CDisconnectRsp	79
	5.5.11	CDisconnectCnf	79
	5.5.12	CProgressInd	80
	5.5.13	CStatusInd	80
	5.5.14	CSetupAckInd	80
	5.5.15	CConnectInfoReq	81
	5.5.16	CProceedingInd	81

5.5.17	CUserInformationReq	82
5.5.18	CUserInformationInd	82
5.5.19	CCongestionControlReq	83
5.5.20	CCongestionControlInd	83
5.5.21	CSuspendReq	84
5.5.22	CSuspendCnf	84
5.5.23	CResumeReq	84
5.5.24	CResumeCnf	85
5.5.25	CNotifyInd	85
5.5.26	CFacilityReq	86
5.5.27	CFacilityInd	86
5.5.28	CExtEquipAvailablityInd	86
5.5.29	CExtEquipBlockDiallingInd	87
5.5.30	CExtEquipKeyPressedInd	87
5.5.31	CExtEquipOffHookInd	87
5.5.32	CExtEquipOnHookInd	88
5.5.33	CAddInfoReq	88
5.5.34	CAddInfoInd	88
5.5.35	CDtmfReq	89
5.5.36	CDtmfCnf	89
5.5.37	CDtmfInd	89
5.5.38	User to User information exchange	90
5.5.39	Implementation of supplementary services	90
	5.5.39.1 Advice of Charge during call (AOC-D)	90
	5.5.39.2 Advice of Charge at End of call (AOC-E)	91
5.6	User Plane	91
5.6.1	User Plane Protocols Management Architecture	91
5.6.1.1	Introduction	91
5.6.1.2	Message access	92
	5.6.1.2.1 The physical layer access (transparent access)	93
	5.6.1.2.2 The link layer access	93
	5.6.1.2.3 The network layer access	93
5.6.1.3	Protocols	94
	5.6.1.3.1 Supported User Plane protocols	94
	5.6.1.3.2 Protocol selection	94
	5.6.1.3.2.1 NCOType parameter	95
	5.6.1.3.2.2 UProtocol parameter	95
5.6.1.4	Co-ordination function	95
5.6.1.5	Selection criteria	97
	5.6.1.5.1 NCO Selection: User Plane information element	97
	5.6.1.5.2 Action if no NCO available: User Plane incoming call	97
5.6.1.6	User Plane error checking	97
5.6.1.7	User Plane attribute sets	97
5.6.2	Layer 1 Protocols	97
5.6.2.1	Transparent B-channel access with byte framing from the network	97
	5.6.2.1.1 Introduction	97
	5.6.2.1.2 Messages	98
	5.6.2.1.2.1 UDataReq	98
	5.6.2.1.2.2 UDataInd	99
	5.6.2.1.2.3 UErrorInd	99
	5.6.2.1.3 Messages parameters	100
	5.6.2.1.3.1 IdleFlag	100
	5.6.2.1.3.2 NCOType	100
	5.6.2.1.3.3 UProtocol	100
	5.6.2.1.3.4 UAttributeName	100
	5.6.2.1.3.5 UDirection	101
	5.6.2.1.3.6 Cause	101
	5.6.2.1.4 State diagram	101
	5.6.2.1.5 Co-ordination function	101

	5.6.2.1.6	Selection criteria.....	101
	5.6.2.1.7	Specific error handling	101
	5.6.2.1.8	Static attributes.....	101
	5.6.2.1.8.1	AttributeSet parameters	101
	5.6.2.1.8.2	Static attribute content.....	102
5.6.3	Layer 2 Protocols.....		102
	5.6.3.1	ISO 7776 protocol.....	102
	5.6.3.1.1	Introduction.....	102
	5.6.3.1.2	Messages.....	103
	5.6.3.1.2.1	UConnectReq.....	103
	5.6.3.1.2.2	UConnectInd	103
	5.6.3.1.2.3	UConnectRsp.....	103
	5.6.3.1.2.4	UConnectCnf.....	104
	5.6.3.1.2.5	UDisconnectReq	104
	5.6.3.1.2.6	UDisconnectInd.....	104
	5.6.3.1.2.7	UDataReq.....	104
	5.6.3.1.2.8	UDataInd	105
	5.6.3.1.2.9	UReadyToReceiveReq.....	105
	5.6.3.1.2.10	UReadyToReceiveInd	106
	5.6.3.1.3	Messages parameters.....	106
	5.6.3.1.3.1	L2ConnectionMode	106
	5.6.3.1.3.2	L2FrameSize	107
	5.6.3.1.3.3	L2WindowSize	107
	5.6.3.1.3.4	L2XID	107
	5.6.3.1.3.5	NCOType	107
	5.6.3.1.3.6	UProtocol.....	108
	5.6.3.1.3.7	UAttributeName.....	108
	5.6.3.1.3.8	UDirection.....	108
	5.6.3.1.3.9	Cause	108
	5.6.3.1.3.10	Origin.....	109
	5.6.3.1.4	State diagram.....	109
	5.6.3.1.5	Co-ordination function	110
	5.6.3.1.6	Selection criteria.....	110
	5.6.3.1.7	Specific error handling and codes	110
	5.6.3.1.8	Static attributes.....	110
	5.6.3.1.8.1	AttributeSet parameters	110
	5.6.3.1.8.2	Static attribute content.....	110
5.6.3.2	HDLC protocol.....		111
	5.6.3.2.1	Introduction.....	111
	5.6.3.2.2	Messages.....	111
	5.6.3.2.2.1	UDataReq.....	111
	5.6.3.2.2.2	UDataInd	112
	5.6.3.2.3	Messages parameters.....	112
	5.6.3.2.3.1	NCOType	112
	5.6.3.2.3.2	UProtocol.....	112
	5.6.3.2.3.3	UAttributeName.....	113
	5.6.3.2.3.4	UDirection.....	113
	5.6.3.2.4	State diagram.....	113
	5.6.3.2.5	Co-ordination function	113
	5.6.3.2.6	Selection criteria.....	113
	5.6.3.2.7	Specific error handling and codes	113
	5.6.3.2.8	Static attributes.....	114
	5.6.3.2.8.1	AttributeSet parameters	114
	5.6.3.2.8.2	Static attribute content.....	114
5.6.3.3	HDLC protocol with error.....		114
	5.6.3.3.1	Introduction.....	114
	5.6.3.3.2	Messages.....	115
	5.6.3.3.2.1	UDataReq.....	115
	5.6.3.3.2.2	UDataInd	115
	5.6.3.3.3	Messages parameters.....	115
	5.6.3.3.3.1	NCOType	116
	5.6.3.3.3.2	UProtocol.....	116
	5.6.3.3.3.3	UAttributeName.....	116

iTeh STANDARD PREVIEW
(standards.iteh.ai)

https://standards.iteh.ai/catalog/standards/sist/300-838-1998-07-c-303f1c1c/sist-ets-300-838-1998-07-c-303f1c1c

	5.6.3.3.3.4	UDirection	116
	5.6.3.3.3.5	Cause.....	117
	5.6.3.3.3.6	State diagram	117
	5.6.3.3.4	Co-ordination function.....	117
	5.6.3.3.5	Selection criteria	117
	5.6.3.3.6	Specific error handling	117
	5.6.3.3.7	Static attributes	117
	5.6.3.3.7.1	AttributeSet parameters.....	117
	5.6.3.3.7.2	Static attribute content	117
5.6.3.4	PPP protocol.....		117
	5.6.3.4.1	Introduction	117
	5.6.3.4.2	Messages	118
	5.6.3.4.2.1	UConnectReq	119
	5.6.3.4.2.2	UConnectInd	119
	5.6.3.4.2.3	UConnectRsp	119
	5.6.3.4.2.4	UConnectCnf	120
	5.6.3.4.2.5	UDisconnectReq.....	120
	5.6.3.4.2.6	UDisconnectInd	120
	5.6.3.4.2.7	UDataReq	120
	5.6.3.4.2.8	UDataInd.....	121
	5.6.3.4.2.9	UErrorInd	121
	5.6.3.4.3	Messages parameters	121
	5.6.3.4.3.1	NCOType	122
	5.6.3.4.3.2	UProtocol	122
	5.6.3.4.3.3	UAttributeName	122
	5.6.3.4.3.4	UDirection	122
	5.6.3.4.3.5	PPPCause	123
	5.6.3.4.3.6	PPPDiagnostic.....	123
	5.6.3.4.3.7	PPPNegotiation.....	124
	5.6.3.4.3.8	PPPOrigin	125
	5.6.3.4.4	State diagram	126
	5.6.3.4.5	Co-ordination function.....	126
	5.6.3.4.6	Selection criteria	126
	5.6.3.4.7	Specific error handling and codes	126
	5.6.3.4.7.1	Errors	126
	5.6.3.4.7.2	Causes.....	127
	5.6.3.4.8	Static attributes	127
	5.6.3.4.8.1	AttributeSet parameters.....	127
	5.6.3.4.8.2	Static attribute content	128
	5.6.3.4.9	Protocol specific NAF property information	128
5.6.3.5	SDLC protocol		128
	5.6.3.5.1	Introduction	128
	5.6.3.5.2	Messages	129
	5.6.3.5.2.1	UConnectReq	130
	5.6.3.5.2.2	UConnectInd	130
	5.6.3.5.2.3	UConnectRsp	130
	5.6.3.5.2.4	UConnectCnf	131
	5.6.3.5.2.5	UDisconnectReq.....	131
	5.6.3.5.2.6	UDisconnectInd	131
	5.6.3.5.2.7	UDataReq	131
	5.6.3.5.2.8	UDataInd.....	132
	5.6.3.5.2.9	UExpeditedDataReq	132
	5.6.3.5.2.10	UExpeditedDataInd.....	132
	5.6.3.5.2.11	UReadyToReceiveReq	133
	5.6.3.5.2.12	UReadyToReceiveInd.....	133
	5.6.3.5.3	Messages parameters	133
	5.6.3.5.3.1	L2ConnectionMode.....	134
	5.6.3.5.3.2	L2FrameSize.....	134
	5.6.3.5.3.3	L2WindowSize	135
	5.6.3.5.3.4	L2XID	135
	5.6.3.5.3.5	NCOType	135
	5.6.3.5.3.6	ReadyFlag.....	135

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ETS 300 838 E1:2003

<https://standards.iteh.ai/catalog/standards/sist/31aba739-d54f-4199-b07c-303f90de1a8c/sist-ets-300-838-e1-2003>

	5.6.3.5.3.7	UProtocol.....	136
	5.6.3.5.3.8	UAttributeName.....	136
	5.6.3.5.3.9	UDirection.....	136
	5.6.3.5.3.10	UserData	136
	5.6.3.5.3.11	SDLCCause	136
	5.6.3.5.3.12	SDLCOrigin	137
	5.6.3.5.4	State diagram	137
	5.6.3.5.5	Co-ordination function	137
	5.6.3.5.6	Selection criteria.....	137
	5.6.3.5.7	Specific error handling and codes.....	138
	5.6.3.5.7.1	Invalid use of user messages.....	138
	5.6.3.5.7.2	Causes	138
	5.6.3.5.8	Static attributes.....	138
	5.6.3.5.8.1	AttributeSet parameters	138
	5.6.3.5.8.2	Static attribute content.....	139
5.6.3.6	V.110 protocol		139
	5.6.3.6.1	Introduction.....	139
	5.6.3.6.2	Messages	140
	5.6.3.6.2.1	UConnectReq.....	140
	5.6.3.6.2.2	UConnectInd	140
	5.6.3.6.2.3	UConnectRsp.....	140
	5.6.3.6.2.4	UConnectCnf.....	141
	5.6.3.6.2.5	UDisconnectReq	141
	5.6.3.6.2.6	UDisconnectInd.....	141
	5.6.3.6.2.7	UDataReq.....	141
	5.6.3.6.2.8	UDataInd	142
	5.6.3.6.2.9	UReadyToReceiveReq.....	142
	5.6.3.6.2.10	UReadyToReceiveInd	142
	5.6.3.6.3	Messages parameters.....	143
	5.6.3.6.3.1	NCOType	143
	5.6.3.6.3.2	ReadyFlag	143
	5.6.3.6.3.3	UProtocol.....	144
	5.6.3.6.3.4	UAttributeName.....	144
	5.6.3.6.3.5	UDirection.....	144
	5.6.3.6.3.6	V.110Cause	144
	5.6.3.6.3.7	V.110Origin	144
	5.6.3.6.3.8	FlowControlMechanism.....	145
	5.6.3.6.3.9	FlowControlCharacters	145
	5.6.3.6.3.10	MomentNumber	145
	5.6.3.6.3.11	V.110BChannelDisconnection.....	145
	5.6.3.6.4	State diagram	146
	5.6.3.6.5	Co-ordination function	146
	5.6.3.6.6	Selection criteria.....	146
	5.6.3.6.7	Specific error handling and codes.....	146
	5.6.3.6.7.1	Invalid use of User Plane messages..	147
	5.6.3.6.7.2	Causes	147
	5.6.3.6.8	Static attributes.....	147
	5.6.3.6.8.1	AttributeSet parameters	147
	5.6.3.6.8.2	Static attribute content.....	147
5.6.4	Layer 3 protocols		147
	5.6.4.1	ISO 8208 protocol and ETS 300 080 protocol	148
	5.6.4.1.1	Introduction.....	148
	5.6.4.1.2	Description of messages.....	148
	5.6.4.1.2.1	UConnectReq.....	150
	5.6.4.1.2.2	UConnectInd	150
	5.6.4.1.2.3	UConnectRsp.....	151
	5.6.4.1.2.4	UConnectCnf.....	152
	5.6.4.1.2.5	UDisconnectReq	152
	5.6.4.1.2.6	UDisconnectInd.....	153
	5.6.4.1.2.7	UDataReq.....	153
	5.6.4.1.2.8	UDataInd	153
	5.6.4.1.2.9	UExpeditedDataReq.....	154
	5.6.4.1.2.10	UExpeditedDataInd	154

iTeh STANDARD PREVIEW
(standards.it.ih.fi)

303912610-ets-300-838-e1-013
<https://standards.iteh.ai/catalog/standards/sist/714954-4199-b07c-303912610-ets-300-838-e1-013>

5.6.4.1.2.11	UResetReq	154
5.6.4.1.2.12	UResetInd	155
5.6.4.1.2.13	UResetRsp	155
5.6.4.1.2.14	UResetCnf	155
5.6.4.1.2.15	UDataAcknowledgeReq	156
5.6.4.1.2.16	UDataAcknowledgeInd	156
5.6.4.1.2.17	UReadyToReceiveReq	156
5.6.4.1.2.18	UReadyToReceiveInd	157
5.6.4.1.3	Messages parameters	157
5.6.4.1.3.1	Algorithm	158
5.6.4.1.3.2	Bilateral closed user group (Bcug)	158
5.6.4.1.3.3	Bit_DQM	159
5.6.4.1.3.4	CalledDTEAddress	159
5.6.4.1.3.5	CalledDTEAddressExt	159
5.6.4.1.3.6	CallingDTEAddress	160
5.6.4.1.3.7	CallingDTEAddressExt	160
5.6.4.1.3.8	ExpeditedData	160
5.6.4.1.3.9	FacilityData	160
5.6.4.1.3.10	FastSelect	161
5.6.4.1.3.11	GroupID	161
5.6.4.1.3.12	L2ConnectionMode	161
5.6.4.1.3.13	L2FrameSize	162
5.6.4.1.3.14	L2WindowSize	162
5.6.4.1.3.15	L2XID	162
5.6.4.1.3.16	L3ConnectionMode	162
5.6.4.1.3.17	L3IncomingVCCCount	162
5.6.4.1.3.18	L3OutgoingVCCCount	163
5.6.4.1.3.19	L3TwoWayVCCCount	163
5.6.4.1.3.20	NCOType	163
5.6.4.1.3.21	PacketSize	163
5.6.4.1.3.22	QOSParameters	164
5.6.4.1.3.23	ReadyFlag	165
5.6.4.1.3.24	ReceiptConfirm	165
5.6.4.1.3.25	RespondingDTEAddress	165
5.6.4.1.3.26	RespondingDTEAddressExt	165
5.6.4.1.3.27	TEI	165
5.6.4.1.3.28	UProtocol	166
5.6.4.1.3.29	UAttributeName	166
5.6.4.1.3.30	UDirection	166
5.6.4.1.3.31	UserData	166
5.6.4.1.3.32	WindowSize	167
5.6.4.1.3.33	X213Cause	167
5.6.4.1.3.34	X213Origin	167
5.6.4.1.3.35	X25Cause	167
5.6.4.1.3.36	X25Diagnostic	168
5.6.4.1.4	State diagram	168
5.6.4.1.5	Co-ordination function	169
5.6.4.1.6	Selection criteria	170
5.6.4.1.6.1	NCO Selection	170
5.6.4.1.6.1.1	Packet size negotiation	170
5.6.4.1.6.1.2	Window size negotiation	170
5.6.4.1.6.1.3	Effective packet size and window size negotiation	170
5.6.4.1.6.2	Action if no NCO available	170
5.6.4.1.7	Specific error handling and codes	170
5.6.4.1.7.1	Invalid use of User Plane messages ..	171
5.6.4.1.7.2	Other errors	171
5.6.4.1.7.3	Causes	171
5.6.4.1.8	AttributeSet	172
5.6.4.1.8.1	AttributeSet parameters	172
5.6.4.1.8.2	Static attribute content	172
5.6.4.2	T.70NL protocol	173
5.6.4.2.1	Introduction	173

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ETS 300 838 E1:2003

<https://standards.iteh.ai/catalog/standards/sist/300-838-e1-2003>

303f90de1a8c/sist-300-838-e1-2003

	5.6.4.2.2	Messages.....	173
	5.6.4.2.2.1	UDataReq.....	174
	5.6.4.2.2.2	UDataInd	174
	5.6.4.2.3	Messages parameters.....	174
	5.6.4.2.3.1	Bit_DQM.....	175
	5.6.4.2.3.2	NCOType	175
	5.6.4.2.3.3	PacketSize	175
	5.6.4.2.3.4	UProtocol.....	176
	5.6.4.2.3.5	UAttributeName.....	176
	5.6.4.2.3.6	UDirection.....	176
	5.6.4.2.4	State diagram.....	176
	5.6.4.2.5	Co-ordination function	176
	5.6.4.2.6	Selection criteria.....	176
	5.6.4.2.7	Specific error handling and codes.....	176
	5.6.4.2.8	Static attributes.....	176
	5.6.4.2.8.1	AttributeSet parameters	176
	5.6.4.2.8.2	Static attribute content.....	177
5.6.5	V.120 Protocol		177
	5.6.5.1	Introduction	177
	5.6.5.2	Messages.....	177
	5.6.5.2.1	UDataReq.....	178
	5.6.5.2.2	UDataInd	178
	5.6.5.2.3	UReadyToReceiveReq.....	178
	5.6.5.2.4	UReadyToReceiveInd	179
	5.6.5.2.5	UErrorInd.....	179
	5.6.5.3	Messages parameters	179
	5.6.5.3.1	NCOType	180
	5.6.5.3.2	ReadyFlag	180
	5.6.5.3.3	UProtocol.....	180
	5.6.5.3.4	UAttributeName.....	180
	5.6.5.3.5	UDirection.....	181
	5.6.5.3.6	Cause	181
	5.6.5.3.7	LowerLayerReference	181
	5.6.5.3.8	BlockType	181
	5.6.5.3.9	V120FunctionMode	181
	5.6.5.4	State diagram.....	182
	5.6.5.5	Co-ordination function.....	182
	5.6.5.6	Selection criteria.....	182
	5.6.5.7	Specific error handling	182
	5.6.5.8	Static attributes	182
	5.6.5.8.1	AttributeSet parameters	182
	5.6.5.8.2	Static attribute content.....	182
	5.6.5.9	Protocol specific NAF property information.....	182
	5.6.5.10	Impact on the Control Plane	182
5.6.6	T.30 protocol.....		183
	5.6.6.1	Overview of T 30 messages	183
	5.6.6.2	Sequencing of User Plane messages.....	185
	5.6.6.3	Detail of T.30 protocol messages	185
	5.6.6.3.1	UConnectReq.....	185
	5.6.6.3.2	UConnectInd	186
	5.6.6.3.3	UConnectRsp.....	186
	5.6.6.3.4	UConnectCnf.....	186
	5.6.6.3.5	UDisconnectReq	186
	5.6.6.3.6	UDisconnectInd.....	187
	5.6.6.3.7	UDataReq.....	187
	5.6.6.3.8	UDataInd	187
	5.6.6.3.9	UDataAcknowledgeReq	188
	5.6.6.3.10	UDataAcknowledgeInd.....	188
	5.6.6.3.11	UReadyToReceiveReq.....	188
	5.6.6.3.12	UReadyToReceiveInd	189
	5.6.6.3.13	UInformationInd.....	189
	5.6.6.3.14	URegisterMailBoxReq	189
	5.6.6.3.15	URegisterMailBoxCnf	190

iTeh STANDARD PREVIEW
(standards.iteh.ai)

<https://standards.iteh.ai/catalog/standards/sist/300-838-e1-2003/sist-ets-300-838-e1-2003>

	5.6.6.3.16	UDestroyMailBoxReq.....	190
	5.6.6.3.17	UDestroyMailBoxCnf.....	190
	5.6.6.3.18	ULocalPollingInd.....	190
	5.6.6.3.19	ULocalPollingRsp.....	191
	5.6.6.3.20	URemotePollingReq.....	191
	5.6.6.3.21	URemotePollingInd.....	191
	5.6.6.3.22	USwitchToVoiceModeReq.....	191
	5.6.6.3.23	USwitchToVoiceModeCnf.....	192
	5.6.6.3.24	USwitchToVoiceModeInd.....	192
	5.6.6.3.25	USwitchToVoiceModeRsp.....	192
5.6.6.4		Message parameters.....	193
	5.6.6.4.1	CalledDTEAddress.....	193
	5.6.6.4.2	NCOType.....	193
	5.6.6.4.3	DataBlock.....	194
	5.6.6.4.4	DataDescription.....	195
	5.6.6.4.5	MailBoxMnemonic.....	195
	5.6.6.4.6	MailBoxNumber.....	196
	5.6.6.4.7	MailBoxType.....	196
	5.6.6.4.8	NegotiatedCharacteristic.....	197
	5.6.6.4.9	OctetInverted.....	198
	5.6.6.4.10	PageAcknowledgement.....	198
	5.6.6.4.11	Password.....	198
	5.6.6.4.12	PollingNumber.....	198
	5.6.6.4.13	PollingFlag.....	198
	5.6.6.4.14	ReceivePageQuality.....	199
	5.6.6.4.15	RemoteDesignation.....	199
	5.6.6.4.16	SwitchFlag.....	199
	5.6.6.4.17	T30Cause.....	199
	5.6.6.4.18	T30Characteristics.....	200
	5.6.6.4.19	UseOfStrips.....	200
5.7		Message parameters.....	200
	5.7.1	AdditionInformation.....	200
	5.7.2	Algorithm.....	201
	5.7.3	BearerCap.....	201
	5.7.4	CalledNumber.....	201
	5.7.5	CalledSubaddress.....	202
	5.7.6	CallingNumber.....	202
	5.7.7	CallingSubaddress.....	203
	5.7.8	CAttributeNAme.....	203
	5.7.9	CauseToNAF.....	203
	5.7.10	CauseToPUF.....	203
	5.7.11	CDirection.....	204
	5.7.12	ChannelIdentification.....	204
	5.7.13	ChargingInfo.....	204
	5.7.14	CompletionStatus.....	205
	5.7.15	CongestionLevel.....	205
	5.7.16	ConnectedNumber.....	205
	5.7.17	ConnectedSubaddress.....	205
	5.7.18	ControllerID.....	206
	5.7.19	CPMessageMask.....	206
	5.7.20	CPPParameterMask.....	206
	5.7.21	DateTime.....	207
	5.7.22	Display.....	207
	5.7.23	DtmfDigits.....	207
	5.7.24	DtmfGapDuration.....	207
	5.7.25	DtmfOperation.....	208
	5.7.26	DtmfResult.....	208
	5.7.27	DtmfToneDuration.....	208
	5.7.28	ExtEquipAvailability.....	208
	5.7.29	ExtEquipBlockDialling.....	209
	5.7.30	ExtEquipKeyPressed.....	209
	5.7.31	ExtEquipName.....	209
	5.7.32	Facility.....	209

5.7.33	GroupID	211
5.7.34	High Layer Compatibility (HLC)	211
5.7.35	Key.....	211
5.7.36	Keypad.....	212
5.7.37	Low Layer Compatibility	212
5.7.38	ManufacturerCode	212
5.7.39	NCOID	212
5.7.40	NCOType	213
5.7.41	NotificationIndicator	213
5.7.42	NumberComplete	213
5.7.43	ProgressIndicator.....	213
5.7.44	RequestID.....	214
5.7.45	SelectorID	214
5.7.46	Signal	214
5.7.47	SuspendID	215
5.7.48	TEI	215
5.7.49	UProtocol	215
5.7.50	UAttributeName	216
5.7.51	UDirection	216
5.7.52	UserToUserInfo	216
5.7.53	V42BisCompression	216
5.7.54	AttributeSet Parameters	216
5.7.55	Administration AttributeSet parameters.....	217
5.7.56	AddressSet parameter.....	217
5.8	Selection criteria.....	218
5.8.1	NCO Selection	218
5.8.1.1	Control Plane information elements.....	218
5.8.2	Action if no NCO available.....	219
5.8.2.1	Control Plane incoming call.....	219
5.8.2.2	User Plane incoming call	219
5.9	Error checking and codes	219
5.9.1	Administration Plane.....	219
5.9.2	Control Plane	219
5.9.2.1	Invalid state for message.....	219
5.9.2.2	Mandatory parameters	220
5.9.2.3	Optional Parameter Content Error	220
5.9.3	Errors in facility requests	220
5.9.4	User Plane	220
5.9.5	Function return codes	220
5.9.6	Administration Plane return code.....	221
5.9.7	Control Plane causes.....	223
5.9.8	User Plane causes.....	224
5.10	Security	224
5.10.1	General aspects of security in ISDN.....	225
5.10.2	Security in Profile A.....	225
5.10.3	Increasing security in Profile A	225
6	Profile B	226
6.1	Reader guidance.....	226
6.2	Message overview.....	226
6.2.1	General message protocol	226
6.2.2	Type definitions.....	227
6.2.3	Message structure	227
6.2.4	Manufacturer specific expansion	228
6.2.5	Table of messages	228
6.3	Exchange mechanism.....	230
6.3.1	Message queues	230
6.3.2	Operations on message queues.....	231
6.3.2.1	Registering an application.....	231
6.3.2.2	Messages from application to Profile B.....	231
6.3.2.3	Messages from Profile B to application.....	231
6.3.2.4	Releasing an application	231
6.3.2.5	Other operations	232

	6.3.2.6	Manufacturer specific expansion	232
	6.3.3	Table of operations	232
6.4		Administration Plane	232
6.5		Control Plane	232
6.6		User Plane	233
6.7		Message descriptions	233
	6.7.1	ALERT_REQ	234
	6.7.2	ALERT_CONF	234
	6.7.3	CONNECT_REQ	234
	6.7.4	CONNECT_CONF	235
	6.7.5	CONNECT_IND	235
	6.7.6	CONNECT_RESP	236
	6.7.7	CONNECT_ACTIVE_IND	237
	6.7.8	CONNECT_ACTIVE_RESP	238
	6.7.9	CONNECT_B3_ACTIVE_IND	238
	6.7.10	CONNECT_B3_ACTIVE_RESP	238
	6.7.11	CONNECT_B3_REQ	238
	6.7.12	CONNECT_B3_CONF	239
	6.7.13	CONNECT_B3_IND	239
	6.7.14	CONNECT_B3_RESP	240
	6.7.15	CONNECT_B3_T90_ACTIVE_IND	240
	6.7.16	CONNECT_B3_T90_ACTIVE_RESP	241
	6.7.17	DATA_B3_REQ	241
	6.7.18	DATA_B3_CONF	241
	6.7.19	DATA_B3_IND	242
	6.7.20	DATA_B3_RESP	243
	6.7.21	DISCONNECT_B3_REQ	244
	6.7.22	DISCONNECT_B3_CONF	244
	6.7.23	DISCONNECT_B3_IND	244
	6.7.24	DISCONNECT_B3_RESP	245
	6.7.25	DISCONNECT_REQ	245
	6.7.26	DISCONNECT_CONF	245
	6.7.27	DISCONNECT_IND	246
	6.7.28	DISCONNECT_RESP	246
	6.7.29	FACILITY_REQ	247
	6.7.30	FACILITY_CONF	247
	6.7.31	FACILITY_IND	247
	6.7.32	FACILITY_RESP	248
	6.7.33	INFO_REQ	248
	6.7.34	INFO_CONF	249
	6.7.35	INFO_IND	249
	6.7.36	INFO_RESP	250
	6.7.37	LISTEN_REQ	250
	6.7.38	LISTEN_CONF	251
	6.7.39	MANUFACTURER_REQ	251
	6.7.40	MANUFACTURER_CONF	252
	6.7.41	MANUFACTURER_IND	252
	6.7.42	MANUFACTURER_RESP	252
	6.7.43	RESET_B3_REQ	253
	6.7.44	RESET_B3_CONF	253
	6.7.45	RESET_B3_IND	254
	6.7.46	RESET_B3_RESP	254
	6.7.47	SELECT_B_PROTOCOL_REQ	254
	6.7.48	SELECT_B_PROTOCOL_CONF	254
6.8		Parameter descriptions	255
	6.8.1	Additional Info	255
	6.8.2	B-channel Information	256
	6.8.3	B Protocol	256
	6.8.4	B1 Protocol	257
	6.8.5	B2 Protocol	257
	6.8.6	B3 Protocol	257
	6.8.7	B1 Configuration	259
	6.8.8	B2 Configuration	260