



Designation: E929 – 83 (Reapproved 2005)

# Standard Test Method for Measuring Electrical Energy Requirements of Processing Equipment<sup>1</sup>

This standard is issued under the fixed designation E929; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon ( $\epsilon$ ) indicates an editorial change since the last revision or reapproval.

## 1. Scope

1.1 This test method covers the determination of the energy and power requirements of processing equipment using an electrical metering system.

1.2 This test method can be used to measure energy and power requirements of processing equipment driven by an electrical motor operating on alternating current.

1.3 This test method includes instructions for installation and checkout of the energy metering system, procedures for measuring and recording energy usage, and methods for calculating the average gross power, average freewheeling power, and average net power requirements of processing equipment.

1.4 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.* For hazard statements, see Section 6.

## 2. Terminology Definitions

2.1 *electrical metering system*—a system composed of current and potential transformers and a wattmeter electrically connected in such a manner so as to measure the energy usage of a piece of equipment driven by an electric motor.

2.2 *freewheeling condition*—a piece of equipment under an unloaded condition wherein the electrical energy is dissipated due to friction and windage.

2.3 *freewheeling power*—power requirement of a piece of equipment under unloaded, or freewheeling, conditions.

2.4 *gross energy*—energy usage of a piece of equipment operating under loaded conditions as measured using an electrical metering system.

2.5 *gross power*—power requirement of a piece of equipment under loaded conditions.

2.6 *loaded condition*—equipment doing processing work on solids, liquids, or gases, or all of these, (for example,

moving material, changing its characteristics, or separating it into different streams).

2.7 *net power*—the difference between gross power and freewheeling power; net power is the power required for processing.

2.8 *specific energy*—energy consumption expressed on the basis of unit mass of throughput.

2.9 *unloaded condition*—equipment not doing processing work (for example, moving, changing the characteristics of, or separating materials), but operating in a freewheeling, or idling, condition.

## 3. Summary of Test Method

3.1 An electrical metering system is installed and checked.

3.2 The metering instrumentation and processing equipment is allowed to warmup.

3.3 Using the electrical metering system, the energy used by the processing equipment under no-load and loaded conditions is measured and recorded.

3.4 The average gross power, average freewheeling power, and average net power required by the equipment is calculated.

## 4. Significance and Use

4.1 Energy usage and power requirements of processing equipment are important from the standpoint of determining if equipment is operating within specification and meeting performance criteria.

4.2 Having determined the energy usage and power requirements of the processing equipment using this method, specific energy may be calculated, with the use of system throughput, and used as one criterion to compare the performance of similar pieces of equipment operating under similar operating conditions.

4.3 Measurements of energy usage can be used for the purpose of identifying inefficient electrical motors and processing equipment.

## 5. Apparatus

5.1 *Calibrated Watthour Meter.*

5.2 *Volt-Ammeter.*

5.3 *Stopwatch*, accurate to 0.1 s.

5.4 *Incandescent Lamps*, for use as a known load.

5.5 *Current Transformers (CTs).*

<sup>1</sup> This test method is under the jurisdiction of ASTM Committee D34 on Waste Management and is the direct responsibility of Subcommittee D34.03 on Treatment, Recovery and Reuse.

Current edition approved Feb. 1, 2005. Published March 2005. Originally approved in 1983. Last previous edition approved in 1999 as E929-83(1999). DOI: 10.1520/E0929-83R05.



Wathour Meter	Serial No.	Type	Class	$K_p$	Accuracy	Date Calibrated
Current Transformer	Serial No.	Type	Ratio		Accuracy Class	Date Calibrated
Potential Transformer	Serial No.	Type	Ratio		Accuracy Class	Date Calibrated

FIG. 1 Electrical Metering System Installation Form

### 5.6 Potential (Voltage) Transformers (PTs).

## 6. Hazards

6.1 When installing metering equipment always de-energize the load side of the processing equipment by locking out the main switch on the electrical control panel.

6.2 Dangerous high voltage results from open current transformer secondaries. Therefore, to avoid equipment damage and electrical shock, use circuit-closing devices or equipment to short circuit the secondaries of current transformers.

6.3 Always observe the polarity markings of current and potential transformers during their installations to ensure proper connection of the metering equipment. These polarity markings are usually denoted on the transformers as white dots, blocks, or “HX” marks.

6.4 Closely observe polarities, and check connections of instrument transformers to the wathour meter.

## 7. Equipment Calibration

7.1 Calibrate all meters and instrument transformers used for energy measurements in accordance with standard practice of calibration.<sup>2,3,4,5</sup> The accuracy of the meters and transformers shall be duly noted on the Electrical Metering Service Installation Form, see Fig. 1.

## 8. Procedure

### 8.1 Meter Installation:

8.1.1 For the piece of equipment to be tested, determine the type of electrical service (for example, single-phase two-wire, three-phase three-wire), voltage requirements, full load power, and current rating of the motor from the motor nameplate or manufacturer’s specifications. For the purpose of meter selection and installation, it can be assumed that 1 hp = 1 kW = 1 kVA. Select the metering system that is compatible with the type of electrical service and with the load on the motor.

8.1.1.1 Self-contained single phase wathour meter can be used when the load is less than 48 kVA.

8.1.1.2 Self-contained polyphase meters can be used when the load is less than 96 kVA (except 480 V delta).

8.1.1.3 Above 48 or 96 kVA, respectively, for single and polyphase loads, use transformer type wathour meters.

8.1.2 For any meter installation, do not exceed the meter’s overload capability listed as follows:

8.1.2.1 *Class 10*—Nominal 2.5-A meter, 10-A overload capability.

8.1.2.2 *Class 20*—Nominal 2.5-A meter, 20-A overload capability.

8.1.2.3 *Class 60*—Nominal 15-A meter, 60-A overload capability.

8.1.2.4 *Class 100*—Nominal 15-A meter, 100-A overload capability.

8.1.2.5 *Class 200*—Nominal 30-A meter, 200-A overload capability.

8.1.2.6 *Class 320*—Nominal 50-A meter, 320-A overload capability.

8.1.3 *Instrument Transformers*—For meter installations requiring instrument transformers (that is, when the primary current or voltage, or both, exceed the operating specifications of the wathour meter), use current and potential (voltage) transformers. Select current and potential transformers with an accuracy class rating of 0.3 (0.3 %) and compatibility with the primary electrical service. If transformers with an accuracy class of 0.3 are not available, substitute another accuracy class and note on the Electrical Metering System Installation Form (Fig. 1).

8.1.4 *Current Transformers*—Calculate the current transformer ratio (CTR) using the following definition.

$$\text{CTR} = \frac{\text{Primary Current}}{\text{Wathour Meter Nominal Current Rating}} \quad (1)$$

Generally, current transformer ratios are denoted such that the secondary current will be 5 amperes when rated amperes are flowing in the primary circuit.

8.1.5 *Potential Transformers*—Potential transformers are used with wathour meters where the primary circuit voltage exceeds the rating of the meter, generally above 480 V and frequently above 240 V. The potential transformer ratio (PTR) can be calculated using the following definition.

<sup>2</sup> *Meter and Instrument Transformer Application Guide*, 5th Edition, Westinghouse Electric Company, Raleigh, NC.

<sup>3</sup> *Metermen’s Handbook*, Duncan Electric Company, Lafayette, IN, No. 5M, April 1976.

<sup>4</sup> *Electrical Metermen’s Handbook*, Edison Electric Institute, New York, NY.

<sup>5</sup> *Guide for Installing General Electric Wathour Meters*, General Electric Company, Somersworth, NH, April 1976.

PTR = Primary Voltage/Watthour Meter Nominal Voltage Rating (2)

8.1.6 Phase relations will be retained if the polarity markings are observed and the current in the potential circuit is considered to flow in on the primary terminal polarity mark and out on the corresponding secondary terminal polarity mark.

8.1.7 The Electrical Metering Service Installation Form (Fig. 1) is recommended for documenting the equipment used for the test.

8.1.8 Mount instrument transformers and watthour meters in an upright position and in a area free from heavy vibration.

8.2 Checking Meter Installation:

8.2.1 Check meter installations for correct connections as soon as the wiring is completed. For installation of self-contained watthour meters this is comparatively simple. It is only necessary to see that line and load wires, and potential taps where required, are connected to the proper points. A quick check on the operation under load conditions may be made to see that the meter is rotating in the proper direction and at approximately the right speed.

8.2.2 Where instrument transformers are used, the installation is more liable to incorrect connections and should, therefore, be checked carefully. It is possible to have incorrect registration even with proper connections, due to a wrong transformer polarity marking, a reversed meter coil, incorrect transformer ratio marking, etc. It is generally not possible to completely check all of these items in the field; however, by making several of the tests listed in Annex A1, it will be possible to determine most of the inconsistencies or incorrect connections that might occur.

8.3 Measurements:

8.3.1 After installation and check-out of the energy metering equipment, measure and record the energy used by the equipment under no-load and loaded conditions in order to determine the average gross and freewheel power requirements of the equipment.

8.3.2 Determine the average freewheeling power of the equipment to be tested by measuring the energy usage of the motor under no-load conditions over a specified time interval. After a suitable warm-up period, time ten disk revolutions to establish the freewheel energy usage at the beginning and end of the test. Prior to taking the first measurement for determining the freewheel energy usage, take two preliminary freewheel energy measurements (10 disk revolutions) approximately 5 min apart. If the preliminary readings differ by more than 10 % or more, extend the warm-up period until two consecutive preliminary measurements fall within 10 % of one another.

8.3.3 After the suitable warm-up period, take and record three initial disk timings of ten revolutions each. Likewise, after the conclusion of the load tests, take and record three final disk timings of ten revolutions each. An Energy Measurement Data Sheet for recording the freewheeling energy measurements is given in Fig. 2. The freewheeling power calculations are described in Section 9.

8.3.4 Determine the gross energy usage ( $E_g$ ) of the equipment undergoing testing by calculating the difference in the register readings or by counting the number of disk revolutions

of the watthour meter while operating the processing equipment under loaded conditions for a suitable measuring period. A suitable measuring period consists of a time span that is long enough to attain at least one disk revolution or at least one complete rotation of the least significant register dial, whichever applies to the particular test situation.

8.3.5 An Energy Measurement Data Sheet for recording the measured data from the tests conducted under loaded conditions is given in Fig. 2. The calculations for determining power demand under loaded conditions are described in Section 9.

8.3.6 Alternative Procedure for Constant Load Power Measurements—If the processing equipment exhibits a constant load as evidenced by power fluctuations of less than  $\pm 10\%$  of the average reading (that is, as may be the case for a conveyor or blower, etc.), a clamp-on wattmeter, an analog wattmeter, or recording wattmeter can be used to measure power if the metering equipment and electrical service can be made compatible with one another. For this procedure, power measurements for both unloaded (freewheeling) and loaded conditions should be made in sufficient numbers so that a reliable average reading can be calculated. The power requirement is read directly from the instrument. The measurements may be recorded on the Gross and Net Power Data Sheet, Fig. 3.

9. Calculation

9.1 Average Freewheeling Power Requirements:

9.1.1 Calculate freewheeling power ( $P_{fw}$ ), in kilowatts, as follows:

$$P_{fw} = 600 (Kh)(CTR)(PTR)/t \tag{3}$$

where:

$Kh$  = disk constant of the watthour meter (kWh/disk revolution),

$CTR$  = current transformer ratio,

$PTR$  = potential transformer ratio, and

$t$  = time duration for 10 disk revolutions (minutes).

9.1.2 Average the three initial freewheeling power measurements and the three final measurements to give the average initial freewheeling power ( $\bar{P}_{fwi}$ ) and final freewheeling power ( $\bar{P}_{fwf}$ ). Then average the average values ( $\bar{P}_{fwi}$  and  $\bar{P}_{fwf}$ ) and use as the average freewheeling power requirement  $\bar{P}_{fw}$  of the equipment corresponding to the interval of gross energy measurement. Record the average value for the freewheeling power in the column titled “Average Freewheel Power” of the Gross and Net Power Data Sheet (see Fig. 3).

9.1.3 Calculate average initial freewheel power ( $\bar{P}_{fwi}$ ) as follows:

$$\bar{P}_{fwi} = (P_{fwi_a} + P_{fwi_b} + P_{fwi_c})/3 \tag{4}$$

where:

$P_{fwi_a}$ ,  $P_{fwi_b}$ , and  $P_{fwi_c}$  are the three initial freewheeling power measurements.

9.1.4 Calculate average final freewheel power ( $\bar{P}_{fwf}$ ) as follows:

$$\bar{P}_{fwf} = (P_{fwf_x} + P_{fwf_y} + P_{fwf_z})/3 \tag{5}$$