



**GEO-Mobile Radio Interface Specifications (Release 3);  
Third Generation Satellite Packet Radio Service;  
Part 4: Radio interface protocol specifications;  
Sub-part 8: Mobile Radio Interface Layer 3 Specifications;  
GMR-1 3G 44.008**

iTerminated PREVIEW  
<https://standards.etsi.org/standards-releases/101-376-series/101-376-4-8-v3.4.1-6e38-4346-b0b3-adc2a29092d3lects-11521>

---

ReferenceRTS/SES-00374-4-8

---

## Keywords

3G, GMPRS, GMR, GPRS, GSM, GSO,  
interface, layer 3, management, MES, MMSS,  
mobile, mobility, MSS, radio, satellite, S-PCN

**ETSI**

650 Route des Lucioles  
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C  
Association à but non lucratif enregistrée à la  
Sous-Préfecture de Grasse (06) N° 7803/88

---

**Important notice**

The present document can be downloaded from:  
<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<http://portal.etsi.org/tb/status/status.asp>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

---

**Copyright Notification**

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2015.  
All rights reserved.

**DECT™, PLUGTESTS™, UMTS™** and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.  
**3GPP™** and **LTE™** are Trade Marks of ETSI registered for the benefit of its Members and  
of the 3GPP Organizational Partners.

**GSM®** and the GSM logo are Trade Marks registered and owned by the GSM Association.

## Contents

Intellectual Property Rights .....	14
Foreword.....	14
Modal verbs terminology.....	15
Introduction .....	15
<b>1 Scope .....</b>	<b>17</b>
1.1 Scope of the present document.....	17
1.2 Application to the interface structures.....	17
1.3 Structure of Layer 3 procedures .....	17
1.4 Use of logical channels.....	17
1.5 Overview of control procedures .....	18
1.5.1 List of procedures .....	18
1.6 Applicability of implementations .....	20
1.6.1 Packet services.....	20
<b>2 References .....</b>	<b>21</b>
2.1 Normative references .....	21
2.2 Informative references.....	23
<b>3 Definitions and abbreviations.....</b>	<b>24</b>
3.1 Definitions.....	24
3.2 Abbreviations .....	25
3.3 Random values .....	25
<b>4 Radio resource management procedures.....</b>	<b>25</b>
4.1 Overview/general .....	25
4.1.0 General.....	25
4.1.1 General (A/Gb mode only).....	25
4.1.2 Services provided to upper layers .....	26
4.1.2.1 Idle mode .....	26
4.1.2.2 Establishment and release of an RR connection.....	26
4.1.2.3 RR connected mode .....	26
4.1.2.4 Packet idle mode (A/Gb mode only).....	26
4.1.2.5 Packet transfer mode (A/Gb mode only).....	26
4.1.3 Services required from data link and physical layers.....	26
4.1.4 RR states .....	26
4.1.5 Change of dedicated channels.....	26
4.1.6 Procedure for service request and contention resolution .....	26
4.2 Idle mode procedures .....	26
4.2.1 Mobile Earth Station (MES) side.....	26
4.2.2 Network side.....	27
4.2.2.1 System information broadcasting.....	27
4.2.2.1.0 General .....	27
4.2.2.1.1 Classes and segments .....	27
4.2.2.1.2 Transmission schedules .....	28
4.2.2.1.3 Change information .....	28
4.2.2.1.4 Encoding and decoding rules.....	29
4.2.2.1.5 Future extensions.....	31
4.2.2.1.6 Anchored(A) and Temporary(T) BCCH (A/Gb mode only) .....	32
4.2.2.1.7 Multiplexing of CCCH and PCCCH (A/Gb mode only) .....	32
4.2.2.1.7a Multiplexing of CCCH and PCCCH (Iu mode only) .....	32
4.2.2.2 GPS satellite ephemeris data broadcasting.....	33
4.2.2.2.0 General .....	33
4.2.2.2.1 GPS satellite ephemeris Earth Centered Earth fixed coordinates on GBCH .....	33
4.2.2.2.2 GPS satellite ephemeris Earth Centered Earth fixed coordinates on GBCH3 .....	34
4.2.2.2.3 GPS satellite ephemeris Keplerian Coordinates on GBCH3 .....	35
4.2.2.3 GPS almanac data transmission .....	36
4.3 RR connection establishment .....	36

4.3.1	RR connection establishment initiated by the Mobile Earth Station (MES): immediate assignment procedure .....	36
4.3.1.0	General .....	36
4.3.1.1	Spot beam selection to access the network .....	36
4.3.1.2	Permission to access the network .....	37
4.3.1.3	Initiation of the immediate assignment procedure (A/Gb mode only) .....	37
4.3.1.3a	Initiation of the immediate assignment procedure (Iu mode only) .....	38
4.3.1.4	Answer from the network .....	39
4.3.1.4.1	On receipt of a CHANNEL REQUEST message (A/Gb mode only) .....	39
4.3.1.4.2	IMMEDIATE ASSIGNMENT from network for MES requesting circuit service (A/Gb mode only) .....	39
4.3.1.4.3	Immediate Assignment from network for MES requesting packet service .....	40
4.3.1.4.4	Assignment rejection (IMMEDIATE ASSIGNMENT REJECT from network) (A/Gb mode only) .....	40
4.3.1.4.4a	Assignment rejection (IMMEDIATE ASSIGNMENT REJECT from network) (Iu mode only) .....	40
4.3.1.4.5	Extended immediate assignment procedure (A/Gb mode) .....	43
4.3.1.4.6	Position verification procedure (A/Gb mode only) .....	44
4.3.1.4.6a	Position verification procedure (Iu mode only) .....	44
4.3.1.5	Assignment procedure completion (A/Gb mode only) .....	45
4.3.1.6	Abnormal cases (A/Gb mode only) .....	45
4.3.2	RR connection establishment initiation by the network: paging procedure .....	45
4.4	RR connection transfer phase (A/Gb mode only) .....	45
4.5	RR connection release procedure (A/Gb mode only) .....	45
4.6	Receiving an RR STATUS message by an RR entity .....	45
4.7	RR procedures on CCCH related to temporary block flow establishment .....	45
4.7.0	General .....	45
4.7.1	Packet paging procedure using CCCH .....	45
4.7.1.0	General .....	45
4.7.1.1	Packet paging initiation by the network .....	45
4.7.1.1a	Packet paging initiation by the network (Iu Mode only) .....	46
4.7.1.2	On receipt of a packet paging request .....	47
4.7.1.3	Alerting initiation by the network (Iu mode only) .....	47
4.7.1.4	Page response by the MES due to alerting (Iu mode only) .....	47
4.7.2	Packet access procedure using CCCH .....	48
4.7.2.0	General .....	48
4.7.2.1	Entering the packet transfer mode: packet access procedure .....	48
4.7.2.1.0	General .....	48
4.7.2.1.1	Permission to access the network .....	48
4.7.2.1.2	Initiation of the packet access procedure: channel request (A/Gb mode only) .....	48
4.7.2.1.2a	Initiation of the packet access procedure: channel request (Iu mode only) .....	48
4.7.2.1.3	Packet immediate assignment .....	49
4.7.2.1.4	Packet access completion .....	51
4.7.2.1.5	Abnormal cases .....	51
4.7.2.2	Sending an RLC/MAC control message: single block packet access procedure .....	51
4.7.3	Packet downlink assignment procedure using CCCH (A/Gb mode only) .....	52
4.7.3.0	General .....	52
4.7.3.1	Entering the packet transfer mode: packet downlink assignment procedure .....	52
4.7.3.1.1	General .....	52
4.7.3.1.2	Initiation of the packet downlink assignment procedure .....	52
4.7.3.1.3	Packet downlink assignment completion .....	53
4.7.3.1.4	Abnormal cases .....	53
4.7.3.2	Sending an RLC/MAC control message: single block packet downlink assignment procedure .....	53
4.8	GMPRS suspend procedure on CCCH (A/Gb mode only) .....	53
4.8.0	General .....	53
4.8.1	Initiation of GMPRS suspend procedure .....	54
4.8.2	Completion of GMPRS suspend procedure .....	54
4.8.3	Abnormal cases .....	54
4.9	GMPRS resume procedure on CCCH (A/Gb mode only) .....	54
4.9.0	General .....	54
4.9.1	Initiation of GMPRS resume procedure .....	54
4.9.2	Completion of GMPRS resume procedure .....	55

4.9.3	Abnormal cases.....	55
5	Elementary procedures for mobility management .....	55
5.1	General .....	55
5.1.0	Common .....	55
5.1.1	MM and GMM procedures .....	55
5.1.1.1	Types of MM and GMM procedures .....	55
5.1.1.1.0	General .....	55
5.1.1.1.1	Integrity Checking of Signalling Messages in the Mobile Station (Iu mode only).....	55
5.1.1.1.1a	Integrity protection for emergency call (Iu mode only).....	55
5.1.1.2	MM-GMM co-ordination for GPRS MESs (A/Gb mode only).....	56
5.1.1.2.1	GPRS MS operating in mode A or B in a network that operates in mode I.....	56
5.1.1.2.2	GPRS MS operating in mode A or B in a network that operates in mode II or III.....	56
5.1.1.3	Core Network System Information for MM (Iu mode only).....	56
5.1.1.4	Core Network System Information for GMM (Iu mode only).....	56
5.1.2	MM sublayer states.....	56
5.1.3	GPRS mobility management (GMM) sublayer states.....	56
5.1.3.0	General .....	56
5.1.3.1	GMM states in the MES.....	56
5.1.3.1.0	General .....	56
5.1.3.1.1	Main states.....	56
5.1.3.1.2	Substates of state GMM-DEREGISTERED.....	57
5.1.3.1.3	Substates of state GMM-REGISTERED.....	58
5.1.3.2	GPRS update status .....	60
5.1.3.3	GMM mobility management states on the network side .....	61
5.1.3.3.0	General .....	61
5.1.3.3.1	Main States .....	61
5.1.3.3.2	Substates of state GMM-REGISTERED .....	61
5.2	Behaviour of the MES in MM idle state, GMM-DEREGISTERED state and GMM-REGISTERED state .....	62
5.2.0	General.....	62
5.2.1	Primary service state selection.....	62
5.2.1.1	Selection of the service state after power-on.....	62
5.2.1.2	Other cases .....	62
5.2.2	Detailed description of MES behaviour in MM idle state (A/Gb mode only).....	62
5.2.3	Service state when back to state MM idle from another state (A/Gb mode only) .....	63
5.2.4	Service state after position verification.....	63
5.2.5	Behaviour in state GMM-DEREGISTERED.....	63
5.2.5.0	General .....	63
5.2.5.1	Primary substate selection .....	63
5.2.5.1.1	Selection of the substate after power on or enabling the MESs GPRS capability .....	63
5.2.5.1.2	Other cases .....	64
5.2.5.2	Detailed description of the MES behaviour in state GMM-DEREGISTERED .....	64
5.2.5.2.0	General .....	64
5.2.5.2.1	Substate, NORMAL-SERVICE .....	64
5.2.5.2.2	Substate, ATTEMPTING-TO-ATTACH .....	64
5.2.5.2.3	Substate, LIMITED-SERVICE .....	64
5.2.5.2.4	Substate, NO-IMSI .....	64
5.2.5.2.5	Substate, NO-CELL .....	64
5.2.5.2.6	Substate, PLMN-SEARCH .....	64
5.2.5.2.7	Substate, ATTACH-NEEDED .....	64
5.2.5.2.8	Substate, SUSPENDED (A/Gb mode only) .....	65
5.2.5.2.9	Substate, INVALID-POSITION (A/Gb mode only) .....	65
5.2.5.2.10	Substate, NORMAL-SERVICE-DARK-BEAM (A/Gb mode only).....	65
5.2.5.3	Substate when back to state GMM-DEREGISTERED from another GMM state .....	65
5.2.6	Behaviour in state GMM-REGISTERED .....	66
5.2.6.0	General .....	66
5.2.6.1	Detailed description of the MES behaviour in state GMM-REGISTERED .....	66
5.2.6.1.0	General .....	66
5.2.6.1.1	Substate, NORMAL-SERVICE .....	66
5.2.6.1.2	Substate, SUSPENDED (A/Gb mode only) .....	66
5.2.6.1.3	Substate, UPDATE-NEEDED.....	66
5.2.6.1.4	Substate, ATTEMPTING-TO-UPDATE .....	67

5.2.6.1.5	Substate, NO-CELL-AVAILABLE .....	67
5.2.6.1.6	Substate, LIMITED-SERVICE .....	67
5.2.6.1.7	Substate, ATTEMPTING-TO-UPDATE-MM .....	67
5.2.6.1.8	Substate, NORMAL-SERVICE-DARK-BEAM (A/Gb mode only).....	67
5.2.6.1.9	Substate, NORMAL-SERVICE-ILLUMINATION-INITIATED (A/Gb mode only) .....	67
5.2.6.1.10	Substate, ROUTING-AREA-UPDATE-DARK-BEAM (A/Gb mode only).....	67
5.2.6.1.11	Substate, ROUTING-AREA-UPDATE-ILLUMINATION-INITIATED (A/Gb mode only).....	67
5.3	MM common procedures .....	68
5.3.1	TMSI reallocation procedure (A/Gb mode only).....	68
5.3.2	Authentication procedure.....	68
5.3.3	Identification procedure.....	68
5.3.4	IMSI detach procedure (A/Gb mode only) .....	68
5.3.5	Abort procedure (A/Gb mode only).....	68
5.3.6	MM information procedure (A/Gb mode only) .....	68
5.4	MM specific procedures (A/Gb mode only).....	68
5.5	Connection management sublayer service provision (A/Gb mode only) .....	68
5.5.1	MM connection establishment.....	68
5.5.1.0	General .....	68
5.5.1.1	MM connection establishment initiated by the MES .....	68
5.5.1.2	Abnormal cases .....	68
5.5.1.3	MM connection establishment initiated by the network .....	68
5.5.1.4	Abnormal cases .....	68
5.5.1.5	MM connection establishment for emergency calls.....	68
5.5.1.6	Call reestablishment .....	68
5.5.1.7	Forced release during MO MM connection establishment .....	69
5.5.1.8	Optimal routing .....	69
5.5.2	MM connection information transfer phase .....	69
5.5.3	MM connection release .....	69
5.6	Receiving an MM STATUS message by an MM entity .....	70
5.7	Elementary mobility management procedures for GPRS services.....	70
5.7.1	General .....	70
5.7.1.0	Common .....	70
5.7.1.1	Lower layer failure .....	70
5.7.1.2	Ciphering of messages (A/Gb mode only) .....	70
5.7.1.3	P-TMSI signature .....	70
5.7.1.4	Radio resource sublayer address handling .....	70
5.7.1.4.0	General .....	70
5.7.1.4.1	Radio resource sublayer address handling (A/Gb mode only) .....	70
5.7.1.5	P-TMSI handling .....	70
5.7.1.6	Change of network mode of operation .....	70
5.7.1.7	Intersystem change between A/Gb mode and Iu mode .....	70
5.7.1.8	List of forbidden PLMN for GPRS service .....	70
5.7.2	GPRS Mobility management timers and UMTS PS signalling connection control .....	71
5.7.2.1	READY timer behaviour .....	71
5.7.2.1.1	READY timer behaviour (A/Gb mode only) .....	71
5.7.2.1.2	READY timer behaviour (Iu mode only) .....	71
5.7.2.2	Periodic routing area updating .....	71
5.7.2.3	PMM-IDLE mode and PMM-CONNECTED mode (Iu mode only) .....	72
5.7.2.4	Handling of <i>Force to standby</i> in Iu mode (Iu mode only) .....	72
5.7.2.5	RA Update procedure for Signalling Connection Re-establishment (Iu mode only) .....	72
5.7.2.6	Cell Update triggered by low layers .....	72
5.7.3	GPRS attach procedure .....	72
5.7.3.0	General .....	72
5.7.3.1	GPRS attach procedure for GPRS services .....	73
5.7.3.1.0	General .....	73
5.7.3.1.1	GPRS attach procedure initiation .....	73
5.7.3.1.2	GMM common procedure initiation .....	73
5.7.3.1.3	GPRS attach accepted by the network .....	73
5.7.3.1.4	GPRS attach not accepted by the network .....	73
5.7.3.1.5	Abnormal cases in the MES .....	74
5.7.3.1.6	Abnormal cases on the network side .....	74
5.7.3.2	Combined GPRS attach procedure for GPRS and non-GPRS services (A/Gb mode only) .....	75

5.7.4	GPRS detach procedure .....	75
5.7.4.0	General .....	75
5.7.4.1	MES initiated GPRS detach procedure .....	75
5.7.4.1.1	MES initiated GPRS detach procedure initiation .....	75
5.7.4.1.2	MES initiated GPRS detach procedure completion for GMPSR services only .....	75
5.7.4.1.3	MES initiated combined GPRS detach procedure completion .....	75
5.7.4.1.4	Abnormal cases in the MES .....	75
5.7.4.2	Network initiated GMPSR detach procedure .....	75
5.7.4.2.1	Network initiated GMPSR detach procedure initiation .....	75
5.7.4.2.2	Network initiated GMPSR detach procedure completion by the MES .....	75
5.7.4.2.3	Network initiated GMPSR detach procedure completion by the network .....	76
5.7.4.2.4	Abnormal cases on the network side .....	76
5.7.5	Routing area updating procedure .....	77
5.7.5.0	General .....	77
5.7.5.1	Normal and periodic routing area updating procedure .....	78
5.7.5.1.0	General .....	78
5.7.5.1.1	Normal and periodic routing area updating procedure initiation .....	78
5.7.5.1.2	GMM Common procedure initiation .....	78
5.7.5.1.3	Normal and periodic routing area updating procedure accepted by the network .....	78
5.7.5.1.4	Normal and periodic routing area updating procedure not accepted by the network .....	78
5.7.5.1.5	Abnormal cases in the MES .....	79
5.7.5.1.6	Abnormal cases on the network side .....	80
5.7.5.2	Combined routing area updating procedure .....	80
5.7.6	P-TMSI reallocation procedure .....	80
5.7.7	Authentication and ciphering procedure .....	80
5.7.8	Identification procedure .....	80
5.7.9	Paging procedure .....	80
5.7.9.1	Paging for GMPSR services .....	80
5.7.9.1.0	General .....	80
5.7.9.1.1	Paging for packet services using P-TMSI .....	80
5.7.9.1.2	Paging for packet services using IMSI .....	80
5.7.9.2	Paging for non-GMPSR services .....	81
5.7.10	Receiving a GMM STATUS message by a GMM entity .....	81
5.7.11	Void .....	81
5.7.12	GMM Information procedure .....	81
5.7.13	Service Request procedure (Iu mode only) .....	81
6	Elementary procedures for circuit-switched call control (A/Gb mode only) .....	81
7	Support of packet services .....	81
8	Examples of structured procedures .....	81
8.0	Common .....	81
8.1	General .....	81
8.1.0	Common .....	81
8.1.1	Paging and alert request .....	82
8.1.2	Immediate assignment .....	82
8.1.3	Service request and contention resolution .....	82
8.1.4	Authentication .....	82
8.1.5	Ciphering mode setting (A/Gb mode only) .....	82
8.1.6	Transaction phase (A/Gb mode only) .....	82
8.1.7	Channel release (A/Gb mode only) .....	82
8.2	Abnormal cases (A/Gb mode only) .....	82
8.3	Selected examples (A/Gb mode only) .....	82
8.3.0	General .....	82
8.3.1	Location updating .....	82
8.3.2	Mobile originating call establishment .....	82
8.3.3	Mobile terminating call establishment .....	82
8.3.4	Call clearing .....	82
8.3.5	DTMF protocol control .....	82
8.3.6	Handover .....	82
8.3.7	In-call modification .....	83
8.3.8	Call reestablishment .....	83

8.3.9	Mobile-to-mobile call establishment .....	83
8.3.10	Multisatellite optimal routing for call establishment .....	83
9	Handling of unknown, unforeseen, and erroneous protocol data .....	83
10	Message functional definitions and contents.....	83
10.0	General .....	83
10.1	Messages for radio resources management .....	84
10.1.0	General.....	84
10.1.1	Additional assignment (A/Gb mode only) .....	85
10.1.2	Assignment command 1 and assignment command 2 (A/Gb mode only) .....	85
10.1.2.1	Assignment command 1 .....	85
10.1.2.2	Assignment command 2 .....	85
10.1.3	Assignment complete (A/Gb mode only) .....	85
10.1.4	Assignment failure (A/Gb mode only).....	85
10.1.5	Channel mode modify (A/Gb mode only) .....	85
10.1.6	Channel mode modify acknowledge (A/Gb mode only) .....	86
10.1.7	Channel release (A/Gb mode only).....	86
10.1.8	Channel request .....	86
10.1.8.0	General .....	86
10.1.8.1	Extended channel request (A/Gb mode only) .....	86
10.1.8.2	Channel request Type 1 (A/Gb mode only) .....	86
10.1.8.3	Channel request Type 2 (A/Gb mode only) .....	90
10.1.8.4	Channel Request Type 3 (Iu mode only).....	92
10.1.9	Ciphering mode command (A/Gb mode only).....	95
10.1.10	Ciphering mode complete (A/Gb mode only).....	95
10.1.11	Classmark change (A/Gb mode only) .....	95
10.1.12	Classmark enquiry (A/Gb mode only).....	95
10.1.13	Frequency redefinition (A/Gb mode only).....	96
10.1.14	Handover access (A/Gb mode only) .....	96
10.1.15	Handover command (A/Gb mode only).....	96
10.1.16	Handover complete (A/Gb mode only).....	96
10.1.17	Handover failure (A/Gb mode only).....	96
10.1.18	Immediate assignment .....	96
10.1.18.1	Immediate assignment (A/Gb mode only) .....	96
10.1.18.2	Extended immediate assignment (A/Gb mode only).....	96
10.1.18.3	Immediate assignment Type 2 (A/Gb mode only) .....	96
10.1.18.3.0	General .....	96
10.1.18.3.1	USF.....	97
10.1.18.3.2	TLLI .....	97
10.1.18.3.3	Packet Power Control Parameters .....	97
10.1.18.3.4	Timing Advance Index (TAI).....	97
10.1.18.4	Immediate Assignment Type 3 (A/Gb mode only) .....	97
10.1.18.4.0	General .....	97
10.1.18.4.1	Page Mode .....	98
10.1.18.4.2	Persistence Level .....	98
10.1.18.4.3	TLLI .....	98
10.1.18.4.4	Packet Power Control Parameters .....	98
10.1.18.4.5	Timing Advance Index .....	98
10.1.18.5	Immediate Assignment Type 4 (Iu mode only).....	98
10.1.18.5.0	General .....	98
10.1.18.5.1	S-RNTI.....	99
10.1.18.5.2	Packet Immediate Assignment Type 4 Parameters.....	99
10.1.18.6	Immediate Assignment Type 5 (Iu mode only).....	99
10.1.18.6.0	General .....	99
10.1.18.6.1	S-RNTI.....	100
10.1.18.6.2	Packet Immediate Assignment Type 5 Parameters.....	100
10.1.19	Immediate assignment extended (A/Gb mode only).....	100
10.1.20	Immediate assignment reject.....	100
10.1.20.1	Immediate assignment reject type 1 .....	100
10.1.20.2	Immediate assignment reject type 2 .....	100
10.1.20.3	Extended immediate assignment reject (A/Gb mode only).....	100

10.1.20.4	Position verification notify (A/Gb mode only) .....	100
10.1.20.4a	Position verification notify Type 2 (Iu mode only).....	100
10.1.20.4a.0	General .....	100
10.1.20.4a.1	S-RNTI .....	101
10.1.20.4a.2	Position Verification Notify Type2 Parameters.....	101
10.1.20.5	Immediate Assignment Reject Type 3 .....	101
10.1.20.5.0	General .....	101
10.1.20.5.1	Packet BCCH Carrier .....	101
10.1.20.5.2	Illumination Retry Timer.....	101
10.1.20.5.3	Pause Timer .....	102
10.1.20.6	Immediate Assignment Reject Type 4 (Iu mode only).....	102
10.1.20.6.0	General .....	102
10.1.20.6.1	BCCH Carrier.....	102
10.1.20.6.2	Illumination Retry Timer.....	102
10.1.20.6.3	Pause Timer.....	103
10.1.20.6.4	CN Information Info.....	103
10.1.21	Measurement report (A/Gb mode only).....	103
10.1.22	Paging request type 1 .....	103
10.1.23	Paging request type 2 .....	103
10.1.24	Paging request type 3 .....	103
10.1.25	Paging response (A/Gb mode only).....	103
10.1.26	Partial release (A/Gb mode only) .....	103
10.1.27	Partial release complete (A/Gb mode only) .....	103
10.1.28	Physical information (A/Gb mode only).....	103
10.1.29	RR status (A/Gb mode only).....	103
10.1.30	Synchronization channel information (A/Gb mode only).....	103
10.1.31	System information type 1 .....	104
10.1.32	System information type 2 .....	104
10.1.33	System information type 2bis (Iu mode only) .....	104
10.1.34	System information type 2ter.....	104
10.1.35	System information type 3 .....	104
10.1.36	System information type 4 .....	104
10.1.37	System information type 5 .....	104
10.1.38	System information type 5bis .....	104
10.1.39	System information type 5ter.....	104
10.1.40	System information type 6 .....	104
10.1.41	System information type 7 .....	104
10.1.42	System information type 8.....	104
10.1.43	Alert request.....	105
10.1.43.0	General.....	105
10.1.43.1	Mobile Identity.....	105
10.1.44	Position update request (A/Gb mode only).....	105
10.1.45	Position update accept (A/Gb mode only) .....	105
10.1.46	GBCH information .....	105
10.1.46a	GBCH3 ECEF information.....	105
10.1.46b	GBCH3 Keplerian Coordinate information .....	122
10.1.47	Guard time violation (A/Gb mode only).....	125
10.1.48	Link correction (A/Gb mode only) .....	125
10.1.49	Power control parameters update (A/Gb mode only) .....	125
10.1.50	TtT signalling link failure (A/Gb mode only).....	125
10.1.51	Information request (A/Gb mode only) .....	125
10.1.52	Information response version (A/Gb mode only) .....	125
10.1.53	Information response spot beam selection (A/Gb mode only).....	125
10.1.54	Information response current beam (A/Gb mode only) .....	125
10.1.55	Information response power control (A/Gb mode only) .....	125
10.1.56	Information response position (A/Gb mode only) .....	125
10.1.57	Information response vendor specific (A/Gb mode only).....	125
10.1.58	Information response error (A/Gb mode only) .....	126
10.1.59	DTMF tone generate request (A/Gb mode only) .....	126
10.1.60	DTMF tone generate acknowledge (A/Gb mode only) .....	126
10.1.61	GMPRS Resume Response (A/Gb mode only) .....	126
10.1.61.0	General .....	126

10.1.61.1	TLLI.....	126
10.1.62	Paging Request Type 4 (Iu mode) .....	126
10.1.62.0	General.....	126
10.1.62.1	Page Mode.....	127
10.1.62.2	Paging Request Type 4 Parameters .....	127
10.2	Messages for mobility management.....	127
10.3	Messages for circuit-switched call control (A/Gb mode only) .....	127
10.4	GPRS Mobility Management messages .....	127
10.5	GPRS Session Management messages .....	127
10.5.0	General.....	127
10.5.1	Streaming service (A/Gb mode only) .....	127
11	General message format and information elements coding.....	128
11.0	General .....	128
11.1	Overview .....	128
11.2	Protocol discriminator .....	128
11.3	Skip indicator and transaction identifier.....	128
11.3.1	Skip indicator.....	128
11.3.2	Transaction identifier.....	128
11.4	Message type .....	128
11.4.0	General.....	128
11.4.1	Radio resource management message types .....	128
11.4.2	DTRS message types .....	129
11.5	Other information elements.....	129
11.5.0	General.....	129
11.5.1	Common information elements.....	129
11.5.1.1	Cell identity.....	129
11.5.1.2	Ciphering key sequence number .....	129
11.5.1.3	Location area identification.....	130
11.5.1.4	Mobile identity.....	130
11.5.1.5	Mobile Earth Station (MES) classmark 1 (A/Gb mode only) .....	130
11.5.1.6	Mobile Earth Station (MES) classmark 2 (A/Gb mode only) .....	131
11.5.1.7	Mobile Earth Station (MES) classmark 3 (A/Gb mode only) .....	131
11.5.1.8	Spare half octet.....	131
11.5.2	Radio resource management IEs.....	131
11.5.2.1	BA range .....	131
11.5.2.2	Cell description .....	131
11.5.2.3	Cell options (BCCH).....	131
11.5.2.4	Cell selection parameters.....	131
11.5.2.5	Channel description .....	132
11.5.2.6	Channel mode .....	132
11.5.2.7	Channel mode 2 .....	132
11.5.2.8	Channel needed .....	132
11.5.2.9	Cipher mode setting (A/Gb mode only) .....	132
11.5.2.10	Cipher response (A/Gb mode only) .....	132
11.5.2.11	Control channel description .....	132
11.5.2.12	Frequency channel sequence .....	132
11.5.2.13	Frequency list .....	132
11.5.2.14	Frequency short list .....	132
11.5.2.15	Handover reference .....	132
11.5.2.16	IA rest octets .....	132
11.5.2.17	IAR rest octets.....	133
11.5.2.18	IAX rest octets .....	133
11.5.2.19	L2 pseudo length.....	133
11.5.2.20	Measurement results.....	133
11.5.2.21	Mobile allocation .....	133
11.5.2.22	Neighbour cells description.....	133
11.5.2.23	P1 rest octets .....	133
11.5.2.24	P2 rest octets .....	133
11.5.2.25	P3 rest octets .....	133
11.5.2.26	Page mode .....	133
11.5.2.27	NCC permitted .....	133

11.5.2.28	Power command.....	134
11.5.2.29	RACH control parameters.....	134
11.5.2.30	Request Reference.....	134
11.5.2.31	RR cause .....	135
11.5.2.32	SI 1 rest octets .....	135
11.5.2.33	SI 2bis rest octets .....	135
11.5.2.34	SI 3 rest octets .....	135
11.5.2.35	SI 4 rest octets .....	135
11.5.2.36	SI 7 rest octets .....	135
11.5.2.37	SI 8 rest octets .....	135
11.5.2.38	Starting time .....	136
11.5.2.39	Synchronization indication.....	136
11.5.2.40	Timing offset.....	136
11.5.2.41	Time difference .....	136
11.5.2.42	TMSI .....	136
11.5.2.43	Wait indication.....	136
11.5.2.44	MES information flag (A/Gb mode only) .....	136
11.5.2.45	TTCH channel description (A/Gb mode only).....	136
11.5.2.46	MES configuration (A/Gb mode only).....	136
11.5.2.47	TtT common cipher key (A/Gb mode only).....	136
11.5.2.48	Access information (A/Gb mode only) .....	136
11.5.2.49	Frequency offset.....	136
11.5.2.50	Extended power class (A/Gb mode only).....	136
11.5.2.51	Paging Information.....	137
11.5.2.52	Position display .....	137
11.5.2.53	GPS position .....	137
11.5.2.54	Idle or dedicated mode position update information	137
11.5.2.55	BCCH carrier .....	137
11.5.2.56	Reject Cause.....	138
11.5.2.57	GPS timestamp.....	138
11.5.2.58	Timing correction.....	138
11.5.2.59	MES information 2 flag .....	138
11.5.2.60	Power control parameters.....	139
11.5.2.61	DTMF digits (A/Gb mode only) .....	139
11.5.2.62	TMSI availability mask.....	139
11.5.2.63	GPS almanac data .....	139
11.5.2.64	Frequency correction.....	139
11.5.2.65	Alerting information.....	139
11.5.2.66	Segment 1A.....	139
11.5.2.67	Void.....	140
11.5.2.68	Segment 2Abis .....	140
11.5.2.69	Void.....	142
11.5.2.70	Segment 2Bbis .....	142
11.5.2.71	Segment 3A.....	142
11.5.2.72	Void.....	143
11.5.2.73	Segment 3Bbis .....	143
11.5.2.74	Segment 3C .....	144
11.5.2.75	Segment 3D .....	144
11.5.2.76	Void.....	145
11.5.2.77	Segment 3Ebis.....	145
11.5.2.78	Segment 3F .....	145
11.5.2.79	Void.....	146
11.5.2.80	Segment 3Gb.....	146
11.5.2.81	Segment 3H (A/Gb Mode) .....	147
11.5.2.82	Segment 3I .....	147
11.5.2.83	Void.....	148
11.5.2.84	Segment 3Jbis .....	148
11.5.2.84a	Segment 3Kbis (Iu Mode) .....	149
11.5.2.84b	Segment 3L (Iu Mode) .....	151
11.5.2.84c	Segment 3M (Iu Mode) .....	151
11.5.2.85	Segment 4A.....	152
11.5.2.86	Segment 4B .....	152

11.5.2.87	Segment 4C .....	152
11.5.2.88	Segment 4D .....	153
11.5.2.89	Segment 4E .....	153
11.5.2.90	Segment 4F .....	153
11.5.2.90a	Segment 4G (Iu mode only) .....	154
11.5.2.90b	Segment 4H (Iu mode only) .....	154
11.5.2.90c	Segment 4I (Iu mode only) .....	154
11.5.2.90d	Segment 4J (Iu mode only) .....	154
11.5.2.90e	Segment 4K (Iu mode only) .....	155
11.5.2.91	Disconnection indication (A/Gb mode only) .....	155
11.5.2.92	Handover parameter (A/Gb mode only) .....	155
11.5.2.93	Information request code (A/Gb mode only) .....	155
11.5.2.94	Last spot beams information (A/Gb mode only) .....	155
11.5.2.95	Current spot beam information (A/Gb mode only) .....	155
11.5.2.96	Power control information (A/Gb mode only) .....	155
11.5.2.97	Version information (A/Gb mode only) .....	155
11.5.2.98	Information response error code (A/Gb mode only) .....	155
11.5.2.99	Vendor specific subcommand (A/Gb mode only) .....	155
11.5.2.100	MSC ID (A/Gb mode only) .....	155
11.5.2.101	GPS discriminator .....	156
11.5.2.102	Current timing offset (A/Gb mode only) .....	156
11.5.2.103	Pause Timer .....	156
11.5.2.104	Packet BCCH carrier .....	156
11.5.2.105	Packet Immediate Assignment Type 3 Parameters (A/Gb mode only) .....	157
11.5.2.106	Packet Frequency Parameters (A/Gb mode only) .....	157
11.5.2.107	Packet Immediate Assignment Type 2 Parameters (A/Gb mode only) .....	158
11.5.2.108	Illumination Retry Timer (A/Gb mode only) .....	159
11.5.2.109	Packet Control Channel Definition (A/Gb mode only) .....	160
11.5.2.109a	Packet Control Channel Definition (Iu Mode Only) .....	160
11.5.2.109b	Packet Control Channel Definition (Iu Mode Only) .....	161
11.5.2.110	USF .....	161
11.5.2.111	GMPRS BCCH options (A/Gb mode only) .....	162
11.5.2.111a	GMPRS BCCH options (Iu mode only) .....	164
11.5.2.112	Uplink PRACH channels (A/Gb mode only) .....	165
11.5.2.113	Void .....	165
11.5.2.114	Void .....	165
11.5.2.115	Void .....	165
11.5.2.116	Void .....	165
11.5.2.117	Void .....	165
11.5.2.118	PRACH overlay (A/Gb mode only) .....	165
11.5.2.119	Uplink PRACH ARFCN (A/Gb mode only) .....	166
11.5.2.120	Uplink PRACH MAC Slots Indicator (A/Gb mode only) .....	166
11.5.2.121	GMPRS Resume Result (A/Gb mode only) .....	166
11.5.2.122	GMPRS Resume Response Rest Octets (A/Gb mode only) .....	166
11.5.2.123	Uplink PRACH Frequency Distance (A/Gb mode only) .....	167
11.5.2.124	PRACH Frame Periodicity (A/Gb mode only) .....	167
11.5.2.125	Packet Immediate Assignment Type 4 Parameters (Iu mode only) .....	167
11.5.2.126	3G Neighbour Cell Description (Iu mode only) .....	169
11.5.2.127	Paging Request Type 4 Parameters (Iu mode only) .....	169
11.5.2.128	Position Verification Notify Type 2 Parameters (Iu mode only) .....	170
11.5.2.129	Directed RAC (Iu mode only) .....	171
11.5.2.130	Packet Immediate Assignment Type 5 Parameters (Iu mode only) .....	171
11.5.2.131	CN Information Info .....	172
11.5.3	Mobility management IEs .....	172
11.5.4	Call control IEs (A/Gb mode only) .....	172
11.5.5	GMM IEs .....	172
11.5.5.1	Attach request .....	172
11.5.5.2	Attach type .....	172
11.5.5.3	Ciphering algorithm .....	172
11.5.5.4	Void .....	172
11.5.5.5	Detach type .....	172
11.5.5.6	DRX parameter .....	172

11.5.5.7	Force to standby .....	173
11.5.5.8	PTMSI signature .....	173
11.5.5.9	Identity type 2 .....	173
11.5.5.10	IMEISV request .....	173
11.5.5.11	Receive N-PDU Numbers list .....	173
11.5.5.12	MS network capability .....	173
11.5.5.12a	MS Radio Access capability (A/Gb mode only) .....	173
11.5.5.13	Void.....	174
11.5.5.14	GMM cause.....	174
11.5.5.15	Routing Area Identification (RAI) .....	175
11.5.5.16	Void.....	175
11.5.5.17	Update result .....	175
11.5.5.18	Update type .....	175
11.5.5.19	A&C reference number .....	175
11.5.6	SM IEs .....	175
11.5.7	GPRS Common Information Elements .....	175
12	List of system parameters.....	175
12.0	General .....	175
12.1	Timers and counters for radio resource management .....	175
12.1.1	Timers on the MES side.....	175
12.1.2	Timers on the network side.....	177
12.1.3	Other parameters.....	177
12.2	Timers of mobility management .....	178
12.2.0	General.....	178
12.2.1	Timer T3240 .....	178
12.2.2	Timers of GPRS mobility management .....	178
12.2.3	Timers of GPRS session management.....	180
12.3	Timers of circuit-switched call control.....	180
<b>Annex A (informative):</b>	<b>Example of subaddress information element coding .....</b>	<b>181</b>
<b>Annex B (informative):</b>	<b>Void .....</b>	<b>182</b>
<b>Annex C (informative):</b>	<b>Void .....</b>	<b>183</b>
<b>Annex D (informative):</b>	<b>Void .....</b>	<b>184</b>
<b>Annex E (informative):</b>	<b>Void .....</b>	<b>185</b>
<b>Annex F (informative):</b>	<b>GMR specific cause values for radio resource management .....</b>	<b>186</b>
<b>Annex G (informative):</b>	<b>GMR specific cause values for session management .....</b>	<b>187</b>
<b>Annex H (informative):</b>	<b>Bibliography .....</b>	<b>188</b>
History .....		189