

ETSI EN 300 392-5 V2.5.1 (2016-10)



Terrestrial Trunked Radio (TETRA); Voice plus Data (V+D) and Direct Mode Operation (DMO); Part 5: Peripheral Equipment Interface (PEI)

ITeH STANDARD PREVIEW
(standards.iteh.ai)
Full standard available on
https://standards.iteh.ai/catalog/standards/sis/4a836289-6e7f-42e4-a865-115afa427348/etsi-en-300-392-5-v2.5.1-2016-10

Reference

REN/TCCE-03246

Keywords

data, interface, TETRA, V+D, voice

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2016.

All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are Trade Marks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

GSM® and the GSM logo are Trade Marks registered and owned by the GSM Association.

Contents

Intellectual Property Rights	22
Foreword.....	22
Modal verbs terminology.....	23
1 Scope	24
2 References	24
2.1 Normative references	24
2.2 Informative references.....	26
3 Symbols and abbreviations.....	26
3.1 Symbols.....	26
3.2 Abbreviations	27
4 Overview of TETRA PEI.....	30
4.1 Introduction	30
4.2 Protocol architecture.....	31
4.3 Context model	32
4.4 Void.....	35
4.5 SDS Message stacks.....	35
4.5.0 General on SDS Message stacks.....	35
4.5.1 Status message texts.....	35
4.5.2 SDS 1 message texts	35
4.5.3 Status and SDS types 1, 2 and 3	35
4.5.4 SDS type 4	36
4.6 Phone books	36
4.7 Reserved status values considerations.....	36
4.8 SDS-TL considerations	36
4.9 AT commands	37
4.9.1 General on AT commands.....	37
4.9.2 AT command state.....	39
4.9.3 AT circuit mode data state	39
4.9.4 TNP1 and packet data state.....	40
4.9.5 Transitions between states	40
4.9.5.1 Transition from AT command state to AT circuit mode data state	40
4.9.5.2 Transition from AT circuit mode data state to AT command state	40
4.9.5.3 Transition from AT command state to TNP1 or packet data state	41
4.9.5.4 Transition from TNP1 and packet data state to AT command state.....	41
4.10 TNP1 and IP network layer	41
4.10.1 General operation.....	41
4.10.2 IP addressing.....	41
4.10.3 Local mode	42
4.10.4 Wide mode.....	42
4.11 TNP1 operation	42
4.12 Link start up at the MT.....	43
5 Physical layer	43
5.1 General on physical layer	43
5.2 Physical layer for V.24/V.28.....	44
5.2.1 Electrical characteristics for V.24/V.28.....	44
5.2.2 Physical connection	44
5.2.3 Character format	45
5.2.4 Data transmission rate for V.24/V.28	45
5.3 Wire-line high rate connectivity technologies.....	45
5.3.1 General.....	45
5.3.2 Universal Serial Bus	46
5.3.3 USB On-The-Go.....	47
5.4 Wireless high rate connectivity	47
5.4.1 General.....	47

5.4.2	Wireless Security	47
5.4.3	Certified Wireless USB	48
5.4.4	Bluetooth	48
6	AT command set	48
6.1	General on AT command set	48
6.2	Limitations	49
6.3	SDS user data	49
6.4	AT command syntax	50
6.4.1	General on AT command syntax	50
6.4.2	Command line	50
6.4.2.0	Command line structure	50
6.4.2.1	Prefix	50
6.4.2.2	Body	50
6.4.2.3	Termination Character	50
6.4.2.4	Concatenating extended commands	50
6.4.2.5	Multiline extended commands	50
6.4.3	Command types	51
6.4.4	Parameters	52
6.4.5	AT command examples	52
6.4.6	Information responses and result codes	53
6.4.6.1	General on information responses and result codes	53
6.4.6.2	Information Responses	53
6.4.6.3	Result Code	53
6.4.6.4	AT result examples in verbose mode	54
6.4.6.5	AT result examples in numeric mode	56
6.4.6.6	Aborting information results and result codes	57
6.4.6.7	Unsolicited nested responses	57
6.4.7	Handling of unknown parameters	59
6.5	Existing V.250 commands for call control	60
6.5.1	Commands	60
6.5.2	Result Codes	60
6.5.3	Dialled string and user identity	60
6.6	Existing V.250 commands for PEI control	61
6.6a	Modified V.250 commands for PEI control	61
6.6a.1	General on modified V.250 commands for PEI control	61
6.6a.2	Line termination character: S3	62
6.6a.2.1	General on S3	62
6.6a.2.2	Description	62
6.6a.2.3	S3 set syntax	62
6.6a.2.4	S3 read syntax	62
6.6a.2.5	S3 read result code text	62
6.6a.2.6	S3 test syntax	62
6.6a.2.7	S3 test result syntax	62
6.6a.3	Response formatting character: S4	63
6.6a.3.1	General on S4	63
6.6a.3.2	Description	63
6.6a.3.3	S4 set syntax	63
6.6a.3.4	S4 read syntax	63
6.6a.3.5	S4 read result code text	63
6.6a.3.6	S4 test syntax	63
6.6a.3.7	S4 test result syntax	63
6.6a.4	Line editing character: S5	63
6.6a.4.1	General on S5	63
6.6a.4.2	Description	64
6.6a.4.3	S5 set syntax	64
6.6a.4.4	S5 read syntax	64
6.6a.4.5	S5 read result code text	64
6.6a.4.6	S5 test syntax	64
6.6a.4.7	S5 test result syntax	64
6.6a.5	Echo: E	64
6.6a.5.1	General on E	64

6.6a.5.2	Description	64
6.6a.5.3	E set syntax	64
6.6a.5.4	E read syntax	65
6.6a.5.5	E read result code text	65
6.6a.5.6	E test syntax	65
6.6a.5.7	E test result syntax	65
6.6a.6	Result code suppression: Q	65
6.6a.6.1	General on Q	65
6.6a.6.2	Description	65
6.6a.6.3	Q set syntax	65
6.6a.6.4	Q read syntax	65
6.6a.6.5	Q read result code text	65
6.6a.6.6	Q test syntax	66
6.6a.6.7	Q test result syntax	66
6.6a.7	MT response format: V	66
6.6a.7.1	General on V	66
6.6a.7.2	Description	66
6.6a.7.3	V set syntax	66
6.6a.7.4	V read syntax	66
6.6a.7.5	V read result code text	66
6.6a.7.6	V test syntax	66
6.6a.7.7	V test result syntax	66
6.6a.8	Circuit 109 (DCD) behavior: &C	67
6.6a.8.1	General on &C	67
6.6a.8.2	Description	67
6.6a.8.3	&C set syntax	67
6.6a.8.4	&C read syntax	67
6.6a.8.5	&C read result code text	67
6.6a.8.6	&C test syntax	67
6.6a.8.7	&C test result syntax	67
6.6a.9	Circuit 108/2 (DTR) behavior: &D	67
6.6a.9.1	General on &D	67
6.6a.9.2	Description	68
6.6a.9.3	&D set syntax	68
6.6a.9.4	&D read syntax	68
6.6a.9.5	&D read result code text	68
6.6a.9.6	&D test syntax	68
6.6a.9.7	&D test result syntax	68
6.6a.10	PEI data rate: +IPR	68
6.6a.10.1	General on +IPR	68
6.6a.10.2	Description	68
6.6a.10.3	+IPR set syntax	68
6.6a.10.4	+IPR read syntax	69
6.6a.10.5	+IPR read result code text	69
6.6a.10.6	+IPR test syntax	69
6.6a.10.7	+IPR test result syntax	69
6.7	Existing V.250 commands for generic MT control	69
6.7a	Modified V.250 commands for generic MT control	69
6.7a.1	General on modified V.250 commands for generic MT control	69
6.7a.2	Full factory defaults Z	70
6.7a.2.1	General on full factory defaults Z	70
6.7a.2.2	Description	70
6.7a.2.3	Z execution syntax	70
6.7a.2.4	Z test syntax	70
6.7a.3	Factory defaults &F	70
6.7a.3.1	General on factory defaults &F	70
6.7a.3.2	Description	70
6.7a.3.3	&F execution syntax	71
6.7a.3.4	&F test syntax	71
6.8	Existing Hayes AT commands for PEI control	71
6.9	Existing 3GPP commands for MT and call control	71
6.10	Modified PCCA wireless extended commands	72

6.11	Modified Cellular commands for MT control	73
6.11.1	General on cellular commands for MT control.....	73
6.11.2	MT Capabilities +GCAP	73
6.11.2.1	General on +GCAP	73
6.11.2.2	Description	73
6.11.2.3	GCAP execution syntax	73
6.11.2.4	GCAP execution read syntax	73
6.11.2.5	GCAP execution read and unsolicited result code text	73
6.11.2.6	GCAP test syntax	74
6.11.3	Network registration +CREG	74
6.11.3.1	General on +CREG	74
6.11.3.2	CREG set syntax	74
6.11.3.3	Description of set command.....	74
6.11.3.4	CREG execution read syntax	74
6.11.3.5	CREG execution read and unsolicited result code text	74
6.11.3.6	CREG test syntax	74
6.11.3.7	CREG test result syntax	75
6.11.4	Get MT TETRA identities +CNUM	75
6.11.4.1	General on +CNUM	75
6.11.4.2	Description	75
6.11.4.3	CNUM execution mode syntax	75
6.11.4.4	CNUM execution read mode syntax	75
6.11.4.5	CNUM execution read result code text	75
6.11.4.6	CNUM test syntax.....	76
6.11.5	Get MT TETRA Identities (alternative commands)	76
6.11.5.1	Get MT TETRA Fixed identity number(s): ITSI and Gateway address(es) +CNUMF	76
6.11.5.1.1	General on +CNUMF	76
6.11.5.1.2	Description	76
6.11.5.1.3	CNUMF execution mode syntax	76
6.11.5.1.4	CNUMF execution read mode syntax	76
6.11.5.1.5	CNUMF execution read result code text	76
6.11.5.1.6	CNUMF test syntax	76
6.11.5.2	Get MT static group identities +CNUMS	76
6.11.5.2.1	General on +CNUMS	76
6.11.5.2.2	Description	77
6.11.5.2.3	CNUMS set or execution/set syntax.....	78
6.11.5.2.4	CNUMS execution read or read syntax	78
6.11.5.2.5	CNUMS execution read or execution/set and unsolicited result code text.....	78
6.11.5.2.6	CNUMS test syntax	79
6.11.5.2.7	CNUMS test result syntax	79
6.11.5.3	Get MT dynamic group identities +CNUMD	80
6.11.5.3.1	General on +CNUMD	80
6.11.5.3.2	Description	80
6.11.5.3.3	CNUMD set or execution/set syntax	81
6.11.5.3.4	CNUMD execution read or read syntax	81
6.11.5.3.5	CNUMD execution read or execution/set and unsolicited result code text	81
6.11.5.3.6	CNUMD test syntax	82
6.11.5.3.7	CNUMD test result syntax	82
6.12	SDS message stack commands.....	82
6.12.1	General on SDS message stack commands.....	82
6.12.2	Delete message +CMGD	83
6.12.2.1	General on +CMGD	83
6.12.2.2	CMGD execution syntax	83
6.12.2.3	Description	83
6.12.2.4	CMGD test syntax.....	83
6.12.2.5	CMGD test result syntax	83
6.12.3	List messages +CMGL	83
6.12.3.1	General on +CMGL	83
6.12.3.2	CMGL execution syntax	84
6.12.3.3	Description	84
6.12.3.4	CMGL execution result code text	84
6.12.3.5	CMGL test syntax	84

6.12.4	Read message +CMGR.....	84
6.12.4.1	General on +CMGR.....	84
6.12.4.2	CMGR execution syntax.....	84
6.12.4.3	Description.....	85
6.12.4.4	CMGR execution result code text.....	85
6.12.4.5	CMGR test syntax.....	85
6.12.5	Write message +CMGW.....	85
6.12.5.1	General on +CMGW.....	85
6.12.5.2	CMGW execution syntax.....	86
6.12.5.3	Description.....	86
6.12.5.4	CMGW execution result code text.....	86
6.12.5.5	CMGW test syntax.....	87
6.12.6	Message send from store +CMSS.....	87
6.12.6.1	General on +CMSS.....	87
6.12.6.2	CMSS execution syntax.....	87
6.12.6.3	Description.....	87
6.12.6.4	CMSS execution result code text.....	88
6.12.6.5	CMSS test syntax.....	88
6.12.7	New message indication +CMTI.....	88
6.12.7.1	General on +CMTI.....	88
6.12.7.2	Description.....	88
6.12.7.3	CMTI unsolicited result code text.....	88
6.13	SDS direct commands.....	89
6.13.1	General on SDS direct commands.....	89
6.13.2	Send message +CMGS.....	89
6.13.2.1	General on +CMGS.....	89
6.13.2.2	CMGS execution syntax.....	89
6.13.2.3	Description.....	89
6.13.2.4	CMGS execution and unsolicited result code text.....	90
6.13.2.5	CMGS test syntax.....	90
6.13.3	TETRA SDS Receive +CTSDSR.....	90
6.13.3.1	General on +CTSDSR.....	90
6.13.3.2	Description.....	90
6.13.3.3	CTSDSR unsolicited result code text.....	90
6.14	TETRA MT control commands.....	91
6.14.1	General on TETRA MT control commands.....	91
6.14.2	TETRA Broadcast +CTBCT.....	91
6.14.2.1	General on +CTBCT.....	91
6.14.2.2	Description.....	91
6.14.2.3	CTBCT execution read and unsolicited result code text.....	91
6.14.2.4	CTBCT execution read syntax.....	91
6.14.2.5	CTBCT test syntax.....	91
6.14.3	TETRA Status Text Read +CTSTR.....	92
6.14.3.1	General on +CTSTR.....	92
6.14.3.2	CTSTR execution syntax.....	92
6.14.3.3	Description.....	92
6.14.3.4	CTSTR execution result code text.....	92
6.14.3.5	CTSTR test syntax.....	92
6.14.4	TETRA Service Profile +CTSP.....	92
6.14.4.1	General on +CTSP.....	92
6.14.4.2	CTSP set syntax.....	92
6.14.4.3	Description.....	93
6.14.4.4	CTSP read syntax.....	94
6.14.4.5	CTSP read result code text.....	95
6.14.4.6	CTSP test syntax.....	95
6.14.4.7	CTSP test result syntax.....	95
6.14.5	TETRA service definition for Circuit Mode services +CTSDC.....	96
6.14.5.1	General on +CTSDC.....	96
6.14.5.2	CTSDC set syntax.....	96
6.14.5.3	Description.....	96
6.14.5.4	CTSDC read syntax.....	96
6.14.5.5	CTSDC read result code text.....	96

6.14.5.6	CTSDC test syntax	96
6.14.5.7	CTSDC test result syntax	97
6.14.6	TETRA service definition for SDS Service +CTSDDS	97
6.14.6.1	General on +CTSDDS	97
6.14.6.2	CTSDDS set syntax	97
6.14.6.3	Description	97
6.14.6.4	CTSDDS read syntax	97
6.14.6.5	CTSDDS read result code text	97
6.14.6.6	CTSDDS test syntax	98
6.14.6.7	CTSDDS test result syntax	98
6.14.7	TETRA operating mode +CTOM	98
6.14.7.1	General on +CTOM	98
6.14.7.2	CTOM set syntax	98
6.14.7.3	Description	98
6.14.7.4	CTOM read syntax	99
6.14.7.5	CTOM read and unsolicited result code text	99
6.14.7.6	CTOM test syntax	99
6.14.7.7	CTOM test result	99
6.14.8	TETRA DM communication type +CTDCT	99
6.14.8.1	General on +CTDCT	99
6.14.8.2	CTDCT set syntax	99
6.14.8.3	Description	99
6.14.8.4	CTDCT read syntax	99
6.14.8.5	CTDCT read and unsolicited result code text	99
6.14.8.6	CTDCT test syntax	100
6.14.8.7	CTDCT test result text	100
6.14.9	TETRA Transient communication type +CTTCT	100
6.14.9.1	General on +CTTCT	100
6.14.9.2	CTTCT set syntax	100
6.14.9.3	Description	100
6.14.9.4	CTTCT unsolicited result code text	100
6.14.9.5	CTTCT read syntax	100
6.14.9.6	CTTCT read result syntax	100
6.14.9.7	CTTCT test syntax	100
6.14.9.8	CTTCT test result syntax	100
6.14.10	TETRA DMO visible gateways/repeaters +CTDGR	101
6.14.10.1	General on +CTDGR	101
6.14.10.2	CTDGR set syntax	101
6.14.10.3	Description	101
6.14.10.4	CTDGR execution read and unsolicited result code text	101
6.14.10.5	CTDGR execution read syntax	101
6.14.10.6	CTDGR test syntax	101
6.14.11	TETRA DM Carrier Selection +CTDCS	102
6.14.11.1	General on +CTDCS	102
6.14.11.2	CTDCS set syntax	102
6.14.11.3	Description	102
6.14.11.4	CTDCS read and unsolicited result code text	102
6.14.11.5	CTDCS read syntax	102
6.14.11.6	CTDCS test syntax	102
6.14.12	MT Reboot R	102
6.14.12.1	General on MT Reboot R	102
6.14.12.2	Description	103
6.14.12.3	R execution syntax	103
6.14.12.4	R test syntax	103
6.14.13	TETRA Broadcast +CTBCF	103
6.14.13.1	General on +CTBCF	103
6.14.13.2	Description	103
6.14.13.3	CTBCF set syntax	103
6.14.13.4	CTBCF execute syntax	103
6.14.13.5	CTBCF execute and unsolicited result code text	103
6.14.13.6	CTBCF read syntax	104
6.14.13.7	CTBCF test syntax	104

6.14.13.8	CTBCF test result text.....	104
6.14.14	TETRA radio frequency sensitive area mode +CTRFSA.....	104
6.14.14.1	General on +CTRFSA.....	104
6.14.14.2	Description.....	104
6.14.14.3	CTRFSA set syntax.....	104
6.14.14.4	CTRFSA read syntax.....	105
6.14.14.5	CTRFSA read and unsolicited result code text.....	105
6.14.14.6	CTRFSA test syntax.....	105
6.14.14.7	CTRFSA test result text.....	105
6.15	New TETRA call handling commands.....	105
6.15.1	General on new TETRA call handling commands.....	105
6.15.2	TETRA Call Connect +CTCC.....	105
6.15.2.1	General on +CTCC.....	105
6.15.2.2	Description.....	105
6.15.2.3	CTCC unsolicited result code text.....	105
6.15.3	TETRA Call Release +CTCR.....	106
6.15.3.1	General on +CTCR.....	106
6.15.3.2	Description.....	106
6.15.3.3	CTCR unsolicited result code text.....	106
6.15.4	TETRA Incoming Call Notification +CTICN.....	106
6.15.4.1	General on +CTICN.....	106
6.15.4.2	Description.....	106
6.15.4.3	CTICN unsolicited result code text.....	106
6.15.5	TETRA outgoing Call progress notification +CTOCP.....	107
6.15.5.1	General on +CTOCP.....	107
6.15.5.2	Description.....	107
6.15.5.3	CTOCP unsolicited result code text.....	107
6.15.6	TETRA Group Set up +CTGS.....	107
6.15.6.1	General on +CTGS.....	107
6.15.6.2	CTGS set syntax.....	107
6.15.6.3	Description.....	108
6.15.6.4	CTGS read syntax.....	108
6.15.6.5	CTGS read and unsolicited result code text.....	108
6.15.6.6	CTGS test syntax.....	108
6.15.6.7	CTGS test result syntax.....	108
6.15.7	Void.....	108
6.15.8	Transmit Demand +CTXD.....	108
6.15.8.1	General on +CTXD.....	108
6.15.8.2	CTXD execution syntax.....	108
6.15.8.3	Description.....	109
6.15.8.4	CTXD test syntax.....	109
6.15.8.5	CTXD test result syntax.....	109
6.15.9	Up Transmit Ceased +CUTXC.....	109
6.15.9.1	General +CUTXC.....	109
6.15.9.2	CUTXC execution syntax.....	109
6.15.9.3	Description.....	109
6.15.9.4	CUTXC test syntax.....	109
6.15.10	Transmission Grant +CTXG.....	109
6.15.10.1	General on +CTXG.....	109
6.15.10.2	Description.....	110
6.15.10.3	CTXG unsolicited result code text.....	110
6.15.11	Down Transmission Ceased +CDTXC.....	110
6.15.11.1	General on +CDTXC.....	110
6.15.11.2	Description.....	110
6.15.11.3	CDTXC unsolicited result code text.....	110
6.15.12	Transmission Continue +CTXN.....	110
6.15.12.1	General on +CTXN.....	110
6.15.12.2	Description.....	110
6.15.12.3	CTXN unsolicited result code text.....	110
6.15.13	Transmission Interrupt +CTXI.....	110
6.15.13.1	General on +CTXI.....	110
6.15.13.2	Description.....	111

6.15.13.3	CTXI unsolicited result code text.....	111
6.15.14	Transmission Wait +CTXW	111
6.15.14.1	General on +CTXW	111
6.15.14.2	Description.....	111
6.15.14.3	CTXW unsolicited result code text	111
6.15.15	Key Status +CTKST	111
6.15.15.1	General on +CTKST	111
6.15.15.2	CTKST set syntax	111
6.15.15.3	Description	111
6.16	MT errors.....	112
6.16.1	General on MT errors	112
6.16.2	Report MT error +CMEE	112
6.16.2.1	General on +CMEE.....	112
6.16.2.2	CMEE set syntax.....	112
6.16.2.3	Description.....	112
6.16.2.4	CMEE set result code text.....	112
6.16.2.5	CMEE read syntax	112
6.16.2.6	CMEE read result code text	112
6.16.2.7	CMEE test syntax.....	112
6.16.3	MT error result code +CME ERROR	113
6.16.3.1	General on +CME ERROR.....	113
6.16.3.2	Description	113
6.16.3.3	CME ERROR unsolicited result code text	113
6.16.4	MT result code +CME PARAMETER	113
6.16.4.1	General on +CME PARAMETER	113
6.16.4.2	Description	113
6.16.4.3	CME PARAMETER unsolicited result code text	113
6.17	Parameter description and values	113
6.17.1	General on parameters	113
6.17.2	Access Priority.....	114
6.17.3	AI service.....	114
6.17.4	AI mode	114
6.17.5	Alpha	115
6.17.5a	Ancillary ID.....	115
6.17.6	Area	115
6.17.6a	Baud rate.....	116
6.17.7	BS service	116
6.17.8	Call status	117
6.17.9	Called party identity.....	117
6.17.10	Calling party identity	117
6.17.11	Called party identity type.....	117
6.17.12	Calling party identity type	117
6.17.13	CC instance	118
6.17.13a	Cell load CA	118
6.17.13b	Cell load CA control	118
6.17.13c	Cell load DA TCH	118
6.17.13d	Cell load DA TCH control.....	118
6.17.13e	Cell load DA PDCH	119
6.17.13f	Cell load DA PDCH control	119
6.17.13g	Cell load DA CCH/SDS	119
6.17.13h	Cell load DA CCH/SDS control	119
6.17.14	Class of MS.....	119
6.17.14a	Circuit 108/2 behaviour	121
6.17.14b	Circuit 109 behaviour	122
6.17.15	CLIR control.....	122
6.17.15a	Command line echo	122
6.17.16	Comms type.....	122
6.17.17	CT unsolic.....	123
6.17.18	Disconnect cause	123
6.17.19	DM carrier	124
6.17.20	DM communication type	124
6.17.21	End to end encryption.....	124

6.17.22	Extended error report	124
6.17.23	Extended error report codes	125
6.17.24	Gateway/repeater address	126
6.17.24a	Gateway/repeater type	126
6.17.25	Group type	126
6.17.26	GR unsolic	127
6.17.27	Hook	127
6.17.28	Ident unsolic.....	127
6.17.29	Importance factor.....	127
6.17.29a	Key name	127
6.17.29b	Key status	128
6.17.30	LA.....	128
6.17.31	Length.....	128
6.17.31a	Line editing character	128
6.17.31b	Line termination character	128
6.17.32	Link identifier	129
6.17.33	Lower range Limit	129
6.17.34	Message index	129
6.17.35	Message reference.....	129
6.17.36	MNI	129
6.17.37	Number of groups	129
6.17.38	Num type	129
6.17.39	Parameter number	130
6.17.40	Void	130
6.17.41	Presence information	130
6.17.42	Priority	130
6.17.43	Priority level	131
6.17.44	Proprietary	131
6.17.45	Proprietary element owner.....	131
6.17.46	Reg stat	131
6.17.47	Reg unsolic	131
6.17.47a	RF SA mode	132
6.17.47b	RF SA unsolic.....	132
6.17.47c	Response format mode.....	132
6.17.47d	Response formatting character.....	132
6.17.47e	Result code suppression.....	132
6.17.48	RqTx	133
6.17.49	SDS instance.....	133
6.17.50	SDS-TL addressing.....	133
6.17.51	SDS Status	133
6.17.52	Security information	133
6.17.53	Service profile.....	134
6.17.54	Service layer1	134
6.17.55	Service layer2	134
6.17.56	Serviced GSSI.....	135
6.17.57	Simplex.....	135
6.17.58	Slots/Codec	135
6.17.59	Stack full.....	136
6.17.60	Stack present.....	136
6.17.61	TPI (Transmitting Party Identity)	136
6.17.62	TPI (Transmitting Party Identity) type.....	136
6.17.63	Transient communication type.....	136
6.17.64	TxCont	137
6.17.65	TxDemandPriority	137
6.17.66	TxGrant.....	137
6.17.67	TxRqPrmsn	137
6.17.68	Upper range limit.....	137
6.17.69	User data	137
6.17.70	Version number	137
6.18	Outgoing call set up methodology.....	138
6.18.1	General on outgoing call set up methodology.....	138
6.18.2	Voice calls	138

6.18.3	Circuit mode data calls	139
6.18.4	Sending of SDS messages.....	140
6.18.4.1	General on sending of SDS messages	140
6.18.4.2	Send via Stack.....	140
6.18.4.3	Direct Send.....	140
6.19	Incoming call set up methodology	140
6.19.1	General on incoming call set up methodology.....	140
6.19.2	Voice calls	140
6.19.3	Circuit mode data calls	141
6.19.4	Reception of SDS messages.....	141
6.19.4.1	Received via Stack	141
6.19.4.2	Direct Received.....	141
6.20	Voice and circuit mode data call maintenance commands	141
6.21	Call clear down commands	142
6.21.1	General on call clear down commands	142
6.21.2	TE Initiated clear	142
6.21.3	Network and MT Initiated clear.....	142
6.22	MEX layer support	142
6.22.0	General on support of MEX layer commands.....	142
6.22.1	MEX Capability +CTMCAP	142
6.22.1.1	General on +CTMCAP	142
6.22.1.2	CTMCAP execution syntax	142
6.22.1.3	CTMCAP execution result code text.....	143
6.22.1.4	CTMCAP test syntax	143
6.22.2	MEX Connect +CTMCON	143
6.22.2.1	General on +CTMCON.....	143
6.22.2.2	CTMCON execution syntax.....	143
6.22.2.3	CTMCON execution result code text.....	143
6.22.2.4	CTMCON test syntax.....	143
6.22.3	MEX End +CTMEND	143
6.22.3.1	General on +CTMEND.....	143
6.22.3.2	CTMEND execution syntax.....	143
6.22.3.3	CTMEND execution and unsolicited result code text.....	143
6.22.3.4	CTMEND test syntax.....	144
6.22.4	MEX Handle +CTMHDL.....	144
6.22.4.1	General on +CTMHDL.....	144
6.22.4.2	CTMHDL execution syntax.....	144
6.22.4.3	CTMHDL execution result code text.....	144
6.22.4.4	CTMHDL test syntax.....	144
6.22.5	MEX Modify +CTMMOD	144
6.22.5.1	General on +CTMMOD.....	144
6.22.5.2	CTMMOD execution syntax.....	144
6.22.5.3	CTMMOD result code text	144
6.22.5.4	CTMMOD unsolicited result code syntax.....	144
6.22.5.5	CTMMOD test syntax.....	145
6.22.6	MEX QOS Class +CTMQC	145
6.22.6.1	General on +CTMQC.....	145
6.22.6.2	CTMQC execution syntax.....	145
6.22.6.3	CTMQC execution result code text.....	145
6.22.6.4	CTMQC test syntax.....	145
6.22.7	Request new logical PEI Connection +CTPCON.....	145
6.22.7.1	General on +CTPCON	145
6.22.7.2	CTPCON execution syntax	145
6.22.7.3	CTPCON execution result code text	145
6.22.7.4	CTPCON test syntax	146
6.22.8	MEX related parameters	146
6.22.8.1	CONTEXT_READY timer.....	146
6.22.8.2	Data class	146
6.22.8.3	Data importance	146
6.22.8.4	Data priority	147
6.22.8.5	DCOMP	147
6.22.8.6	Delay class	147

6.22.8.7	Device address	147
6.22.8.8	Endpoint address	147
6.22.8.9	Maximum transmission unit.....	147
6.22.8.10	Mean active throughput.....	148
6.22.8.11	Mean throughput	148
6.22.8.12	MEX capability	148
6.22.8.13	MEX connect reject cause.....	149
6.22.8.14	MEX connect report.....	150
6.22.8.15	MEX data importance	150
6.22.8.16	MEX data priority	150
6.22.8.17	MEX deactivation type	150
6.22.8.18	MEX escalate DSCP5 Flag Enable	151
6.22.8.19	MEX escalate DSCP5 Flag Reset	151
6.22.8.20	MEX filter	151
6.22.8.21	MEX filter operation.....	151
6.22.8.22	MEX filter type	151
6.22.8.23	MEX handle	151
6.22.8.24	MEX mode.....	152
6.22.8.25	MEX modify reject cause.....	152
6.22.8.26	MEX modify report.....	152
6.22.8.27	MEX NSAPI usage	153
6.22.8.28	MEX PDP address	153
6.22.8.29	MEX PDP type.....	153
6.22.8.30	MEX PDU priority max	153
6.22.8.31	MEX precedence.....	153
6.22.8.32	MEX precedence rank.....	154
6.22.8.33	MEX precedence supported	154
6.22.8.34	MEX peer IP filter.....	154
6.22.8.35	MEX QoS.....	154
6.22.8.36	MEX QoS class.....	154
6.22.8.37	MEX QoS class access.....	154
6.22.8.38	MEX QoS class upper/lower (Downlink)	154
6.22.8.39	MEX QoS class upper/lower (Uplink)	155
6.22.8.40	MEX QoS filter	155
6.22.8.41	MEX transaction type	155
6.22.8.42	Minimum peak throughput.....	155
6.22.8.43	Mobile IPv4 information.....	156
6.22.8.44	NSAPI.....	156
6.22.8.45	NSAPI data priority.....	156
6.22.8.46	NSAPI QoS negotiation	156
6.22.8.47	PCOMP	156
6.22.8.48	PCON result	157
6.22.8.49	PDU priority.....	157
6.22.8.50	PDU priority max.....	157
6.22.8.51	Reliability class	157
6.22.8.52	Schedule availability	157
6.22.8.53	Scheduled access.....	157
6.22.8.54	Scheduled number of N-PDUs per grant.....	158
6.22.8.55	Scheduled N-PDU size.....	158
6.22.8.56	Schedule repetition period.....	158
6.22.8.57	Schedule timing error.....	158
6.22.8.58	Share response flag	159
7	TNP1 service description	159
7.1	Service primitives at the TNP1A-SAP	159
7.2	Service primitives at the TNP1B-SAP	159
7.3	Service primitives at TNP1A-SAP and TNP1B-SAP	159
7.4	Primitive descriptions.....	160
7.4.1	TNP1-Services CAPABILITY	160
7.4.2	TNP1-SDS-TL CAPABILITY	160
7.4.3	TNP1-IDENTIFICATION.....	160
7.4.4	TNP1-IDENTITIES.....	161