
**Measurement of radioactivity in the
environment — Air: radon-222 —**

**Part 8:
Methodologies for initial and
additional investigations in buildings**

iTeh STANDARD PREVIEW
*Mesurage de la radioactivité dans l'environnement — Air: radon 222 —
Partie 8: Méthodologies appliquées aux investigations initiales et
complémentaires dans les bâtiments*

[ISO 11665-8:2012](https://standards.iteh.ai/catalog/standards/sist/35333f6e-7e2f-4591-b6f8-9e0691cc8a69/iso-11665-8-2012)

<https://standards.iteh.ai/catalog/standards/sist/35333f6e-7e2f-4591-b6f8-9e0691cc8a69/iso-11665-8-2012>



iTeh STANDARD PREVIEW
(standards.iteh.ai)

ISO 11665-8:2012

<https://standards.iteh.ai/catalog/standards/sist/35333f6e-7e2f-4591-b6f8-9e0691cc8a69/iso-11665-8-2012>



COPYRIGHT PROTECTED DOCUMENT

© ISO 2012

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.org
Web www.iso.org

Published in Switzerland

Contents

	Page
Foreword.....	iv
Introduction.....	v
1 Scope.....	1
2 Normative references.....	1
3 Terms, definitions and symbols.....	1
3.1 Terms and definitions.....	1
3.2 Symbols.....	3
4 Organization of the measuring stages.....	4
5 Initial investigations.....	4
5.1 Objective.....	4
5.2 Methodology followed during the initial investigation.....	4
5.3 Selection of measuring devices.....	4
5.4 Location of the measuring points.....	5
5.5 Installation and removal of the measuring devices.....	6
5.6 Processing of the measuring devices.....	7
5.7 Data analysis.....	7
5.8 Initial investigation report.....	7
6 Additional investigations.....	8
6.1 General.....	8
6.2 Methodology for additional investigations.....	9
6.3 Report of additional investigations.....	11
7 Immediate post-mitigation testing of the technical solutions applied.....	11
8 Control of the effectiveness of the technical solutions applied.....	12
9 Control of the sustainability.....	12
Annex A (informative) Organization of radon measuring phases in a building.....	13
Annex B (informative) Examples of underground buildings and buried levels.....	14
Annex C (informative) Initial investigation report.....	15
Annex D (informative) Example of analysis of initial investigation measurement results.....	18
Bibliography.....	19

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 11665-8 was prepared by Technical Committee ISO/TC 85, *Nuclear energy, nuclear technologies, and radiological protection*, Subcommittee SC 2, *Radiological protection*.

ISO 11665 consists of the following parts, under the general title *Measurement of radioactivity in the environment — Air: radon-222*:

- Part 1: *Origins of radon and its short-lived decay products and associated measurement methods*
- Part 2: *Integrated measurement method for determining average potential alpha energy concentration of its short-lived decay products*
- Part 3: *Spot measurement method of the potential alpha energy concentration of its short-lived decay products*
- Part 4: *Integrated measurement method for determining average activity concentration using passive sampling and delayed analysis*
- Part 5: *Continuous measurement method of the activity concentration*
- Part 6: *Spot measurement method of the activity concentration*
- Part 7: *Accumulation method for estimating surface exhalation rate*
- Part 8: *Methodologies for initial and additional investigations in buildings*

The following parts are under preparation:

- Part 9: *Method for determining exhalation rate of dense building materials*
- Part 10: *Determination of diffusion coefficient in waterproof materials using activity concentration measurement*
- Part 11: *Test method for soil gas*

Introduction

Radon isotopes 222 and 220 are radioactive gases produced by the disintegration of radium isotopes 226, and 224, which are decay products of uranium-238 and thorium-232 respectively, and are all found in the earth's crust. Solid elements, also radioactive, followed by stable lead are produced by radon disintegration [1].

Radon is today considered to be the main source of human exposure to natural radiation. The UNSCEAR (2008) report [2] suggests that, at the worldwide level, radon accounts for around 52 % of global average exposure to natural radiation. The radiological impact of isotope 222 (48 %) is far more significant than isotope 220 (4 %), while isotope 219 is considered negligible.

The International Cancer Research Centre (ICRC) of the World Health Organization (WHO) has recognized radon as a lung carcinogen in humans since 1987.

In this part of ISO 11665, the term radon refers to its isotope 222.

Radon activity concentration can vary from one to multiple orders of magnitude over time and space. Exposure to radon and its decay products varies tremendously from one area to another, as it depends on the amount of radon emitted by the soil, on the weather conditions, and on the degree of containment in the areas where individuals are exposed [3].

Radon activity concentration is usually higher in buildings than in the outside atmosphere due to the lower air renewal rates. The more the ventilation is reduced, the greater the accumulation of radon in buildings. The underlying soil is usually the dominant source of radon in buildings. Building materials, outside air, tap water and even city gas can also contribute to increasing radon activity concentration.

Radon enters buildings mainly via a convection mechanism, the so-called "stack effect" that is due to a difference in air temperature between the inside and the outside of the building, which generates a difference in pressure between the air in the building and the air contained in the underlying soil. The radon activity concentration depends on the architecture, equipment (chimney, mechanical ventilation systems, etc.) and the environmental parameters of the building (temperature, pressure, etc.) and on the occupants' lifestyle.

Radon activity concentrations vary inside buildings by several tens of becquerels per cubic metre to several hundreds of becquerels per cubic metre [4]. Activity concentration can be as high as several thousands of becquerels per cubic metre in very confined spaces.

The assessment of the radon activity concentration of the atmosphere in a building is based on a step-by-step procedure with two measuring stages: the initial investigation, to estimate the annual average value of the radon activity concentration in the building, and, when needed, additional investigations.

When it is decided that the radon activity concentration in a building has to be reduced, mitigation techniques will be adapted to each individual case [5][6][7]. The impact of the mitigation will be assessed using new radon measurements in the building.

NOTE The origin of radon-222 and its short-lived decay products in the atmospheric environment are described generally in ISO 11665-1 together with measurement methods.

iTeh STANDARD PREVIEW
(standards.iteh.ai)

[ISO 11665-8:2012](https://standards.iteh.ai/catalog/standards/sist/35333f6e-7e2f-4591-b6f8-9e0691cc8a69/iso-11665-8-2012)

<https://standards.iteh.ai/catalog/standards/sist/35333f6e-7e2f-4591-b6f8-9e0691cc8a69/iso-11665-8-2012>

Measurement of radioactivity in the environment — Air: radon-222 —

Part 8: Methodologies for initial and additional investigations in buildings

1 Scope

This part of ISO 11665 specifies requirements for the determination of the activity concentration of radon in all types of buildings. The buildings can be single family houses, public buildings, industrial buildings, underground buildings, etc.

This part of ISO 11665 describes the measurement methods used to assess, during the initial investigation phase, the average annual activity concentration of radon in buildings. It also deals with investigations needed to identify the source, entry routes and transfer pathways of the radon in the building (additional investigations).

Finally, this part of ISO 11665 outlines the applicable requirements for the immediate post-mitigation testing of the implemented mitigation techniques, monitoring of their effectiveness and testing of the sustainability of the building's behaviour towards radon.

This part of ISO 11665 does not address the technical building diagnostic or the prescription of mitigation work.

<https://standards.iteh.ai/catalog/standards/sist/35333f6e-7e2f-4591-b6f8-9e0691cc8a69/iso-11665-8-2012>

2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 6707-1, *Building and civil engineering — Vocabulary — Part 1: General terms*

ISO 11665-1, *Measurement of radioactivity in the environment — Air: radon-222 — Part 1: Origins of radon and its short-lived decay products and associated measurement methods*

ISO 11665-4, *Measurement of radioactivity in the environment — Air: radon-222 — Part 4: Integrated measurement method for determining average activity concentration using passive sampling and delayed analysis*

3 Terms, definitions and symbols

3.1 Terms and definitions

For the purposes of this document, the terms and definitions given in ISO 11665-1 and ISO 6707-1 and the following apply.

3.1.1 additional investigations

stage of actions, including measurements, when identifying the sources of radon and its entry routes and transfer pathways in a building

3.1.2

building

anything that is constructed or results from construction operations, usually partially or totally enclosed and designed to stand permanently in one place, and whose main purpose is to provide shelter for its occupants and contents

NOTE 1 In this part of ISO 11665, a building is considered as underground if its roof is partly or entirely underground (see Figure B.1).

NOTE 2 The buried levels of a building are those with their ceiling entirely below the ground level (see Figure B.2).

3.1.3

building mapping

spatial presentation of measurement results showing the distribution of radon activity concentration data in the different spaces of the building in order to identify those where radon activity concentration is the highest

NOTE The measurements carried out for the building mapping are representative of the prevailing conditions at the time of sampling and thus cannot be used to establish the annual average activity concentrations.

3.1.4

homogeneous zone

zone including one or more adjacent volumes inside the building that share identical or very close characteristics (type of walls, floors, basement, foundations, building level, water supply, water usage patterns, ventilation, openings, temperature, etc.) with a homogeneous activity concentration of radon

NOTE 1 A homogeneous zone is defined based on the following main criteria:

- same type of soil-building interface;
- same ventilation conditions (no ventilation system, natural ventilation, mechanical ventilation, etc.);
- same temperature level.

NOTE 2 In cases where water can be a potential source of radon, the following additional criteria apply:

- same mode of water supply (direct, indirect, continuous, recycled);
- same type of water usage patterns (washing, showering, therapeutic care).

3.1.5

initial investigation

first stage of actions, including measurements, when determining the annual average activity concentration of radon in a building

3.1.6

mitigation techniques

technical means implemented in an existing building in order to reduce the activity concentration of radon

3.1.7

occupied volume

volume regularly occupied with a residence time justifying an interest with regard to the radon exposure risk

EXAMPLE Living-room, workshop, office, classroom, etc.

3.1.8

radon entry routes

passages and vectors (air or water) that permit radon to penetrate the building

NOTE Radon does not enter uniformly across the entire envelope of the building. The preferred entry routes are cracks in the soil-building interface, piping runs, etc.

3.1.9**radon source**

origin of radon present in the building

NOTE The main source of radon in buildings is usually the underlying soil. In some cases, building materials, the outdoor air, water (inflow water, supply water, thermal water, etc.) and even city gas are additional sources that can increase the radon activity concentration.

3.1.10**radon transfer pathways**

passages and vectors (air or water) that permit radon to move from one volume in the building to another

NOTE Radon transfer pathways commonly include piping runs, staircases, doorways, etc.

3.1.11**soil-building interface**

contact surface between the soil and the building

NOTE The soil-building interface can, for example, be formed by:

- a beaten-earth floor;
- an earthen floor;
- a slab or floor on a crawl space, technical space, basement or cellar;
- buried or semi-buried walls in contact with the ground;
- etc.

3.1.12**technical building diagnostic**

investigation operations conducted to identify the causes of the presence of radon detected in a building during the initial investigation, and to provide the data and information needed to choose appropriate long-lasting mitigation techniques

3.1.13**value of interest**

pre-fixed value of the annual average radon activity concentration, from which actions shall be taken to reduce the annual average activity concentration in a building [8]

NOTE The values of interest, also referred to as reference levels, are fixed by regulations issued by the competent administrative national authority or agreed contractually by the parties involved.

3.1.14**volume**

closed space in a building

EXAMPLE Room, corridor, box room, workshop, office, classroom, crawl space, cellar, etc.

3.2 Symbols

For the purposes of this document, the symbols given in ISO 11665-1 and the following apply.

\bar{C} average annual radon activity concentration, in becquerels per cubic metre

\bar{C}_I value of interest of the radon activity concentration, in becquerels per cubic metre

4 Organization of the measuring stages

The assessment of the radon activity concentration of the atmosphere in a building is based on a step-by-step procedure with different measuring stages:

- The presence of radon in a building shall be demonstrated through an initial investigation in accordance with the requirements described in Clause 5. The aim of this stage is to obtain measurement data with which to assess the annual average activity concentration of radon that will be compared to the value of interest.
- If the initial investigation demonstrates that the radon activity concentration is lower than any values of interest, the sustainability of the building's behaviour towards radon is monitored in accordance with the requirements set out in Clause 9. If changes in the building can alter its sustainability, the initial investigation shall be performed again in accordance with the requirements set out in Clause 5.
- If the initial investigation demonstrates that the radon activity concentration is higher than any values of interest, investigations shall be performed in order to identify the causes of the presence of radon at this level in the building (technical building diagnostic, etc.). Depending on the type of building involved, and particularly for large-footprint buildings with complex structure configurations, additional investigations may be carried out to help identify the sources of radon (soil, building materials and water) and its entry routes and transfer pathways in the building. These additional investigations shall be carried out in accordance with the requirements set out in Clause 6.
- If mitigation techniques (simple actions such as power on ventilation, building works, etc.) are implemented, immediate post-mitigation testing may be performed using short-term radon measurements that are not representative of the annual average value (Clause 7). The effectiveness and the sustainability of these mitigation techniques shall be monitored in accordance with the requirements set out in Clauses 8 and 9.

NOTE An example of the organization of the different stages is given in Annex A.

5 Initial investigations

5.1 Objective

The aim of the initial investigation is to determine whether a building or part of a building shows an annual average value of radon activity concentration above any values of interest.

5.2 Methodology followed during the initial investigation

The initial investigation shall be performed following the time sequence described below:

- selection of measuring devices;
- location of the measuring points in the building;
- installation and removal of measuring devices;
- processing of measuring devices;
- data analysis of measurement results obtained for each homogeneous zone;
- initial investigation report drafting.

5.3 Selection of measuring devices

The measurement method used to assess the annual average activity concentration shall be the long-term integrated measurement method described in ISO 11665-4.

Several types of measuring device complying with the requirements of ISO 11665-4 may be used during the initial investigation. However, to facilitate the data analysis and the interpretation of the measurement results, the same type of measuring device shall be used per building.

For a specific atmosphere with a high variable equilibrium factor (dusty atmosphere, high humidity, highly ventilated, etc.), a passive measuring device in so-called “closed configuration” shall be used.

5.4 Location of the measuring points

5.4.1 General

The installation of the measuring devices follows a three-stage protocol which determines:

- the homogeneous zones in the building under investigation;
- the number of devices per homogeneous zone required to take the representative measurements;
- the locations of the measuring points in the homogeneous zones.

5.4.2 Determination and selection of the homogeneous zones

Homogeneous zones are determined from the lowest floor upwards in order to progressively select a total surface of occupied homogeneous zone that is at least equal to the ground level area of the building. This approach is expected to select the homogeneous zones with the highest activity concentration of radon.

This approach is performed following two steps:

- The determination of homogeneous zones is based on:
 - the following main criteria:
 - same type of soil-building interface, [ISO 11665-8:2012](https://standards.iteh.ai/catalog/standards/sist/35333f6e-7e2f-4591-b6f8-9e0691cc8a69/iso-11665-8-2012)
 - same ventilation conditions (no ventilation system, natural ventilation, mechanical ventilation, etc.);
 - same temperature level;
 - the following additional criteria when water can be a potential source of radon:
 - same mode of water supply (direct, indirect, continuous, recycled);
 - same type of water usage patterns (washing, showering, therapeutic care).
- The selection of homogeneous zones shall comprise at least one occupied room.

In specific cases where specific sources other than soil (water and/or building materials) have been identified, this approach is performed for each building floor concerned.

For buried levels of a building, this approach is performed for each floor that is below ground-level, and each homogeneous zone that is occupied is selected.

For underground buildings, this approach is performed for each building floor.

NOTE 1 In the case of large buildings or buildings with a complex structure, the determination of the homogeneous zones requires a visit to these premises.

NOTE 2 In the case of single family houses, the determination of the homogeneous zones is usually simple as each floor constitutes a homogeneous zone.