

---

---

**Indoor air —**

Part 6:

**Determination of volatile organic  
compounds in indoor and test chamber  
air by active sampling on Tenax TA<sup>®</sup>  
sorber, thermal desorption and gas  
chromatography using MS or MS-FID**

iTeh STANDARD PREVIEW  
(standards.iteh.ai)

*Air intérieur —*

*Partie 6: Dosage des composés organiques volatils dans l'air intérieur  
des locaux et chambres d'essai par échantillonnage actif sur le sorbant  
Tenax TA<sup>®</sup>, désorption thermique et chromatographie en phase  
gazeuse utilisant MS ou MS-FID*



## iTeh STANDARD PREVIEW (standards.iteh.ai)

ISO 16000-6:2011

<https://standards.iteh.ai/catalog/standards/sist/7cbc9321-c802-4b62-9d11-d28f47a7aa54/iso-16000-6-2011>



### **COPYRIGHT PROTECTED DOCUMENT**

© ISO 2011

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office  
Case postale 56 • CH-1211 Geneva 20  
Tel. + 41 22 749 01 11  
Fax + 41 22 749 09 47  
E-mail [copyright@iso.org](mailto:copyright@iso.org)  
Web [www.iso.org](http://www.iso.org)

Published in Switzerland

# Contents

Page

Foreword .....	iv
Introduction.....	vi
1 Scope .....	1
2 Normative references .....	1
3 Terms and definitions .....	1
4 Principle .....	2
5 Reagents and materials .....	2
6 Apparatus .....	4
7 Conditioning and storage of sorbent tubes.....	6
7.1 Conditioning .....	6
7.2 Storage of conditioned sorbent tubes before sampling .....	6
8 Sampling .....	6
8.1 Indoor air sampling .....	6
8.2 Test chamber air sampling.....	6
8.3 Sampling volumes .....	7
8.4 Storage of loaded samples.....	7
8.5 Field blanks .....	7
9 Analysis.....	7
9.1 General .....	7
9.2 Thermal desorption .....	8
9.3 Temperature programme .....	8
9.4 Analysis of the samples.....	8
10 Identification of single VOCs .....	8
11 Concentration of analytes in the sampled air .....	9
11.1 General .....	9
11.2 Volatile organic compounds .....	9
11.3 Total volatile organic compounds .....	10
11.4 VVOC and SVOC compounds observed outside the TVOC range.....	10
12 Performance characteristics .....	11
13 Test report.....	12
14 Quality control .....	12
Annex A (informative) Examples of compounds detected in indoor air and from building products in test chambers .....	13
Annex B (informative) Safe sampling volumes for selected organic vapours sampled on Tenax TA® .....	19
Annex C (informative) Storage recovery of solvents on Tenax TA® sorbent tubes.....	21
Annex D (informative) Determination of very volatile and semi-volatile organic compounds in conjunction with volatile organic compounds .....	23
Bibliography.....	28

## Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 16000-6 was prepared by Technical Committee ISO/TC 146, *Air quality*, Subcommittee SC 6, *Indoor air*.

This second edition cancels and replaces the first edition (ISO 16000-6:2004), which has been technically revised.

ISO 16000 consists of the following parts, under the general title *Indoor air*:

- *Part 1: General aspects of sampling strategy* [ISO 16000-6:2011](https://standards.iteh.ai/catalog/standards/sist/7cbc9321-c802-4b62-9d11-d28f47a7aa54/iso-16000-6-2011)
- *Part 2: Sampling strategy for formaldehyde*
- *Part 3: Determination of formaldehyde and other carbonyl compounds in indoor air and test chamber air — Active sampling method*
- *Part 4: Determination of formaldehyde — Diffusive sampling method*
- *Part 5: Sampling strategy for volatile organic compounds (VOCs)*
- *Part 6: Determination of volatile organic compounds in indoor and test chamber air by active sampling on Tenax TA<sup>®</sup> sorbent, thermal desorption and gas chromatography using MS or MS-FID*
- *Part 7: Sampling strategy for determination of airborne asbestos fibre concentrations*
- *Part 8: Determination of local mean ages of air in buildings for characterizing ventilation conditions*
- *Part 9: Determination of the emission of volatile organic compounds from building products and furnishing — Emission test chamber method*
- *Part 10: Determination of the emission of volatile organic compounds from building products and furnishing — Emission test cell method*
- *Part 11: Determination of the emission of volatile organic compounds from building products and furnishing — Sampling, storage of samples and preparation of test specimens*
- *Part 12: Sampling strategy for polychlorinated biphenyls (PCBs), polychlorinated dibenzo-p-dioxins (PCDDs), polychlorinated dibenzofurans (PCDFs) and polycyclic aromatic hydrocarbons (PAHs)*

- *Part 13: Determination of total (gas and particle-phase) polychlorinated dioxin-like biphenyls (PCBs) and polychlorinated dibenzo-p-dioxins/dibenzofurans (PCDDs/PCDFs) — Collection on sorbent-backed filters*
  - *Part 14: Determination of total (gas and particle-phase) polychlorinated dioxin-like biphenyls (PCBs) and polychlorinated dibenzo-p-dioxins/dibenzofurans (PCDDs/PCDFs) — Extraction, clean-up and analysis by high-resolution gas chromatography and mass spectrometry*
  - *Part 15: Sampling strategy for nitrogen dioxide (NO<sub>2</sub>)*
  - *Part 16: Detection and enumeration of moulds — Sampling by filtration*
  - *Part 17: Detection and enumeration of moulds — Culture-based method*
  - *Part 18: Detection and enumeration of moulds — Sampling by impaction*
  - *Part 19: Sampling strategy for moulds*
  - *Part 23: Performance test for evaluating the reduction of formaldehyde concentrations by sorptive building materials*
  - *Part 24: Performance test for evaluating the reduction of volatile organic compound (except formaldehyde) concentrations by sorptive building materials*
  - *Part 25: Determination of the emission of semi-volatile organic compounds by building products — Micro-chamber method*
  - *Part 26: Sampling strategy for carbon dioxide (CO<sub>2</sub>)*
  - *Part 28: Determination of odour emissions from building products using test chambers*
- <https://standards.iteh.ai/catalog/standards/sist/7cbc9321-c802-4b62-9d11-c2017a7aa54/iso-16000-6-2011>
- The following parts are under preparation:
- *Part 21: Detection and enumeration of moulds — Sampling from materials*
  - *Part 27: Determination of settled fibrous dust on surfaces by SEM (scanning electron microscopy) (direct method)*
  - *Part 29: Test methods for VOC detectors*
  - *Part 30: Sensory testing of indoor air*
  - *Part 31: Measurement of flame retardants and plasticizers based on organophosphorus compounds — Phosphoric acid ester*
  - *Part 32: Investigation of constructions on pollutants and other injurious factors — Inspections*

## Introduction

ISO 16000-1 establishes general requirements relating to the measurement of indoor air pollutants and the important conditions to be observed before or during the sampling of individual pollutants or groups of pollutants. Aspects of the determination (sampling and analysis) and the sampling strategy of specific pollutants or groups of pollutants are specified in the subsequent parts of ISO 16000 (see Foreword).

ISO 16000-5 (dealing with VOC sampling strategy) is a link between ISO 16000-1 (a generic standard establishing the principles) and this part of ISO 16000, which deals with sampling and analytical measurements.

ISO 16017 (see Clause 2 and Reference [8]) and ISO 12219<sup>[3]–[7]</sup> also focus on volatile organic compound (VOC) measurements.

## iTeh STANDARD PREVIEW (standards.iteh.ai)

[ISO 16000-6:2011](https://standards.iteh.ai/catalog/standards/sist/7cbc9321-c802-4b62-9d11-d28f47a7aa54/iso-16000-6-2011)

<https://standards.iteh.ai/catalog/standards/sist/7cbc9321-c802-4b62-9d11-d28f47a7aa54/iso-16000-6-2011>

## Indoor air —

### Part 6:

## Determination of volatile organic compounds in indoor and test chamber air by active sampling on Tenax TA<sup>®</sup> sorbent, thermal desorption and gas chromatography using MS or MS-FID

### 1 Scope

This part of ISO 16000 specifies a method for determination of volatile organic compounds (VOCs) in indoor air and in air sampled for the determination of the emission of VOCs from building products or materials and other products used in indoor environments using test chambers and test cells. The method uses Tenax TA<sup>®</sup> sorbent with subsequent thermal desorption (TD) and gas chromatographic (GC) analysis<sup>[13]</sup> employing a capillary column or columns and a flame ionization detector (FID) and/or a mass spectrometric (MS) detector.

iTeh STANDARD PREVIEW

The method is applicable to the measurement of non-polar and slightly polar VOCs at concentrations ranging from sub-micrograms per cubic metre to several milligrams per cubic metre. Using the principles specified in this method, some very volatile compounds (VVOC) and semi-volatile organic compounds (SVOC) can also be analysed (see Annex D).

[ISO 16000-6:2011](https://standards.iteh.ai/catalog/standards/sist/7cbc9321-c802-4b62-9d11-d28f47a7aa54/iso-16000-6-2011)

<https://standards.iteh.ai/catalog/standards/sist/7cbc9321-c802-4b62-9d11-d28f47a7aa54/iso-16000-6-2011>

### 2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 16000-1, *Indoor air — Part 1: General aspects of sampling strategy*

ISO 16017-1:2000, *Indoor, ambient and workplace air — Sampling and analysis of volatile organic compounds by sorbent tube/thermal desorption/capillary gas chromatography — Part 1: Pumped sampling*

### 3 Terms and definitions

For the purposes of this document, the following terms and definitions apply.

#### 3.1

##### semi-volatile organic compound

SVOC

organic compound whose boiling point is in the range from (240 °C to 260 °C) to (380 °C to 400 °C)

NOTE 1 This classification has been defined by the World Health Organization<sup>[14]</sup>.

1) Tenax TA<sup>®</sup> is the trade name of a product supplied by Buchem. This information is given for the convenience of users of this document and does not constitute an endorsement by ISO of the product named. Equivalent products may be used if they can be shown to lead to the same results.

NOTE 2 Boiling points of some compounds are difficult or impossible to determine because they decompose before they boil at atmospheric pressure. Vapour pressure is another criterion for classification of compound volatility that may be used for classification of organic chemicals<sup>[15]</sup>.

### 3.2 volatile organic compound

VOC

organic compound whose boiling point is in the range from (50 °C to 100 °C) to (240 °C to 260 °C)

NOTE 1 This classification has been defined by the World Health Organization<sup>[14]</sup>.

NOTE 2 Boiling points of some compounds are difficult or impossible to determine because they decompose before they boil at atmospheric pressure. Vapour pressure is another criterion for classification of compound volatility that may be used for classification of organic chemicals<sup>[15]</sup>.

### 3.3 very volatile organic compound

VVOC

organic compound whose boiling point is in the range from <0 °C to (50 °C to 100 °C)

NOTE 1 This classification has been defined by the World Health Organization<sup>[14]</sup>.

NOTE 2 Boiling points of some compounds are difficult or impossible to determine because they decompose before they boil at atmospheric pressure. Vapour pressure is another criterion for classification of compound volatility that may be used for classification of organic chemicals<sup>[15]</sup>.

### 3.4 total volatile organic compounds

TVOCs

sum of volatile organic compounds, sampled on Tenax TA<sup>®</sup>, which elute between and including *n*-hexane and *n*-hexadecane on a non-polar capillary column, detected with a flame ionization detector (TVOC-FID) or mass spectrometric detector (TVOC-MS), and quantified by converting the total area of the chromatogram in that analytical window to a nominal mass using the chromatographic response factor for toluene (toluene equivalents)

NOTE While this part of ISO 16000 specifies the determination of individual VOCs, it is common in practice to generate a single concentration value to characterize the total amount of VOCs present in the air. This value is called the TVOC value (see 11.3 and Clause 13). It should be emphasized that the TVOC value so obtained depends on the sampling and analytical methods used, and therefore should be interpreted taking into account the full description of these methods.

## 4 Principle

A measured volume of sample air is collected from room air, an emission test chamber (see ISO 16000-9) or an emission test cell (see ISO 16000-10) by drawing through one (or more) sorbent tube containing Tenax TA<sup>®</sup> sorbent. Volatile organic compounds (VOCs) are retained by the sorbent tube, and the compounds are subsequently analysed in the laboratory. The collected VOCs are desorbed by heat and transferred under inert carrier gas via a cold trap or sorbent trap into a gas chromatograph equipped with a capillary column or columns and a flame ionization detector and/or a mass spectrometric detector.

## 5 Reagents and materials

5.1 **Volatile organic compounds** for calibration, of chromatographic quality.

5.2 **Dilution solvent**, for preparing calibration blend solution for liquid spiking, of chromatographic quality, free from compounds co-eluting with the compound(s) of interest (5.1).

NOTE It is in most cases beneficial to use dilution solvent that is considerably more volatile than the VOCs to be analysed. Methanol most commonly fulfils this criterion. Health and safety data for organic compounds are given, for example, in International Chemical Safety Cards (ICSCs)<sup>[24]</sup>.



### 5.3 Tenax TA<sup>®</sup>, particle size 0,18 mm to 0,60 mm (30 mesh to 80 mesh).

Tenax TA<sup>®</sup> is a porous polymer based on 2,6-diphenyleneoxide. Manufactured Tenax TA<sup>®</sup> contains quantities of impurities, which shall be removed before using it for VOC sampling. Perform cleaning by thermal conditioning the Tenax TA<sup>®</sup> under a flow of pure carrier gas. Select cleaning conditions so that no degradation of the polymer occurs, e.g. at a temperature of 300 °C for 10 h using a carrier gas flow rate of 50 ml/min to 100 ml/min for packed sampling tubes. Pack pre-cleaned Tenax TA<sup>®</sup> into sampling tubes that are tightly sealed and store in a closed, emission-free container. Check the success of the cleaning procedure by performing an analysis of the cleaned sorbent.

NOTE Pre-packed, conditioned (cleaned) and capped sorbent tubes are available commercially.

### 5.4 Standard atmospheres, of known concentrations of the compound(s) of interest, prepared by a recognized procedure. Methods specified in ISO 6141<sup>[1]</sup> and the appropriate part of ISO 6145<sup>[2]</sup> are suitable.

Prepare standard atmospheres equivalent to about 100 µg/m<sup>3</sup>. If the procedure is not applied under conditions that allow the establishment of full traceability of the generated concentrations to primary standards of mass and/or volume, or if the chemical inertness of the generation system cannot be guaranteed, the concentrations shall be confirmed using an independent procedure.

### 5.5 Standard sorbent tubes, loaded by spiking from standard atmospheres (5.4), prepared by passing an accurately known volume of the standard atmosphere through the sorbent tube, e.g. by means of a pump.

The volume of atmosphere sampled shall not exceed the breakthrough volume of the analyte-sorbent combination. After loading, disconnect and seal the tube. Prepare fresh standards with each batch of samples. For indoor air and test chamber air, load sorbent tubes with e.g. 100 ml, 200 ml, 400 ml, 1 l, 2 l, 4 l or 10 l of the 100 µg/m<sup>3</sup> standard atmosphere selected.

### 5.6 Calibration blend solutions for liquid spiking.

**5.6.1 General.** The stability and safe storage times of calibration blend solutions shall be determined. Fresh standard solutions shall be prepared accordingly or if there is evidence of deterioration, e.g. reactions between alcohols and ketones. Appropriate calibration solution concentrations vary depending upon expected target analyte levels in each batch of samples. Examples of solution preparation for a range of applications are given in 5.6.2 to 5.6.6.

**5.6.2 Solution containing approximately 10 mg/ml of each liquid component.** Introduce 50 ml of dilution solvent into a 100 ml volumetric flask. Accurately weigh approximately 1 g of substance or substances of interest into a 100 ml volumetric flask, starting with the least volatile substance. Make up to 100 ml with dilution solvent, stopper and shake to mix.

**5.6.3 Solution containing approximately 1 000 µg/ml of each liquid component.** Introduce 50 ml of dilution solvent into a 100 ml volumetric flask. Add 10 ml of solution 5.6.2. Make up to 100 ml with dilution solvent, stopper and shake to mix.

**5.6.4 Solution containing approximately 100 µg/ml of each liquid component.** Introduce 50 ml of dilution solvent into a 100 ml volumetric flask. Add 10 ml of solution 5.6.3. Make up to 100 ml with dilution solvent, stopper and shake to mix.

**5.6.5 Solution containing approximately 10 µg/ml of each liquid component.** Introduce 50 ml of dilution solvent into a 100 ml volumetric flask. Add 10 ml of solution 5.6.4. Make up to 100 ml with dilution solvent, stopper and shake to mix.

**5.6.6 Solution containing approximately 1 µg/ml of each liquid component.** Introduce 50 ml of dilution solvent into a 100 ml volumetric flask. Add 10 ml of solution 5.6.5. Make up to 100 ml with dilution solvent, stopper and shake to mix.

### 5.7 Standard sorbent tubes, loaded by spiking, prepared by injecting aliquots of standard solutions on to clean sorbent tubes.

The sampling end of a sorbent tube is fitted to the unheated injection unit of the gas chromatograph (GC) (6.10) through which inert purge gas is passed at 100 ml/min, and a 1 µl to 5 µl aliquot of an appropriate standard solution is injected through the septum. After 5 min, the tube is disconnected and sealed. Prepare fresh standard tubes with each batch of samples.

Introducing liquid standards on to sorbent tubes via a GC injector is considered the optimum approach to liquid standard introduction, as components reach the sorbent bed in the vapour phase. Alternatively, liquid standards may be introduced directly on to the sorbent bed using a syringe (6.3).

Calibration mixtures should be prepared in controlled ambient temperature conditions. Before use, temper the solutions accordingly.

NOTE 1 When preparing standard tubes containing SVOC analytes, efficient transfer is enhanced if the configuration of injector allows the tip of the syringe to make gentle contact with the sorbent retaining mechanism (e.g. gauze or frit) within the tube.

NOTE 2 Standard tubes containing VVOCs are more typically prepared either from standard atmospheres (see 5.4 and 5.5) or from concentrated gas standards sourced commercially. It is appropriate for concentrated gas standards to be introduced to the sampling end of sorbent tubes in a stream of carrier gas via an unheated GC injector.

NOTE 3 If standard tubes are being prepared by introducing aliquots from more than one standard solution or gas, it is appropriate first to introduce the standard containing higher boiling components and to introduce the lightest components last. This minimizes risk of analyte breakthrough during the standard tube loading process.

**5.8 Commercial, preloaded standard tubes**, certified, are available and can be used for establishing analytical quality control and for routine calibration.

**5.9 Inert carrier gas**, e.g. He, Ar, N<sub>2</sub>. The purity of the carrier gas should permit the detection of an injection of 0,5 ng of toluene.

**CAUTION — The quality of the carrier gas is of great importance, as contaminants possibly contained in the gases are enriched in the cold trap together with the substances to be analysed.**

## 6 Apparatus

Ordinary laboratory apparatus and in particular the following.

**6.1 Sorbent tubes, of stainless steel or glass**, containing at least 200 mg of Tenax TA<sup>®</sup> sorbent (5.3), with metal screw caps and polytetrafluoroethene (PTFE) ferrules.

Tubes with outside diameter of 6,4 mm (0.25 inch), inside diameter of 5 mm, and of length 89 mm (3.5 inch) fulfil the requirement and are used in many commercial thermal desorbers. Use deactivated glass wool or other suitable mechanism, e.g. stainless steel frit, to retain the sorbent in the tube.

NOTE 1 The unit inch is not allowed in ISO documents; inch equivalents are given for information only.

Pre-cleaned sorbent tubes containing Tenax TA<sup>®</sup> are available commercially. Alternatively, sorbent tubes can be filled in the laboratory as follows.

Weigh the appropriate amount of adsorbent, using no less than 200 mg of sorbent per tube to maintain the sorption capacity. To pack the tube, insert a plug of deactivated glass wool or a stainless steel gauze into one end of the tube. Transfer the adsorbent into the tube, assisted by suction if desired. Place an additional plug or gauze after the sorbent to retain it in the tube.

NOTE 2 The determination of breakthrough volume is specified in ISO 16017-1:2000, Annex B. Breakthrough volumes are proportional to the dimensions of the sampling tube and quantity of sorbent. As an approximate measure, doubling the bed length while tube diameter is kept constant doubles the safe sampling volume (SSV).

**6.2 Sorbent tube unions.** For sampling, two sorbent tubes connected in series using metal screw-cap couplings with PTFE ferrules.

**6.3 Precision syringes,** readable to at least 0,1 µl.

**6.4 Sampling pump,** fulfilling the requirements of EN 1232<sup>[11]</sup> or ASTM D3686<sup>[10]</sup>.

**6.5 Tubing,** of polyethylene (PE) or PTFE, of appropriate diameter, used to ensure a leak-proof fit to both pump and sample tube.

Sampling tubes shall not be used with plastic tubing upstream of the sorbent. Interferences from the tubing can introduce contaminants.

**6.6 Flow meter calibrator.** Bubble meter or other suitable device for gas flow calibration.

**6.7 Gas chromatographic (GC) system,** fitted with a flame ionization detector and/or mass spectrometric detector capable of detecting an injection of at least 1 ng of toluene with a signal-to-noise ratio of at least 5 to 1.

**6.8 Capillary column.** A suitable GC capillary column is selected for separation of analytes in the sample. Bonded 100 % dimethylpolysiloxane columns of 30 m to 60 m, internal diameter 0,25 mm to 0,32 mm and phase thickness 0,25 µm to 0,5 µm are examples of columns proven to be suitable for VOC analysis of indoor air, emission test chamber (in accordance with ISO 16000-9) air, and emission test cell (in accordance with ISO 16000-10) air.

NOTE A dimethylpolysiloxane column, e.g. an HP-1<sup>2</sup> column, does not separate 3-carene from 2-ethyl-1-hexanol with certain oven programmes, nor does it separate *m*- and *p*-xylenes.

**6.9 Thermal desorption apparatus,** for the two-stage thermal desorption of the sorbent tubes and transfer of desorbed vapours via an inert gas flow into a GC.

A typical apparatus contains a mechanism for holding the tubes to be desorbed while they are heated and purged simultaneously with inert carrier gas. The desorption temperature and time are adjustable, as is the carrier gas flow rate. The apparatus may also incorporate additional features, such as automatic sample-tube loading, leak testing, and a cold trap or other suitable device to concentrate the desorbed sample. The desorbed sample, contained in the purge gas, is routed to the gas chromatograph and capillary column via a heated transfer line.

**6.10 Injection facility** for preparing standards by liquid spiking (optional). A conventional gas chromatographic injection unit or equivalent device may be used for preparing calibration standards. This can be used *in situ*, or it can be mounted separately. The injector should be unheated to eliminate risk of heat transfer to the tube and associated risk of analyte breakthrough. The back of the injection unit should be adapted if necessary to fit the sample tube. This can be done conveniently by means of compression coupling with an O-ring seal.

NOTE When preparing standard tubes containing SVOC analytes, efficient transfer is enhanced if the configuration of the injector allows the tip of the syringe to make gentle contact with the sorbent retaining mechanism (e.g. gauze or frit) within the tube.

**6.11 Calibration of pump.** Calibrate the pump with the sorbent tube assembly in line, using an appropriate external calibrated meter.

2) HP-1 is the trade name of a product manufactured by Agilent, Inc. This information is given for the convenience of users of this document and does not constitute an endorsement by ISO of the product named.

## 7 Conditioning and storage of sorbent tubes

### 7.1 Conditioning

Prior to each sampling use, condition the pre-cleaned sorbent tubes at 300 °C for 10 min under inert carrier gas at a flow rate of 50 ml/min to 100 ml/min, to remove trace organic volatiles possibly trapped on the tube. Analyse a representative number of conditioned tubes for blank value, using routine analytical parameters, to ensure that the thermal desorption blank is sufficiently small. The sorbent tube blank level is acceptable if artefact peaks are no greater than 10 % of the typical peak areas of the analytes of interest. If the blank is unacceptable, recondition the tubes by repeating the conditioning procedure. If after repeated conditioning the blank is still unacceptable, the tubes shall be refilled (see procedure in 6.1).

### 7.2 Storage of conditioned sorbent tubes before sampling

Seal conditioned sorbent tubes with metal screw-cap fittings with PTFE ferrules and store in an emission-free container at room temperature. Use conditioned sampling tubes within four weeks. Recondition tubes stored for more than four weeks before sampling.

## 8 Sampling

### 8.1 Indoor air sampling

Assemble the sampling line. If more than one tube is used in order to ensure that the breakthrough volume for one tube and the analyte of interest is not exceeded, prepare a tube assembly by joining the tubes in series with a union (6.2). Attach the pump to the sorbent tube or tube assembly with PE or PTFE tubing. Start the pump and note and record the sampling flow rate or register reading, note starting time, temperature and, if necessary for calculation, also atmospheric pressure. An appropriate sampling flow rate is in the range of 50 ml/min to 200 ml/min. At the end of the sampling period, note and record the flow rate or register reading, turn the pump off, and note and record the time, temperature and, if necessary, atmospheric pressure. Disconnect the sampling tube from the sampling line and seal both ends using screw-cap fittings with PTFE ferrules.

If sampling flow rate is determined using an integrated flow-measuring device, e.g. a mass flow meter, connect the sampling tube to the sampling line, start the pump, note and record the time and flow rate or register reading. Note and record temperature and, if necessary, atmospheric pressure. An appropriate sampling flow rate is in the range of 50 ml/min to 200 ml/min. At the end of the sampling period, note and record the flow rate or register reading, turn off the pump, note and register the time the pump was turned off. Disconnect the sampling tube from the sampling line and seal both ends using screw-cap fittings with PTFE ferrules.

Sampling from indoor air shall be performed taking into account the general aspects of sampling strategy as specified in ISO 16000-1.

Sampling flow rates lower than 50 ml/min may be used if the operator finds it necessary, e.g. to enable longer sampling times.

### 8.2 Test chamber air sampling

Assemble the sampling line. If the sampling flow rate is determined with a calibrator, start the pump, note and record the sampling flow rate. Appropriate sampling flow rate is in the range of 50 ml/min to 200 ml/min. When sampling from an emission chamber, the sampling flow shall not exceed 80 % of the air flow rate of the chamber. Connect the sampling tube to the test chamber outlet or other sampling port of the emission test chamber, note and record the time the tube was connected. Note and record temperature and if necessary atmospheric pressure. At the end of the sampling period, disconnect the sampling tube from the chamber sampling port, note and record the time of disconnection, repeat the sampling flow determination, and turn off the pump. Disconnect the sampling tube from the sampling line and seal both ends using screw cap fittings with PTFE ferrules.