## INTERNATIONAL STANDARD

# ISO 10033-1

First edition 2011-04-15

## Laminated Veneer Lumber (LVL) — Bonding quality —

Part 1: Test methods

Lamibois — Qualité du collage iTeh STPartie 1: Méthodes d'essai EVIEW (standards.iteh.ai)

<u>ISO 10033-1:2011</u> https://standards.iteh.ai/catalog/standards/sist/23dc6f08-96ca-4a0a-9d3da96ea3fb3268/iso-10033-1-2011



Reference number ISO 10033-1:2011(E)

## iTeh STANDARD PREVIEW (standards.iteh.ai)

<u>ISO 10033-1:2011</u> https://standards.iteh.ai/catalog/standards/sist/23dc6f08-96ca-4a0a-9d3da96ea3fb3268/iso-10033-1-2011



#### COPYRIGHT PROTECTED DOCUMENT

#### © ISO 2011

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office Case postale 56 • CH-1211 Geneva 20 Tel. + 41 22 749 01 11 Fax + 41 22 749 09 47 E-mail copyright@iso.org Web www.iso.org

Published in Switzerland

### Contents

Forewo	ord	iv
1	Scope	1
2	Normative references	1
3 3.1 3.2	Test pieces Sampling Shape and size	1 1 1
4	Apparatus	2
5 5.1	Pre-treatment Sequence of pre-treatment	2 2
6 6.1 6.2 6.3	Procedure Test piece preparation Measurement of delamination Alternative procedures	3 3 4
7	Expression of results	4
8	Test report iTeh STANDARD PREVIEW	4
Annex	A (normative) Bond testing and evaluation using the shear testing procedures (suitable for internal production control)	5
Annex	B (normative) Bond testing and evaluation_using the chisel/knife testing procedures (suitable for internal production control) assist23dc6f08-96ca-4a0a-9d3d	14

### Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 10033-1 was prepared by Technical Committee ISO/TC 89, *Wood-based panels*, Subcommittee SC 3, *Plywood*.

ISO 10033 consists of the following parts, under the general title Laminated Veneer Lumber (LVL) — Bonding quality: (standards.iteh.ai)

- Part 1: Test methods
- Part 2: Requirements

<u>ISO 10033-1:2011</u> https://standards.iteh.ai/catalog/standards/sist/23dc6f08-96ca-4a0a-9d3da96ea3fb3268/iso-10033-1-2011

## Laminated Veneer Lumber (LVL) — Bonding quality —

Part 1: Test methods

#### 1 Scope

This part of ISO 10033 specifies test methods for determining the bonding quality of Laminated Veneer Lumber (LVL) bonded with thermosetting resin.

NOTE If it is possible to demonstrate a correlation between the methods defined in this part of ISO 10033 and other methods, those methods can be used.

#### 2 Normative references

## The following referenced documents are indispensable for the application of this document. For dated

references, only the edition cited applies. For undated references, the latest edition of the referenced documents) applies.

ISO 10033-2, Laminated Veneer Lumber (LVD) 100 Bonding quality — Part 2: Requirements https://standards.iteh.ai/catalog/standards/sist/23dc6f08-96ca-4a0a-9d3d-

ISO 12466-1, Plywood — Bonding quality 3th Part 19-Test methods

ISO 12466-2, Plywood — Bonding quality — Part 2: Requirements

ISO 16999, Wood-based panels — Sampling and cutting of test pieces

#### 3 Test pieces

#### 3.1 Sampling

Sampling shall be in accordance with ISO 16999.

The test pieces shall be without any visible defect in the testing area.

#### 3.2 Shape and size

Each test piece shall be a  $(75 \pm 1)$  mm ×  $(75 \pm 1)$  mm square and the full thickness of the LVL as shown in Figure 1. If the LVL sample is less than 75 mm across the end section, the test specimen shall have the actual width of the sample and a length of 75 mm. Permitted imperfection may be included in the test pieces.



#### Key

- t thickness
- L length
- w width
- G grain direction

## iTeh STANDARD PREVIEW (standards.iteh.ai)

#### Figure 1 — Test piece — Shape and size <u>ISO 10033-1:2011</u> https://standards.iteh.ai/catalog/standards/sist/23dc6f08-96ca-4a0a-9d3da96ea3fb3268/iso-10033-1-2011

#### 4 Apparatus

**4.1** Temperature-controlled water bath, suitable for immersing test pieces and capable of maintaining a minimum temperature of 17 °C, and/or (70  $\pm$  3) °C.

NOTE Temperature capability depends on employed pre-treatment cycle(s).

4.2 Boiling tank, enabling test pieces to be immersed in boiling water.

**4.3** Ventilated drying oven, capable of maintaining a temperature of  $(60 \pm 3)$  °C and/or  $(70 \pm 3)$  °C at all points.

NOTE Temperature capability depends on bonding class.

**4.4 Vacuum pressure chamber**, capable of maintaining in water at room temperature a vacuum of 85 kPa for 30 min followed immediately by application of pressure of  $(465 \pm 15)$  kPa for 30 min.

**4.5** Autoclave, capable of maintaining steam pressure at  $(200 \pm 7)$  kPa for 6 h ± 15 min.

#### 5 Pre-treatment

#### 5.1 Sequence of pre-treatment

The choice of pre-treatment, described in 5.1.1 to 5.1.7 for particular LVL bonding classes, shall be made in accordance with ISO 10033-2.

5.1.1 24 h cold soak: immersion for 24 h in water at a temperature not lower than 17 °C.

NOTE  $(20 \pm 3)$  °C can be considered as a test reference temperature.

**5.1.2 6 h boil:** immersion for 6 h in boiling water, followed by cooling in water at less than 30 °C for at least 1 h.

**5.1.3 BDB (boil-dry-boil):** immersion for 4 h in boiling water, then drying in the ventilated drying oven for 16 h to 20 h at  $(60 \pm 3)$  °C, then immersion in boiling water for 4 h, followed by cooling in water at less than 30 °C for at least 1 h.

**5.1.4 VP (vacuum pressure):** test specimens are immersed in water at room temperature and a vacuum of 85 kPa is applied for 30 min followed by the immediate application of a pressure of  $(465 \pm 15)$  kPa for 30 min.

**5.1.5 72 h boil:** immersion for  $(72 \pm 1)$  h in boiling water, followed by cooling in water at less than 30 °C for at least 1 h.

**5.1.6** Steam: specimens are placed in steam at  $(200 \pm 7)$  kPa pressure for 6 h ± 15 min followed by cooling for at least 1 h in water at less than 30 °C.

**5.1.7** Hot water soak: immersion in water at  $(70 \pm 3)$  °C for 2 h. This test is not applicable to Annex A or B.

#### 6 Procedure

6.1

#### iTeh STANDARD PREVIEW Test piece preparation

(standards.iteh.ai)

After the pre-treatment, test pieces shall be processed as follows:

- bonding class 1: after the pre-treatment, test pieces shall be dried at a temperature of (60 ± 3) °C for 24 h, prior to evaluation;
- bonding class 2: after the pre-treatment, test pieces shall be dried at a temperature of (70 ± 3) °C for 24 h, prior to evaluation;
- bonding class 3: the pre-treatment shall be carried out twice. Test pieces shall be dried after each cycle of pre-treatment at (70 ± 3) °C for 24 h, prior to evaluation.

#### 6.2 Measurement of delamination

The length of delamination in each glueline on the four sides of the test piece shall be measured. Delamination of a length less than 3 mm shall be ignored. The ratio of the delamination in each single glueline to the total length of the glueline on four sides shall be determined as a percentage. The ratio of the total length of delamination on the four sides to the total length of all gluelines on four sides shall also be calculated as a percentage.

The ratio of delamination shall be calculated by the following equations:

Ratio of delamination (%)

$$r_{\text{single}} = rac{l_{\text{d,single}} \times 100}{l_{\text{g,single}}}$$

© ISO 2011 - All rights reserved

(1)

where

 $l_{d,single}$  is the total length of delamination in a single glueline on four sides;

 $l_{g,single}$  is the total length of a single glueline on four sides;

$$r_{\text{total}} = \frac{l_{\text{d,total}} \times 100}{l_{\text{g,total}}}$$
(2)

where

 $l_{d,total}$  is the total length of delamination in all gluelines on four sides;

 $l_{q,total}$  is the total length of all gluelines on four sides.

#### 6.3 Alternative procedures

Alternative procedures for bond testing and evaluation, the lap shear test and the knife or chisel test are provided in Annexes A and B. These procedures are deemed suitable for quality control purposes.

#### 7 Expression of results

# The results shall be expressed as two ratios in percentages.

- 1) ratio of delamination (%) in any single glueline,
- 2) ratio of delamination (%) in total length of all gluelines 2011

https://standards.iteh.ai/catalog/standards/sist/23dc6f08-96ca-4a0a-9d3da96ea3fb3268/iso-10033-1-2011

#### 8 Test report

The test report shall be in accordance with ISO 16999 and shall also contain the following information:

- a) ratio of delamination (%) in any single glueline;
- b) ratio of delamination (%) in total length of all gluelines;
- c) details of pre-treatment (see 5.1);
- d) reference to this part of ISO 10033.

### Annex A

#### (normative)

# Bond testing and evaluation using the shear testing procedures (suitable for internal production control)

#### A.1 General

For the evaluation of the bonding quality of LVL, apply ISO 12466-1 with the following modifications.

Depending on the lay-up and the position of the layers, the shear load shall be applied to the glueline by tension or compression of test pieces.

#### A.2 Test pieces

#### A.2.1 Preparation of test pieces

#### A.2.1.1 General

## iTeh STANDARD PREVIEW

The making of the test pieces may require the removal of the material not to be tested and, in some cases, to bond a wood or plywood plate on the face(s) of the remaining material. It depends on:

- the number of plies in a layer: one or twoplies in one direction and more than two plies in one direction; https://standards.iteh.ai/catalog/standards/sist/23dc6f08-96ca-4a0a-9d3d-
- the position of the layer in the lay-up a3fb3268/iso-10033-1-2011

#### A.2.1.2 Layers with one or two plies in one direction

#### A.2.1.2.1 General

The test piece design is such that the tension load is applied across the grain of the layer to be tested.

#### A.2.1.2.2 Face layer (Figure A.1)

Cut a sample of a set of test pieces in such a way so that the length of a piece shall be across the grain of the face layer.

Keep the face layers and those underneath up to 15 mm and machine off the rest.

Cut a plate of 15 mm LVL made of the same species.

Bond this plate on the face layer of the LVL sample (the grain of the latter being at right angles to the grain of the face of the plate).

This glueline shall be compatible with the pre-treatment and the shear force applied to control the resistance of the glueline of the LVL to be tested.

On the LVL face, make a saw cut through it so that it reaches into the LVL face layer of the sample.

On the cleared face of the test sample, make a saw cut through the opposite layers so it reaches into the LVL face layer of the sample.

Cut the individual test pieces out of the sample.

The dimensions in the plane of the test pieces are the following:

- distance between the closer edges of the saw cuts: (25  $\pm$  0,5) mm;
- width of the test piece:  $(25 \pm 0,5)$  mm.

Total length of the test piece shall be consistent with:

- a shear area dimension along the load direction of 25 mm;
- a clearance of 50 mm, at least, between the clamps;
- the necessary length for its gripping.

Prior to pre-treatment, condition the test pieces in the standard climate  $(20 \pm 2)$  °C and  $(65 \pm 5)$  % RH so as to achieve the curing of the bond of the plates and the equilibrium of the moisture content.

Cohesive wood fibre failure (or wood fibre adhesion) shall be evaluated only on the glueline between the face layer and across the layer below.

NOTE The evaluation of the wood fibre adhesion of the glueline bonding the 15 mm LVL plate is not relevant.

## A.2.1.2.3 Core layers (Figure A.1) h STANDARD PREVIEW

Considering the pair of gluelines to be tested, keep one or more layers on both sides of the layer in-between and machine off excess material on both sides; the test piece shall be nominally symmetrical.

Make a saw cut so as to reach into the layer between the two gluelines to be tested.

https://standards.iteh.ai/catalog/standards/sist/23dc6f08-96ca-4a0a-9d3d-

A.2.1.3 Layers with more than two plies <sup>a96ea3fb3268/iso-10033-1-2011</sup>

#### A.2.1.3.1 General

The shear strength is evaluated by applying a load along the direction of the grain of the layers to be tested.

Two options are available:

- testing gluelines per pair;
- testing gluelines per sets of more than two.

#### ISO 10033-1:2011(E)

Dimensions in millimetres



https://standards.iteh.ai/catalog/standards/sist/23dc6f08-96ca-4a0a-9d3da96ea3fb3268/iso-10033-1-2011

- a Remove these layers.
- <sup>b</sup> Add these layers.
- c Glueline to be tested.
- d Layer (one or two plies) with grain across the length of test piece.
- e Notch.

Key

= same dimension

#### Figure A.1 — Layers with one or two plies in one direction intended for a shear

#### A.2.1.3.2 Testing with a single pair of gluelines

The shear strength is evaluated by application of a tension force along the grain of the test piece; the length of a piece shall be along the grain.

Pick a pair of gluelines and cut the samples. Cut off the excess material to make the test piece symmetrical (at least one ply shall remain on both sides of the pair of gluelines to be tested and more may be needed if the plies are thin).

On each face of each sample test piece, make the saw cuts so as to reach the opposite glueline and indent into the ply beyond, to a depth of  $(0,3 \pm 0,2)$  mm. The pair of gluelines between the bottoms of the two saw cuts shall thus be controlled (see detail in Figure A.2).

Cut the individual test pieces (the dimensions in the plane of the test pieces are those already defined in A.2.1.2.2).