
ReferenceRTS/TSGR-0625331vbi0

KeywordsUMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the only prevailing document is the print of the Portable Document Format (PDF) version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2018.

All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.

3GPP™ and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M logo is protected for the benefit of its Members.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

| | |
|---|----|
| Intellectual Property Rights | 2 |
| Foreword..... | 2 |
| Modal verbs terminology..... | 2 |
| Foreword..... | 39 |
| 1 Scope | 40 |
| 2 References | 40 |
| 3 Definitions and abbreviations..... | 43 |
| 3.1 Definitions | 43 |
| 3.2 Abbreviations | 45 |
| 4 General | 48 |
| 4.1 Overview of the specification..... | 48 |
| 4.2 RRC Layer Model | 49 |
| 4.3 Protocol specification principles | 52 |
| 5 RRC Functions and Services provided to upper layers | 52 |
| 5.1 RRC Functions | 52 |
| 5.2 RRC Services provided to upper layers..... | 53 |
| 5.3 Primitives between RRC and upper layers..... | 53 |
| 6 Services expected from lower layers..... | 53 |
| 6.1 Services expected from Layer 2 | 53 |
| 6.2 Services expected from Layer 1 | 53 |
| 6.3 Signalling Radio Bearers..... | 53 |
| 7 Protocol states | 54 |
| 7.1 Overview of RRC States and State Transitions including GSM and E-UTRA | 54 |
| 7.2 Processes in UE modes/states..... | 55 |
| 7.2.1 UE Idle mode..... | 55 |
| 7.2.2 UTRA RRC Connected mode..... | 55 |
| 7.2.2.1 URA_PCH or CELL_PCH state | 55 |
| 7.2.2.2 CELL_FACH state..... | 56 |
| 7.2.2.3 CELL_DCH state..... | 58 |
| 8 RRC procedures | 58 |
| 8.1 RRC Connection Management Procedures | 59 |
| 8.1.1 Broadcast of system information | 59 |
| 8.1.1.1 General | 59 |
| 8.1.1.1.1 System information structure..... | 60 |
| 8.1.1.1.2 System information blocks | 60 |
| 8.1.1.1.3 Segmentation and concatenation of system information blocks..... | 67 |
| 8.1.1.1.4 Re-assembly of segments | 69 |
| 8.1.1.1.5 Scheduling of system information | 69 |
| 8.1.1.2 Initiation..... | 70 |
| 8.1.1.3 Reception of SYSTEM INFORMATION messages by the UE..... | 70 |
| 8.1.1.4 Void..... | 70 |
| 8.1.1.5 Actions upon reception of the Master Information Block and Scheduling Block(s)..... | 70 |
| 8.1.1.6 Actions upon reception of system information blocks | 75 |
| 8.1.1.6.1 System Information Block type 1 | 76 |
| 8.1.1.6.2 System Information Block type 2 | 77 |
| 8.1.1.6.3 System Information Block type 3..... | 77 |
| 8.1.1.6.4 System Information Block type 4..... | 82 |
| 8.1.1.6.5 System Information Block type 5 and 5bis..... | 82 |
| 8.1.1.6.6 System Information Block type 6..... | 88 |
| 8.1.1.6.7 System Information Block type 7..... | 91 |
| 8.1.1.6.8 Void..... | 91 |

| | | |
|---------------|---|-----|
| 8.1.1.6.9 | Void..... | 91 |
| 8.1.1.6.10 | Void..... | 91 |
| 8.1.1.6.11 | System Information Block type 11..... | 92 |
| 8.1.1.6.11a | System Information Block type 11bis..... | 93 |
| 8.1.1.6.12 | System Information Block type 12..... | 94 |
| 8.1.1.6.13 | System Information Block type 13..... | 95 |
| 8.1.1.6.14 | System Information Block type 14..... | 96 |
| 8.1.1.6.15 | System Information Block type 15..... | 96 |
| 8.1.1.6.15.0 | System Information Block type 15bis..... | 96 |
| 8.1.1.6.15.1 | System Information Block type 15.1..... | 96 |
| 8.1.1.6.15.1a | System Information Block type 15.1bis..... | 97 |
| 8.1.1.6.15.2 | System Information Block type 15.2..... | 97 |
| 8.1.1.6.15.2a | System Information Block type 15.2bis..... | 97 |
| 8.1.1.6.15.2b | System Information Block type 15.2ter..... | 98 |
| 8.1.1.6.15.3 | System Information Block type 15.3..... | 98 |
| 8.1.1.6.15.3a | System Information Block type 15.3bis..... | 99 |
| 8.1.1.6.15.4 | System Information Block type 15.4..... | 99 |
| 8.1.1.6.15.5 | System Information Block type 15.5..... | 100 |
| 8.1.1.6.15.6 | System Information Block type 15.6..... | 100 |
| 8.1.1.6.15.7 | System Information Block type 15.7..... | 100 |
| 8.1.1.6.15.8 | System Information Block type 15.8..... | 100 |
| 8.1.1.6.16 | System Information Block type 16..... | 100 |
| 8.1.1.6.17 | System Information Block type 17..... | 101 |
| 8.1.1.6.18 | System Information Block type 18..... | 101 |
| 8.1.1.6.19 | System Information Block type 19..... | 102 |
| 8.1.1.6.20 | System Information Block type 20..... | 103 |
| 8.1.1.6.21 | System Information Block type 21..... | 103 |
| 8.1.1.6.22 | System Information Block type 22..... | 104 |
| 8.1.1.7 | Modification of system information..... | 104 |
| 8.1.1.7.1 | Modification of system information blocks using a value tag..... | 104 |
| 8.1.1.7.2 | Synchronised modification of system information blocks..... | 104 |
| 8.1.1.7.3 | Actions upon system information change..... | 105 |
| 8.1.1.7.4 | Actions upon expiry of a system information expiry timer..... | 105 |
| 8.1.1.8 | Reception of System Information Container by the UE..... | 106 |
| 8.1.2 | Paging..... | 106 |
| 8.1.2.1 | General..... | 106 |
| 8.1.2.2 | Initiation..... | 107 |
| 8.1.2.3 | Reception of a PAGING TYPE 1 message by the UE..... | 107 |
| 8.1.3 | RRC connection establishment..... | 109 |
| 8.1.3.1 | General..... | 109 |
| 8.1.3.2 | Initiation..... | 109 |
| 8.1.3.3 | RRC CONNECTION REQUEST message contents to set..... | 110 |
| 8.1.3.4 | Reception of an RRC CONNECTION REQUEST message by the UTRAN..... | 113 |
| 8.1.3.5 | Cell re-selection, T300 or T318 timeout..... | 114 |
| 8.1.3.5a | Abortion of RRC connection establishment..... | 115 |
| 8.1.3.6 | Reception of an RRC CONNECTION SETUP message by the UE..... | 115 |
| 8.1.3.7 | Physical channel failure or cell re-selection..... | 121 |
| 8.1.3.8 | Invalid RRC CONNECTION SETUP message, unsupported configuration or invalid configuration..... | 121 |
| 8.1.3.9 | Reception of an RRC CONNECTION REJECT message by the UE..... | 122 |
| 8.1.3.10 | Invalid RRC CONNECTION REJECT message..... | 126 |
| 8.1.3.11 | Logging of failed RRC Connection Establishment..... | 126 |
| 8.1.4 | RRC connection release..... | 127 |
| 8.1.4.1 | General..... | 128 |
| 8.1.4.2 | Initiation..... | 128 |
| 8.1.4.3 | Reception of an RRC CONNECTION RELEASE message by the UE..... | 128 |
| 8.1.4.4 | Invalid RRC CONNECTION RELEASE message..... | 130 |
| 8.1.4.5 | Cell re-selection or radio link failure..... | 130 |
| 8.1.4.6 | Expiry of timer T308, unacknowledged mode transmission..... | 131 |
| 8.1.4.7 | Void..... | 131 |
| 8.1.4.8 | Reception of an RRC CONNECTION RELEASE COMPLETE message by UTRAN..... | 132 |

| | | |
|------------|---|-----|
| 8.1.4.9 | Unsuccessful transmission of the RRC CONNECTION RELEASE COMPLETE message, acknowledged mode transmission..... | 132 |
| 8.1.4.10 | Detection of loss of dedicated physical channel by UTRAN in CELL_DCH state | 132 |
| 8.1.4.11 | Failure to receive RRC CONNECTION RELEASE COMPLETE message by UTRAN..... | 132 |
| 8.1.4a | RRC connection release requested by upper layers | 132 |
| 8.1.4a.1 | General | 132 |
| 8.1.4a.2 | Initiation..... | 132 |
| 8.1.5 | Void | 133 |
| 8.1.6 | Transmission of UE capability information..... | 133 |
| 8.1.6.1 | General | 133 |
| 8.1.6.2 | Initiation..... | 133 |
| 8.1.6.3 | Reception of a UE CAPABILITY INFORMATION message by the UTRAN..... | 136 |
| 8.1.6.4 | Reception of the UE CAPABILITY INFORMATION CONFIRM message by the UE | 137 |
| 8.1.6.5 | Invalid UE CAPABILITY INFORMATION CONFIRM message | 137 |
| 8.1.6.6 | T304 timeout..... | 138 |
| 8.1.7 | UE capability enquiry | 138 |
| 8.1.7.1 | General | 138 |
| 8.1.7.2 | Initiation..... | 138 |
| 8.1.7.3 | Reception of a UE CAPABILITY ENQUIRY message by the UE | 138 |
| 8.1.7.4 | Invalid UE CAPABILITY ENQUIRY message | 139 |
| 8.1.8 | Initial Direct transfer..... | 139 |
| 8.1.8.1 | General | 139 |
| 8.1.8.2 | Initiation of Initial direct transfer procedure in the UE | 139 |
| 8.1.8.2a | RLC re-establishment or inter-RAT change | 142 |
| 8.1.8.2ab | Inter-RAT handover from UTRAN to GERAN <i>Iu mode</i> | 142 |
| 8.1.8.2b | Abortion of signalling connection establishment | 142 |
| 8.1.8.2c | Inter-RAT handover from UTRAN to E-UTRAN | 142 |
| 8.1.8.3 | Reception of INITIAL DIRECT TRANSFER message by the UTRAN | 142 |
| 8.1.9 | Downlink Direct transfer | 143 |
| 8.1.9.1 | General | 143 |
| 8.1.9.2 | Initiation of downlink direct transfer procedure in the UTRAN | 143 |
| 8.1.9.3 | Reception of a DOWNLINK DIRECT TRANSFER message by the UE | 143 |
| 8.1.9.3a | No signalling connection exists..... | 143 |
| 8.1.9.4 | Invalid DOWNLINK DIRECT TRANSFER message | 144 |
| 8.1.10 | Uplink Direct transfer | 144 |
| 8.1.10.1 | General | 144 |
| 8.1.10.2 | Initiation of uplink direct transfer procedure in the UE | 145 |
| 8.1.10.2a | RLC re-establishment or inter-RAT change | 145 |
| 8.1.10.2b | Inter-RAT handover from UTRAN to GERAN <i>Iu mode</i> | 146 |
| 8.1.10.2c | Inter-RAT handover from UTRAN to E-UTRAN | 146 |
| 8.1.10.3 | Reception of UPLINK DIRECT TRANSFER message by the UTRAN | 146 |
| 8.1.11 | UE dedicated paging..... | 146 |
| 8.1.11.1 | General | 146 |
| 8.1.11.2 | Initiation..... | 146 |
| 8.1.11.3 | Reception of a PAGING TYPE 2 message by the UE | 147 |
| 8.1.11.4 | Invalid PAGING TYPE 2 message..... | 147 |
| 8.1.12 | Security mode control..... | 147 |
| 8.1.12.1 | General | 148 |
| 8.1.12.2 | Initiation..... | 148 |
| 8.1.12.2.1 | Ciphering configuration change | 148 |
| 8.1.12.2.2 | Integrity protection configuration change..... | 149 |
| 8.1.12.3 | Reception of SECURITY MODE COMMAND message by the UE | 151 |
| 8.1.12.3.1 | New ciphering and integrity protection keys..... | 155 |
| 8.1.12.4 | Void..... | 156 |
| 8.1.12.4a | Incompatible simultaneous security reconfiguration..... | 156 |
| 8.1.12.4b | Cell update procedure during security reconfiguration | 157 |
| 8.1.12.4c | Invalid configuration..... | 158 |
| 8.1.12.5 | Reception of SECURITY MODE COMPLETE message by the UTRAN | 158 |
| 8.1.12.6 | Invalid SECURITY MODE COMMAND message..... | 160 |
| 8.1.13 | Signalling connection release procedure..... | 161 |
| 8.1.13.1 | General | 161 |
| 8.1.13.2 | Initiation of SIGNALLING CONNECTION RELEASE by the UTRAN..... | 161 |

| | | |
|-----------|---|-----|
| 8.1.13.3 | Reception of SIGNALLING CONNECTION RELEASE by the UE..... | 161 |
| 8.1.13.4 | Invalid SIGNALLING CONNECTION RELEASE message..... | 161 |
| 8.1.13.5 | Invalid configuration..... | 162 |
| 8.1.14 | Signalling connection release indication procedure..... | 162 |
| 8.1.14.1 | General..... | 162 |
| 8.1.14.2 | Initiation..... | 162 |
| 8.1.14.2a | RLC re-establishment or inter-RAT change..... | 164 |
| 8.1.14.3 | Reception of SIGNALLING CONNECTION RELEASE INDICATION by the UTRAN..... | 165 |
| 8.1.14.4 | Expiry of timer T323..... | 165 |
| 8.1.15 | Counter check procedure..... | 165 |
| 8.1.15.1 | General..... | 165 |
| 8.1.15.2 | Initiation..... | 165 |
| 8.1.15.3 | Reception of a COUNTER CHECK message by the UE..... | 166 |
| 8.1.15.4 | Reception of the COUNTER CHECK RESPONSE message by UTRAN..... | 166 |
| 8.1.15.5 | Cell re-selection..... | 166 |
| 8.1.15.6 | Invalid COUNTER CHECK message..... | 167 |
| 8.1.16 | Inter RAT handover information transfer..... | 167 |
| 8.1.16.1 | General..... | 167 |
| 8.1.16.2 | Initiation..... | 167 |
| 8.1.16.3 | INTER RAT HANDOVER INFO message contents to set..... | 168 |
| 8.1.17 | ETWS primary notification with security procedure..... | 170 |
| 8.1.17.1 | General..... | 170 |
| 8.1.17.2 | Initiation..... | 170 |
| 8.1.17.3 | Void..... | 170 |
| 8.1.17.4 | Reception of the ETWS PRIMARY NOTIFICATION WITH SECURITY message..... | 170 |
| 8.1.17.5 | Forward of the ETWS primary notification to the upper layers..... | 170 |
| 8.1.17.6 | Void..... | 170 |
| 8.2 | Radio Bearer control procedures..... | 171 |
| 8.2.1 | Radio bearer establishment..... | 171 |
| 8.2.2 | Reconfiguration procedures..... | 171 |
| 8.2.2.1 | General..... | 173 |
| 8.2.2.2 | Initiation..... | 173 |
| 8.2.2.2a | Initiation of handover from GERAN <i>Iu mode</i> | 175 |
| 8.2.2.3 | Reception of RADIO BEARER SETUP or RADIO BEARER RECONFIGURATION or RADIO BEARER RELEASE or TRANSPORT CHANNEL RECONFIGURATION or PHYSICAL CHANNEL RECONFIGURATION message or Target cell HS-SCCH order by the UE..... | 175 |
| 8.2.2.3a | Reception of RADIO BEARER RECONFIGURATION message by the UE performing handover from GERAN <i>Iu mode</i> | 194 |
| 8.2.2.4 | Transmission of a response message by the UE, normal case..... | 195 |
| 8.2.2.5 | Reception of a response message by the UTRAN, normal case..... | 197 |
| 8.2.2.5a | Rejection by the UE..... | 198 |
| 8.2.2.6 | Unsupported configuration in the UE..... | 199 |
| 8.2.2.7 | Physical channel failure..... | 199 |
| 8.2.2.8 | Cell re-selection..... | 200 |
| 8.2.2.9 | Transmission of a response message by the UE, failure case..... | 200 |
| 8.2.2.10 | Reception of a response message by the UTRAN, failure case..... | 201 |
| 8.2.2.11 | Invalid configuration..... | 202 |
| 8.2.2.12 | Incompatible simultaneous reconfiguration..... | 202 |
| 8.2.2.12a | Incompatible simultaneous security reconfiguration..... | 202 |
| 8.2.2.12b | Cell update procedure during security reconfiguration..... | 203 |
| 8.2.2.13 | Invalid received message..... | 203 |
| 8.2.2.14 | Radio link failure..... | 204 |
| 8.2.3 | Radio bearer release..... | 205 |
| 8.2.4 | Transport channel reconfiguration..... | 205 |
| 8.2.5 | Transport format combination control..... | 205 |
| 8.2.5.1 | General..... | 205 |
| 8.2.5.2 | Initiation..... | 206 |
| 8.2.5.3 | Reception of a TRANSPORT FORMAT COMBINATION CONTROL message by the UE..... | 206 |
| 8.2.5.4 | Invalid configuration..... | 208 |
| 8.2.5.5 | Invalid TRANSPORT FORMAT COMBINATION CONTROL message..... | 208 |
| 8.2.6 | Physical channel reconfiguration..... | 209 |

| | | |
|-----------|--|-----|
| 8.2.7 | Physical Shared Channel Allocation [TDD only] | 209 |
| 8.2.7.1 | General | 209 |
| 8.2.7.2 | Initiation | 209 |
| 8.2.7.3 | Reception of a PHYSICAL SHARED CHANNEL ALLOCATION message by the UE | 209 |
| 8.2.7.4 | Invalid PHYSICAL SHARED CHANNEL ALLOCATION message | 212 |
| 8.2.8 | PUSCH capacity request [TDD only] | 212 |
| 8.2.8.1 | General | 212 |
| 8.2.8.2 | Initiation | 212 |
| 8.2.8.3 | PUSCH CAPACITY REQUEST message contents to set | 213 |
| 8.2.8.4 | Reception of a PUSCH CAPACITY REQUEST message by the UTRAN | 214 |
| 8.2.8.5 | T310 expiry | 214 |
| 8.2.9 | Void | 214 |
| 8.2.10 | Uplink Physical Channel Control [TDD only] | 214 |
| 8.2.10.1 | General | 214 |
| 8.2.10.2 | Initiation | 215 |
| 8.2.10.3 | Reception of UPLINK PHYSICAL CHANNEL CONTROL message by the UE | 215 |
| 8.2.10.4 | Invalid UPLINK PHYSICAL CHANNEL CONTROL message | 215 |
| 8.2.11 | Physical channel reconfiguration failure | 216 |
| 8.2.11.1 | General | 216 |
| 8.2.11.2 | Runtime error due to overlapping compressed mode configurations | 216 |
| 8.2.11.3 | Void | 216 |
| 8.3 | RRC connection mobility procedures | 217 |
| 8.3.1 | Cell and URA update procedures | 217 |
| 8.3.1.1 | General | 219 |
| 8.3.1.2 | Initiation | 220 |
| 8.3.1.3 | CELL UPDATE / URA UPDATE message contents to set | 229 |
| 8.3.1.4 | T305 expiry and the UE detects "out of service area" | 234 |
| 8.3.1.4.1 | Re-entering "in service area" | 234 |
| 8.3.1.4.2 | Expiry of timer T307 | 235 |
| 8.3.1.5 | Reception of an CELL UPDATE/URA UPDATE message by the UTRAN | 235 |
| 8.3.1.6 | Reception of the CELL UPDATE CONFIRM/URA UPDATE CONFIRM message by the UE | 236 |
| 8.3.1.7 | Transmission of a response message to UTRAN | 245 |
| 8.3.1.7a | Physical channel failure | 249 |
| 8.3.1.8 | Unsupported configuration by the UE | 251 |
| 8.3.1.9 | Invalid configuration | 252 |
| 8.3.1.9a | Incompatible simultaneous reconfiguration | 253 |
| 8.3.1.9b | Security reconfiguration during Cell update procedure | 254 |
| 8.3.1.10 | Confirmation error of URA ID list | 254 |
| 8.3.1.11 | Invalid CELL UPDATE CONFIRM/URA UPDATE CONFIRM message | 255 |
| 8.3.1.12 | T302 expiry or cell reselection | 256 |
| 8.3.1.13 | T314 expiry | 260 |
| 8.3.1.14 | T315 expiry | 260 |
| 8.3.1.15 | Reception of the UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN | 261 |
| 8.3.1.16 | T320 Expiry | 261 |
| 8.3.2 | URA update | 262 |
| 8.3.3 | UTRAN mobility information | 262 |
| 8.3.3.1 | General | 262 |
| 8.3.3.2 | Initiation | 262 |
| 8.3.3.3 | Reception of UTRAN MOBILITY INFORMATION message by the UE | 262 |
| 8.3.3.4 | Reception of an UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN | 266 |
| 8.3.3.5 | Cell re-selection | 266 |
| 8.3.3.5a | Incompatible simultaneous security reconfiguration | 267 |
| 8.3.3.6 | Invalid UTRAN MOBILITY INFORMATION message | 267 |
| 8.3.3.7 | T322 expiry | 268 |
| 8.3.4 | Active set update | 268 |
| 8.3.4.1 | General | 268 |
| 8.3.4.2 | Initiation | 268 |
| 8.3.4.3 | Reception of an ACTIVE SET UPDATE message by the UE | 270 |
| 8.3.4.3a | Handling of ACTIVE SET UPDATE message on secondary uplink frequency (FDD only) | 272 |
| 8.3.4.4 | Unsupported configuration in the UE | 273 |
| 8.3.4.5 | Invalid configuration | 273 |
| 8.3.4.5a | Void | 274 |

| | | |
|-----------|--|-----|
| 8.3.4.5b | Incompatible simultaneous reconfiguration | 274 |
| 8.3.4.6 | Reception of the ACTIVE SET UPDATE COMPLETE message by the UTRAN | 275 |
| 8.3.4.7 | Reception of the ACTIVE SET UPDATE FAILURE message by the UTRAN | 275 |
| 8.3.4.8 | Invalid ACTIVE SET UPDATE message..... | 275 |
| 8.3.4.9 | Reception of an ACTIVE SET UPDATE message in wrong state | 276 |
| 8.3.5 | Hard handover | 276 |
| 8.3.5.1 | Timing re-initialised hard handover | 276 |
| 8.3.5.1.1 | General | 276 |
| 8.3.5.1.2 | Initiation (FDD only)..... | 276 |
| 8.3.5.2 | Timing-maintained hard handover | 278 |
| 8.3.5.2.1 | General | 278 |
| 8.3.5.2.2 | Initiation (FDD only)..... | 278 |
| 8.3.6 | Inter-RAT handover to UTRAN | 278 |
| 8.3.6.1 | General | 278 |
| 8.3.6.2 | Initiation..... | 279 |
| 8.3.6.3 | Reception of HANDOVER TO UTRAN COMMAND message by the UE | 279 |
| 8.3.6.4 | Invalid Handover to UTRAN command message..... | 285 |
| 8.3.6.4a | Unsupported configuration in HANDOVER TO UTRAN COMMAND message..... | 285 |
| 8.3.6.5 | UE fails to perform handover..... | 285 |
| 8.3.6.6 | Reception of message HANDOVER TO UTRAN COMPLETE by the UTRAN | 286 |
| 8.3.7 | Inter-RAT handover from UTRAN | 286 |
| 8.3.7.1 | General | 286 |
| 8.3.7.2 | Initiation..... | 287 |
| 8.3.7.3 | Reception of a HANDOVER FROM UTRAN COMMAND message by the UE..... | 287 |
| 8.3.7.4 | Successful completion of the inter-RAT handover | 288 |
| 8.3.7.5 | UE fails to complete requested handover | 289 |
| 8.3.7.6 | Invalid HANDOVER FROM UTRAN COMMAND message | 290 |
| 8.3.7.7 | Reception of an HANDOVER FROM UTRAN FAILURE message by UTRAN | 290 |
| 8.3.7.8 | Unsupported configuration in HANDOVER FROM UTRAN COMMAND message..... | 290 |
| 8.3.7.8a | Reception of HANDOVER FROM UTRAN COMMAND message by UE in CELL_FACH..... | 291 |
| 8.3.8 | Inter-RAT cell reselection to UTRAN | 292 |
| 8.3.8.1 | General | 292 |
| 8.3.8.2 | Initiation..... | 292 |
| 8.3.8.2a | Initiation of inter-RAT cell reselection from GERAN <i>Iu mode</i> | 292 |
| 8.3.8.3 | UE fails to complete an inter-RAT cell reselection..... | 293 |
| 8.3.8.3a | UE fails to complete an inter-RAT cell reselection from GERAN <i>Iu mode</i> | 293 |
| 8.3.9 | Inter-RAT cell reselection from UTRAN | 293 |
| 8.3.9.1 | General | 293 |
| 8.3.9.2 | Initiation..... | 293 |
| 8.3.9.2a | Initiation of inter-RAT cell reselection to GERAN <i>Iu mode</i> | 293 |
| 8.3.9.3 | Successful cell reselection..... | 294 |
| 8.3.9.4 | UE fails to complete an inter-RAT cell reselection..... | 294 |
| 8.3.10 | Inter-RAT cell change order to UTRAN | 294 |
| 8.3.10.1 | General | 294 |
| 8.3.10.2 | Initiation..... | 294 |
| 8.3.10.3 | UE fails to complete an inter-RAT cell change order | 294 |
| 8.3.11 | Inter-RAT cell change order from UTRAN..... | 295 |
| 8.3.11.1 | General | 295 |
| 8.3.11.2 | Initiation..... | 295 |
| 8.3.11.3 | Reception of an CELL CHANGE ORDER FROM UTRAN message by the UE | 295 |
| 8.3.11.4 | Successful completion of the cell change order | 296 |
| 8.3.11.5 | Expiry of timer T309 or UE fails to complete requested cell change order | 296 |
| 8.3.11.6 | Unsupported configuration in CELL CHANGE ORDER FROM UTRAN message | 298 |
| 8.3.11.7 | Invalid CELL CHANGE ORDER FROM UTRAN message..... | 298 |
| 8.4 | Measurement procedures..... | 299 |
| 8.4.0 | Measurement related definitions | 299 |
| 8.4.1 | Measurement control | 301 |
| 8.4.1.1 | General | 301 |
| 8.4.1.2 | Initiation..... | 301 |
| 8.4.1.3 | Reception of MEASUREMENT CONTROL by the UE | 301 |
| 8.4.1.4 | Unsupported measurement in the UE..... | 313 |
| 8.4.1.4a | Configuration Incomplete | 313 |

| | | |
|------------|---|-----|
| 8.4.1.5 | Invalid MEASUREMENT CONTROL message..... | 314 |
| 8.4.1.6 | Measurements after transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state ... | 314 |
| 8.4.1.6.1 | Intra-frequency measurement | 314 |
| 8.4.1.6.2 | Inter-frequency measurement | 315 |
| 8.4.1.6.3 | Inter-RAT measurement | 316 |
| 8.4.1.6.4 | Quality measurement | 317 |
| 8.4.1.6.5 | UE internal measurement | 317 |
| 8.4.1.6.6 | Traffic volume measurement | 317 |
| 8.4.1.6.7 | UE positioning measurement..... | 318 |
| 8.4.1.6.8 | CSG Proximity detection measurement..... | 320 |
| 8.4.1.6a | Actions in CELL_FACH/CELL_PCH/URA_PCH state upon cell re-selection | 320 |
| 8.4.1.7 | Measurements after transition from CELL_FACH to CELL_DCH state | 320 |
| 8.4.1.7.1 | Intra-frequency measurement | 320 |
| 8.4.1.7.2 | Inter-frequency measurement | 321 |
| 8.4.1.7.3 | Inter-RAT measurement | 321 |
| 8.4.1.7.4 | Traffic volume measurement..... | 321 |
| 8.4.1.7.5 | UE positioning measurement..... | 322 |
| 8.4.1.7.6 | CSG Proximity detection measurement..... | 322 |
| 8.4.1.7.7 | E-UTRA measurement for CELL_FACH | 323 |
| 8.4.1.8 | Measurements after transition from idle mode to CELL_DCH state | 323 |
| 8.4.1.8.1 | Intra-frequency measurement | 323 |
| 8.4.1.8.2 | Inter-frequency measurement | 323 |
| 8.4.1.8.3 | Inter-RAT measurement | 323 |
| 8.4.1.8.4 | Traffic volume measurement..... | 323 |
| 8.4.1.8.5 | UE positioning measurement..... | 323 |
| 8.4.1.9 | Measurements after transition from idle mode to CELL_FACH state | 324 |
| 8.4.1.9.1 | Intra-frequency measurement | 324 |
| 8.4.1.9.2 | Inter-frequency measurement | 324 |
| 8.4.1.9.3 | Inter-RAT measurement | 324 |
| 8.4.1.9.4 | Traffic volume measurement..... | 325 |
| 8.4.1.9.5 | UE positioning measurement..... | 325 |
| 8.4.1.9a | Measurements after transition from connected mode to idle mode..... | 325 |
| 8.4.1.9a.1 | Intra-frequency measurement | 325 |
| 8.4.1.9a.2 | Inter-frequency measurement | 326 |
| 8.4.1.9a.3 | Inter-RAT measurement | 326 |
| 8.4.1.9a.4 | UE positioning measurement..... | 326 |
| 8.4.1.9b | Measurements after transition from CELL_FACH to CELL_PCH/URA_PCH | 326 |
| 8.4.1.9b.1 | Traffic volume measurement..... | 326 |
| 8.4.1.9b.2 | UE positioning measurement..... | 327 |
| 8.4.1.9b.3 | Inter-RAT measurement | 327 |
| 8.4.1.9b.4 | Intra-frequency measurement | 327 |
| 8.4.1.9b.5 | Inter-frequency measurement | 327 |
| 8.4.1.9b.6 | E-UTRA measurement for CELL_FACH | 327 |
| 8.4.1.9c | Measurements after transition from CELL_PCH/URA_PCH to CELL_FACH | 328 |
| 8.4.1.9c.1 | Traffic volume measurement | 328 |
| 8.4.1.9c.2 | UE positioning measurement..... | 328 |
| 8.4.1.9c.3 | Inter-RAT measurement | 328 |
| 8.4.1.10 | Changes in measurement objects | 329 |
| 8.4.1.10.1 | Traffic volume measurement..... | 329 |
| 8.4.1.10.2 | Quality measurement | 330 |
| 8.4.1.10.3 | Intra-frequency, Inter-frequency and Inter-RAT measurements | 330 |
| 8.4.1.11 | Cell Reselection (FDD only and 1.28 Mcps TDD only) | 330 |
| 8.4.1.11.1 | Traffic volume measurement..... | 330 |
| 8.4.2 | Measurement report | 331 |
| 8.4.2.1 | General | 331 |
| 8.4.2.2 | Initiation..... | 331 |
| 8.4.3 | Assistance Data Delivery..... | 334 |
| 8.4.3.1 | General | 334 |
| 8.4.3.2 | Initiation..... | 334 |
| 8.4.3.3 | Reception of ASSISTANCE DATA DELIVERY message by the UE..... | 334 |
| 8.4.3.4 | Invalid ASSISTANCE DATA DELIVERY message..... | 334 |
| 8.5 | General procedures..... | 335 |

| | | |
|-----------|--|-----|
| 8.5.1 | Selection of initial UE identity | 335 |
| 8.5.2 | Actions when entering idle mode from connected mode | 335 |
| 8.5.3 | Open loop power control upon establishment of DPCH | 337 |
| 8.5.4 | Physical channel establishment criteria in CELL_DCH state | 337 |
| 8.5.4A | Physical channel establishment criteria for Enhanced Uplink in CELL_FACH state and Idle mode | 338 |
| 8.5.4B | Physical channel establishment criteria in CELL_DCH state on the secondary uplink frequency (FDD only) | 338 |
| 8.5.5 | Actions in "out of service area" and "in service area" | 338 |
| 8.5.5.1 | Detection of "out of service" area | 338 |
| 8.5.5.1.1 | Actions following detection of "out of service" area in URA_PCH or CELL_PCH state | 338 |
| 8.5.5.1.2 | Actions following detection of "out of service" area in CELL_FACH state | 338 |
| 8.5.5.1.3 | Actions following detection of "out of service" area on transition from CELL_DCH to URA_PCH or CELL_PCH | 339 |
| 8.5.5.1.4 | Actions following detection of "out of service" area on transition from CELL_DCH to CELL_FACH | 339 |
| 8.5.5.2 | Detection of "in service" area | 339 |
| 8.5.5.2.1 | Actions following Re-entry into "in service area" in URA_PCH or CELL_PCH state | 339 |
| 8.5.5.2.2 | Actions following re-entry into "in service area" in CELL_FACH state | 340 |
| 8.5.5.3 | T316 expiry | 340 |
| 8.5.5.4 | T317 expiry | 340 |
| 8.5.6 | Radio link failure criteria and actions upon radio link failure | 340 |
| 8.5.6a | Radio link failure criteria and actions upon radio link failure on the secondary uplink frequency (FDD only) | 341 |
| 8.5.7 | Open loop power control | 341 |
| 8.5.8 | Maintenance of Hyper Frame Numbers | 346 |
| 8.5.9 | START value calculation | 347 |
| 8.5.10 | Integrity protection | 347 |
| 8.5.10.1 | Integrity protection in downlink | 348 |
| 8.5.10.2 | Integrity protection in uplink | 349 |
| 8.5.10.3 | Calculation of message authentication code | 350 |
| 8.5.11 | FACH measurement occasion calculation | 350 |
| 8.5.11a | CELL_DCH measurement occasion calculation (1.28 Mcps TDD only) | 352 |
| 8.5.12 | Establishment of Access Service Classes | 352 |
| 8.5.13 | Mapping of Access Classes to Access Service Classes | 353 |
| 8.5.14 | PLMN Type Selection | 354 |
| 8.5.14a | Neighbour cells list narrowing for cell reselection | 354 |
| 8.5.15 | CFN calculation | 354 |
| 8.5.15.1 | Initialisation for CELL_DCH state after state transition | 354 |
| 8.5.15.2 | Initialisation in CELL_DCH state at hard handover | 354 |
| 8.5.15.3 | Initialisation for CELL_FACH | 355 |
| 8.5.15.4 | Initialisation after intersystem handover to UTRAN | 355 |
| 8.5.15.5 | Initialisation for MTCH and/or MSCH carried on S-CCPCH that may be soft combined | 355 |
| 8.5.16 | Configuration of CTCH occasions | 355 |
| 8.5.17 | PRACH selection | 356 |
| 8.5.18 | Selection of RACH TTI | 357 |
| 8.5.18.1 | FDD | 357 |
| 8.5.18.2 | 1.28 Mcps TDD | 358 |
| 8.5.19 | Secondary CCPCH selection | 358 |
| 8.5.19a | Secondary CCPCH and FACH selection for MCCH reception | 359 |
| 8.5.20 | Unsupported configuration | 359 |
| 8.5.21 | Actions related to Radio Bearer mapping | 359 |
| 8.5.22 | Actions when entering another RAT from connected mode | 368 |
| 8.5.23 | Measured results on RACH | 368 |
| 8.5.24 | Change of PLMN while in RRC connected mode | 371 |
| 8.5.25 | Actions related to HS_DSCH_RECEPTION variable | 372 |
| 8.5.26 | Service prioritisation | 374 |
| 8.5.27 | MBMS frequency selection | 374 |
| 8.5.28 | Actions related to E_DCH_TRANSMISSION variable | 376 |
| 8.5.29 | MBMS modification period identity calculation | 379 |
| 8.5.30 | Detecting MBMS service reception inability | 379 |
| 8.5.31 | Actions related to DEFERRED_MEASUREMENT_STATUS variable | 380 |
| 8.5.32 | Actions related to MIMO_PARAMS variable | 380 |

| | | |
|----------|---|-----|
| 8.5.33 | Actions related to MIMO_STATUS variable | 381 |
| 8.5.34 | Actions related to DTX_DRX_STATUS variable (FDD only) | 382 |
| 8.5.35 | Actions related to HS_SCCH_LESS_STATUS variable (FDD only) | 383 |
| 8.5.36 | Actions related to HS_DSCH_RECEPTION_CELL_FACH_STATE variable (FDD and 1.28 Mcps TDD only) | 384 |
| 8.5.37 | Actions related to HS_DSCH_RECEPTION_OF_CCCH_ENABLED variable (FDD and 1.28 Mcps TDD only) | 386 |
| 8.5.37a | Actions related to HS_DSCH_RECEPTION_GENERAL | 386 |
| 8.5.38 | Common H-RNTI selection (FDD and 1.28 Mcps TDD only) | 387 |
| 8.5.39 | PICH selection for HSDPA based paging (FDD and 1.28 Mcps TDD only) | 387 |
| 8.5.40 | HS_DSCH Reception in CELL_PCH and URA_PCH (FDD only) | 388 |
| 8.5.40a | HS_DSCH Reception in CELL_PCH and URA_PCH (1.28 Mcps TDD only) | 389 |
| 8.5.41 | HS-PDSCH channelisation codes selection for paging reception (FDD and 1.28 Mcps TDD only) | 390 |
| 8.5.42 | Autonomous UTRAN DRX Cycle length coefficient change | 391 |
| 8.5.43 | Reception of MBMS from a cell operating in MBSFN mode | 391 |
| 8.5.44 | HS-DSCH CQI reporting tables | 391 |
| 8.5.45 | Enhanced Uplink in CELL_FACH state and Idle mode (FDD only) | 391 |
| 8.5.45a | Enhanced Uplink in CELL_FACH state and Idle mode (1.28 Mcps TDD only) | 394 |
| 8.5.46 | Actions related to COMMON_E_DCH_TRANSMISSION variable (FDD and 1.28 Mcps TDD only) | 395 |
| 8.5.47 | Actions related to READY_FOR_COMMON_EDCH variable (FDD and 1.28 Mcps TDD only) | 397 |
| 8.5.48 | Actions related to HS_DSCH_DRX_CELL_FACH_STATUS variable (FDD and 1.28 Mcps TDD only) and HS_DSCH_DRX_CELL_FACH_2CYCLE_STATUS variable (FDD only) | 399 |
| 8.5.49 | CELL_FACH HS-DSCH DRX operation (FDD only) | 400 |
| 8.5.49a | CELL_FACH HS-DSCH DRX operation (1.28 Mcps TDD only) | 401 |
| 8.5.49b | CELL_FACH HS-DSCH DRX operation with second DRX cycle (FDD only) | 401 |
| 8.5.50 | Common E-RNTI selection (1.28 Mcps TDD only) | 403 |
| 8.5.51 | Actions related to SECONDARY_CELL_HS_DSCH_RECEPTION variable (FDD only) | 404 |
| 8.5.52 | Actions related to TARGET_CELL_PRECONFIGURATION variable (FDD only) | 405 |
| 8.5.53 | Actions related to CONTROL_CHANNEL_DRX_STATUS variable (1.28 Mcps TDD only) | 406 |
| 8.5.54 | Actions related to E_DCH_SPS_STATUS variable (1.28 Mcps TDD only) | 407 |
| 8.5.55 | Actions related to HS_DSCH_SPS_STATUS variable (1.28 Mcps TDD only) | 407 |
| 8.5.56 | Actions related to HSPA_RNTI_STORED_CELL_PCH variable (FDD and 1.28 Mcps TDD only) | 408 |
| 8.5.57 | Actions related to SECONDARY_CELL_MIMO_STATUS variable | 409 |
| 8.5.58 | Actions related to SECONDARY_CELL_E_DCH_TRANSMISSION variable (FDD only) | 410 |
| 8.5.59 | Actions related to reception of a HS-SCCH order for secondary uplink frequency activation/deactivation (FDD only) | 412 |
| 8.5.60 | Configuration of "TSN field extension" for MAC-ehs entity | 413 |
| 8.5.61 | Actions related to MU_MIMO_STATUS variable (1.28 Mcps TDD only) | 413 |
| 8.5.62 | Actions related to MULTI_CARRIER_E_DCH_TRANSMISSION variable (1.28 Mcps TDD only) | 414 |
| 8.5.63 | Logged Measurements Configuration | 415 |
| 8.5.63.1 | General | 415 |
| 8.5.63.2 | Initiation | 415 |
| 8.5.63.3 | Reception of LOGGING MEASUREMENT CONFIGURATION by the UE | 415 |
| 8.5.63.4 | T326 Expiry | 416 |
| 8.5.63.5 | T327 Expiry | 416 |
| 8.5.64 | UE INFORMATION | 416 |
| 8.5.64.1 | General | 416 |
| 8.5.64.2 | Initiation | 417 |
| 8.5.64.3 | Reception of the UE INFORMATION REQUEST message by the UE | 417 |
| 8.5.64.4 | Reception of the UE INFORMATION RESPONSE message by the UTRAN | 418 |
| 8.5.65 | Measurements logging | 418 |
| 8.5.65.1 | General | 418 |
| 8.5.65.2 | Initiation | 418 |
| 8.5.66 | Release of Logged Measurements Configuration | 419 |
| 8.5.66.1 | General | 419 |
| 8.5.66.2 | Initiation | 419 |
| 8.5.67 | Measurements logging for ANR | 419 |
| 8.5.67.1 | General | 419 |
| 8.5.67.2 | Initiation | 419 |
| 8.5.68 | Release of ANR Logging Measurements Configuration | 421 |
| 8.5.68.1 | General | 421 |

| | | |
|-----------|---|-----|
| 8.5.68.2 | Initiation..... | 421 |
| 8.5.69 | Actions related to UPLINK_CLTD_TRANSMISSION variable (FDD only) | 421 |
| 8.5.70 | Actions related to UPLINK_OLTD_TRANSMISSION variable (FDD only) | 422 |
| 8.5.71 | Actions related to MULTIFLOW_STATUS variable (FDD only)..... | 423 |
| 8.5.72 | Selection of common E-DCH TTI (FDD only) | 424 |
| 8.5.73 | PRACH preamble control parameters selection with Concurrent Deployment of 2ms and 10ms TTI (for Enhanced Uplink, FDD only) | 425 |
| 8.5.74 | PRACH preamble control parameters selection without Concurrent Deployment of 2ms and 10ms TTI (for Enhanced Uplink, FDD only) | 426 |
| 8.5.75 | Actions related to READY_FOR_COMMON_ERGCH variable (FDD only) | 427 |
| 8.5.76 | Actions related to FALLBACK_R99_PRACH_ENABLED variable (FDD only) | 428 |
| 8.5.77 | Actions related to READY_FOR_FALLBACK_R99_PRACH variable (FDD only) | 429 |
| 8.5.78 | Actions related to MIMO_MODE_WITH_FOUR_TRANSMIT_ANTENNAS_PARAMS variable (FDD only)..... | 430 |
| 8.5.79 | Actions related to MIMO_MODE_WITH_FOUR_TRANSMIT_ANTENNAS_STATUS variable(FDD only)..... | 430 |
| 8.5.80 | Actions related to SECONDARY_CELL_MIMO_MODE_WITH_FOUR_TRANSMIT_ANTENNAS_STATUS variable (FDD only)..... | 431 |
| 8.5.81 | Actions related to UPLINK_MIMO_TRANSMISSION variable (FDD only) | 432 |
| 8.6 | Generic actions on receipt and absence of an information element..... | 433 |
| 8.6.1 | CN information elements..... | 433 |
| 8.6.1.1 | Void..... | 433 |
| 8.6.1.2 | CN information info | 433 |
| 8.6.1.3 | Signalling connection release indication | 434 |
| 8.6.2 | UTRAN mobility information elements | 434 |
| 8.6.2.1 | URA identity | 434 |
| 8.6.2.2 | Mapping info..... | 435 |
| 8.6.2.3 | RNC support for change of UE capability | 435 |
| 8.6.2.4 | CSG PSC Split Information | 435 |
| 8.6.2.5 | E-UTRA detection | 436 |
| 8.6.3 | UE information elements | 436 |
| 8.6.3.1 | Activation time..... | 436 |
| 8.6.3.1a | CN domain specific DRX cycle length coefficient | 437 |
| 8.6.3.1b | H-RNTI..... | 437 |
| 8.6.3.2 | UTRAN DRX Cycle length coefficient | 438 |
| 8.6.3.3 | Generic state transition rules depending on received information elements | 438 |
| 8.6.3.4 | Ciphering mode info | 439 |
| 8.6.3.5 | Integrity protection mode info..... | 442 |
| 8.6.3.5.1 | Initialisation of Integrity Protection..... | 443 |
| 8.6.3.5.2 | Integrity Protection Re-configuration for SRNS Relocation, intra-RAT SR-VCC and handover from GERAN Iu mode..... | 444 |
| 8.6.3.5.3 | Integrity Protection modification in case of new keys or initialisation of signalling connection .. | 445 |
| 8.6.3.6 | Void..... | 446 |
| 8.6.3.7 | Void..... | 446 |
| 8.6.3.8 | Integrity check info | 446 |
| 8.6.3.9 | New C-RNTI..... | 446 |
| 8.6.3.9a | New DSCH-RNTI..... | 446 |
| 8.6.3.10 | New U-RNTI..... | 446 |
| 8.6.3.11 | RRC transaction identifier..... | 447 |
| 8.6.3.12 | Capability Update Requirement | 451 |
| 8.6.3.13 | Group release information..... | 452 |
| 8.6.3.14 | New E-RNTI..... | 453 |
| 8.6.3.15 | SR-VCC Info..... | 454 |
| 8.6.3.16 | rSR-VCC Info | 454 |
| 8.6.4 | Radio bearer information elements | 454 |
| 8.6.4.1 | Signalling RB information to setup list..... | 454 |
| 8.6.4.2 | RAB information for setup..... | 455 |
| 8.6.4.2a | RAB information to reconfigure | 457 |
| 8.6.4.3 | RB information to setup | 457 |
| 8.6.4.4 | RB information to be affected..... | 460 |
| 8.6.4.4a | Void..... | 460 |