



SLOVENSKI STANDARD
SIST EN 300 392-5 V2.7.1:2020

01-julij-2020

Prizemni snopovni radio (TETRA) - Govor in podatki (V+D) ter neposredni način zveze (DMO) - 5. del: Vmesnik periferne opreme (PEI)

Terrestrial Trunked Radio (TETRA) - Voice plus Data (V+D) and Direct Mode Operation (DMO) - Part 5: Peripheral Equipment Interface (PEI)

iTeh STANDARD PREVIEW
(standards.iteh.ai)

Ta slovenski standard je istoveten z: ~~SIST EN 300 392-5 V2.7.1:2020~~ ETSI EN 300 392-5 V2.7.1 (2020-04)

<https://standards.iteh.ai/catalog/standards/sist/ab0dc079-ab6a-41be-a3e2-e420713ebe9a/sist-en-300-392-5-v2-7-1-2020>

ICS:

33.070.10	Prizemni snopovni radio (TETRA)	Terrestrial Trunked Radio (TETRA)
-----------	---------------------------------	-----------------------------------

SIST EN 300 392-5 V2.7.1:2020

en

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST EN 300 392-5 V2.7.1:2020

<https://standards.iteh.ai/catalog/standards/sist/ab0dc079-ab6a-41be-a3e2-e420713ebe9a/sist-en-300-392-5-v2-7-1-2020>

ETSI EN 300 392-5 V2.7.1 (2020-04)



Terrestrial Trunked Radio (TETRA); Voice plus Data (V+D) and Direct Mode Operation (DMO); Part 5: Peripheral Equipment Interface (PEI)

[SIST EN 300 392-5 V2.7.1:2020](https://standards.iteh.ai/catalog/standards/sist/ab0dc079-ab6a-41be-a3e2-e420713ebe9a/sist-en-300-392-5-v2-7-1-2020)

<https://standards.iteh.ai/catalog/standards/sist/ab0dc079-ab6a-41be-a3e2-e420713ebe9a/sist-en-300-392-5-v2-7-1-2020>

Reference

REN/TCCE-03266

Keywords

data, interface, TETRA, V+D, voice

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

iTeh STANDARD PREVIEW
(standards.iteh.ai)

Important notice

<https://standards.iteh.ai/catalog/standards/sist/ab0dc079-ab6a-41be-a3e2-e4201198e9a/sist-en-300-392-5-v2-7-1-2020>
The present document can be downloaded from:
<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at <https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:
<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2020.
All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M™ logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Contents

Intellectual Property Rights	22
Foreword.....	22
Modal verbs terminology.....	23
1 Scope	24
2 References	24
2.1 Normative references	24
2.2 Informative references.....	26
3 Definition of terms, symbols and abbreviations.....	26
3.1 Terms.....	26
3.2 Symbols.....	26
3.3 Abbreviations	27
4 Overview of TETRA PEI.....	31
4.1 Introduction	31
4.2 Protocol architecture.....	31
4.3 Context model	32
4.4 Void.....	35
4.5 SDS Message stacks.....	35
4.5.0 General on SDS Message stacks.....	35
4.5.1 Status message texts.....	35
4.5.2 SDS 1 message texts.....	35
4.5.3 Status and SDS types 1, 2 and 3	36
4.5.4 SDS type 4	36
4.6 Phone books	36
4.7 Reserved status values considerations.....	36
4.8 SDS-TL considerations	37
4.9 AT commands	38
4.9.1 General on AT commands.....	38
4.9.2 AT command state.....	39
4.9.3 AT circuit mode data state	40
4.9.4 TNP1 and packet data state.....	40
4.9.5 Transitions between states	40
4.9.5.1 Transition from AT command state to AT circuit mode data state	40
4.9.5.2 Transition from AT circuit mode data state to AT command state	41
4.9.5.3 Transition from AT command state to TNP1 or packet data state	41
4.9.5.4 Transition from TNP1 and packet data state to AT command state.....	41
4.10 TNP1 and IP network layer	41
4.10.1 General operation.....	41
4.10.2 IP addressing.....	42
4.10.3 Local mode	42
4.10.4 Wide mode.....	42
4.11 TNP1 operation	43
4.12 Link start up at the MT.....	44
5 Physical layer	44
5.1 General on physical layer.....	44
5.2 Physical layer for V.24/V.28	44
5.2.1 Electrical characteristics for V.24/V.28.....	44
5.2.2 Physical connection	44
5.2.3 Character format	45
5.2.4 Data transmission rate for V.24/V.28	46
5.3 Wire-line high rate connectivity technologies.....	46
5.3.1 General.....	46
5.3.2 Universal Serial Bus	47
5.3.3 USB On-The-Go.....	47
5.4 Wireless high rate connectivity	48

5.4.1	General.....	48
5.4.2	Wireless Security	48
5.4.3	Certified Wireless USB	48
5.4.4	Bluetooth	48
6	AT command set	49
6.1	General on AT command set.....	49
6.2	Limitations	49
6.3	SDS user data	49
6.4	AT command syntax	50
6.4.1	General on AT command syntax	50
6.4.2	Command line.....	50
6.4.2.0	Command line structure	50
6.4.2.1	Prefix.....	50
6.4.2.2	Body.....	50
6.4.2.3	Termination Character	51
6.4.2.4	Concatenating extended commands	51
6.4.2.5	Multiline extended commands	51
6.4.3	Command types	51
6.4.4	Parameters.....	52
6.4.5	AT command examples	52
6.4.6	Information responses and result codes	53
6.4.6.1	General on information responses and result codes	53
6.4.6.2	Information Responses.....	54
6.4.6.3	Result Code	54
6.4.6.4	AT result examples in verbose mode	54
6.4.6.5	AT result examples in numeric mode.....	56
6.4.6.6	Aborting information results and result codes.....	57
6.4.6.7	Unsolicited nested responses.....	57
6.4.7	Handling of unknown parameters.....	60
6.5	Existing V.250 commands for call control.....	60
6.5.1	Commands	60
6.5.2	Result Codes.....	61
6.5.3	Dialled string and user identity	61
6.6	Existing V.250 commands for PEI control.....	61
6.6a	Modified V.250 commands for PEI control	62
6.6a.1	General on modified V.250 commands for PEI control.....	62
6.6a.2	Line termination character: S3.....	62
6.6a.2.1	General on S3.....	62
6.6a.2.2	Description	62
6.6a.2.3	S3 set syntax.....	62
6.6a.2.4	S3 read syntax	62
6.6a.2.5	S3 read result code text	63
6.6a.2.6	S3 test syntax	63
6.6a.2.7	S3 test result syntax.....	63
6.6a.3	Response formatting character: S4	63
6.6a.3.1	General on S4.....	63
6.6a.3.2	Description	63
6.6a.3.3	S4 set syntax.....	63
6.6a.3.4	S4 read syntax	63
6.6a.3.5	S4 read result code text	63
6.6a.3.6	S4 test syntax	64
6.6a.3.7	S4 test result syntax.....	64
6.6a.4	Line editing character: S5	64
6.6a.4.1	General on S5.....	64
6.6a.4.2	Description	64
6.6a.4.3	S5 set syntax.....	64
6.6a.4.4	S5 read syntax	64
6.6a.4.5	S5 read result code text	64
6.6a.4.6	S5 test syntax	64
6.6a.4.7	S5 test result syntax.....	65
6.6a.5	Echo: E	65

6.6a.5.1	General on E.....	65
6.6a.5.2	Description	65
6.6a.5.3	E set syntax	65
6.6a.5.4	E read syntax.....	65
6.6a.5.5	E read result code text.....	65
6.6a.5.6	E test syntax	65
6.6a.5.7	E test result syntax	65
6.6a.6	Result code suppression: Q.....	66
6.6a.6.1	General on Q.....	66
6.6a.6.2	Description	66
6.6a.6.3	Q set syntax.....	66
6.6a.6.4	Q read syntax	66
6.6a.6.5	Q read result code text.....	66
6.6a.6.6	Q test syntax.....	66
6.6a.6.7	Q test result syntax.....	66
6.6a.7	MT response format: V.....	66
6.6a.7.1	General on V	66
6.6a.7.2	Description	66
6.6a.7.3	V set syntax.....	67
6.6a.7.4	V read syntax	67
6.6a.7.5	V read result code text.....	67
6.6a.7.6	V test syntax.....	67
6.6a.7.7	V test result syntax	67
6.6a.8	Circuit 109 (DCD) behavior: &C	67
6.6a.8.1	General on &C	67
6.6a.8.2	Description	67
6.6a.8.3	&C set syntax.....	67
6.6a.8.4	&C read syntax.....	67
6.6a.8.5	&C read result code text.....	68
6.6a.8.6	&C test syntax	68
6.6a.8.7	&C test result syntax	68
6.6a.9	Circuit 108/2 (DTR) behavior: &D.....	68
6.6a.9.1	General on &D.....	68
6.6a.9.2	Description	68
6.6a.9.3	&D set syntax.....	68
6.6a.9.4	&D read syntax	68
6.6a.9.5	&D read result code text	68
6.6a.9.6	&D test syntax.....	69
6.6a.9.7	&D test result syntax.....	69
6.6a.10	PEI data rate: +IPR.....	69
6.6a.10.1	General on +IPR.....	69
6.6a.10.2	Description	69
6.6a.10.3	+IPR set syntax	69
6.6a.10.4	+IPR read syntax.....	69
6.6a.10.5	+IPR read result code text.....	69
6.6a.10.6	+IPR test syntax	69
6.6a.10.7	+IPR test result syntax	69
6.7	Existing V.250 commands for generic MT control.....	70
6.7a	Modified V.250 commands for generic MT control	70
6.7a.1	General on modified V.250 commands for generic MT control.....	70
6.7a.2	Full factory defaults Z.....	70
6.7a.2.1	General on full factory defaults Z	70
6.7a.2.2	Description	70
6.7a.2.3	Z execution syntax	71
6.7a.2.4	Z test syntax	71
6.7a.3	Factory defaults &F	71
6.7a.3.1	General on factory defaults &F.....	71
6.7a.3.2	Description	71
6.7a.3.3	&F execution syntax	71
6.7a.3.4	&F test syntax	71
6.8	Existing Hayes AT commands for PEI control	72
6.9	Existing 3GPP commands for MT and call control.....	72

6.10	Modified PCCA wireless extended commands	72
6.11	Modified Cellular commands for MT control	73
6.11.1	General on cellular commands for MT control	73
6.11.2	MT Capabilities +GCAP	73
6.11.2.1	General on +GCAP	73
6.11.2.2	Description	73
6.11.2.3	GCAP execution syntax	73
6.11.2.4	GCAP execution read syntax	74
6.11.2.5	GCAP execution read and unsolicited result code text	74
6.11.2.6	GCAP test syntax	74
6.11.3	Network registration +CREG	74
6.11.3.1	General on +CREG	74
6.11.3.2	CREG set syntax	74
6.11.3.3	Description of set command	74
6.11.3.4	CREG execution read syntax	75
6.11.3.5	CREG execution read and unsolicited result code text	75
6.11.3.6	CREG test syntax	75
6.11.3.7	CREG test result syntax	75
6.11.4	Get MT TETRA identities +CNUM	75
6.11.4.1	General on +CNUM	75
6.11.4.2	Description	75
6.11.4.3	CNUM execution mode syntax	75
6.11.4.4	CNUM execution read mode syntax	75
6.11.4.5	CNUM execution read result code text	76
6.11.4.6	CNUM test syntax	76
6.11.5	Get MT TETRA Identities (alternative commands)	76
6.11.5.1	Get MT TETRA Fixed identity number(s); ITSI, and Gateway address(es) +CNUMF	76
6.11.5.1.1	General on +CNUMF	76
6.11.5.1.2	Description	76
6.11.5.1.3	CNUMF execution mode syntax	76
6.11.5.1.4	CNUMF execution read mode syntax	76
6.11.5.1.5	CNUMF execution read result code text	77
6.11.5.1.6	CNUMF test syntax	77
6.11.5.2	Get MT static group identities +CNUMS	77
6.11.5.2.1	General on +CNUMS	77
6.11.5.2.2	Description	77
6.11.5.2.3	CNUMS set or execution/set syntax	78
6.11.5.2.4	CNUMS execution read or read syntax	78
6.11.5.2.5	CNUMS execution read or execution/set and unsolicited result code text	79
6.11.5.2.6	CNUMS test syntax	80
6.11.5.2.7	CNUMS test result syntax	80
6.11.5.3	Get MT dynamic group identities +CNUMD	80
6.11.5.3.1	General on +CNUMD	80
6.11.5.3.2	Description	80
6.11.5.3.3	CNUMD set or execution/set syntax	81
6.11.5.3.4	CNUMD execution read or read syntax	82
6.11.5.3.5	CNUMD execution read or execution/set and unsolicited result code text	82
6.11.5.3.6	CNUMD test syntax	82
6.11.5.3.7	CNUMD test result syntax	82
6.12	SDS message stack commands	83
6.12.1	General on SDS message stack commands	83
6.12.2	Delete message +CMGD	83
6.12.2.1	General on +CMGD	83
6.12.2.2	CMGD execution syntax	83
6.12.2.3	Description	83
6.12.2.4	CMGD test syntax	83
6.12.2.5	CMGD test result syntax	84
6.12.3	List messages +CMGL	84
6.12.3.1	General on +CMGL	84
6.12.3.2	CMGL execution syntax	84
6.12.3.3	Description	84
6.12.3.4	CMGL execution result code text	84

6.12.3.5	CMGL test syntax	85
6.12.4	Read message +CMGR.....	85
6.12.4.1	General on +CMGR	85
6.12.4.2	CMGR execution syntax	85
6.12.4.3	Description	85
6.12.4.4	CMGR execution result code text	85
6.12.4.5	CMGR test syntax	86
6.12.5	Write message +CMGW.....	86
6.12.5.1	General on +CMGW	86
6.12.5.2	CMGW execution syntax.....	86
6.12.5.3	Description	86
6.12.5.4	CMGW execution result code text	87
6.12.5.5	CMGW test syntax	87
6.12.6	Message send from store +CMSS	87
6.12.6.1	General on +CMSS	87
6.12.6.2	CMSS execution syntax	88
6.12.6.3	Description	88
6.12.6.4	CMSS test, execution and unsolicited result code text.....	88
6.12.6.5	CMSS test syntax	88
6.12.7	New message indication +CMTI	88
6.12.7.1	General on +CMTI.....	88
6.12.7.2	Description	89
6.12.7.3	CMTI unsolicited result code text	89
6.13	SDS direct commands	89
6.13.1	General on SDS direct commands	89
6.13.2	Send message +CMGS	89
6.13.2.1	General on +CMGS	89
6.13.2.2	CMGS execution syntax	90
6.13.2.3	Description	90
6.13.2.4	CMGS execution and unsolicited result code text	90
6.13.2.5	CMGS test syntax	90
6.13.3	TETRA SDS Receive +CTSDSR	91
6.13.3.1	General on +CTSDSR	91
6.13.3.2	Description	91
6.13.3.3	CTSDSR unsolicited result code text	91
6.14	TETRA MT control commands.....	91
6.14.1	General on TETRA MT control commands	91
6.14.2	TETRA Broadcast +CTBCT	91
6.14.2.1	General on +CTBCT	91
6.14.2.2	Description	92
6.14.2.3	CTBCT execution read and unsolicited result code text	92
6.14.2.4	CTBCT execution read syntax	92
6.14.2.5	CTBCT test syntax	92
6.14.3	TETRA Status Text Read +CTSTR.....	92
6.14.3.1	General on +CTSTR	92
6.14.3.2	CTSTR execution syntax	92
6.14.3.3	Description	92
6.14.3.4	CTSTR execution result code text	92
6.14.3.5	CTSTR test syntax	92
6.14.4	TETRA Service Profile +CTSP	93
6.14.4.1	General on +CTSP	93
6.14.4.2	CTSP set syntax	93
6.14.4.3	Description	93
6.14.4.4	CTSP read syntax.....	95
6.14.4.5	CTSP read result code text	95
6.14.4.6	CTSP test syntax	95
6.14.4.7	CTSP test result syntax	95
6.14.5	TETRA service definition for Circuit Mode services +CTSDC	96
6.14.5.1	General on +CTSDC	96
6.14.5.2	CTSDC set syntax	96
6.14.5.3	Description	97
6.14.5.4	CTSDC read syntax.....	97

6.14.5.5	CTSDC read result code text.....	97
6.14.5.6	CTSDC test syntax.....	97
6.14.5.7	CTSDC test result syntax.....	97
6.14.6	TETRA service definition for SDS Service +CTSDS.....	98
6.14.6.1	General on +CTSDS.....	98
6.14.6.2	CTSDS set syntax.....	98
6.14.6.3	Description.....	98
6.14.6.4	CTSDS read syntax.....	98
6.14.6.5	CTSDS read result code text.....	98
6.14.6.6	CTSDS test syntax.....	98
6.14.6.7	CTSDS test result syntax.....	99
6.14.7	TETRA operating mode +CTOM.....	99
6.14.7.1	General on +CTOM.....	99
6.14.7.2	CTOM set syntax.....	99
6.14.7.3	Description.....	99
6.14.7.4	CTOM read syntax.....	99
6.14.7.5	CTOM read and unsolicited result code text.....	99
6.14.7.6	CTOM test syntax.....	100
6.14.7.7	CTOM test result.....	100
6.14.8	TETRA DM communication type +CTDCT.....	100
6.14.8.1	General on +CTDCT.....	100
6.14.8.2	CTDCT set syntax.....	100
6.14.8.3	Description.....	100
6.14.8.4	CTDCT read syntax.....	100
6.14.8.5	CTDCT read and unsolicited result code text.....	100
6.14.8.6	CTDCT test syntax.....	100
6.14.8.7	CTDCT test result text.....	100
6.14.9	TETRA Transient communication type +CTTCT.....	101
6.14.9.1	General on +CTTCT.....	101
6.14.9.2	CTTCT set syntax.....	101
6.14.9.3	Description.....	101
6.14.9.4	CTTCT unsolicited result code text.....	101
6.14.9.5	CTTCT read syntax.....	101
6.14.9.6	CTTCT read result syntax.....	101
6.14.9.7	CTTCT test syntax.....	101
6.14.9.8	CTTCT test result syntax.....	101
6.14.10	TETRA DMO visible gateways/repeaters +CTDGR.....	101
6.14.10.1	General on +CTDGR.....	101
6.14.10.2	CTDGR set syntax.....	102
6.14.10.3	Description.....	102
6.14.10.4	CTDGR execution read and unsolicited result code text.....	102
6.14.10.5	CTDGR execution read syntax.....	102
6.14.10.6	CTDGR test syntax.....	102
6.14.11	TETRA DM Carrier Selection +CTDCS.....	102
6.14.11.1	General on +CTDCS.....	102
6.14.11.2	CTDCS set syntax.....	102
6.14.11.3	Description.....	103
6.14.11.4	CTDCS read and unsolicited result code text.....	103
6.14.11.5	CTDCS read syntax.....	103
6.14.11.6	CTDCS test syntax.....	103
6.14.12	MT Reboot R.....	103
6.14.12.1	General on MT Reboot R.....	103
6.14.12.2	Description.....	103
6.14.12.3	R execution syntax.....	103
6.14.12.4	R test syntax.....	103
6.14.13	TETRA Broadcast +CTBCF.....	104
6.14.13.1	General on +CTBCF.....	104
6.14.13.2	Description.....	104
6.14.13.3	CTBCF set syntax.....	104
6.14.13.4	CTBCF execute syntax.....	104
6.14.13.5	CTBCF execute and unsolicited result code text.....	104
6.14.13.6	CTBCF read syntax.....	104

6.14.13.7	CTBCF test syntax	104
6.14.13.8	CTBCF test result text.....	105
6.14.14	TETRA radio frequency sensitive area mode +CTRFSA.....	105
6.14.14.1	General on +CTRFSA.....	105
6.14.14.2	Description.....	105
6.14.14.3	CTRFSA set syntax.....	105
6.14.14.4	CTRFSA read syntax	105
6.14.14.5	CTRFSA read and unsolicited result code text	105
6.14.14.6	CTRFSA test syntax.....	105
6.14.14.7	CTRFSA test result text	106
6.15	New TETRA call handling commands.....	106
6.15.1	General on new TETRA call handling commands	106
6.15.2	TETRA Call Connect +CTCC.....	106
6.15.2.1	General on +CTCC	106
6.15.2.2	Description.....	106
6.15.2.3	CTCC unsolicited result code text	106
6.15.3	TETRA Call Release +CTCR.....	106
6.15.3.1	General on +CTCR	106
6.15.3.2	Description.....	106
6.15.3.3	CTCR unsolicited result code text	106
6.15.4	TETRA Incoming Call Notification +CTICN	107
6.15.4.1	General on +CTICN.....	107
6.15.4.2	Description.....	107
6.15.4.3	CTICN unsolicited result code text.....	107
6.15.5	TETRA outgoing Call progress notification +CTOCP	107
6.15.5.1	General on +CTOCP.....	107
6.15.5.2	Description.....	108
6.15.5.3	CTOCP unsolicited result code text.....	108
6.15.6	TETRA Group Set up +CTGS.....	108
6.15.6.1	General on +CTGS.....	108
6.15.6.2	CTGS set syntax.....	108
6.15.6.3	Description.....	108
6.15.6.4	CTGS read syntax.....	108
6.15.6.5	CTGS read and unsolicited result code text.....	108
6.15.6.6	CTGS test syntax	109
6.15.6.7	CTGS test result syntax.....	109
6.15.7	Void	109
6.15.8	Transmit Demand +CTXD	109
6.15.8.1	General on +CTXD.....	109
6.15.8.2	CTXD execution syntax.....	109
6.15.8.3	Description.....	109
6.15.8.4	CTXD test syntax.....	109
6.15.8.5	CTXD test result syntax.....	109
6.15.9	Up Transmit Ceased +CUTXC.....	110
6.15.9.1	General +CUTXC	110
6.15.9.2	CUTXC execution syntax	110
6.15.9.3	Description.....	110
6.15.9.4	CUTXC test syntax	110
6.15.10	Transmission Grant +CTXG.....	110
6.15.10.1	General on +CTXG	110
6.15.10.2	Description.....	110
6.15.10.3	CTXG unsolicited result code text.....	110
6.15.11	Down Transmission Ceased +CDTXC.....	110
6.15.11.1	General on +CDTXC	110
6.15.11.2	Description.....	111
6.15.11.3	CDTXC unsolicited result code text	111
6.15.12	Transmission Continue +CTXN	111
6.15.12.1	General on +CTXN.....	111
6.15.12.2	Description.....	111
6.15.12.3	CTXN unsolicited result code text.....	111
6.15.13	Transmission Interrupt +CTXI	111
6.15.13.1	General on +CTXI	111

6.15.13.2	Description	111
6.15.13.3	CTXI unsolicited result code text	111
6.15.14	Transmission Wait +CTXW	111
6.15.14.1	General on +CTXW	111
6.15.14.2	Description	111
6.15.14.3	CTXW unsolicited result code text	112
6.15.15	Key Status +CTKST	112
6.15.15.1	General on +CTKST	112
6.15.15.2	CTKST set syntax	112
6.15.15.3	Description	112
6.16	MT errors	112
6.16.1	General on MT errors	112
6.16.2	Report MT error +CMEE	112
6.16.2.1	General on +CMEE	112
6.16.2.2	CMEE set syntax	113
6.16.2.3	Description	113
6.16.2.4	CMEE set result code text	113
6.16.2.5	CMEE read syntax	113
6.16.2.6	CMEE read result code text	113
6.16.2.7	CMEE test syntax	113
6.16.3	MT error result code +CME ERROR	113
6.16.3.1	General on +CME ERROR	113
6.16.3.2	Description	113
6.16.3.3	CME ERROR unsolicited result code text	114
6.16.4	MT result code +CME PARAMETER	114
6.16.4.1	General on +CME PARAMETER	114
6.16.4.2	Description	114
6.16.4.3	CME PARAMETER unsolicited result code text	114
6.17	Parameter description and values	114
6.17.1	General on parameters	114
6.17.2	Access Priority	114
6.17.3	AI service	114
6.17.4	AI mode	115
6.17.5	Alpha	115
6.17.5a	Ancillary ID	115
6.17.6	Area	116
6.17.6a	Baud rate	116
6.17.7	BS service	117
6.17.8	Call status	117
6.17.9	Called party identity	117
6.17.10	Calling party identity	118
6.17.11	Called party identity type	118
6.17.12	Calling party identity type	118
6.17.13	CC instance	118
6.17.13a	Cell load CA	119
6.17.13b	Cell load CA control	119
6.17.13c	Cell load DA TCH	119
6.17.13d	Cell load DA TCH control	119
6.17.13e	Cell load DA PDCH	119
6.17.13f	Cell load DA PDCH control	120
6.17.13g	Cell load DA CCH/SDS	120
6.17.13h	Cell load DA CCH/SDS control	120
6.17.14	Class of MS	120
6.17.14a	Circuit 108/2 behaviour	122
6.17.14b	Circuit 109 behaviour	123
6.17.15	CLIR control	123
6.17.15a	Command line echo	123
6.17.16	Comms type	123
6.17.17	CT unsolic	124
6.17.18	Disconnect cause	124
6.17.19	DM carrier	125
6.17.20	DM communication type	125

6.17.21	End to end encryption	125
6.17.22	Extended error report	125
6.17.23	Extended error report codes	126
6.17.24	Gateway/repeater address	127
6.17.24a	Gateway/repeater type	127
6.17.25	Group type	127
6.17.26	GR unsolic	128
6.17.27	Hook	128
6.17.28	Ident unsolic.....	128
6.17.29	Importance factor.....	128
6.17.29a	Key name	128
6.17.29b	Key status	129
6.17.30	LA.....	129
6.17.31	Length.....	129
6.17.31a	Line editing character	129
6.17.31b	Line termination character	129
6.17.32	Link identifier	130
6.17.33	Lower range Limit	130
6.17.34	Message index	130
6.17.35	Message reference.....	130
6.17.36	MNI	130
6.17.37	Number of groups	130
6.17.38	Num type	130
6.17.39	Parameter number	131
6.17.40	Void	131
6.17.41	Presence information	131
6.17.42	Priority	131
6.17.43	Priority level	132
6.17.44	Proprietary	132
6.17.45	Proprietary element owner.....	132
6.17.46	Reg stat	132
6.17.47	Reg unsolic	133
6.17.47a	RF SA mode.....	133
6.17.47b	RF SA unsolic.....	133
6.17.47c	Response format mode.....	133
6.17.47d	Response formatting character.....	133
6.17.47e	Result code suppression.....	133
6.17.48	RqTx	134
6.17.49	SDS instance	134
6.17.50	SDS-TL addressing.....	134
6.17.51	SDS Status	134
6.17.52	Security information	134
6.17.53	Service profile.....	135
6.17.54	Service layer1	135
6.17.55	Service layer2	135
6.17.56	Serviced GSSI.....	136
6.17.57	Simplex	136
6.17.58	Slots/Codec	136
6.17.59	Stack full.....	137
6.17.60	Stack present.....	137
6.17.61	TPI (Transmitting Party Identity)	137
6.17.62	TPI (Transmitting Party Identity) type.....	137
6.17.63	Transient communication type.....	137
6.17.64	TxCont	138
6.17.65	TxDemandPriority	138
6.17.66	TxGrant.....	138
6.17.67	TxRqPrmsn	138
6.17.68	Upper range limit.....	138
6.17.69	User data	138
6.17.70	Version number	138
6.18	Outgoing call set up methodology.....	139
6.18.1	General on outgoing call set up methodology.....	139

iTech STANDARD PREVIEW
(standards.itech.ai)

SIST EN 300 392-5 V2.7.1:2020

[https://standards.itech.ai/catalog/standards/sist/ab0dc079-ab6a-41be-a3e2-](https://standards.itech.ai/catalog/standards/sist/ab0dc079-ab6a-41be-a3e2-e420713ebe9a/sist-en-300-392-5-v2-7-1-2020)

[e420713ebe9a/sist-en-300-392-5-v2-7-1-2020](https://standards.itech.ai/catalog/standards/sist/ab0dc079-ab6a-41be-a3e2-e420713ebe9a/sist-en-300-392-5-v2-7-1-2020)

6.18.2	Voice calls	139
6.18.3	Circuit mode data calls	140
6.18.4	Sending of SDS messages.....	141
6.18.4.1	General on sending of SDS messages	141
6.18.4.2	Send via Stack.....	141
6.18.4.3	Direct Send.....	141
6.19	Incoming call set up methodology	141
6.19.1	General on incoming call set up methodology.....	141
6.19.2	Voice calls	141
6.19.3	Circuit mode data calls	142
6.19.4	Reception of SDS messages.....	142
6.19.4.1	Received via Stack	142
6.19.4.2	Direct Received.....	142
6.20	Voice and circuit mode data call maintenance commands	142
6.21	Call clear down commands	143
6.21.1	General on call clear down commands	143
6.21.2	TE Initiated clear	143
6.21.3	Network and MT Initiated clear.....	143
6.22	MEX layer support.....	143
6.22.0	General on support of MEX layer commands.....	143
6.22.1	MEX Capability +CTMCAP	143
6.22.1.1	General on +CTMCAP	143
6.22.1.2	CTMCAP execution syntax	143
6.22.1.3	CTMCAP execution result code text.....	144
6.22.1.4	CTMCAP test syntax	144
6.22.2	MEX Connect +CTMCON.....	144
6.22.2.1	General on +CTMCON.....	144
6.22.2.2	CTMCON execution syntax.....	144
6.22.2.3	CTMCON execution result code text.....	144
6.22.2.4	CTMCON test syntax.....	144
6.22.3	MEX End +CTMEND.....	144
6.22.3.1	General on +CTMEND.....	144
6.22.3.2	CTMEND execution syntax.....	144
6.22.3.3	CTMEND execution and unsolicited result code text.....	144
6.22.3.4	CTMEND test syntax.....	145
6.22.4	MEX Handle +CTMHDL.....	145
6.22.4.1	General on +CTMHDL.....	145
6.22.4.2	CTMHDL execution syntax.....	145
6.22.4.3	CTMHDL execution result code text.....	145
6.22.4.4	CTMHDL test syntax.....	145
6.22.5	MEX Modify +CTMMOD	145
6.22.5.1	General on +CTMMOD.....	145
6.22.5.2	CTMMOD execution syntax.....	145
6.22.5.3	CTMMOD result code text	145
6.22.5.4	CTMMOD unsolicited result code syntax.....	146
6.22.5.5	CTMMOD test syntax.....	146
6.22.6	MEX QOS Class +CTMQC	146
6.22.6.1	General on +CTMQC.....	146
6.22.6.2	CTMQC execution syntax.....	146
6.22.6.3	CTMQC execution result code text.....	146
6.22.6.4	CTMQC test syntax.....	146
6.22.7	Request new logical PEI Connection +CTPCON.....	146
6.22.7.1	General on +CTPCON.....	146
6.22.7.2	CTPCON execution syntax.....	146
6.22.7.3	CTPCON execution result code text	147
6.22.7.4	CTPCON test syntax	147
6.22.8	MEX related parameters	147
6.22.8.1	CONTEXT_READY timer.....	147
6.22.8.2	Data class	147
6.22.8.3	Data importance	148
6.22.8.4	Data priority	148
6.22.8.5	DCOMP	148

6.22.8.6	Delay class	148
6.22.8.7	Device address	148
6.22.8.8	Endpoint address	148
6.22.8.9	Maximum transmission unit.....	149
6.22.8.10	Mean active throughput.....	149
6.22.8.11	Mean throughput	149
6.22.8.12	MEX capability	150
6.22.8.13	MEX connect reject cause.....	150
6.22.8.14	MEX connect report.....	151
6.22.8.15	MEX data importance	151
6.22.8.16	MEX data priority	151
6.22.8.17	MEX deactivation type	152
6.22.8.18	MEX escalate DSCP5 Flag Enable.....	152
6.22.8.19	MEX escalate DSCP5 Flag Reset	152
6.22.8.20	MEX filter	152
6.22.8.21	MEX filter operation.....	152
6.22.8.22	MEX filter type	152
6.22.8.23	MEX handle	153
6.22.8.24	MEX mode.....	153
6.22.8.25	MEX modify reject cause.....	153
6.22.8.26	MEX modify report.....	153
6.22.8.27	MEX NSAPI usage	154
6.22.8.28	MEX PDP address	154
6.22.8.29	MEX PDP type.....	154
6.22.8.30	MEX PDU priority max	154
6.22.8.31	MEX precedence.....	155
6.22.8.32	MEX precedence rank.....	155
6.22.8.33	MEX precedence supported.....	155
6.22.8.34	MEX peer IP filter.....	155
6.22.8.35	MEX QoS.....	155
6.22.8.36	MEX QoS class.....	155
6.22.8.37	MEX QoS class access.....	155
6.22.8.38	MEX QoS class upper/lower (Downlink).....	156
6.22.8.39	MEX QoS class upper/lower (Uplink).....	156
6.22.8.40	MEX QoS filter.....	156
6.22.8.41	MEX transaction type	156
6.22.8.42	Minimum peak throughput.....	156
6.22.8.43	Mobile IPv4 information.....	157
6.22.8.44	NSAPI.....	157
6.22.8.45	NSAPI data priority.....	157
6.22.8.46	NSAPI QoS negotiation	157
6.22.8.47	PCOMP	157
6.22.8.48	PCON result	158
6.22.8.49	PDU priority.....	158
6.22.8.50	PDU priority max.....	158
6.22.8.51	Reliability class	158
6.22.8.52	Schedule availability	158
6.22.8.53	Scheduled access.....	158
6.22.8.54	Scheduled number of N-PDUs per grant.....	159
6.22.8.55	Scheduled N-PDU size.....	159
6.22.8.56	Schedule repetition period.....	159
6.22.8.57	Schedule timing error.....	159
6.22.8.58	Share response flag	160
7	TNP1 service description	160
7.1	Service primitives at the TNP1A-SAP	160
7.2	Service primitives at the TNP1B-SAP	160
7.3	Service primitives at TNP1A-SAP and TNP1B-SAP	160
7.4	Primitive descriptions.....	161
7.4.1	TNP1-Services CAPABILITY	161
7.4.2	TNP1-SDS-TL CAPABILITY	161
7.4.3	TNP1-IDENTIFICATION.....	161