

ETSI TS 136 413 V14.9.0 (2019-07)



LTE;
Evolved Universal Terrestrial
Radio Access Network (E-UTRAN);
S1 Application Protocol (S1AP)
(3GPP TS 36.413 version 14.9.0 Release 14)



ReferenceRTS/TSGR-0336413ve90

KeywordsLTE

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2019.

All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.

3GPP™ and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M™ logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	14
1 Scope	15
2 References	15
3 Definitions and abbreviations.....	17
3.1 Definitions	17
3.2 Abbreviations	18
4 General	19
4.1 Procedure Specification Principles.....	19
4.2 Forwards and Backwards Compatibility	20
4.3 Specification Notations	20
5 S1AP Services	21
6 Services Expected from Signalling Transport.....	22
7 Functions of S1AP	23
8 S1AP Procedures	25
8.1 List of S1AP Elementary procedures	25
8.2 E-RAB Management procedures.....	27
8.2.1 E-RAB Setup	27
8.2.1.1 General	27
8.2.1.2 Successful Operation.....	27
8.2.1.3 Unsuccessful Operation	28
8.2.1.4 Abnormal Conditions	29
8.2.2 E-RAB Modify	29
8.2.2.1 General	29
8.2.2.2 Successful Operation.....	29
8.2.2.3 Unsuccessful Operation	30
8.2.2.4 Abnormal Conditions	30
8.2.3 E-RAB Release	31
8.2.3.1 General	31
8.2.3.2 Successful Operation.....	31
8.2.3.2.1 E-RAB Release – MME initiated	31
8.2.3.2.2 E-RAB Release Indication – eNB initiated	32
8.2.3.3 Abnormal Conditions	32
8.2.4 E-RAB Modification Indication	32
8.2.4.1 General	32
8.2.4.2 Successful Operation.....	33
8.2.4.3 Unsuccessful Operation	33
8.2.4.4 Abnormal Conditions	34
8.3 Context Management procedures	34
8.3.1 Initial Context Setup	34
8.3.1.1 General	34
8.3.1.2 Successful Operation.....	34
8.3.1.3 Unsuccessful Operation	38
8.3.1.4 Abnormal Conditions	38
8.3.2 UE Context Release Request (eNB initiated)	38
8.3.2.1 General	38
8.3.2.2 Successful Operation.....	38
8.3.3 UE Context Release (MME initiated).....	39
8.3.3.1 General	39

8.3.3.2	Successful Operation.....	39
8.3.3.3	Abnormal Conditions	40
8.3.4	UE Context Modification.....	40
8.3.4.1	General	40
8.3.4.2	Successful Operation.....	40
8.3.4.3	Unsuccessful Operation	42
8.3.4.4	Abnormal Conditions	42
8.3.5	UE Radio Capability Match.....	42
8.3.5.1	General	42
8.3.5.2	Successful Operation.....	43
8.3.5.3	Unsuccessful Operation	43
8.3.5.4	Abnormal Conditions	43
8.3.6	UE Context Modification Indication	43
8.3.6.1	General	43
8.3.6.2	Successful Operation.....	44
8.3.6.3	Unsuccessful Operation	44
8.3.6.4	Abnormal Conditions	44
8.3.7	UE Context Suspend	44
8.3.7.1	General	44
8.3.7.2	Successful Operation.....	44
8.3.8	UE Context Resume.....	45
8.3.8.1	General	45
8.3.8.2	Successful Operation.....	45
8.3.8.3	Unsuccessful Operation	46
8.3.9	Connection Establishment Indication	46
8.3.9.1	General	46
8.3.9.2	Successful Operation.....	46
8.3.9.3	Unsuccessful Operation	47
8.3.9.4	Abnormal Conditions	47
8.3.10	Retrieve UE Information	47
8.3.10.1	General	47
8.3.10.2	Successful Operation.....	47
8.3.10.3	Unsuccessful Operation	47
8.3.10.4	Abnormal Conditions	47
8.3.11	UE Information Transfer	47
8.3.11.1	General	47
8.3.11.2	Successful Operation.....	47
8.3.11.3	Unsuccessful Operation	48
8.3.11.4	Abnormal Conditions	48
8.3.12	eNB CP Relocation Indication.....	48
8.3.12.1	General	48
8.3.12.2	Successful Operation.....	48
8.3.12.3	Unsuccessful Operation	49
8.3.12.4	Abnormal Conditions	49
8.3.13	MME CP Relocation Indication.....	49
8.3.13.1	General	49
8.3.13.2	Successful Operation.....	49
8.3.13.3	Unsuccessful Operation	49
8.3.13.4	Abnormal Conditions	49
8.4	Handover Signalling.....	49
8.4.1	Handover Preparation	49
8.4.1.1	General	49
8.4.1.2	Successful Operation.....	50
8.4.1.3	Unsuccessful Operation	53
8.4.1.4	Abnormal Conditions	53
8.4.2	Handover Resource Allocation.....	54
8.4.2.1	General	54
8.4.2.2	Successful Operation.....	54
8.4.2.3	Unsuccessful Operation	57
8.4.2.4	Abnormal Conditions	57
8.4.3	Handover Notification	58
8.4.3.1	General	58

8.4.3.2	Successful Operation.....	58
8.4.3.3	Abnormal Conditions	58
8.4.4	Path Switch Request	58
8.4.4.1	General	58
8.4.4.2	Successful Operation.....	58
8.4.4.3	Unsuccessful Operation	60
8.4.4.4	Abnormal Conditions	61
8.4.5	Handover Cancellation	61
8.4.5.1	General	61
8.4.5.2	Successful Operation.....	61
8.4.5.3	Unsuccessful Operation	61
8.4.5.4	Abnormal Conditions	61
8.4.6	eNB Status Transfer.....	62
8.4.6.1	General	62
8.4.6.2	Successful Operation.....	62
8.4.6.3	Unsuccessful Operation	62
8.4.6.4	Abnormal Conditions	62
8.4.7	MME Status Transfer.....	62
8.4.7.1	General	62
8.4.7.2	Successful Operation.....	63
8.4.7.3	Unsuccessful Operation	63
8.4.7.4	Abnormal Conditions	63
8.5	Paging.....	63
8.5.1	General.....	63
8.5.2	Successful Operation	64
8.5.3	Unsuccessful Operation	65
8.5.4	Abnormal Conditions.....	65
8.6	NAS transport.....	65
8.6.1	General.....	65
8.6.2	Successful Operations	65
8.6.2.1	Initial UE Message.....	65
8.6.2.2	DOWNLINK NAS TRANSPORT	66
8.6.2.3	UPLINK NAS TRANSPORT	67
8.6.2.4	NAS NON DELIVERY INDICATION	68
8.6.2.4a	NAS DELIVERY INDICATION	68
8.6.2.5	Reroute NAS Request	69
8.6.3	Unsuccessful Operation	69
8.6.4	Abnormal Conditions.....	69
8.7	Management procedures.....	69
8.7.1	Reset	69
8.7.1.1	General	69
8.7.1.2	Successful Operation.....	70
8.7.1.2.1	Reset Procedure Initiated from the MME.....	70
8.7.1.2.2	Reset Procedure Initiated from the E-UTRAN	71
8.7.1.3	Abnormal Conditions	71
8.7.1.3.1	Abnormal Condition at the EPC	71
8.7.1.3.2	Abnormal Condition at the E-UTRAN	72
8.7.1.3.3	Crossing of Reset Messages	72
8.7.2	Error Indication.....	72
8.7.2.1	General	72
8.7.2.2	Successful Operation.....	72
8.7.2.3	Abnormal Conditions	73
8.7.3	S1 Setup	73
8.7.3.1	General	73
8.7.3.2	Successful Operation.....	73
8.7.3.3	Unsuccessful Operation	74
8.7.3.4	Abnormal Conditions	74
8.7.4	eNB Configuration Update	74
8.7.4.1	General	74
8.7.4.2	Successful Operation.....	74
8.7.4.3	Unsuccessful Operation	75
8.7.4.4	Abnormal Conditions	75

8.7.5	MME Configuration Update	75
8.7.5.1	General	75
8.7.5.2	Successful Operation.....	76
8.7.5.3	Unsuccessful Operation	76
8.7.5.4	Abnormal Conditions	76
8.7.6	Overload Start	77
8.7.6.1	General	77
8.7.6.2	Successful Operation.....	77
8.7.6.3	Unsuccessful Operation	78
8.7.7	Overload Stop	78
8.7.7.1	General	78
8.7.7.2	Successful Operation.....	78
8.7.7.3	Unsuccessful Operation	78
8.8	S1 CDMA2000 Tunnelling Procedures.....	78
8.8.1	General.....	78
8.8.2	Successful Operations.....	79
8.8.2.1	Downlink S1 CDMA2000 Tunnelling	79
8.8.2.2	Uplink S1 CDMA2000 Tunnelling	79
8.8.3	Unsuccessful Operation	80
8.8.4	Abnormal Conditions.....	80
8.9	UE Capability Info Indication	80
8.9.1	General.....	80
8.9.2	Successful Operation	80
8.10	Trace Procedures	81
8.10.1	Trace Start.....	81
8.10.1.1	General	81
8.10.1.2	Successful Operation.....	81
8.10.2	Trace Failure Indication.....	82
8.10.2.1	General	82
8.10.2.2	Successful Operation.....	82
8.10.3	Deactivate Trace	82
8.10.3.1	General	82
8.10.3.2	Successful Operation.....	82
8.10.4	Cell Traffic Trace.....	83
8.10.4.1	General	83
8.10.4.2	Successful Operation.....	83
8.11	Location Reporting Procedures	83
8.11.1	Location Reporting Control	83
8.11.1.1	General	83
8.11.1.2	Successful Operation.....	83
8.11.1.3	Abnormal Conditions	84
8.11.2	Location Report Failure Indication	84
8.11.2.1	General	84
8.11.2.2	Successful Operation.....	84
8.11.3	Location Report	84
8.11.3.1	General	84
8.11.3.2	Successful Operation.....	84
8.11.3.3	Abnormal Conditions	85
8.12	Warning Message Transmission Procedures	85
8.12.1	Write-Replace Warning	85
8.12.1.1	General	85
8.12.1.2	Successful Operation.....	85
8.12.1.3	Abnormal Conditions	86
8.12.2	Kill.....	86
8.12.2.1	General	86
8.12.2.2	Successful Operation.....	86
8.12.3	PWS Restart Indication.....	87
8.12.3.1	General	87
8.12.3.2	Successful Operation.....	87
8.12.4	PWS Failure Indication.....	87
8.12.4.1	General	87
8.12.4.2	Successful Operation.....	88

8.13	eNB Direct Information Transfer	88
8.13.1	General.....	88
8.13.2	Successful Operation	88
8.13.2.1	eNB Direct Information Transfer	88
8.13.3	Abnormal Conditions.....	88
8.14	MME Direct Information Transfer	89
8.14.1	General.....	89
8.14.2	Successful Operation	89
8.14.2.1	MME Direct Information Transfer.....	89
8.14.3	Abnormal Conditions.....	89
8.15	eNB Configuration Transfer.....	89
8.15.1	General.....	89
8.15.2	Successful Operation	90
8.15.2.1	eNB Configuration Transfer.....	90
8.15.3	Abnormal Conditions.....	90
8.16	MME Configuration Transfer.....	90
8.16.1	General.....	90
8.16.2	Successful Operation	90
8.16.2.1	MME Configuration Transfer	90
8.16.3	Abnormal Conditions.....	91
8.17	LPPa transport	91
8.17.1	General.....	91
8.17.2	Successful Operations.....	92
8.17.2.1	DOWNLINK UE ASSOCIATED LPPA TRANSPORT	92
8.17.2.2	UPLINK UE ASSOCIATED LPPA TRANSPORT	92
8.17.2.3	DOWNLINK NON UE ASSOCIATED LPPA TRANSPORT	92
8.17.2.4	UPLINK NON UE ASSOCIATED LPPA TRANSPORT	93
8.17.3	Unsuccessful Operation	93
8.17.4	Abnormal Conditions.....	93
9	Elements for S1AP Communication	94
9.1	Message Functional Definition and Content	94
9.1.1	General.....	94
9.1.2	Message Contents	94
9.1.2.1	Presence	94
9.1.2.2	Criticality	94
9.1.2.3	Range	94
9.1.2.4	Assigned Criticality.....	94
9.1.3	E-RAB Management Messages	95
9.1.3.1	E-RAB SETUP REQUEST	95
9.1.3.2	E-RAB SETUP RESPONSE.....	96
9.1.3.3	E-RAB MODIFY REQUEST	97
9.1.3.4	E-RAB MODIFY RESPONSE	97
9.1.3.5	E-RAB RELEASE COMMAND	98
9.1.3.6	E-RAB RELEASE RESPONSE	98
9.1.3.7	E-RAB RELEASE INDICATION.....	99
9.1.3.8	E-RAB MODIFICATION INDICATION	100
9.1.3.9	E-RAB MODIFICATION CONFIRM	101
9.1.4	Context Management Messages	101
9.1.4.1	INITIAL CONTEXT SETUP REQUEST	101
9.1.4.2	Void.....	102
9.1.4.3	INITIAL CONTEXT SETUP RESPONSE	103
9.1.4.4	INITIAL CONTEXT SETUP FAILURE.....	103
9.1.4.5	UE CONTEXT RELEASE REQUEST	103
9.1.4.6	UE CONTEXT RELEASE COMMAND	104
9.1.4.7	UE CONTEXT RELEASE COMPLETE	104
9.1.4.8	UE CONTEXT MODIFICATION REQUEST.....	104
9.1.4.9	UE CONTEXT MODIFICATION RESPONSE.....	105
9.1.4.10	UE CONTEXT MODIFICATION FAILURE.....	105
9.1.4.11	UE RADIO CAPABILITY MATCH REQUEST	106
9.1.4.12	UE RADIO CAPABILITY MATCH RESPONSE	106
9.1.4.13	UE CONTEXT MODIFICATION INDICATION	106

9.1.4.14	UE CONTEXT MODIFICATION CONFIRM	106
9.1.4.15	UE CONTEXT SUSPEND REQUEST	107
9.1.4.16	UE CONTEXT SUSPEND RESPONSE	107
9.1.4.17	UE CONTEXT RESUME REQUEST	107
9.1.4.18	UE CONTEXT RESUME RESPONSE	108
9.1.4.19	UE CONTEXT RESUME FAILURE	108
9.1.4.20	CONNECTION ESTABLISHMENT INDICATION	109
9.1.4.21	RETRIEVE UE INFORMATION	109
9.1.4.22	UE INFORMATION TRANSFER	109
9.1.4.23	eNB CP RELOCATION INDICATION	110
9.1.4.24	MME CP RELOCATION INDICATION	110
9.1.5	Handover Signalling Messages	111
9.1.5.1	HANDOVER REQUIRED	111
9.1.5.2	HANDOVER COMMAND	112
9.1.5.3	HANDOVER PREPARATION FAILURE	113
9.1.5.4	HANDOVER REQUEST	114
9.1.5.5	HANDOVER REQUEST ACKNOWLEDGE	115
9.1.5.6	HANDOVER FAILURE	116
9.1.5.7	HANDOVER NOTIFY	116
9.1.5.8	PATH SWITCH REQUEST	117
9.1.5.9	PATH SWITCH REQUEST ACKNOWLEDGE	118
9.1.5.10	PATH SWITCH REQUEST FAILURE	119
9.1.5.11	HANDOVER CANCEL	119
9.1.5.12	HANDOVER CANCEL ACKNOWLEDGE	119
9.1.5.13	eNB STATUS TRANSFER	119
9.1.5.14	MME STATUS TRANSFER	119
9.1.6	PAGING	120
9.1.7	NAS Transport Messages	121
9.1.7.1	INITIAL UE MESSAGE	121
9.1.7.2	DOWNLINK NAS TRANSPORT	122
9.1.7.3	UPLINK NAS TRANSPORT	122
9.1.7.4	NAS NON DELIVERY INDICATION	122
9.1.7.4a	NAS DELIVERY INDICATION	123
9.1.7.5	REROUTE NAS REQUEST	123
9.1.8	Management messages	123
9.1.8.1	RESET	123
9.1.8.2	RESET ACKNOWLEDGE	124
9.1.8.3	ERROR INDICATION	124
9.1.8.4	S1 SETUP REQUEST	124
9.1.8.5	S1 SETUP RESPONSE	125
9.1.8.6	S1 SETUP FAILURE	126
9.1.8.7	ENB CONFIGURATION UPDATE	126
9.1.8.8	ENB CONFIGURATION UPDATE ACKNOWLEDGE	127
9.1.8.9	ENB CONFIGURATION UPDATE FAILURE	127
9.1.8.10	MME CONFIGURATION UPDATE	127
9.1.8.11	MME CONFIGURATION UPDATE ACKNOWLEDGE	128
9.1.8.12	MME CONFIGURATION UPDATE FAILURE	128
9.1.8.13	OVERLOAD START	128
9.1.8.14	OVERLOAD STOP	129
9.1.9	S1 CDMA2000 Tunnelling Messages	130
9.1.9.1	DOWNLINK S1 CDMA2000 TUNNELLING	130
9.1.9.2	UPLINK S1 CDMA2000 TUNNELLING	130
9.1.10	UE CAPABILITY INFO INDICATION	130
9.1.11	Trace Messages	131
9.1.11.1	TRACE START	131
9.1.11.2	TRACE FAILURE INDICATION	131
9.1.11.3	DEACTIVATE TRACE	131
9.1.12	Location Reporting Messages	132
9.1.12.1	LOCATION REPORTING CONTROL	132
9.1.12.2	LOCATION REPORT FAILURE INDICATION	132
9.1.12.3	LOCATION REPORT	132
9.1.13	Warning Message Transmission Messages	132

9.1.13.1	WRITE-REPLACE WARNING REQUEST	132
9.1.13.2	WRITE-REPLACE WARNING RESPONSE	133
9.1.13.3	KILL REQUEST	133
9.1.13.4	KILL RESPONSE	133
9.1.13.5	PWS RESTART INDICATION	134
9.1.13.6	PWS FAILURE INDICATION	134
9.1.14	eNB DIRECT INFORMATION TRANSFER	135
9.1.15	MME DIRECT INFORMATION TRANSFER	135
9.1.16	eNB CONFIGURATION TRANSFER	135
9.1.17	MME CONFIGURATION TRANSFER	135
9.1.18	CELL TRAFFIC TRACE	135
9.1.19	LPPa Transport Messages	136
9.1.19.1	DOWNLINK UE ASSOCIATED LPPA TRANSPORT	136
9.1.19.2	UPLINK UE ASSOCIATED LPPA TRANSPORT	136
9.1.19.3	DOWNLINK NON UE ASSOCIATED LPPA TRANSPORT	137
9.1.19.4	UPLINK NON UE ASSOCIATED LPPA TRANSPORT	137
9.2	Information Element Definitions	137
9.2.0	General	137
9.2.1	Radio Network Layer Related IEs	137
9.2.1.1	Message Type	137
9.2.1.2	E-RAB ID	138
9.2.1.3	Cause	138
9.2.1.3a	RRC Establishment Cause	142
9.2.1.4	Trace Activation	142
9.2.1.5	Source ID	143
9.2.1.6	Target ID	143
9.2.1.7	Source eNB to Target eNB Transparent Container	144
9.2.1.8	Target eNB to Source eNB Transparent Container	145
9.2.1.9	Source RNC to Target RNC Transparent Container	145
9.2.1.10	Target RNC to Source RNC Transparent Container	145
9.2.1.11	Source BSS to Target BSS Transparent Container	145
9.2.1.12	Target BSS to Source BSS Transparent Container	145
9.2.1.13	Handover Type	145
9.2.1.14	Extended RNC-ID	146
9.2.1.15	E-RAB Level QoS Parameters	146
9.2.1.16	Paging DRX	146
9.2.1.17	Paging Cause	146
9.2.1.18	GBR QoS Information	146
9.2.1.19	Bit Rate	147
9.2.1.20	UE Aggregate Maximum Bit Rate	147
9.2.1.21	Criticality Diagnostics	147
9.2.1.22	Handover Restriction List	148
9.2.1.23	CDMA2000-PDU	149
9.2.1.24	CDMA2000 RAT Type	149
9.2.1.25	CDMA2000 Sector ID	150
9.2.1.26	Security Context	150
9.2.1.27	UE Radio Capability	151
9.2.1.28	CDMA2000 HO Status	151
9.2.1.29	CDMA2000 HO Required Indication	151
9.2.1.30	1xRTT MEID	151
9.2.1.31	eNB Status Transfer Transparent Container	151
9.2.1.32	COUNT Value	153
9.2.1.33	CDMA2000 1xRTT RAND	153
9.2.1.34	Request Type	153
9.2.1.35	CDMA2000 1xRTT SRVCC Info	154
9.2.1.36	E-RAB List	154
9.2.1.37	Global eNB ID	155
9.2.1.38	E-UTRAN CGI	155
9.2.1.39	Subscriber Profile ID for RAT/Frequency priority	155
9.2.1.40	UE Security Capabilities	155
9.2.1.41	Security Key	156
9.2.1.42	UE History Information	156

9.2.1.43	Last Visited Cell Information.....	156
9.2.1.43a	Last Visited E-UTRAN Cell Information	157
9.2.1.43b	Last Visited GERAN Cell Information	157
9.2.1.44	Message Identifier.....	157
9.2.1.45	Serial Number	158
9.2.1.46	Warning Area List.....	158
9.2.1.47	Emergency Area ID.....	158
9.2.1.48	Repetition Period.....	158
9.2.1.49	Number of Broadcasts Requested	159
9.2.1.50	Warning Type	159
9.2.1.51	Warning Security Information	159
9.2.1.52	Data Coding Scheme.....	159
9.2.1.53	Warning Message Contents.....	159
9.2.1.54	Broadcast Completed Area List	159
9.2.1.55	Inter-system Information Transfer Type	160
9.2.1.56	Source To Target Transparent Container	160
9.2.1.57	Target To Source Transparent Container	161
9.2.1.58	SRVCC Operation Possible	162
9.2.1.59	SRVCC HO Indication.....	162
9.2.1.60	Allocation and Retention Priority	162
9.2.1.61	Time to wait	163
9.2.1.62	CSG Id	163
9.2.1.63	CSG Id List	163
9.2.1.64	MS Classmark 2	164
9.2.1.65	MS Classmark 3	164
9.2.1.66	Cell Type.....	164
9.2.1.67	Old BSS to New BSS Information.....	164
9.2.1.68	Layer 3 Information	164
9.2.1.69	E-UTRAN Round Trip Delay Estimation Info	164
9.2.1.70	Broadcast Cancelled Area List.....	164
9.2.1.71	Number of Broadcasts.....	165
9.2.1.72	Concurrent Warning Message Indicator.....	165
9.2.1.73	CSG Membership Status.....	166
9.2.1.74	Cell Access Mode	166
9.2.1.75	Extended Repetition Period.....	166
9.2.1.76	Data Forwarding Not Possible	166
9.2.1.77	PS Service Not Available.....	166
9.2.1.78	Paging Priority	166
9.2.1.79	Relay Node Indicator	167
9.2.1.80	Correlation ID	167
9.2.1.81	MDT Configuration	167
9.2.1.82	MME Relay Support Indicator.....	170
9.2.1.83	Management Based MDT Allowed.....	170
9.2.1.84	GW Context Release Indication.....	170
9.2.1.85	Voice Support Match Indicator	171
9.2.1.86	M3 Configuration.....	171
9.2.1.87	M4 Configuration.....	171
9.2.1.88	M5 Configuration.....	171
9.2.1.89	MDT PLMN List	171
9.2.1.90	COUNT Value Extended	172
9.2.1.91	Kill-all Warning Messages Indicator	172
9.2.1.92	LHN ID	172
9.2.1.93	User Location Information.....	172
9.2.1.94	MBSFN-ResultToLog.....	172
9.2.1.95	EARFCN.....	173
9.2.1.96	Expected UE Behaviour	173
9.2.1.97	Expected UE Activity Behaviour.....	174
9.2.1.98	UE Radio Capability for Paging.....	174
9.2.1.99	ProSe Authorized	174
9.2.1.100	COUNT Value for PDCP SN Length 18.....	175
9.2.1.101	M6 Configuration.....	175
9.2.1.102	M7 Configuration.....	175

9.2.1.103	Assistance Data for Paging	176
9.2.1.104	Assistance Data for Recommended Cells	176
9.2.1.105	Information on Recommended Cells and eNBs for Paging	176
9.2.1.106	Recommended Cells for Paging	176
9.2.1.107	Recommended eNBs for Paging	177
9.2.1.108	Assistance Data for CE capable UEs	177
9.2.1.109	Cell Identifier and Coverage Enhancement Level.....	178
9.2.1.110	Paging Attempt Information.....	178
9.2.1.111	Paging eDRX Information	178
9.2.1.112	UE Retention Information.....	178
9.2.1.113	UE User Plane CIoT Support Indicator.....	178
9.2.1.114	NB-IoT Default Paging DRX.....	179
9.2.1.115	NB-IoT Paging eDRX Information.....	179
9.2.1.116	Bearer Type.....	179
9.2.1.117	RAT Type	179
9.2.1.118	CE-mode-B Support Indicator	179
9.2.1.119	SRVCC Operation Not Possible	179
9.2.1.120	V2X Services Authorized	180
9.2.1.121	Served DCNs Items.....	180
9.2.1.122	UE Sidelink Aggregate Maximum Bit Rate.....	180
9.2.1.123	Enhanced Coverage Restricted.....	180
9.2.1.124	CE-mode-B Restricted	181
9.2.2	Transport Network Layer Related IEs	182
9.2.2.1	Transport Layer Address.....	182
9.2.2.2	GTP-TEID.....	182
9.2.2.3	Tunnel Information	182
9.2.3	NAS Related IEs.....	182
9.2.3.1	LAI.....	182
9.2.3.2	RAC	182
9.2.3.3	MME UE S1AP ID	183
9.2.3.4	eNB UE S1AP ID	183
9.2.3.5	NAS-PDU	183
9.2.3.6	S-TMSI	183
9.2.3.7	TAC.....	183
9.2.3.8	PLMN Identity	183
9.2.3.9	GUMMEI.....	184
9.2.3.10	UE Identity Index value	184
9.2.3.11	IMSI.....	184
9.2.3.12	MMEC	184
9.2.3.13	UE Paging Identity.....	185
9.2.3.14	DL Forwarding.....	185
9.2.3.15	Direct Forwarding Path Availability.....	185
9.2.3.16	TAI.....	185
9.2.3.17	Relative MME Capacity.....	186
9.2.3.18	UE S1AP ID pair.....	186
9.2.3.19	Overload Response.....	186
9.2.3.20	Overload Action.....	186
9.2.3.21	CS Fallback Indicator.....	186
9.2.3.22	CN Domain	187
9.2.3.23	RIM Transfer.....	187
9.2.3.24	RIM Information	187
9.2.3.25	RIM Routing Address	187
9.2.3.26	SON Configuration Transfer	188
9.2.3.27	SON Information.....	188
9.2.3.28	SON Information Reply	189
9.2.3.29	X2 TNL Configuration Info	189
9.2.3.30	NAS Security Parameters from E-UTRAN.....	190
9.2.3.31	NAS Security Parameters to E-UTRAN	190
9.2.3.32	LPPa-PDU.....	191
9.2.3.33	Routing ID.....	191
9.2.3.34	Time Synchronisation Info.....	191
9.2.3.35	Void.....	191

9.2.3.36	Traffic Load Reduction Indication.....	191
9.2.3.37	Additional CS Fallback Indicator.....	191
9.2.3.38	Masked IMEISV	192
9.2.3.39	SON Information Report.....	192
9.2.3.40	RLF Report Information	192
9.2.3.41	Muting Pattern Information.....	192
9.2.3.42	Synchronisation Information.....	193
9.2.3.43	Listening Subframe Pattern.....	193
9.2.3.44	MME Group ID.....	193
9.2.3.45	Additional GUTI.....	193
9.2.3.46	Extended UE Identity Index Value	194
9.2.3.47	NB-IoT UE Identity Index Value.....	194
9.2.3.48	DL NAS PDU Delivery Request.....	194
9.2.3.49	DL CP Security Information	194
9.2.3.50	UL CP Security Information	194
9.2.3.51	Pending Data Indication.....	194
9.3	Message and Information Element Abstract Syntax (with ASN.1).....	196
9.3.0	General.....	196
9.3.1	Usage of private message mechanism for non-standard use.....	196
9.3.2	Elementary Procedure Definitions	197
9.3.3	PDU Definitions	211
9.3.4	Information Element Definitions	268
9.3.5	Common Definitions.....	311
9.3.6	Constant Definitions	311
9.3.7	Container Definitions.....	319
9.4	Message Transfer Syntax	323
9.5	Timers	323
10	Handling of Unknown, Unforeseen and Erroneous Protocol Data	324
10.1	General	324
10.2	Transfer Syntax Error.....	324
10.3	Abstract Syntax Error.....	324
10.3.1	General.....	324
10.3.2	Criticality Information	325
10.3.3	Presence Information	325
10.3.4	Not comprehended IE/IE group	326
10.3.4.1	Procedure Code	326
10.3.4.1A	Type of Message	326
10.3.4.2	IEs other than the Procedure Code and Type of Message.....	326
10.3.5	Missing IE or IE group	327
10.3.6	IEs or IE groups received in wrong order or with too many occurrences or erroneously present	328
10.4	Logical Error	329
10.5	Exceptions	329
10.6	Handling of AP ID	330
Annex A (informative):	S1AP Transparent containers content.....	331
Annex B (normative):	IEs for SON Transfer	332
B.1	Tabular definition.....	332
B.1.1	SON Transfer Application Identity	332
B.1.2	SON Transfer Request Container	332
B.1.3	SON Transfer Response Container	333
B.1.4	SON Transfer Cause.....	334
B.1.5	Cell Load Reporting Response.....	336
B.1.6	E-UTRAN Cell Load Reporting Response	336
B.1.7	Multi-Cell Load Reporting Request	337
B.1.8	IRAT Cell ID.....	337
B.1.9	Multi-Cell Load Reporting Response.....	337
B.1.10	Cell Load Reporting Cause	338
B.1.11	Event-Triggered Cell Load Reporting Request	339
B.1.12	Event-triggered Cell Load Reporting Response	339
B.1.13	HO Report	339