

ETSI TS 136 331 V15.7.0 (2019-10)



LTE;
Evolved Universal Terrestrial Radio Access (E-UTRA);
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 36.331 version 15.7.0 Release 15)



Reference

RTS/TSGR-0236331vf70

Keywords

LTE

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2019.

All rights reserved.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members.

3GPP™ and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

oneM2M™ logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners.

GSM® and the GSM logo are trademarks registered and owned by the GSM Association.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	22
1 Scope	23
2 References	23
3 Definitions, symbols and abbreviations	27
3.1 Definitions	27
3.2 Abbreviations	29
4 General	33
4.1 Introduction	33
4.2 Architecture	34
4.2.1 UE states and state transitions including inter RAT	34
4.2.2 Signalling radio bearers	38
4.3 Services	39
4.3.1 Services provided to upper layers	39
4.3.2 Services expected from lower layers	40
4.4 Functions	40
4.5 Data available for transmission for NB-IoT	41
5 Procedures	41
5.1 General	41
5.1.1 Introduction.....	41
5.1.2 General requirements.....	42
5.2 System information	43
5.2.1 Introduction.....	43
5.2.1.1 General	43
5.2.1.2 Scheduling.....	44
5.2.1.2a Scheduling for NB-IoT	45
5.2.1.3 System information validity and notification of changes	46
5.2.1.4 Indication of ETWS notification.....	47
5.2.1.5 Indication of CMAS notification.....	48
5.2.1.6 Notification of EAB parameters change	48
5.2.1.7 Access Barring parameters change in NB-IoT.....	48
5.2.2 System information acquisition	49
5.2.2.1 General	49
5.2.2.2 Initiation.....	49
5.2.2.3 System information required by the UE.....	49
5.2.2.4 System information acquisition by the UE.....	50
5.2.2.5 Essential system information missing	54
5.2.2.6 Actions upon reception of the <i>MasterInformationBlock</i> message.....	55
5.2.2.7 Actions upon reception of the <i>SystemInformationBlockType1</i> message	55
5.2.2.8 Actions upon reception of <i>SystemInformation</i> messages	57
5.2.2.9 Actions upon reception of <i>SystemInformationBlockType2</i>	57
5.2.2.10 Actions upon reception of <i>SystemInformationBlockType3</i>	58
5.2.2.11 Actions upon reception of <i>SystemInformationBlockType4</i>	59
5.2.2.12 Actions upon reception of <i>SystemInformationBlockType5</i>	59
5.2.2.13 Actions upon reception of <i>SystemInformationBlockType6</i>	60
5.2.2.14 Actions upon reception of <i>SystemInformationBlockType7</i>	61
5.2.2.15 Actions upon reception of <i>SystemInformationBlockType8</i>	61
5.2.2.16 Actions upon reception of <i>SystemInformationBlockType9</i>	62
5.2.2.17 Actions upon reception of <i>SystemInformationBlockType10</i>	62
5.2.2.18 Actions upon reception of <i>SystemInformationBlockType11</i>	62
5.2.2.19 Actions upon reception of <i>SystemInformationBlockType12</i>	63

5.2.2.20	Actions upon reception of <i>SystemInformationBlockType13</i>	63
5.2.2.21	Actions upon reception of <i>SystemInformationBlockType14</i>	64
5.2.2.22	Actions upon reception of <i>SystemInformationBlockType15</i>	64
5.2.2.23	Actions upon reception of <i>SystemInformationBlockType16</i>	64
5.2.2.24	Actions upon reception of <i>SystemInformationBlockType17</i>	64
5.2.2.25	Actions upon reception of <i>SystemInformationBlockType18</i>	64
5.2.2.26	Actions upon reception of <i>SystemInformationBlockType19</i>	64
5.2.2.27	Actions upon reception of <i>SystemInformationBlockType20</i>	65
5.2.2.28	Actions upon reception of <i>SystemInformationBlockType21</i>	65
5.2.2.29	Actions upon reception of <i>SystemInformationBlockType22-NB</i>	65
5.2.2.30	Actions upon reception of <i>SystemInformationBlockType23-NB</i>	65
5.2.2.31	Actions upon reception of <i>SystemInformationBlockType24</i>	65
5.2.2.32	Actions upon reception of <i>SystemInformationBlockType25</i>	65
5.2.2.33	Actions upon reception of <i>SystemInformationBlockType26</i>	65
5.2.2.34	Actions upon reception of <i>SystemInformationBlockPos</i>	66
5.2.3	Acquisition of an SI message.....	66
5.2.3a	Acquisition of an SI message by BL UE or UE in CE or a NB-IoT UE.....	67
5.2.3b	Acquisition of an SI message from MBMS-dedicated cell.....	68
5.3	Connection control	68
5.3.1	Introduction.....	68
5.3.1.1	RRC connection control	68
5.3.1.2	Security	70
5.3.1.2a	RN security	72
5.3.1.3	Connected mode mobility	72
5.3.1.4	Connection control in NB-IoT	73
5.3.2	Paging	74
5.3.2.1	General	74
5.3.2.2	Initiation.....	75
5.3.2.3	Reception of the <i>Paging</i> message by the UE	75
5.3.3	RRC connection establishment	76
5.3.3.1	General	76
5.3.3.1a	Conditions for establishing RRC Connection for sidelink communication/ discovery/ V2X sidelink communication.....	79
5.3.3.1b	Conditions for initiating EDT	80
5.3.3.2	Initiation.....	81
5.3.3.3	Actions related to transmission of <i>RRCConnectionRequest</i> message	87
5.3.3.3a	Actions related to transmission of <i>RRCConnectionResumeRequest</i> message	88
5.3.3.3b	Actions related to transmission of <i>RRCEarlyDataRequest</i> message.....	90
5.3.3.3c	UE actions upon receiving EDT fallback indication from lower layers.....	91
5.3.3.4	Reception of the <i>RRCConnectionSetup</i> by the UE.....	91
5.3.3.4a	Reception of the <i>RRCConnectionResume</i> by the UE	94
5.3.3.4b	Reception of the <i>RRCEarlyDataComplete</i> by the UE.....	98
5.3.3.5	Cell re-selection or cell selection while T300, T302, T303, T305, T306, T308 or T309 is running.....	99
5.3.3.6	T300 expiry	100
5.3.3.7	T302, T303, T305, T306, or T308 expiry or stop	102
5.3.3.8	Reception of the <i>RRCConnectionReject</i> by the UE	102
5.3.3.9	Abortion of RRC connection establishment.....	104
5.3.3.9a	Abortion of UP-EDT	104
5.3.3.10	Handling of SSAC related parameters	104
5.3.3.11	Access barring check.....	105
5.3.3.12	EAB check	106
5.3.3.13	Access barring check for ACDC.....	107
5.3.3.14	Access Barring check for NB-IoT.....	107
5.3.3.15	Failure to deliver NAS information in <i>RRCConnectionSetupComplete</i> message	109
5.3.3.16	Integrity check failure from lower layers while T300 is running for UP-EDT or <i>RRC_INACTIVE</i>	109
5.3.3.17	Inability to comply with <i>RRCConnectionResume</i>	110
5.3.4	Initial security activation	110
5.3.4.1	General	110
5.3.4.2	Initiation.....	110
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE.....	110
5.3.5	RRC connection reconfiguration	112

5.3.5.1	General	112
5.3.5.2	Initiation	112
5.3.5.3	Reception of an <i>RRCConnectionReconfiguration</i> not including the <i>mobilityControlInfo</i> by the UE	112
5.3.5.4	Reception of an <i>RRCConnectionReconfiguration</i> including the <i>mobilityControlInfo</i> by the UE (handover)	115
5.3.5.5	Reconfiguration failure	121
5.3.5.6	T304 expiry (handover failure)	121
5.3.5.7	Void	123
5.3.5.7a	T307 expiry (SCG change failure)	123
5.3.5.8	Radio Configuration involving full configuration option	123
5.3.6	Counter check	125
5.3.6.1	General	125
5.3.6.2	Initiation	125
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	125
5.3.7	RRC connection re-establishment	126
5.3.7.1	General	126
5.3.7.2	Initiation	127
5.3.7.3	Actions following cell selection while T311 is running	129
5.3.7.4	Actions related to transmission of <i>RRCConnectionReestablishmentRequest</i> message	129
5.3.7.5	Reception of the <i>RRCConnectionReestablishment</i> by the UE	130
5.3.7.6	T311 expiry	133
5.3.7.7	T301 expiry or selected cell no longer suitable	134
5.3.7.8	Reception of <i>RRCConnectionReestablishmentReject</i> by the UE	134
5.3.8	RRC connection release	134
5.3.8.1	General	134
5.3.8.2	Initiation	134
5.3.8.3	Reception of the <i>RRCConnectionRelease</i> by the UE	134
5.3.8.4	T320 expiry	137
5.3.8.5	T322 expiry	137
5.3.8.6	UE actions upon receiving the expiry of <i>DataInactivityTimer</i>	137
5.3.8.7	UE actions upon entering RRC_INACTIVE	137
5.3.9	RRC connection release requested by upper layers	138
5.3.9.1	General	138
5.3.9.2	Initiation	138
5.3.10	Radio resource configuration	138
5.3.10.0	General	138
5.3.10.1	SRB addition/ modification	139
5.3.10.1a	SCG RLC bearer addition or reconfiguration for SRBs	141
5.3.10.2	DRB release	141
5.3.10.3	DRB addition/ modification	142
5.3.10.3a1	DC specific DRB addition or reconfiguration	143
5.3.10.3a2	LWA specific DRB addition or reconfiguration	146
5.3.10.3a3	LWIP specific DRB addition or reconfiguration	147
5.3.10.3a4	SCG RLC bearer addition or reconfiguration for DRBs in NE-DC	148
5.3.10.3a	SCell release	148
5.3.10.3b	SCell addition/ modification	148
5.3.10.3c	PSCell addition or modification	149
5.3.10.3d	SCell group release	149
5.3.10.3e	SCell group addition/ modification	149
5.3.10.4	MAC main reconfiguration	150
5.3.10.5	Semi-persistent scheduling reconfiguration	151
5.3.10.6	Physical channel reconfiguration	151
5.3.10.7	Radio Link Failure Timers and Constants reconfiguration	152
5.3.10.8	Time domain measurement resource restriction for serving cell	152
5.3.10.9	Other configuration	152
5.3.10.10	SCG reconfiguration	155
5.3.10.11	SCG dedicated resource configuration	157
5.3.10.12	Reconfiguration SCG or split DRB by <i>drb-ToAddModList</i>	158
5.3.10.13	Neighbour cell information reconfiguration	158
5.3.10.14	Void	158
5.3.10.15	Sidelink dedicated configuration	158

5.3.10.15a	V2X sidelink Communication dedicated configuration	159
5.3.10.16	T370 expiry	160
5.3.10.17	SRB release	160
5.3.10.18	Scheduling Request Configuration for NB-IoT	161
5.3.10.19	NE-DC release	161
5.3.11	Radio link failure related actions	161
5.3.11.1	Detection of physical layer problems in RRC_CONNECTED	161
5.3.11.1a	Early detection of physical layer problems in RRC_CONNECTED	161
5.3.11.1b	Detection of physical layer improvements in RRC_CONNECTED	161
5.3.11.2	Recovery of physical layer problems	162
5.3.11.2a	Recovery of early detection of physical layer problems	162
5.3.11.2b	Cancellation of physical layer improvements in RRC_CONNECTED	162
5.3.11.3	Detection of radio link failure	162
5.3.11.3a	Detection of early-out-of-sync event	164
5.3.11.3b	Detection of early-in-sync event	164
5.3.12	UE actions upon leaving RRC_CONNECTED or RRC_INACTIVE	165
5.3.13	UE actions upon PUCCH/ SPUCCH/ SRS release request	166
5.3.13a	UE actions upon SR release request for NB-IoT	167
5.3.14	Proximity indication	167
5.3.14.1	General	167
5.3.14.2	Initiation	167
5.3.14.3	Actions related to transmission of <i>ProximityIndication</i> message	168
5.3.15	Void	168
5.3.16	Unified Access Control	168
5.3.16.1	General	168
5.3.16.2	Initiation	168
5.3.16.3	Void	170
5.3.16.4	T302, T309 expiry or stop (Barring alleviation)	170
5.3.16.5	Access barring check	170
5.3.17	RAN notification area update	171
5.3.17.1	General	171
5.3.17.2	Initiation	171
5.3.17.3	Inter RAT cell reselection or CN type change	171
5.4	Inter-RAT mobility	172
5.4.1	Introduction	172
5.4.2	Handover to E-UTRA	172
5.4.2.1	General	172
5.4.2.2	Initiation	172
5.4.2.3	Reception of the <i>RRCConnectionReconfiguration</i> by the UE	172
5.4.2.4	Reconfiguration failure	176
5.4.2.5	T304 expiry (handover to E-UTRA failure)	176
5.4.3	Mobility from E-UTRA	176
5.4.3.1	General	176
5.4.3.2	Initiation	177
5.4.3.3	Reception of the <i>MobilityFromEUTRACommand</i> by the UE	177
5.4.3.4	Successful completion of the mobility from E-UTRA	179
5.4.3.5	Mobility from E-UTRA failure	179
5.4.4	Handover from E-UTRA preparation request (CDMA2000)	180
5.4.4.1	General	180
5.4.4.2	Initiation	180
5.4.4.3	Reception of the <i>HandoverFromEUTRAPreparationRequest</i> by the UE	180
5.4.5	UL handover preparation transfer (CDMA2000)	181
5.4.5.1	General	181
5.4.5.2	Initiation	181
5.4.5.3	Actions related to transmission of the <i>ULHandoverPreparationTransfer</i> message	181
5.4.5.4	Failure to deliver the <i>ULHandoverPreparationTransfer</i> message	181
5.4.6	Inter-RAT cell change order to E-UTRAN	182
5.4.6.1	General	182
5.4.6.2	Initiation	182
5.4.6.3	UE fails to complete an inter-RAT cell change order	182
5.5	Measurements	182
5.5.1	Introduction	182

5.5.2	Measurement configuration	184
5.5.2.1	General	184
5.5.2.2	Measurement identity removal	185
5.5.2.2a	Measurement identity autonomous removal	186
5.5.2.3	Measurement identity addition/ modification	186
5.5.2.4	Measurement object removal	187
5.5.2.5	Measurement object addition/ modification	187
5.5.2.6	Reporting configuration removal	190
5.5.2.7	Reporting configuration addition/ modification	190
5.5.2.8	Quantity configuration	191
5.5.2.9	Measurement gap configuration	191
5.5.2.9a	Measurement gap configuration for RSTD measurements with dense PRS configuration	192
5.5.2.10	Discovery signals measurement timing configuration	193
5.5.2.11	RSSI measurement timing configuration	193
5.5.2.12	Measurement gap sharing configuration	193
5.5.2.13	NR measurement timing configuration	194
5.5.3	Performing measurements	194
5.5.3.1	General	194
5.5.3.2	Layer 3 filtering	198
5.5.3.3	Derivation of NR cell quality	199
5.5.3.4	Derivation of NR beam quality	199
5.5.4	Measurement report triggering	199
5.5.4.1	General	199
5.5.4.2	Event A1 (Serving becomes better than threshold)	205
5.5.4.3	Event A2 (Serving becomes worse than threshold)	206
5.5.4.4	Event A3 (Neighbour becomes offset better than PCell/ PSCell)	206
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	207
5.5.4.6	Event A5 (PCell/ PSCell becomes worse than threshold1 and neighbour becomes better than threshold2)	208
5.5.4.6a	Event A6 (Neighbour becomes offset better than SCell)	209
5.5.4.7	Event B1 (Inter RAT neighbour becomes better than threshold)	209
5.5.4.8	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	210
5.5.4.9	Event C1 (CSI-RS resource becomes better than threshold)	211
5.5.4.10	Event C2 (CSI-RS resource becomes offset better than reference CSI-RS resource)	211
5.5.4.11	Event W1 (WLAN becomes better than a threshold)	212
5.5.4.12	Event W2 (All WLAN inside WLAN mobility set becomes worse than threshold1 and a WLAN outside WLAN mobility set becomes better than threshold2)	212
5.5.4.13	Event W3 (All WLAN inside WLAN mobility set becomes worse than a threshold)	213
5.5.4.14	Event V1 (The channel busy ratio is above a threshold)	214
5.5.4.15	Event V2 (The channel busy ratio is below a threshold)	214
5.5.4.16	Event H1 (The Aerial UE height is above a threshold)	215
5.5.4.17	Event H2 (The Aerial UE height is below a threshold)	215
5.5.5	Measurement reporting	216
5.5.5.1	General	216
5.5.5.2	Determination of available NR measurement results	222
5.5.5.3	Selection of NR sorting quality	223
5.5.6	Measurement related actions	223
5.5.6.1	Actions upon handover and re-establishment	223
5.5.6.2	Speed dependant scaling of measurement related parameters	224
5.5.7	Inter-frequency RSTD measurement indication	225
5.5.7.1	General	225
5.5.7.2	Initiation	225
5.5.7.3	Actions related to transmission of <i>InterFreqRSTDMeasurementIndication</i> message	225
5.6	Other	226
5.6.0	General	226
5.6.1	DL information transfer	226
5.6.1.1	General	226
5.6.1.2	Initiation	227
5.6.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	227
5.6.2	UL information transfer	227
5.6.2.1	General	227

5.6.2.2	Initiation.....	227
5.6.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message.....	228
5.6.2.4	Failure to deliver <i>ULInformationTransfer</i> message.....	228
5.6.2a	UL information transfer for MR-DC.....	228
5.6.2a.1	General.....	228
5.6.2a.2	Initiation.....	228
5.6.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message.....	229
5.6.2a.4	Void.....	229
5.6.3	UE capability transfer.....	229
5.6.3.1	General.....	229
5.6.3.2	Initiation.....	229
5.6.3.3	Reception of the <i>UECapabilityEnquiry</i> by the UE.....	229
5.6.4	CSFB to 1x Parameter transfer.....	234
5.6.4.1	General.....	234
5.6.4.2	Initiation.....	234
5.6.4.3	Actions related to transmission of <i>CSFBParametersRequestCDMA2000</i> message.....	234
5.6.4.4	Reception of the <i>CSFBParametersResponseCDMA2000</i> message.....	234
5.6.5	UE Information.....	234
5.6.5.1	General.....	234
5.6.5.2	Initiation.....	235
5.6.5.3	Reception of the <i>UEInformationRequest</i> message.....	235
5.6.6	Logged Measurement Configuration.....	236
5.6.6.1	General.....	236
5.6.6.2	Initiation.....	237
5.6.6.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE.....	237
5.6.6.4	T330 expiry.....	237
5.6.7	Release of Logged Measurement Configuration.....	238
5.6.7.1	General.....	238
5.6.7.2	Initiation.....	238
5.6.8	Measurements logging.....	238
5.6.8.1	General.....	238
5.6.8.2	Initiation.....	238
5.6.9	In-device coexistence indication.....	241
5.6.9.1	General.....	241
5.6.9.2	Initiation.....	241
5.6.9.3	Actions related to transmission of <i>InDeviceCoexIndication</i> message.....	242
5.6.10	UE Assistance Information.....	244
5.6.10.1	General.....	244
5.6.10.2	Initiation.....	244
5.6.10.3	Actions related to transmission of <i>UEAssistanceInformation</i> message.....	245
5.6.11	Mobility history information.....	247
5.6.11.1	General.....	247
5.6.11.2	Initiation.....	247
5.6.12	RAN-assisted WLAN interworking.....	247
5.6.12.1	General.....	247
5.6.12.2	Dedicated WLAN offload configuration.....	248
5.6.12.3	WLAN offload RAN evaluation.....	248
5.6.12.4	T350 expiry or stop.....	248
5.6.12.5	Cell selection/ re-selection while T350 is running.....	248
5.6.13	SCG failure information.....	249
5.6.13.1	General.....	249
5.6.13.2	Initiation.....	249
5.6.13.3	Actions related to transmission of <i>SCGFailureInformation</i> message.....	249
5.6.13.4	Failure type determination in NE-DC.....	250
5.6.13.5	Setting the contents of <i>MeasResultSCG-FailureMRDC</i>	250
5.6.13a	NR SCG failure information.....	251
5.6.13a.1	General.....	251
5.6.13a.2	Initiation.....	251
5.6.13a.3	Actions related to transmission of <i>SCGFailureInformationNR</i> message.....	251
5.6.14	LTE-WLAN Aggregation.....	252
5.6.14.1	Introduction.....	252
5.6.14.2	Reception of LWA configuration.....	252

5.6.14.3	Release of LWA configuration	252
5.6.15	WLAN connection management.....	253
5.6.15.1	Introduction.....	253
5.6.15.2	WLAN connection status reporting.....	253
5.6.15.2.1	General	253
5.6.15.2.2	Initiation	253
5.6.15.2.3	Actions related to transmission of <i>WLANConnectionStatusReport</i> message	254
5.6.15.3	T351 Expiry (WLAN connection attempt timeout)	254
5.6.15.4	WLAN status monitoring	254
5.6.16	RAN controlled LTE-WLAN interworking.....	255
5.6.16.1	General	255
5.6.16.2	WLAN traffic steering command.....	255
5.6.17	LTE-WLAN aggregation with IPsec tunnel	256
5.6.17.1	General	256
5.6.17.2	LWIP reconfiguration	256
5.6.17.3	LWIP release.....	256
5.6.18	Void	257
5.6.19	Application layer measurement reporting	257
5.6.19.1	General	257
5.6.19.2	Initiation.....	257
5.6.20	IDLE Mode Measurements.....	257
5.6.20.1	General	257
5.6.20.2	Initiation.....	257
5.6.20.3	T331 expiry or stop	258
5.6.21	Failure information	258
5.6.21.1	General	258
5.6.21.2	Initiation.....	259
5.6.21.3	Actions related to transmission of <i>FailureInformation</i> message.....	259
5.7	Generic error handling.....	259
5.7.1	General.....	259
5.7.2	ASN.1 violation or encoding error.....	259
5.7.3	Field set to a not comprehended value.....	259
5.7.4	Mandatory field missing.....	260
5.7.5	Not comprehended field.....	261
5.8	MBMS.....	261
5.8.1	Introduction.....	261
5.8.1.1	General	261
5.8.1.2	Scheduling.....	262
5.8.1.3	MCCH information validity and notification of changes.....	262
5.8.2	MCCH information acquisition	263
5.8.2.1	General	263
5.8.2.2	Initiation.....	263
5.8.2.3	MCCH information acquisition by the UE.....	263
5.8.2.4	Actions upon reception of the <i>MBSFNAreaConfiguration</i> message	264
5.8.2.5	Actions upon reception of the <i>MBMScountingRequest</i> message.....	264
5.8.3	MBMS PTM radio bearer configuration.....	264
5.8.3.1	General	264
5.8.3.2	Initiation.....	264
5.8.3.3	MRB establishment.....	264
5.8.3.4	MRB release.....	264
5.8.4	MBMS Counting Procedure	265
5.8.4.1	General	265
5.8.4.2	Initiation.....	265
5.8.4.3	Reception of the <i>MBMScountingRequest</i> message by the UE	265
5.8.5	MBMS interest indication.....	266
5.8.5.1	General	266
5.8.5.2	Initiation.....	266
5.8.5.3	Determine MBMS frequencies of interest.....	267
5.8.5.4	Actions related to transmission of <i>MBMSInterestIndication</i> message	268
5.8a	SC-PTM	269
5.8a.1	Introduction.....	269
5.8a.1.1	General	269

5.8a.1.2	SC-MCCH scheduling	269
5.8a.1.3	SC-MCCH information validity and notification of changes.....	269
5.8a.1.4	Procedures.....	270
5.8a.2	SC-MCCH information acquisition	270
5.8a.2.1	General.....	270
5.8a.2.2	Initiation.....	270
5.8a.2.3	SC-MCCH information acquisition by the UE	270
5.8a.2.4	Actions upon reception of the <i>SCPTMConfiguration</i> message.....	271
5.8a.3	SC-PTM radio bearer configuration	271
5.8a.3.1	General.....	271
5.8a.3.2	Initiation.....	271
5.8a.3.3	SC-MRB establishment.....	271
5.8a.3.4	SC-MRB release	272
5.9	RN procedures.....	272
5.9.1	RN reconfiguration	272
5.9.1.1	General.....	272
5.9.1.2	Initiation.....	272
5.9.1.3	Reception of the <i>RNReconfiguration</i> by the RN.....	272
5.10	Sidelink	273
5.10.1	Introduction.....	273
5.10.1a	Conditions for sidelink communication operation.....	273
5.10.1d	Conditions for V2X sidelink communication operation.....	274
5.10.2	Sidelink UE information.....	274
5.10.2.1	General.....	274
5.10.2.2	Initiation.....	275
5.10.2.3	Actions related to transmission of <i>SidelinkUEInformation</i> message	280
5.10.3	Sidelink communication monitoring.....	282
5.10.4	Sidelink communication transmission	284
5.10.5	Sidelink discovery monitoring.....	285
5.10.6	Sidelink discovery announcement.....	286
5.10.6a	Sidelink discovery announcement pool selection	289
5.10.6b	Sidelink discovery announcement reference carrier selection	289
5.10.7	Sidelink synchronisation information transmission.....	290
5.10.7.1	General.....	290
5.10.7.2	Initiation.....	291
5.10.7.3	Transmission of <i>SLSS</i>	293
5.10.7.4	Transmission of <i>MasterInformationBlock-SL</i> or <i>MasterInformationBlock-SL-V2X</i> message	295
5.10.7.5	Void.....	296
5.10.8	Sidelink synchronisation reference	296
5.10.8.1	General.....	296
5.10.8.2	Selection and reselection of synchronisation reference.....	296
5.10.8a	Selection and reselection of synchronisation carrier frequency.....	299
5.10.9	Sidelink common control information	302
5.10.9.1	General.....	302
5.10.9.2	Actions related to reception of <i>MasterInformationBlock-SL/ MasterInformationBlock-SL-V2X</i> message	302
5.10.10	Sidelink relay UE operation.....	302
5.10.10.1	General.....	302
5.10.10.2	AS-conditions for relay related sidelink communication transmission by sidelink relay UE	303
5.10.10.3	AS-conditions for relay PS related sidelink discovery transmission by sidelink relay UE	303
5.10.10.4	Sidelink relay UE threshold conditions.....	303
5.10.11	Sidelink remote UE operation.....	303
5.10.11.1	General.....	303
5.10.11.2	AS-conditions for relay related sidelink communication transmission by sidelink remote UE	304
5.10.11.3	AS-conditions for relay PS related sidelink discovery transmission by sidelink remote UE	304
5.10.11.4	Selection and reselection of sidelink relay UE.....	304
5.10.11.5	Sidelink remote UE threshold conditions.....	305
5.10.12	V2X sidelink communication monitoring.....	305
5.10.13	V2X sidelink communication transmission	306
5.10.13.1	Transmission of V2X sidelink communication.....	306
5.10.13.1a	Transmission of P2X related V2X sidelink communication.....	308
5.10.13.2	V2X sidelink communication transmission pool selection	309

5.10.13.3 V2X sidelink communication transmission reference cell selection 310

5.10.14 DFN derivation from GNSS 311

6 Protocol data units, formats and parameters (tabular & ASN.1) 311

6.1 General 311

6.2 RRC messages 313

6.2.1 General message structure 313

- EUTRA-RRC-Definitions 313
- BCCH-BCH-Message 313
- BCCH-BCH-Message-MBMS 313
- BCCH-DL-SCH-Message 314
- BCCH-DL-SCH-Message-BR 314
- BCCH-DL-SCH-Message-MBMS 314
- MCCH-Message 315
- PCCH-Message 315
- DL-CCCH-Message 315
- DL-DCCH-Message 316
- UL-CCCH-Message 316
- UL-DCCH-Message 317
- SC-MCCH-Message 317

6.2.2 Message definitions 318

- CounterCheck 318
- CounterCheckResponse 319
- CSFBParametersRequestCDMA2000 320
- CSFBParametersResponseCDMA2000 320
- DLInformationTransfer 321
- FailureInformation 322
- HandoverFromEUTRAPreparationRequest (CDMA2000) 322
- InDeviceCoexIndication 324
- InterFreqRSTDMeasurementIndication 326
- LoggedMeasurementConfiguration 328
- MasterInformationBlock 330
- MasterInformationBlock-MBMS 331
- MBMSCountingRequest 331
- MBMSCountingResponse 332
- MBMSInterestIndication 333
- MBSFNAreaConfiguration 334
- MeasReportAppLayer 335
- MeasurementReport 335
- MobilityFromEUTRACommand 336
- Paging 339
- ProximityIndication 340
- RNReconfiguration 341
- RNReconfigurationComplete 342
- RRCConnectionReconfiguration 342
- RRCConnectionReconfigurationComplete 351
- RRCConnectionReestablishment 352
- RRCConnectionReestablishmentComplete 353
- RRCConnectionReestablishmentReject 354
- RRCConnectionReestablishmentRequest 355
- RRCConnectionReject 355
- RRCConnectionRelease 356
- RRCConnectionRequest 362
- RRCConnectionResume 363
- RRCConnectionResumeComplete 364
- RRCConnectionResumeRequest 365
- RRCConnectionSetup 366
- RRCConnectionSetupComplete 366
- RRCEarlyDataComplete 369
- RRCEarlyDataRequest 370
- SCGFailureInformation 371
- SCGFailureInformationNR 372

–	<i>SCPTMConfiguration</i>	373
–	<i>SCPTMConfiguration-BR</i>	373
–	<i>SecurityModeCommand</i>	374
–	<i>SecurityModeComplete</i>	374
–	<i>SecurityModeFailure</i>	375
–	<i>SidelinkUEInformation</i>	375
–	<i>SystemInformation</i>	379
–	<i>SystemInformationBlockType1</i>	380
–	<i>SystemInformationBlockType1-MBMS</i>	388
–	<i>UEAssistanceInformation</i>	390
–	<i>UECapabilityEnquiry</i>	394
–	<i>UECapabilityInformation</i>	395
–	<i>UEInformationRequest</i>	396
–	<i>UEInformationResponse</i>	397
–	<i>ULHandoverPreparationTransfer (CDMA2000)</i>	403
–	<i>ULInformationTransfer</i>	404
–	<i>ULInformationTransferMRDC</i>	405
–	<i>WLANConnectionStatusReport</i>	405
6.3	RRC information elements	406
6.3.1	System information blocks	406
–	<i>SystemInformationBlockPos</i>	406
–	<i>SystemInformationBlockType2</i>	406
–	<i>SystemInformationBlockType3</i>	412
–	<i>SystemInformationBlockType4</i>	415
–	<i>SystemInformationBlockType5</i>	416
–	<i>SystemInformationBlockType6</i>	421
–	<i>SystemInformationBlockType7</i>	424
–	<i>SystemInformationBlockType8</i>	425
–	<i>SystemInformationBlockType9</i>	429
–	<i>SystemInformationBlockType10</i>	430
–	<i>SystemInformationBlockType11</i>	430
–	<i>SystemInformationBlockType12</i>	431
–	<i>SystemInformationBlockType13</i>	432
–	<i>SystemInformationBlockType14</i>	432
–	<i>SystemInformationBlockType15</i>	433
–	<i>SystemInformationBlockType16</i>	434
–	<i>SystemInformationBlockType17</i>	435
–	<i>SystemInformationBlockType18</i>	436
–	<i>SystemInformationBlockType19</i>	437
–	<i>SystemInformationBlockType20</i>	440
–	<i>SystemInformationBlockType21</i>	443
–	<i>SystemInformationBlockType24</i>	444
–	<i>SystemInformationBlockType25</i>	447
–	<i>SystemInformationBlockType26</i>	448
6.3.2	Radio resource control information elements	449
–	<i>AntennaInfo</i>	449
–	<i>AntennaInfoUL</i>	452
–	<i>AUL-Config</i>	452
–	<i>CQI-ReportAperiodic</i>	453
–	<i>CQI-ReportBoth</i>	457
–	<i>CQI-ReportConfig</i>	458
–	<i>CQI-ReportPeriodic</i>	461
–	<i>CQI-ReportPeriodicProcExtId</i>	465
–	<i>CrossCarrierSchedulingConfig</i>	465
–	<i>CSI-IM-Config</i>	466
–	<i>CSI-IM-ConfigId</i>	467
–	<i>CSI-Process</i>	467
–	<i>CSI-ProcessId</i>	468
–	<i>CSI-RS-Config</i>	469
–	<i>CSI-RS-ConfigBeamformed</i>	470
–	<i>CSI-RS-ConfigEMIMO</i>	471
–	<i>CSI-RS-ConfigNonPrecoded</i>	472