

# ETSI TS 136 300 V15.9.0 (2020-04)



**LTE;  
Evolved Universal Terrestrial Radio Access (E-UTRA)  
and Evolved Universal Terrestrial  
Radio Access Network (E-UTRAN);  
Overall description;  
Stage 2  
(3GPP TS 36.300 version 15.9.0 Release 15)**



---

**Reference**RTS/TSGR-0236300v90

---

**Keywords**

---

LTE

**ETSI**

---

650 Route des Lucioles  
F-06921 Sophia Antipolis Cedex - FRANCE

---

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C  
Association à but non lucratif enregistrée à la  
Sous-Préfecture de Grasse (06) N° 7803/88

iTeh STANDARD PREVIEW  
(standards.iteh.ai)

**Important notice**

---

ETSI TS 136 300 V15.9.0 (2020-04)  
<https://standards.iteh.ai/catalog/standards/sist/a02569b8-17ce-432a-9f79-4cc9b1e1d1e1/etsi-ts-136-300-v15-9-0-2020-04>  
The present document can be downloaded from:  
<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at [www.etsi.org/deliver](http://www.etsi.org/deliver).

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at <https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:  
<https://portal.etsi.org/People/CommiteeSupportStaff.aspx>

---

**Copyright Notification**

---

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2020.  
All rights reserved.

**DECT™**, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

**oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners.

**GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

---

# Intellectual Property Rights

## Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

## Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

---

# Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

<https://standards.iteh.ai/catalog/standards/sist/a02569b8-17ce-432a-9f79-4cccabaacded/etsi-ts-136-300-v15-9-0-2020-04>

---

# Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

# Contents

Intellectual Property Rights .....	2
Legal Notice .....	2
Modal verbs terminology.....	2
Foreword.....	18
1 Scope .....	19
2 References .....	19
3 Definitions, symbols and abbreviations .....	22
3.1 Definitions .....	22
3.2 Abbreviations .....	25
4 Overall architecture .....	30
4.0 General .....	30
4.1 Functional Split .....	31
4.2 Void.....	33
4.2.1 Void .....	33
4.2.2 Void .....	33
4.3 Radio Protocol architecture .....	33
4.3.0 General.....	33
4.3.1 User plane .....	34
4.3.2 Control plane .....	34
4.4 Synchronization.....	35
4.5 IP fragmentation.....	35
4.6 Support of HeNBs .....	35
4.6.1 Architecture .....	35
4.6.2 Functional Split.....	37
4.6.3 Interfaces.....	39
4.6.3.1 Protocol Stack for S1 User Plane .....	39
4.6.3.2 Protocol Stacks for S1 Control Plane.....	40
4.6.3.3 Protocol Stack for S5 interface.....	41
4.6.3.4 Protocol Stack for SGi interface.....	41
4.6.3.5 Protocol Stack for X2 User Plane and X2 Control Plane.....	41
4.6.4 Void .....	41
4.6.5 Support of LIPA with HeNB .....	41
4.6.6 Support of X2 GW.....	43
4.6.6.1 Enhanced TNL Address Discovery.....	44
4.6.6.2 Routing of X2AP messages .....	44
4.6.6.3 (H)eNB unavailability.....	44
4.6.6.4 (H)eNB registration.....	44
4.7 Support for relaying.....	44
4.7.1 General.....	44
4.7.2 Architecture .....	45
4.7.3 S1 and X2 user plane aspects.....	45
4.7.4 S1 and X2 control plane aspects .....	46
4.7.5 Radio protocol aspects .....	47
4.7.6 Signalling procedures .....	48
4.7.6.1 RN attach procedure.....	48
4.7.6.2 E-RAB activation/modification.....	49
4.7.6.3 RN startup procedure .....	49
4.7.6.4 RN detach procedure.....	50
4.7.6.5 Neighbouring Information Transfer .....	51
4.7.6.6 Mobility to or from RN .....	51
4.7.7 Relay Node OAM Aspects .....	51
4.7.7.1 Architecture.....	51
4.7.7.2 OAM Traffic QoS Requirements .....	52
4.7.7.3 Security Aspects.....	52

4.7.7.4	Void.....	52
4.7.7.5	OAM Requirements for Configuration Parameters.....	52
4.7.7.5.1	Parameters Associated with Relay Bearer Mapping.....	52
4.8	Support of SIPTO at the Local Network .....	52
4.8.1	General.....	52
4.8.2	SIPTO at the Local Network with collocated L-GW .....	53
4.8.3	Support for SIPTO@LN with Stand-Alone Gateway .....	54
4.9	Support for Dual Connectivity .....	54
4.9.1	General.....	54
4.9.2	Radio Protocol Architecture .....	54
4.9.3	Network Interfaces.....	55
4.9.3.1	E-UTRAN Control Plane for Dual Connectivity .....	55
4.9.3.2	E-UTRAN User Plane for Dual Connectivity .....	55
4.9.3.3	Support of HeNBs for Dual Connectivity .....	56
4.9.3.4	Support of SIPTO@LN and LIPA for Dual Connectivity .....	56
4.10	NB-IoT .....	58
4.11	Support for UE assistance information for local cache .....	58
5	Physical Layer for E-UTRA.....	58
5.0	Frame structures and channels.....	58
5.1	Downlink Transmission Scheme.....	61
5.1.1	Basic transmission scheme based on OFDM.....	61
5.1.1a	Basic transmission scheme based on OFDM for NB-IoT.....	62
5.1.2	Physical-layer processing .....	62
5.1.3	Physical downlink control channels.....	62
5.1.4	Downlink Reference signal and synchronization signals.....	64
5.1.4a	Downlink Reference signal and synchronization signals for NB-IoT.....	64
5.1.5	Downlink multi-antenna transmission.....	64
5.1.5a	Downlink multi-antenna transmission for NB-IoT.....	65
5.1.6	MBSFN transmission.....	65
5.1.7	Physical layer procedure.....	65
5.1.7.1	Link adaptation .....	65
5.1.7.2	Power Control.....	65
5.1.7.3	Cell search.....	65
5.1.7.3a	Cell search for NB-IoT.....	65
5.1.8	Physical layer measurements definition.....	65
5.1.9	Coordinated Multi-Point transmission.....	66
5.1.10	Wake-up signal for NB-IoT .....	66
5.1.11	Wake-up signal for BL UE or UE in enhanced coverage .....	66
5.2	Uplink Transmission Scheme.....	66
5.2.1	Basic transmission scheme .....	66
5.2.1a	Basic transmission scheme for NB-IoT .....	67
5.2.2	Physical-layer processing .....	67
5.2.3	Physical uplink control channel.....	68
5.2.3a	Uplink control information for NB-IoT.....	68
5.2.4	Uplink Reference signal.....	68
5.2.4a	Uplink Reference signal for NB-IoT .....	69
5.2.5	Random access preamble.....	69
5.2.5a	Random access preamble for NB-IoT.....	69
5.2.6	Uplink multi-antenna transmission .....	69
5.2.7	Physical channel procedure.....	70
5.2.7.1	Link adaptation .....	70
5.2.7.2	Uplink Power control .....	70
5.2.7.3	Uplink timing control.....	70
5.2.8	Coordinated Multi-Point reception .....	70
5.3	Transport Channels.....	70
5.3.0	Transport channel types .....	70
5.3.1	Mapping between transport channels and physical channels.....	72
5.3.1a	Mapping between transport channels and narrowband physical channels.....	73
5.4	E-UTRA physical layer model .....	73
5.4.1	Void .....	74
5.4.2	Void .....	74

5.5	Carrier Aggregation.....	74
5.5.0	General.....	74
5.5.1	SRS switching between component carriers.....	74
5.5a	Multi-carrier operation for NB-IoT.....	75
5.6	Sidelink.....	75
5.6.0	General.....	75
5.6.1	Basic transmission scheme.....	75
5.6.2	Physical-layer processing.....	76
5.6.3	Physical Sidelink control channel.....	76
5.6.4	Sidelink reference signals.....	76
5.6.5	Physical channel procedure.....	76
5.6.5.1	Sidelink power control.....	76
5.6.6	Physical layer measurements definition.....	76
5.7	Licensed-Assisted Access.....	76
5.7.0	General.....	76
5.7.1	Channel Access Priority Classes.....	77
5.7.2	Multiplexing of data.....	77
5.8	Short Processing Time.....	78
5.9	Short Transmission Time Interval.....	78
6	Layer 2.....	78
6.0	Overview.....	78
6.1	MAC Sublayer.....	80
6.1.0	General.....	80
6.1.1	Services and Functions.....	80
6.1.2	Logical Channels.....	81
6.1.2.0	General.....	81
6.1.2.1	Control Channels.....	81
6.1.2.2	Traffic Channels.....	82
6.1.3	Mapping between logical channels and transport channels.....	82
6.1.3.1	Mapping in Uplink.....	82
6.1.3.2	Mapping in Downlink.....	82
6.1.3.3	Mapping in Sidelink.....	83
6.2	RLC Sublayer.....	84
6.2.0	General.....	84
6.2.1	Services and Functions.....	84
6.2.2	PDU Structure.....	84
6.3	PDCP Sublayer.....	85
6.3.0	General.....	85
6.3.1	Services and Functions.....	85
6.3.2	PDU Structure.....	86
6.4	Carrier Aggregation.....	86
6.5	Dual Connectivity.....	87
7	RRC.....	89
7.0	General.....	89
7.1	Services and Functions.....	89
7.2	RRC protocol states & state transitions.....	90
7.3	Transport of NAS messages.....	91
7.3a	CIoT signalling reduction optimizations.....	91
7.3a.1	General.....	91
7.3a.2	Control Plane CIoT EPS optimizations.....	91
7.3a.3	User Plane CIoT EPS optimizations.....	92
7.3b	EDT.....	95
7.3b.1	General.....	95
7.3b.2	EDT for Control Plane CIoT EPS optimizations.....	95
7.3b.3	EDT for User Plane CIoT EPS optimizations.....	96
7.4	System Information.....	99
7.5	Carrier Aggregation.....	101
7.6	Dual Connectivity.....	102
8	E-UTRAN identities.....	103
8.1	E-UTRA related UE identities.....	103

8.2	Network entity related Identities .....	103
8.3	Sidelink communication and V2X Sidelink Communication related identities .....	104
8.4	MBMS related identities .....	105
9	ARQ and HARQ .....	105
9.0	General .....	105
9.1	HARQ principles.....	105
9.2	ARQ principles.....	107
9.3	Void.....	107
10	Mobility.....	107
10.0	General .....	107
10.1	Intra E-UTRAN.....	108
10.1.0	General.....	108
10.1.1	Mobility Management in ECM-IDLE .....	108
10.1.1.1	Cell selection.....	108
10.1.1.2	Cell reselection.....	108
10.1.1.3	Void.....	109
10.1.1.4	Void.....	109
10.1.1.5	Void.....	109
10.1.2	Mobility Management in ECM-CONNECTED/CM-CONNECTED.....	109
10.1.2.0	General .....	109
10.1.2.1	Handover .....	111
10.1.2.1.1	C-plane handling .....	111
10.1.2.1.2	U-plane handling .....	114
10.1.2.2	Path Switch .....	115
10.1.2.2.1	Path Switch upon handover .....	115
10.1.2.2.2	Path Update upon Dual Connectivity specific activities.....	116
10.1.2.2.3	Path Switch upon UE context resume .....	116
10.1.2.3	Data forwarding .....	116
10.1.2.3.1	For RLC-AM DRBs .....	116
10.1.2.3.2	For RLC-UM DRBs .....	117
10.1.2.3.3	SRB handling .....	117
10.1.2.3.4	User data forwarding for Dual Connectivity .....	117
10.1.2.4	Void.....	118
10.1.2.5	Void.....	118
10.1.2.6	Void.....	118
10.1.2.7	Timing Advance.....	118
10.1.2.8	Dual Connectivity operation .....	119
10.1.2.8.1	SeNB Addition .....	119
10.1.2.8.2	SeNB Modification.....	120
10.1.2.8.2.1	Intra-MeNB handover involving SCG change.....	122
10.1.2.8.3	SeNB Release .....	123
10.1.2.8.4	Change of SeNB .....	125
10.1.2.8.5	MeNB to eNB Change.....	126
10.1.2.8.6	SCG change .....	127
10.1.2.8.7	eNB to MeNB change .....	127
10.1.2.8.8	Inter-MeNB handover without SeNB change.....	128
10.1.2.8.9	Addition of a hybrid HeNB as the SeNB.....	131
10.1.2.9	LWA mobility .....	132
10.1.2.9.1	Inter-eNB handover without WT change.....	132
10.1.2.10	EN-DC Operation .....	134
10.1.3	Measurements .....	134
10.1.3.0	General .....	134
10.1.3.1	Intra-frequency neighbour (cell) measurements.....	136
10.1.3.2	Inter-frequency neighbour (cell) measurements.....	136
10.1.4	Paging and C-plane establishment .....	136
10.1.5	Random Access Procedure .....	137
10.1.5.0	General .....	137
10.1.5.1	Contention based random access procedure.....	138
10.1.5.2	Non-contention based random access procedure .....	141
10.1.5.3	Interaction model between L1 and L2/3 for Random Access Procedure .....	142

10.1.6	Radio Link Failure .....	142
10.1.7	Radio Access Network Sharing .....	144
10.1.8	Handling of Roaming and Area Restrictions for UEs in ECM-CONNECTED .....	144
10.1.8a	Handling of Roaming and Access Restrictions for UEs in ECM-CONNECTED .....	144
10.1.9	Mobility in RRC_INACTIVE .....	144
10.1.9.1	Overview .....	144
10.1.9.2	Cell Reselection .....	145
10.1.9.3	RAN-Based Notification Area .....	145
10.1.9.4	State Transitions .....	145
10.1.9.4.1	UE triggered transition from RRC_INACTIVE to RRC_CONNECTED .....	145
10.1.9.4.2	Network triggered transition from RRC_INACTIVE to RRC_CONNECTED .....	145
10.1.9.5	RNA update .....	145
10.2	Inter RAT .....	145
10.2.0	General .....	145
10.2.1	Cell reselection .....	145
10.2.2	Handover .....	146
10.2.2a	Inter-RAT cell change order to GERAN with NACC .....	147
10.2.2b	Inter-RAT handovers from E-UTRAN .....	147
10.2.2b.1	Data forwarding .....	147
10.2.2b.1.1	For RLC-AM bearers .....	147
10.2.2b.1.2	For RLC-UM bearers .....	147
10.2.2c	Intra-EUTRA inter-system Handover .....	148
10.2.3	Measurements .....	148
10.2.3.1	Inter-RAT handovers from E-UTRAN .....	148
10.2.3.2	Inter-RAT handovers to E-UTRAN .....	148
10.2.3.3	Inter-RAT cell reselection from E-UTRAN .....	148
10.2.3.4	Limiting measurement load at UE .....	148
10.2.4	Network Aspects .....	149
10.2.5	CS fallback .....	149
10.3	Mobility between E-UTRAN and Non-3GPP radio technologies .....	150
10.3.1	UE Capability Configuration .....	150
10.3.2	Mobility between E-UTRAN and cdma2000 network .....	150
10.3.2.1	Tunnelling of cdma2000 Messages over E-UTRAN between UE and cdma2000 Access Nodes .....	151
10.3.2.2	Mobility between E-UTRAN and HRPD .....	152
10.3.2.2.1	Mobility from E-UTRAN to HRPD .....	152
10.3.2.2.1.1	HRPD System Information Transmission in E-UTRAN .....	152
10.3.2.2.1.2	Measuring HRPD from E-UTRAN .....	152
10.3.2.2.1.2.1	Idle Mode Measurement Control .....	152
10.3.2.2.1.2.2	Active Mode Measurement Control .....	152
10.3.2.2.1.2.3	Active Mode Measurement .....	152
10.3.2.2.1.3	Pre-registration to HRPD Procedure .....	152
10.3.2.2.1.4	E-UTRAN to HRPD Cell Re-selection .....	153
10.3.2.2.1.5	E-UTRAN to HRPD Handover .....	153
10.3.2.2.2	Mobility from HRPD to E-UTRAN .....	153
10.3.2.3	Mobility between E-UTRAN and cdma2000 1xRTT .....	153
10.3.2.3.1	Mobility from E-UTRAN to cdma2000 1xRTT .....	153
10.3.2.3.1.1	cdma2000 1xRTT System Information Transmission in E-UTRAN .....	153
10.3.2.3.1.2	Measuring cdma2000 1xRTT from E-UTRAN .....	153
10.3.2.3.1.2.1	Idle Mode Measurement Control .....	154
10.3.2.3.1.2.2	Active Mode Measurement Control .....	154
10.3.2.3.1.2.3	Active Mode Measurement .....	154
10.3.2.3.1.3	E-UTRAN to cdma2000 1xRTT Cell Re-selection .....	154
10.3.2.3.1.4	E-UTRAN to cdma2000 1xRTT Handover .....	154
10.3.2.3.2	Mobility from cdma2000 1xRTT to E-UTRAN .....	154
10.3.2.3.3	1xRTT CS Fallback .....	155
10.3.3	CDMA2000 interworking in LTE shared networks .....	156
10.4	Area Restrictions .....	156
10.4a	Roaming and Access Restrictions .....	157
10.5	Mobility to and from CSG and Hybrid cells .....	157
10.5.0	Principles for idle-mode mobility with CSG cells .....	157
10.5.0.1	Intra-frequency mobility .....	157
10.5.0.2	Inter-frequency mobility .....	157



10.5.0.3	Inter-RAT Mobility .....	158
10.5.1	Inbound mobility to CSG cells .....	158
10.5.1.1	RRC_IDLE.....	158
10.5.1.2	RRC_CONNECTED.....	158
10.5.2	Outbound mobility from CSG cells .....	161
10.5.2.1	RRC_IDLE.....	161
10.5.2.2	RRC_CONNECTED.....	161
10.6	Measurement Model.....	161
10.7	Hybrid Cells .....	162
10.7.0	General.....	162
10.7.1	RRC_IDLE .....	162
10.7.2	RRC_CONNECTED .....	162
10.7.2.1	Inbound Mobility .....	162
10.7.2.2	Outbound Mobility.....	162
11	Scheduling and Rate Control.....	162
11.0	General .....	162
11.1	Basic Scheduler Operation .....	162
11.1.1	Downlink Scheduling .....	163
11.1.2	Uplink Scheduling .....	164
11.2	Activation/Deactivation Mechanism .....	165
11.3	Measurements to Support Scheduler Operation .....	166
11.4	Rate Control of GBR, MBR and UE-AMBR .....	166
11.4.1	Downlink .....	166
11.4.2	Uplink .....	166
11.4.3	UE-AMBR for Dual Connectivity.....	166
11.5	CQI reporting for Scheduling .....	167
11.6	Explicit Congestion Notification .....	167
11.7	DL channel quality reporting in NB-IoT .....	167
12	DRX in RRC_CONNECTED .....	168
13	QoS.....	169
13.0	General .....	169
13.1	Bearer service architecture .....	169
13.2	QoS parameters .....	170
13.3	QoS support in Hybrid Cells .....	171
14	Security.....	171
14.1	Overview and Principles .....	171
14.2	Security termination points.....	174
14.3	State Transitions and Mobility .....	175
14.3.1	RRC_IDLE to RRC_CONNECTED .....	175
14.3.2	RRC_CONNECTED to RRC_IDLE .....	175
14.3.3	Intra E-UTRAN Mobility .....	175
14.3.4	SeNB Removal .....	175
14.4	AS Key Change in RRC_CONNECTED .....	176
14.5	Security Interworking.....	176
14.6	RN integrity protection for DRB(s).....	176
15	MBMS.....	176
15.0	MBMS-Specific Definitions.....	176
15.1	General .....	177
15.1.0	Overview .....	177
15.1.1	E-MBMS Logical Architecture.....	178
15.1.2	E-MBMS User Plane Protocol Architecture .....	180
15.1.3	E-MBMS Control Plane Protocol Architecture .....	180
15.2	MBMS Cells.....	181
15.2.1	MBMS-dedicated cell .....	181
15.2.2	MBMS/Unicast-mixed cell .....	181
15.2.2.1	FeMBMS/Unicast-mixed cell .....	181
15.3	MBMS Transmission.....	181
15.3.1	General.....	181
15.3.2	Single-cell transmission .....	181

15.3.3	Multi-cell transmission .....	182
15.3.4	MBMS Reception States.....	184
15.3.5	MCCH Structure .....	184
15.3.5a	SC-MCCH structure .....	185
15.3.6	MBMS signalling on BCCH.....	185
15.3.7	MBMS User Data flow synchronisation.....	186
15.3.8	Synchronisation of MCCH Update Signalling via M2 .....	187
15.3.9	IP Multicast Distribution .....	187
15.4	Service Continuity.....	187
15.5	Network sharing .....	189
15.6	Network Functions for Support of Multiplexing.....	189
15.7	Procedures .....	190
15.7.1	Procedures for Broadcast mode .....	190
15.7.1.1	Session Start procedure.....	190
15.7.1.2	Session Stop procedure .....	191
15.7a	M1 Interface.....	192
15.7a.1	M1 User Plane .....	192
15.8	M2 Interface .....	193
15.8.1	M2 Control Plane.....	193
15.8.2	M2 Interface Functions.....	194
15.8.2.1	General .....	194
15.8.2.2	MBMS Session Handling Function.....	194
15.8.2.3	MBMS Scheduling Information Provision Function .....	194
15.8.2.4	M2 Interface Management Function .....	194
15.8.2.5	M2 Configuration Function.....	194
15.8.2.6	MBMS Service Counting Function.....	194
15.8.2.7	MBMS Service Suspension and Resumption Function.....	194
15.8.2.8	MBMS Overload Notification Function.....	195
15.8.3	M2 Interface Signalling Procedures.....	195
15.8.3.1	General .....	195
15.8.3.2	MBMS Session signalling procedure .....	195
15.8.3.3	MBMS Scheduling Information procedure .....	195
15.8.3.4	M2 Interface Management procedures.....	195
15.8.3.4.1	Reset procedure.....	195
15.8.3.4.2	Error Indication procedure.....	195
15.8.3.5	M2 Configuration procedures .....	195
15.8.3.5.1	M2 Setup procedure .....	195
15.8.3.5.2	eNB Configuration Update procedure.....	195
15.8.3.5.3	MCE Configuration Update procedure.....	196
15.8.3.6	MBMS Service Counting procedures .....	196
15.8.3.6.1	MBMS Service Counting procedure .....	196
15.8.3.6.2	MBMS Service Counting Results Report procedure.....	196
15.8.3.7	MBMS Overload Notification procedure.....	196
15.9	M3 Interface .....	196
15.9.1	M3 Control Plane.....	196
15.9.2	M3 Interface Functions.....	197
15.9.2.1	General .....	197
15.9.2.2	MBMS Session Handling Function.....	197
15.9.2.3	M3 Interface Management Function .....	197
15.9.2.4	M3 Configuration Function.....	197
15.9.3	M3 Interface Signalling Procedures.....	197
15.9.3.1	General .....	197
15.9.3.2	MBMS Session signalling procedure .....	197
15.9.3.3	M3 Interface Management procedures.....	198
15.9.3.3.1	Reset procedure .....	198
15.9.3.3.2	Error Indication procedure.....	198
15.9.3.4	M3 Configuration procedures .....	198
15.9.3.4.1	M3 Setup procedure .....	198
15.9.3.4.2	MCE Configuration Update procedure.....	198
15.10	MBMS Counting .....	198
15.10.1	General.....	198
15.10.2	Counting Procedure .....	198

15.11	MBMS service reception using Receive Only Mode .....	199
16	Radio Resource Management aspects .....	199
16.0	General .....	199
16.1	RRM functions .....	199
16.1.1	Radio Bearer Control (RBC) .....	199
16.1.2	Radio Admission Control (RAC).....	199
16.1.3	Connection Mobility Control (CMC) .....	200
16.1.4	Dynamic Resource Allocation (DRA) - Packet Scheduling (PS) .....	200
16.1.5	Inter-cell Interference Coordination (ICIC).....	200
16.1.5.0	General .....	200
16.1.5.1	UE configurations for time domain ICIC.....	201
16.1.5.2	OAM requirements for time domain ICIC .....	201
16.1.5.2.1	Configuration for CSG cell.....	201
16.1.5.2.2	Configuration for interfering non-CSG cell.....	201
16.1.6	Load Balancing (LB) .....	201
16.1.7	Inter-RAT Radio Resource Management .....	202
16.1.8	Subscriber Profile ID for RAT/Frequency Priority.....	202
16.1.9	Inter-eNB CoMP.....	202
16.1.10	Cell on/off and cell discovery .....	202
16.2	RRM architecture .....	202
16.2.1	Centralised Handling of certain RRM Functions.....	202
16.2.2	De-Centralised RRM .....	203
16.2.2.1	UE History Information .....	203
16.2.3	Void .....	203
16.3	UE assistance information for RRM, and UE power optimisations and UE overheating .....	203
17	Void.....	204
17.1	Void.....	204
18	UE capabilities .....	204
19	S1 Interface .....	205
19.1	S1 User plane .....	205
19.2	S1 Control Plane.....	206
19.2.0	General.....	206
19.2.1	S1 Interface Functions .....	207
19.2.1.0	General .....	207
19.2.1.1	S1 Paging function .....	208
19.2.1.2	S1 UE Context Management function.....	208
19.2.1.3	Initial Context Setup Function .....	208
19.2.1.3a	UE Context Modification Function.....	208
19.2.1.3b	UE Context Resume Function.....	208
19.2.1.4	Mobility Functions for UEs in ECM-CONNECTED .....	208
19.2.1.4.1	Intra-LTE Handover .....	208
19.2.1.4.2	Inter-3GPP-RAT Handover.....	209
19.2.1.5	E-RAB Service Management function.....	209
19.2.1.6	NAS Signalling Transport function.....	209
19.2.1.7	NAS Node Selection Function (NNSF) .....	209
19.2.1.8	S1-interface management functions .....	209
19.2.1.9	MME Load balancing Function .....	209
19.2.1.10	Location Reporting Function .....	210
19.2.1.11	Warning Message Transmission function.....	210
19.2.1.12	Overload Function.....	210
19.2.1.13	RAN Information Management Function .....	210
19.2.1.14	S1 CDMA2000 Tunnelling function.....	210
19.2.1.15	Configuration Transfer Function.....	210
19.2.1.16	LPPa Signalling Transport function.....	210
19.2.1.17	Trace Function .....	210
19.2.1.18	UE Radio Capability Match .....	210
19.2.1.19	Retrieve UE Information Function.....	210
19.2.1.20	UE Information Transfer Function.....	211
19.2.1.21	Report of Secondary RAT data volumes Function.....	211

**iTech STANDARD PREVIEW**  
(standards.itech.ai)

[ETSI TS 136 300 V15.9.0 \(2020-04\)](https://standards.itech.ai/catalog/standards/sis/a02569b8-17ce-432a-9f79-4cccabaaedcd/etsi-ts-136-300-v15-9-0-2020-04)

[https://standards.itech.ai/catalog/standards/sis/a02569b8-17ce-432a-9f79-](https://standards.itech.ai/catalog/standards/sis/a02569b8-17ce-432a-9f79-4cccabaaedcd/etsi-ts-136-300-v15-9-0-2020-04)

[4cccabaaedcd/etsi-ts-136-300-v15-9-0-2020-04](https://standards.itech.ai/catalog/standards/sis/a02569b8-17ce-432a-9f79-4cccabaaedcd/etsi-ts-136-300-v15-9-0-2020-04)

19.2.2	S1 Interface Signalling Procedures .....	211
19.2.2.0	General .....	211
19.2.2.1	Paging procedure.....	211
19.2.2.2	S1 UE Context Release procedure .....	211
19.2.2.2.0	General .....	211
19.2.2.2.1	S1 UE Context Release (EPC triggered) .....	212
19.2.2.2.2	S1 UE Context Release Request (eNB triggered).....	212
19.2.2.3	Initial Context Setup procedure.....	212
19.2.2.3a	UE Context Modification procedure .....	213
19.2.2.4	E-RAB signalling procedures.....	214
19.2.2.4.1	E-RAB Setup procedure .....	214
19.2.2.4.2	E-RAB Modification procedure .....	215
19.2.2.4.3	E-RAB Release procedure.....	216
19.2.2.4.4	E-RAB Release Indication procedure.....	217
19.2.2.4.5	E-RAB Modification Indication procedure .....	217
19.2.2.5	Handover signalling procedures.....	217
19.2.2.5.0	General .....	217
19.2.2.5.1	Handover Preparation procedure .....	218
19.2.2.5.2	Handover Resource Allocation procedure.....	218
19.2.2.5.3	Handover Notification procedure .....	219
19.2.2.5.4	Handover Cancellation .....	219
19.2.2.5.5	Path Switch procedure .....	220
19.2.2.5.6	Message sequence diagrams .....	220
19.2.2.5.7	eNB Status Transfer procedure.....	228
19.2.2.5.8	MME Status Transfer procedure .....	229
19.2.2.6	NAS transport procedures .....	229
19.2.2.7	S1 interface Management procedures .....	232
19.2.2.7.1	Reset procedure .....	232
19.2.2.7.1a	eNB initiated Reset procedure .....	232
19.2.2.7.1b	MME initiated Reset procedure .....	233
19.2.2.7.2	Error Indication functions and procedures.....	233
19.2.2.7.2a	eNB initiated error indication .....	233
19.2.2.7.2b	MME initiated error indication .....	233
19.2.2.8	S1 Setup procedure.....	234
19.2.2.9	eNB Configuration Update procedure.....	234
19.2.2.9a	eNB Configuration Transfer procedure.....	235
19.2.2.10	MME Configuration Update procedure .....	235
19.2.2.10a	MME Configuration Transfer procedure .....	236
19.2.2.11	Location Reporting procedures .....	236
19.2.2.11.0	General .....	236
19.2.2.11.1	Location Reporting Control procedure.....	237
19.2.2.11.2	Location Report procedure .....	237
19.2.2.11.3	Location Report Failure Indication procedure.....	237
19.2.2.12	Overload procedure .....	238
19.2.2.12.1	Overload Start procedure.....	238
19.2.2.12.2	Overload Stop procedure .....	238
19.2.2.13	Write-Replace Warning procedure.....	239
19.2.2.14	eNB Direct Information Transfer procedure .....	239
19.2.2.15	MME Direct Information Transfer procedure.....	240
19.2.2.16	S1 CDMA2000 Tunnelling procedures.....	240
19.2.2.16.1	Downlink S1 CDMA2000 Tunnelling procedure.....	240
19.2.2.16.2	Uplink S1 CDMA2000 Tunnelling procedure.....	240
19.2.2.17	Kill procedure .....	241
19.2.2.18	LPPa Transport procedures .....	241
19.2.2.18.0	General .....	241
19.2.2.18.1	Downlink UE Associated LPPa Transport procedure .....	242
19.2.2.18.2	Uplink UE Associated LPPa Transport procedure .....	242
19.2.2.18.3	Downlink Non UE Associated LPPa Transport procedure.....	242
19.2.2.18.4	Uplink Non UE Associated LPPa Transport procedure .....	243
19.2.2.19	Trace procedures .....	243
19.2.2.19.0	General .....	243
19.2.2.19.1	Trace Start procedure .....	243

19.2.2.19.2	Trace Failure Indication procedure.....	244
19.2.2.19.3	Deactivate Trace procedure.....	244
19.2.2.19.4	Cell Traffic Trace procedure.....	244
19.2.2.20	UE Capability Info Indication procedure.....	244
19.2.2.21	UE Radio Capability Match procedure.....	245
19.2.2.22	PWS Restart Indication procedure.....	245
19.2.2.23	PWS Failure Indication procedure.....	246
19.2.2.24	UE Context Modification Indication procedure.....	246
19.2.2.25	Connection Establishment Indication procedure.....	247
19.2.2.26	UE Context Suspend procedure.....	247
19.2.2.27	UE Context Resume procedure.....	248
19.2.2.28	Retrieve UE Information procedure.....	248
19.2.2.29	UE Information Transfer procedure.....	249
19.2.2.30	eNB CP Relocation Indication.....	249
19.2.2.31	MME CP Relocation Indication.....	249
19.2.2.32	Secondary RAT Report.....	250
20	X2 Interface.....	250
20.1	User Plane.....	250
20.1.1	Flow Control Functions.....	251
20.2	Control Plane.....	251
20.2.0	X2-CP Overview.....	251
20.2.1	X2-CP Functions.....	252
20.2.2	X2-CP Procedures.....	253
20.2.2.0	Overview of X2-CP procedures.....	253
20.2.2.1	Handover Preparation procedure.....	253
20.2.2.2	Handover Cancel procedure.....	253
20.2.2.2a	SeNB Addition Preparation procedure.....	254
20.2.2.2b	SeNB Reconfiguration Completion procedure.....	254
20.2.2.2c	MeNB initiated SeNB Modification Preparation procedure.....	254
20.2.2.2d	SeNB initiated SeNB Modification procedure.....	255
20.2.2.2e	MeNB initiated SeNB Release procedure.....	255
20.2.2.2f	SeNB initiated SeNB Release procedure.....	256
20.2.2.2g	SeNB Counter Check procedure.....	256
20.2.2.3	UE Context Release procedure.....	256
20.2.2.4	SN Status Transfer procedure.....	257
20.2.2.5	Error Indication procedure.....	258
20.2.2.6	Load Indication procedure.....	259
20.2.2.7	X2 Setup procedure.....	260
20.2.2.8	eNB Configuration Update procedure.....	260
20.2.2.9	Reset procedure.....	261
20.2.2.10	Resource Status Reporting Initiation procedure.....	262
20.2.2.11	Resource Status Reporting procedure.....	262
20.2.2.12	Radio Link Failure Indication procedure.....	262
20.2.2.13	Handover Report procedure.....	263
20.2.2.14	Mobility Settings Change procedure.....	263
20.2.2.15	Cell Activation procedure.....	264
20.2.2.16	X2 Release procedure.....	264
20.2.2.17	X2AP Message Transfer procedure.....	265
20.2.2.18	X2 Removal procedure.....	265
20.2.2.19	Retrieve UE Context.....	266
20.2.2.20	SgNB Addition Preparation procedure.....	267
20.2.2.21	SgNB Reconfiguration Completion procedure.....	268
20.2.2.22	MeNB initiated SgNB Modification Preparation procedure.....	268
20.2.2.23	SgNB initiated SgNB Modification Preparation procedure.....	268
20.2.2.24	MeNB initiated SgNB Release procedure.....	269
20.2.2.25	SgNB initiated SgNB Release procedure.....	269
20.2.2.26	SgNB initiated SgNB Change procedure.....	269
20.2.2.27	SgNB Counter Check procedure.....	270
20.2.2.28	EN-DC X2 Setup procedure.....	270
20.2.2.29	EN-DC Configuration Update procedure.....	271
20.2.2.30	EN-DC Cell Activation procedure.....	272

20.2.2.31	E-UTRA - NR Cell Resource Coordination procedure .....	272
20.2.2.32	Partial Reset procedure for EN-DC .....	273
20.2.3	Void .....	274
21	Void .....	274
21.1	Void .....	274
21.2	Void .....	274
21.3	Void .....	274
22	Support for self-configuration and self-optimisation .....	274
22.1	Definitions .....	274
22.2	UE Support for self-configuration and self-optimisation .....	275
22.3	Self-configuration .....	275
22.3.1	Dynamic configuration of the S1-MME interface .....	275
22.3.1.1	Prerequisites .....	275
22.3.1.2	SCTP initialization .....	275
22.3.1.3	Application layer initialization .....	276
22.3.2	Dynamic Configuration of the X2 interface .....	276
22.3.2.1	Prerequisites .....	276
22.3.2.2	SCTP initialization .....	276
22.3.2.3	Application layer initialization .....	276
22.3.2a	Automatic Neighbour Relation Function .....	277
22.3.3	Intra-LTE/frequency Automatic Neighbour Relation Function .....	278
22.3.4	Inter-RAT/Inter-frequency Automatic Neighbour Relation Function .....	279
22.3.4a	Automatic Neighbour Relation Function towards NR .....	280
22.3.5	Framework for PCI Selection .....	280
22.3.6	TNL address discovery .....	281
22.3.6.1	TNL address discovery of candidate eNB via S1 interface .....	281
22.3.6.2	TNL address discovery of a candidate en-gNB via the S1 interface .....	281
22.3.6.3	TNL address discovery of a candidate en-gNB via inter-system signalling .....	282
22.3.7	Dynamic configuration of the Xw-C interface .....	282
22.3.7.1	Prerequisites .....	282
22.3.7.2	SCTP initialization .....	282
22.3.7.3	Application layer initialization .....	282
22.4	Self-optimisation .....	282
22.4.1	Support for Mobility Load Balancing .....	282
22.4.1.1	General .....	282
22.4.1.2.1	Load reporting for intra-LTE scenario .....	283
22.4.1.2.2	Load reporting for inter-RAT scenario .....	284
22.4.1.3	Load balancing action based on handovers .....	284
22.4.2	Support for Mobility Robustness Optimisation .....	284
22.4.2.1	General .....	284
22.4.2.2	Connection failure due to intra-LTE mobility .....	284
22.4.2.2a	Connection failure due to inter-RAT mobility .....	287
22.4.2.3	Unnecessary HO to another RAT .....	288
22.4.2.4	O&M Requirements .....	289
22.4.2.5	Inter-RAT ping-pong .....	289
22.4.2.6	Dynamic coverage configuration changes .....	290
22.4.3	Support for RACH Optimisation .....	290
22.4.4	Support for Energy Saving .....	290
22.4.4.1	General .....	290
22.4.4.2	Solution description .....	291
22.4.4.2.1	E-UTRA cell case .....	291
22.4.4.2.2	EN-DC cell case .....	291
22.4.4.3	O&M requirements .....	291
22.4.5	Radio Link Failure report .....	292
22.5	Void .....	292
22.6	Void .....	292
22A	LTE-WLAN Aggregation and RAN Controlled LTE-WLAN Interworking .....	292
22A.1	LTE-WLAN Aggregation .....	292
22A.1.1	General .....	292
22A.1.2	Radio Protocol Architecture .....	293

22A.1.3	Network Interfaces.....	294
22A.1.3.1	General.....	294
22A.1.3.2	User Plane.....	294
22A.1.3.3	Control Plane.....	295
22A.1.4	Mobility.....	296
22A.1.5	WLAN Measurements.....	296
22A.1.6	Procedure for WLAN Connection Status Reporting.....	296
22A.1.7	LTE-WLAN Aggregation Operation.....	297
22A.1.7.1	WT Addition.....	297
22A.1.7.2	WT Modification.....	298
22A.1.7.3	WT Release.....	299
22A.1.7.4	Change of WT.....	301
22A.1.8	WLAN Authentication.....	301
22A.2	RAN Controlled LTE WLAN Interworking.....	301
22A.2.1	General.....	301
22A.2.2	Network Interfaces.....	302
22A.2.2.1	General.....	302
22A.2.2.2	User Plane.....	302
22A.2.2.3	Control Plane.....	302
22A.2.3	Mobility.....	302
22A.2.4	WLAN Measurements.....	302
22A.2.5	Procedure for WLAN Connection Status Reporting.....	302
22A.2.6	Traffic Steering Operation.....	302
22A.2.6.1	Traffic Steering from E-UTRAN to WLAN.....	302
22A.2.6.2	Traffic Steering from WLAN to E-UTRAN.....	303
22A.3	LTE/WLAN Radio Level Integration with IPsec Tunnel.....	303
22A.3.0	General.....	303
22A.3.1	LWIP Operation.....	306
22A.3.1.1	LWIP Tunnel Setup and Data Bearer Configuration.....	306
22A.3.1.2	Reconfiguration to Remove WLAN Resources from Data Bearer.....	307
22A.3.1.3	LWIP Tunnel Release.....	307
22A.3.2	Network Interfaces.....	308
22A.3.2.1	General.....	308
22A.3.2.2	User Plane.....	308
22A.3.2.3	Control Plane.....	308
22B	Xw Interface.....	309
22B.1	User Plane.....	309
22B.2	Control Plane.....	309
22B.2.0	General.....	309
22B.2.1	Xw-CP Functions.....	310
22B.2.2	Xw-CP Procedures.....	310
22B.2.2.1	WT Addition Preparation procedure.....	310
22B.2.2.2	WT Association Confirmation procedure.....	310
22B.2.2.3	eNB initiated WT Modification Preparation procedure.....	311
22B.2.2.4	WT initiated WT Modification procedure.....	311
22B.2.2.5	eNB initiated WT Release procedure.....	312
22B.2.2.6	WT initiated WT Release procedure.....	312
22B.2.2.7	WT Status Reporting Initiation.....	313
22B.2.2.8	WT Status Reporting.....	313
22B.2.2.9	Xw Setup procedure.....	313
22B.2.2.10	WT Configuration Update procedure.....	314
22B.2.2.11	Error Indication procedure.....	314
22B.2.2.11.0	General.....	314
22B.2.2.11.1	WT initiated error indication.....	315
22B.2.2.11.2	eNB initiated error indication.....	315
22B.2.2.12	Reset procedure.....	315
22B.2.2.12.0	General.....	315
22B.2.2.12.1	WT initiated reset.....	315
22B.2.2.12.2	eNB initiated reset.....	316
22B.2.2.13	LWIP Addition Preparation procedure.....	316
22B.2.2.14	eNB initiated LWIP Modification Preparation procedure.....	316