
**Wood-based panels — Determination
of formaldehyde release —**

**Part 2:
Small-scale chamber method**

*Panneaux à base de bois — Détermination du dégagement de
formaldéhyde —*

Partie 2: Méthode à la petite chambre

**iTeh standards
(<https://standards.iteh.ai>)
Document Preview**

[ISO 12460-2:2018](#)

<https://standards.iteh.ai/catalog/standards/iso/15ae7107-e2c7-4881-a2da-c91faf6e9abe/iso-12460-2-2018>



Reference number
ISO 12460-2:2018(E)

© ISO 2018

iTeh Standards
(<https://standards.iteh.ai>)
Document Preview

[ISO 12460-2:2018](#)

<https://standards.iteh.ai/catalog/standards/iso/15ae7107-e2c7-4881-a2da-c91faf6e9abe/iso-12460-2-2018>



COPYRIGHT PROTECTED DOCUMENT

© ISO 2018

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
CP 401 • Ch. de Blandonnet 8
CH-1214 Vernier, Geneva
Phone: +41 22 749 01 11
Fax: +41 22 749 09 47
Email: copyright@iso.org
Website: www.iso.org

Published in Switzerland

Contents

Page

Foreword	iv
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 General	2
5 Significance and use	2
6 Interferences	3
7 Apparatus	3
7.1 Test chamber	3
7.2 Make-up air	3
7.2.1 General	3
7.2.2 Air circulation	3
7.2.3 Air sampling port	4
8 Hazards	4
8.1 Chromotropic acid reagent treatment	4
8.2 Cleaning chemicals for glassware	4
9 Test specimens	4
9.1 Standard loading ratio	4
9.2 Number of test pieces	4
9.3 Nonstandard sample configuration testing products with single surface exposed	4
10 Sample material handling and specimen conditioning	4
10.1 Handling	4
10.2 Conditioning	4
11 Procedure	5
11.1 Test procedure for materials	5
11.2 Air sampling	5
11.3 Analysis of air samples	5
11.4 Absorbance readings	6
12 Calculation	6
13 Report	7
Annex A (normative) Conversion factors for formaldehyde, standard solutions, calibration curve	9
Bibliography	15

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see www.iso.org/patents).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT) see: www.iso.org/iso/foreword.html.

The committee responsible for this document is ISO/TC 89, *Wood-based panels*.

A list of all the parts in the ISO 12460 series can be found on the ISO website.

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at www.iso.org/members.html.

<https://standards.iteh.ai/catalog/standards/iso/12460-2/107-e2c7-4881-a2da-c91faf6e9abe/iso-12460-2-2018>

Wood-based panels — Determination of formaldehyde release —

Part 2: Small-scale chamber method

1 Scope

This document specifies a test method to measure the formaldehyde concentrations in air from wood products under defined test conditions of temperature and relative humidity. Results obtained from this small-scale chamber test method are often used for quality assurance and can be comparable to, or can provide useful correlations to, results obtained from testing larger product samples in larger chamber test methods for wood products, such as the 1 m³ chamber method specified in ISO 12460-1.

NOTE 1 This document is based on the general principles and methods of ASTM D 6007.

NOTE 2 ISO 12460-1 for the 1 m³ chamber is the reference method for the determination of formaldehyde release. For factory production control the derived test methods according to this document, ISO 12460-3, ISO 12460-4 and ISO 12460-5 are used.

2 Normative references

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 12460-1, *Wood-based panels — Determination of formaldehyde release — Part 1: Formaldehyde emission by the 1-cubic-metre chamber method* ISO 12460-2:2018
http://www.iso.org/obp/07-e2c7-4881-a2da-c91faf6e9abe/iso-12460-2-2018

3 Terms and definitions

For the purposes of this document, the following terms and definitions apply.

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- IEC Electropedia: available at <http://www.electropedia.org/>
- ISO Online browsing platform: available at <http://www.iso.org/obp>

3.1

air change rate

N

ratio of conditioned and filtered air, *Q*, that enters or is replaced in the small chamber in one hour divided by the interior volume of the small chamber, *V*, air changes per hour (ACH)

3.2

loading ratio

L

total exposed surface area, *A*, excluding panel edges, of the product being tested divided by the test chamber's interior volume, *V*, in m²/m³

Note 1 to entry: *L* is equal to *A/V*.

3.3

make-up airflow

Q

quantity of conditioned and filtered air fed into the chamber per unit time, in m^3/h

3.4

Q/A ratio

ratio of air flow through the chamber (*Q*) to sample surface area (*A*), in m/h

3.5

sample surface area

A

total area of all sample faces exposed in the chamber, in m^2

3.6

measured concentration

C

formaldehyde concentration (expressed in mg/m^3) under the defined environmental test parameters of this method

3.7

volume of closed system

V

interior volume of the test chamber, in m^3

iTeh Standards

(<https://standards.iteh.ai>)

4 General

This method measures the quantity of formaldehyde in an air sample from a small chamber as determined by a modification of the National Institute for Occupational Safety and Health (NIOSH) 3500 chromotropic acid test procedure (see Bibliography). Other analytical procedures may be used to determine the quantity of formaldehyde in the air sample provided that such methods give comparable results. The test report shall include full description of the analytical procedure employed.

This test method specifies testing at the loading rate and air exchange rate used in ISO 12460-1. The test results and test report shall be properly qualified and shall specify the make-up air flow, sample surface area, and chamber volume.

Ideal candidates for small-scale chamber testing are products relatively homogeneous in the formaldehyde release characteristics. Still, product inhomogeneities shall be considered when selecting and preparing samples for small-scale chamber testing.

The values stated in SI units are the standard values. Any values given in parentheses are for information only.

NOTE This document does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.

5 Significance and use

5.1 Various national and regional regulations on formaldehyde emission levels have been established for wood panels. This international test method was adapted from the small chamber test method specified in ASTM D6007 where its use has been well established as part of monitoring mill compliance to formaldehyde regulations of the U.S. Department of Housing and Urban development (HUD)^[1]. This test method provides a means of testing smaller samples and reduces the time required for testing.

5.2 Formaldehyde concentration levels obtained by this small-scale method can differ from expected in full-scale indoor environments. Variations in product loading, temperature, relative humidity, and air exchange will affect formaldehyde emission rates and thus likely indoor air formaldehyde concentrations.

5.3 This test method requires the use of a chamber of 0,02 m³ to 1 m³ in volume to evaluate the formaldehyde concentration in air using the following controlled conditions which are defined within this standard method:

- a) conditioning of specimens prior to testing;
- b) exposed surface area of the specimens in the test chamber;
- c) test chamber temperature and relative humidity;
- d) the *Q/A* ratio;
- e) air circulation within the chamber.

6 Interferences

The NIOSH 3500 analytical method lists phenols as a negative interference when present at an 8:1 excess over formaldehyde. Modification in the analytical procedure shall be made when relatively high phenol to formaldehyde concentrations (8:1) are anticipated (see Hakes paper^[8] and Tech Bulletin 415^[9]). Interferences of other analytical methods should be determined by reference to other applicable standard test methods.

7 Apparatus (<https://standards.iteh.ai>)

7.1 Test chamber

The interior volume of the small chamber shall be from 0,02 m³ to 1 m³. The interior of the test chamber shall be free of refrigeration coils that condense water and items such as humidifiers with water reservoirs since water has the potential for collecting formaldehyde and thus influencing test results. The interior surfaces of the small chamber, including any sample support system, shall be a non-absorbent material. Stainless steel, aluminium, and polytetrafluoroethylene (PTFE) have been found appropriate as chamber lining materials. All joints except for doors used for loading and unloading specimens should be sealed. Doors shall be self-sealing.

7.2 Make-up air

7.2.1 General

The make-up air shall come from a filtered dust-free environment and contain no more than 0,006 mg/m³ of formaldehyde. This can be accomplished by passing make-up air through a filter bed of activated carbon, activated alumina impregnated with potassium permanganate, or other materials capable of absorbing, or oxidizing formaldehyde.

Make-up air for the chamber shall pass through a calibrated air flow measuring device.

7.2.2 Air circulation

Low speed mixing fans or multi-port inlet and outlet diffusers are two techniques that have been used successfully to ensure mixing of the chamber air over all sample surfaces.

7.2.3 Air sampling port

The exhaust flow (that is, chamber outlet) is normally used as the sampling point, although separate sampling ports in the chamber can be used. The sampling system shall be constructed of a material to minimize absorption (for example, glass stainless steel), and the system should be maintained at the same temperature as the test chambers.

8 Hazards

8.1 Chromotropic acid reagent treatment

During this hazardous operation, the operator must wear rubber gloves, apron, and a full face mask or be protected from splashing by a transparent shield such as a hood window. The solution becomes extremely hot during addition of sulfuric acid. If acid is not added slowly, some loss of sample could occur due to splattering (see [11.3.4](#) and [11.3.5](#)).

8.2 Cleaning chemicals for glassware

Use appropriate precautions if cleaning chemicals are considered to be hazardous.

9 Test specimens

9.1 Standard loading ratio

$(L \text{ or } A/V)$ is defined as the total exposed specimen surface area, excluding edge area, divided by the chamber volume. The loading ratio, L , shall be $(1,0 \pm 0,02) \text{ m}^2/\text{m}^3$.

9.2 Number of test pieces

Two square test pieces, sized to meet the loading ratio specified in [9.1](#), shall be cut.

9.3 Nonstandard sample configuration testing products with single surface exposed

Some products have significantly different formaldehyde release characteristics for each surface. In those cases, panels may be tested back-to-back with edges taped together. The panels shall be identified as tested in the back-to-back mode.

10 Sample material handling and specimen conditioning

10.1 Handling

Materials selected for testing shall be wrapped in polyethylene plastic having a minimum thickness of 0,15 mm (6 mil) until sample conditioning is initiated. When testing wood products that are not newly manufactured such as after original application, installation or use, the method of packaging and shipping the products for testing shall be fully described. Information on the age and history of the product shall be detailed in the test report.

10.2 Conditioning

Condition test specimens with a minimum distance of 0,15 m (6 in.) between each specimen for $2 \text{ h} \pm 15 \text{ min}$ at the conditions of $(24 \pm 3)^\circ\text{C}$ $(75 \pm 5)^\circ\text{F}$ and $(50 \pm 5)\%$ relative humidity. The formaldehyde concentration in the air within 0,3 m (12 in.) of where panels are conditioned shall be not more than $0,01 \text{ mg/m}^3$ during the conditioning period. Alternative conditioning intervals can give better correlation to larger chamber test methods, such as 7 days $\pm 3 \text{ h}$ conditioning or 15 days conditioning that parallels ISO 12460-1.

The air exchange ratio (Q/V ratio) shall be $(1,0 \pm 0,05)/h$.

10.3 Sealing of test piece edges

After conditioning, test piece edges shall be partly sealed using self-adhesive aluminium tape to give a constant ratio of the length, U , of the open (unsealed) edges to the surface area, A , so that $U/A = 1,5 \text{ m/m}^2$.

NOTE As a result of the constant ratio $U/A = 1,5 \text{ m/m}^2$, the percentage of open edges area related to the surface area depends on the thickness of the test piece, as shown in the following examples.

Panel thickness	Percentage of open edges area
10 mm	1,5 %
19 mm	2,8 %
32 mm	4,8 %

11 Procedure

11.1 Test procedure for materials

11.1.1 Purge the chamber by running empty or with the use of filters designed to reduce the formaldehyde background concentration in air, or both. The formaldehyde background concentration in air of the empty operating chamber shall not exceed $0,006 \text{ mg/m}^3$. Clean chamber surfaces with water or suitable solvent if formaldehyde background concentrations approach $0,005 \text{ mg/m}^3$.

11.1.2 Load specimens to obtain a loading rate, L , of $1, \text{ m}^2/\text{m}^3$. Locate the specimens in the chamber so that the conditioned air stream circulates over all panel surfaces.

11.1.3 Operate the chamber at $(25 \pm 1) \text{ }^\circ\text{C}$ $(77 \pm 2) \text{ }^\circ\text{F}$ and $(50 \pm 4) \text{ %}$ relative humidity. Record the temperature, relative humidity, and barometric pressure during the testing period. Conduct the chamber test at the specified Q/V ratio and record this ratio in the report. Conduct the chamber test at the specified Q/V ratio of $(1,0 \pm 0,05)/h$ and record this ratio in the report. The air exchange and loading ratios result in a Q/A ratio of $1,0$.

11.1.4 After placing the specimens in the chamber, allow time for no less than two full air changes before beginning the air sampling.

11.2 Air sampling

Purge air sampling lines for 1 min. At the sampling station, bubble air through a single impinger containing 20 ml of a 1 % sodium bisulfite (NaHSO_3) solution. A filter trap may be placed between the impinger and the flowmeter. Set a calibrated flowmeter to maintain an average airflow of $(1 \pm 0,05) \text{ l/min}$ for 30 min to 60 min with time measured accurately to within 5 s resulting in a minimum air sampling of 30 l to 60 l. For products with very low emission rates, it may be necessary to sample the air for 60 min. Following air sampling, analyse the collection solution.

11.3 Analysis of air samples

The following analysis is based on the chromotropic acid method as described in the ASTM D6007 method from which this standard was derived. Other analytical methods, such as the acetyl acetone method described in ISO 12460-1:2007, Clause 9 is a permitted alternate analytical method. Other methods are acceptable if they provide similar results.

11.3.1 Pipet 4 ml of the NaHSO_3 solution from the impinger into each of three 16 mm by 150 mm screwcap test tubes for triplicate analysis of each impinger sample.

11.3.2 Pipet 4 ml of 1 % NaHSO₃ into a 16 mm by 150 mm screwcap test tube to act as a reagent blank.

11.3.3 Add 0,1 ml of 1 % chromotropic acid reagent to each test tube. Shake tube after addition.

11.3.4 Slowly and carefully pipet 6,0 ml concentrated sulfuric acid (H₂SO₄) into each test tube (Precaution – see [8.1](#)) and allow to flow down the side of test tube. Allow the volumetric pipet to drain. Do not blow out. Before placing caps on test tubes, check the condition of the polytetrafluoroethylene (PTFE) cap liners to make sure they are clean and not deteriorated.

11.3.5 Slowly and gently agitate test tubes to affect mixing. Mixing is complete when there is no sign of stratification. Caution needs to be taken due to the exothermic chemical reaction. Rapid mixing will cause heating and a pressure increase which may break the test tube. Vent test tubes to release pressure.

11.3.6 If absorbance readings exceed 1,0 or if spectrophotometric analysis is performed within 2 h, heat capped test tubes to 95 °C or place capped test tubes in a boiling water bath for (15 ± 2) min. to ensure that the chemical reaction is completed. Remove tubes from water bath and allow to cool to room temperature.

11.4 Absorbance readings

11.4.1 Standardize the spectrophotometer using distilled water at 580 nm in accordance with the instrument's operating instructions. The reagent blank shall be read against distilled water because an absorbance above 0,100 for the reagent blank indicates contamination of reagent blank or improper solution preparation. If absorbance for the reagent blank compared to distilled water is greater than 0,100, repeat the entire standardization procedure.

11.4.2 Zero the instrument using the reagent blank if the absorbance is not greater than 0,100 (compared to distilled water as zero). Alternatively, the instrument may be left zeroed on distilled water, and the absorbance of the reagent blank subtracted from the absorbance of the standard solutions.

11.4.3 Read and record absorbance at 580 nm for each test tube prepared (see [A.4.6](#) to [A.4.9](#)). If the absorbance of the specimen solution is found to fall outside the preferred absorbance range (>1,0), steps [11.3.1](#) to [11.3.4](#) may be repeated using an appropriate dilution of each impinger solution.

12 Calculation

12.1 Convert the volume of air sampled to the volume of air at standard conditions as per [Formula \(1\)](#):

$$V_s = \frac{V \times P \times 298}{101 \times (T + 273)} \quad (1)$$

where

V_1 is the volume of air at standard conditions (101 kPa and 298 K), in litres l;

V is the volume of air sampled, in litres l;

P is the barometric pressure, in kPa;

T is the temperature of sample air, in °C.