



**5G;
NR;
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 38.331 version 17.0.0 Release 17)**

<https://standards.iteh.ai/catalog/standards/sist/c7ab1252-8957-4b84-9602-6f900befac5b/etsi-ts-138-331-v17-0-0-2022-05>



ReferenceRTS/TSGR-0238331vh00

Keywords5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2022.

All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

(standards.iteh.ai)

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document **"shall"**, **"shall not"**, **"should"**, **"should not"**, **"may"**, **"need not"**, **"will"**, **"will not"**, **"can"** and **"cannot"** are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"must" and **"must not"** are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	23
1 Scope	24
2 References	24
3 Definitions, symbols and abbreviations	27
3.1 Definitions	27
3.2 Abbreviations	28
4 General	31
4.1 Introduction	31
4.2 Architecture	31
4.2.1 UE states and state transitions including inter RAT	31
4.2.2 Signalling radio bearers	34
4.3 Services	35
4.3.1 Services provided to upper layers	35
4.3.2 Services expected from lower layers	35
4.4 Functions	35
5 Procedures	36
5.1 General	36
5.1.1 Introduction.....	36
5.1.2 General requirements.....	36
5.1.3 Requirements for UE in MR-DC	37
5.2 System information	38
5.2.1 Introduction.....	38
5.2.2 System information acquisition.....	39
5.2.2.1 General UE requirements.....	39
5.2.2.2 SIB validity and need to (re)-acquire SIB.....	39
5.2.2.2.1 SIB validity.....	39
5.2.2.2.2 SI change indication and PWS notification	40
5.2.2.3 Acquisition of System Information	42
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i>	42
5.2.2.3.2 Acquisition of an SI message	43
5.2.2.3.3 Request for on demand system information	44
5.2.2.3.3a Request for on demand positioning system information	45
5.2.2.3.4 Actions related to transmission of <i>RRCSystemInfoRequest</i> message	46
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in <i>RRC_CONNECTED</i>	46
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message	47
5.2.2.4 Actions upon receipt of System Information	47
5.2.2.4.1 Actions upon reception of the <i>MIB</i>	47
5.2.2.4.2 Actions upon reception of the <i>SIB1</i>	48
5.2.2.4.3 Actions upon reception of <i>SIB2</i>	51
5.2.2.4.4 Actions upon reception of <i>SIB3</i>	52
5.2.2.4.5 Actions upon reception of <i>SIB4</i>	52
5.2.2.4.6 Actions upon reception of <i>SIB5</i>	53
5.2.2.4.7 Actions upon reception of <i>SIB6</i>	53
5.2.2.4.8 Actions upon reception of <i>SIB7</i>	53
5.2.2.4.9 Actions upon reception of <i>SIB8</i>	54
5.2.2.4.10 Actions upon reception of <i>SIB9</i>	55
5.2.2.4.11 Actions upon reception of <i>SIB10</i>	55
5.2.2.4.12 Actions upon reception of <i>SIB11</i>	55
5.2.2.4.13 Actions upon reception of <i>SIB12</i>	55
5.2.2.4.14 Actions upon reception of <i>SIB13</i>	56

5.2.2.4.15	Actions upon reception of <i>SIB14</i>	56
5.2.2.4.16	Actions upon reception of <i>SIBpos</i>	56
5.2.2.4.17	Actions upon reception of <i>SIB15</i>	56
5.2.2.4.18	Actions upon reception of <i>SIB16</i>	57
5.2.2.4.19	Actions upon reception of <i>SIB17</i>	57
5.2.2.4.20	Actions upon reception of <i>SIB18</i>	57
5.2.2.4.21	Actions upon reception of <i>SIB19</i>	57
5.2.2.4.22	Actions upon reception of <i>SIB20</i>	57
5.2.2.4.23	Actions upon reception of <i>SIB21</i>	57
5.2.2.5	Essential system information missing	57
5.3	Connection control	58
5.3.1	Introduction	58
5.3.1.1	RRC connection control	58
5.3.1.2	AS Security	59
5.3.2	Paging	60
5.3.2.1	General	60
5.3.2.2	Initiation	60
5.3.2.3	Reception of the <i>Paging message</i> by the UE	60
5.3.3	RRC connection establishment	62
5.3.3.1	General	62
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	62
5.3.3.2	Initiation	63
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message	63
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE	64
5.3.3.5	Reception of the <i>RRCReject</i> by the UE	67
5.3.3.6	Cell re-selection or cell selection while T390, T300 or T302 is running (UE in RRC_IDLE)	67
5.3.3.7	T300 expiry	68
5.3.3.8	Abortion of RRC connection establishment	69
5.3.4	Initial AS security activation	69
5.3.4.1	General	69
5.3.4.2	Initiation	70
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE	70
5.3.5	RRC reconfiguration	71
5.3.5.1	General	71
5.3.5.2	Initiation	72
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE	72
5.3.5.4	Secondary cell group release	82
5.3.5.5	Cell Group configuration	82
5.3.5.5.1	General	82
5.3.5.5.2	Reconfiguration with sync	83
5.3.5.5.3	RLC bearer release	85
5.3.5.5.4	RLC bearer addition/modification	85
5.3.5.5.5	MAC entity configuration	86
5.3.5.5.6	RLF Timers & Constants configuration	87
5.3.5.5.7	SpCell Configuration	87
5.3.5.5.8	SCell Release	88
5.3.5.5.9	SCell Addition/Modification	88
5.3.5.5.10	BH RLC channel release	89
5.3.5.5.11	BH RLC channel addition/modification	90
5.3.5.5.12	Uu Relay RLC channel release	90
5.3.5.5.13	Uu Relay RLC channel addition/modification	90
5.3.5.6	Radio Bearer configuration	90
5.3.5.6.1	General	90
5.3.5.6.2	SRB release	91
5.3.5.6.3	SRB addition/modification	91
5.3.5.6.4	DRB release	93
5.3.5.6.5	DRB addition/modification	93
5.3.5.6.6	Multicast MRB release	96
5.3.5.6.7	Multicast MRB addition/modification	97
5.3.5.7	AS Security key update	97
5.3.5.8	Reconfiguration failure	99

5.3.5.8.1	Void	99
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i>	99
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure) or T420 expiry (Path switch failure)	101
5.3.5.9	Other configuration	102
5.3.5.10	MR-DC release	106
5.3.5.11	Full configuration	106
5.3.5.12	BAP configuration	108
5.3.5.12a	IAB Other Configuration	108
5.3.5.12a.1	IP address management	108
5.3.5.12a.1.1	IP Address Release	108
5.3.5.12a.1.2	IP Address Addition/Modification	109
5.3.5.13	Conditional Reconfiguration	110
5.3.5.13.1	General	110
5.3.5.13.2	Conditional reconfiguration removal	110
5.3.5.13.3	Conditional reconfiguration addition/modification	110
5.3.5.13.4	Conditional reconfiguration evaluation	111
5.3.5.13.4a	Conditional reconfiguration evaluation of SN initiated inter-SN CPC for EN-DC	112
5.3.5.13.5	Conditional reconfiguration execution	113
5.3.5.13a	SCG activation	113
5.3.5.13b	SCG deactivation	113
5.3.5.13c	FR2 UL gap configuration	114
5.3.5.13d	Application layer measurement configuration	114
5.3.5.14	Sidelink dedicated configuration	115
5.3.5.15	L2 U2N Relay UE configuration	117
5.3.5.15.1	General	117
5.3.5.15.2	L2 U2N Remote UE Release	117
5.3.5.15.3	L2 U2N Remote UE Addition/Modification	117
5.3.5.16	L2 U2N Remote UE configuration	118
5.3.5.16.1	General	118
5.3.6	Counter check	118
5.3.6.1	General	118
5.3.6.2	Initiation	118
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	118
5.3.7	RRC connection re-establishment	119
5.3.7.1	General	119
5.3.7.2	Initiation	120
5.3.7.3	Actions following cell selection while T311 is running	122
5.3.7.3a	Actions following relay selection while T311 is running	124
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message	125
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE	126
5.3.7.6	T311 expiry	127
5.3.7.7	T301 expiry or selected cell no longer suitable	127
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE	127
5.3.8	RRC connection release	128
5.3.8.1	General	128
5.3.8.2	Initiation	128
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE	128
5.3.8.4	T320 expiry	131
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i>	132
5.3.8.6	T346g expiry	132
5.3.9	RRC connection release requested by upper layers	132
5.3.9.1	General	132
5.3.9.2	Initiation	132
5.3.10	Radio link failure related actions	132
5.3.10.1	Detection of physical layer problems in RRC_CONNECTED	132
5.3.10.2	Recovery of physical layer problems	132
5.3.10.3	Detection of radio link failure	133
5.3.10.4	RLF cause determination	134
5.3.10.5	RLF report content determination	135
5.3.11	UE actions upon going to RRC_IDLE	139
5.3.12	UE actions upon PUCCH/SRS release request	140
5.3.13	RRC connection resume	140

5.3.13.1	General	140
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	141
5.3.13.1b	Conditions for initiating SDT	142
5.3.13.2	Initiation	142
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message	145
5.3.13.4	Reception of the <i>RRCResume</i> by the UE	146
5.3.13.5	Handling of failure to resume RRC Connection	151
5.3.13.6	Cell re-selection or cell selection or L2 U2N relay (re)selection while T390, T319, T319a or T302 is running (UE in RRC_INACTIVE)	152
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE	152
5.3.13.8	RNA update	152
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE	153
5.3.13.10	Reception of the <i>RRCReject</i> by the UE	153
5.3.13.11	Inability to comply with <i>RRCResume</i>	153
5.3.13.12	Inter RAT cell reselection	153
5.3.14	Unified Access Control	153
5.3.14.1	General	153
5.3.14.2	Initiation	154
5.3.14.3	Void	155
5.3.14.4	T302, T390 expiry or stop (Barring alleviation)	155
5.3.14.5	Access barring check	156
5.3.15	RRC connection reject	157
5.3.15.1	Initiation	157
5.3.15.2	Reception of the <i>RRCReject</i> by the UE	157
5.4	Inter-RAT mobility	158
5.4.1	Introduction	158
5.4.2	Handover to NR	158
5.4.2.1	General	158
5.4.2.2	Initiation	158
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE	158
5.4.3	Mobility from NR	159
5.4.3.1	General	159
5.4.3.2	Initiation	159
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE	159
5.4.3.4	Successful completion of the mobility from NR	160
5.4.3.5	Mobility from NR failure	160
5.5	Measurements	161
5.5.1	Introduction	161
5.5.2	Measurement configuration	164
5.5.2.1	General	164
5.5.2.2	Measurement identity removal	165
5.5.2.3	Measurement identity addition/modification	165
5.5.2.4	Measurement object removal	166
5.5.2.5	Measurement object addition/modification	167
5.5.2.6	Reporting configuration removal	169
5.5.2.7	Reporting configuration addition/modification	169
5.5.2.8	Quantity configuration	169
5.5.2.9	Measurement gap configuration	169
5.5.2.10	Reference signal measurement timing configuration	172
5.5.2.10a	RSSI measurement timing configuration	173
5.5.2.11	Measurement gap sharing configuration	173
5.5.3	Performing measurements	174
5.5.3.1	General	174
5.5.3.2	Layer 3 filtering	178
5.5.3.3	Derivation of cell measurement results	179
5.5.3.3a	Derivation of layer 3 beam filtered measurement	180
5.5.3.4	Derivation of L2 U2N Relay UE measurement results	180
5.5.4	Measurement report triggering	180
5.5.4.1	General	180
5.5.4.2	Event A1 (Serving becomes better than threshold)	187
5.5.4.3	Event A2 (Serving becomes worse than threshold)	187

5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell)	188
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	189
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2)	189
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell)	190
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold)	191
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	191
5.5.4.10	Event I1 (Interference becomes higher than threshold)	192
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold)	193
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold)	193
5.5.4.13	Void	194
5.5.4.14	Void	194
5.5.4.15	Event D1	194
5.5.4.16	CondEvent T1	194
5.5.4.17	Event X1 (Serving L2 U2N Relay UE becomes worse than threshold1 and NR Cell becomes better than threshold2)	195
5.5.4.18	Event X2 (Serving L2 U2N Relay UE becomes worse than threshold)	196
5.5.4.19	Event Y1 (PCell becomes worse than threshold1 and candidate L2 U2N Relay UE becomes better than threshold2)	196
5.5.4.20	Event Y2 (Candidate L2 U2N Relay UE becomes better than threshold)	197
5.5.5	Measurement reporting	198
5.5.5.1	General	198
5.5.5.2	Reporting of beam measurement information	206
5.5.5.3	Sorting of cell measurement results	206
5.5.6	Location measurement indication	207
5.5.6.1	General	207
5.5.6.2	Initiation	207
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message	208
5.5a	Logged Measurements	209
5.5a.1	Logged Measurement Configuration	209
5.5a.1.1	General	209
5.5a.1.2	Initiation	209
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE	209
5.5a.1.4	T330 expiry	210
5.5a.2	Release of Logged Measurement Configuration	210
5.5a.2.1	General	210
5.5a.2.2	Initiation	210
5.5a.3	Measurements logging	210
5.5a.3.1	General	210
5.5a.3.2	Initiation	210
5.6	UE capabilities	213
5.6.1	UE capability transfer	213
5.6.1.1	General	213
5.6.1.2	Initiation	213
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	213
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE	214
5.6.1.5	Void	217
5.7	Other	217
5.7.1	DL information transfer	217
5.7.1.1	General	217
5.7.1.2	Initiation	217
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	217
5.7.1a	DL information transfer for MR-DC	218
5.7.1a.1	General	218
5.7.1a.2	Initiation	218
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message	218
5.7.2	UL information transfer	219
5.7.2.1	General	219
5.7.2.2	Initiation	219
5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message	219
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message	219

5.7.2a	UL information transfer for MR-DC	220
5.7.2a.1	General	220
5.7.2a.2	Initiation	220
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message	220
5.7.2b	UL transfer of IRAT information	220
5.7.2b.1	General	220
5.7.2b.2	Initiation	221
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	221
5.7.3	SCG failure information	221
5.7.3.1	General	221
5.7.3.2	Initiation	221
5.7.3.3	Failure type determination for (NG)EN-DC	222
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i>	223
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message	223
5.7.3a	EUTRA SCG failure information	226
5.7.3a.1	General	226
5.7.3a.2	Initiation	226
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message	226
5.7.3b	MCG failure information	227
5.7.3b.1	General	227
5.7.3b.2	Initiation	227
5.7.3b.3	Failure type determination	227
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message	228
5.7.3b.5	T316 expiry	229
5.7.4	UE Assistance Information	230
5.7.4.1	General	230
5.7.4.2	Initiation	230
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	236
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE	244
5.7.4.4	Relaxed measurement criterion for a stationary UE	245
5.7.4a	Void	245
5.7.5	Failure information	245
5.7.5.1	General	245
5.7.5.2	Initiation	246
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message	246
5.7.6	DL message segment transfer	246
5.7.6.1	General	246
5.7.6.2	Initiation	247
5.7.6.3	Reception of <i>DLDedicatedMessageSegment</i> by the UE	247
5.7.7	UL message segment transfer	247
5.7.7.1	General	247
5.7.7.2	Initiation	247
5.7.7.3	Actions related to transmission of <i>ULDedicatedMessageSegment</i> message	248
5.7.8	Idle/inactive Measurements	248
5.7.8.1	General	248
5.7.8.1a	Measurement configuration	248
5.7.8.2	Void	249
5.7.8.2a	Performing measurements	249
5.7.8.3	T331 expiry or stop	252
5.7.8.4	Cell re-selection or cell selection while T331 is running	252
5.7.9	Mobility history information	252
5.7.9.1	General	252
5.7.9.2	Initiation	252
5.7.10	UE Information	255
5.7.10.1	General	255
5.7.10.2	Initiation	255
5.7.10.3	Reception of the <i>UEInformationRequest</i> message	255
5.7.10.4	Actions upon successful completion of a random-access procedure or on successful or unsuccessful completion of a procedure for request of on-demand system information	258
5.7.10.5	RA information determination for RA report and RLF report	259
5.7.10.6	Actions for the successful handover report determination	261
5.7.12	IAB Other Information	264

5.7.12.1	General	264
5.7.12.2	Initiation	264
5.7.12.3	Actions related to transmission of <i>IABOtherInformation</i> message	264
5.7.13	RLM/BFD relaxation	266
5.7.13.1	Relaxed measurement criterion for low mobility	266
5.7.13.2	Relaxed measurement criterion for good serving cell quality	266
5.7.14	UE Positioning Assistance Information	267
5.7.14.1	General	267
5.7.14.2	Initiation	267
5.7.14.3	Actions related to transmission of <i>UEPositioningAssistanceInfo</i> message	267
5.7.15	SRS for Positioning in RRC_INACTIVE	267
5.7.15.1	General	267
5.7.15.2	Actions Related to SRS for Positioning at Cell Re-selection in RRC_INACTIVE	268
5.8	Sidelink	269
5.8.1	General	269
5.8.2	Conditions for NR sidelink communication operation	270
5.8.3	Sidelink UE information for NR sidelink communication	270
5.8.3.1	General	270
5.8.3.2	Initiation	271
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message	275
5.8.4	Void	278
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication	278
5.8.5.1	General	278
5.8.5.2	Initiation	279
5.8.5.3	Transmission of SLSS	279
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication	281
5.8.5a.1	General	281
5.8.5a.2	Initiation	281
5.8.6	Sidelink synchronisation reference	281
5.8.6.1	General	281
5.8.6.2	Selection and reselection of synchronisation reference	281
5.8.6.3	Sidelink communication transmission reference cell selection	284
5.8.7	Sidelink communication reception	284
5.8.8	Sidelink communication transmission	285
5.8.9	Sidelink RRC procedure	287
5.8.9.1	Sidelink RRC reconfiguration	287
5.8.9.1.1	General	287
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message	288
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE	289
5.8.9.1.4	Void	290
5.8.9.1.5	Void	290
5.8.9.1.6	Void	290
5.8.9.1.7	Void	290
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE	290
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE	290
5.8.9.1a	Sidelink radio bearer management	291
5.8.9.1a.1	Sidelink DRB release	291
5.8.9.1a.2	Sidelink DRB addition/modification	292
5.8.9.1a.3	Sidelink SRB release	294
5.8.9.1a.4	Sidelink SRB addition	294
5.8.9.2	Sidelink UE capability transfer	294
5.8.9.2.1	General	294
5.8.9.2.2	Initiation	295
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE	295
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE	295
5.8.9.3	Sidelink radio link failure related actions	295
5.8.9.4	Sidelink common control information	296
5.8.9.4.1	General	296
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message	296
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message	296
5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers or AS layer	298
5.8.9.6	UE assistance information Sidelink	298

5.8.9.6.1	General	298
5.8.9.6.2	Initiation	298
5.8.9.6.3	Actions related to reception of <i>UEAssistanceInformationSidelink</i> message	299
5.8.9.8	Remote UE information	300
5.8.9.8.1	General	300
5.8.9.8.2	Actions related to transmission of <i>RemoteUEInformationSidelink</i> message	300
5.8.9.8.3	Reception of <i>RemoteUEInformationSidelink</i> message by the L2 U2N Relay UE	300
5.8.9.9	Uu message transfer in sidelink	301
5.8.9.9.1	General	301
5.8.9.9.2	Actions related to transmission of <i>UuMessageTransferSidelink</i> message	301
5.8.9.9.3	Reception of the <i>UuMessageTransferSidelink</i>	302
5.8.9.10	Notification Message	302
5.8.9.10.1	General	302
5.8.9.10.2	Initiation	302
5.8.9.10.3	Actions related to transmission of <i>NotificationMessageSidelink</i> message	302
5.8.9.10.4	Actions related to reception of <i>NotificationMessageSidelink</i> message	303
5.8.10	Sidelink measurement	303
5.8.10.1	Introduction	303
5.8.10.2	Sidelink measurement configuration	304
5.8.10.2.1	General	304
5.8.10.2.2	Sidelink measurement identity removal	304
5.8.10.2.3	Sidelink measurement identity addition/modification	305
5.8.10.2.4	Sidelink measurement object removal	305
5.8.10.2.5	Sidelink measurement object addition/modification	305
5.8.10.2.6	Sidelink reporting configuration removal	306
5.8.10.2.7	Sidelink reporting configuration addition/modification	306
5.8.10.2.8	Sidelink quantity configuration	306
5.8.10.3	Performing NR sidelink measurements	307
5.8.10.3.1	General	307
5.8.10.3.2	Derivation of NR sidelink measurement results	307
5.8.10.4	Sidelink measurement report triggering	307
5.8.10.4.1	General	307
5.8.10.4.2	Event S1 (Serving becomes better than threshold)	308
5.8.10.4.3	Event S2 (Serving becomes worse than threshold)	309
5.8.10.5	Sidelink measurement reporting	309
5.8.10.5.1	General	309
5.8.11	Zone identity calculation	310
5.8.12	DFN derivation from GNSS	310
5.9	MBS Broadcast	315
5.9.1	Introduction	315
5.9.1.1	General	315
5.9.1.2	MCCH scheduling	316
5.9.1.3	MCCH information validity and notification of changes	316
5.9.2	MCCH information acquisition	316
5.9.2.1	General	316
5.9.2.2	Initiation	317
5.9.2.3	MCCH information acquisition by the UE	317
5.9.2.4	Actions upon reception of the <i>MBSBroadcastConfiguration</i> message	317
5.9.3	Broadcast MRB configuration	317
5.9.3.1	General	317
5.9.3.2	Initiation	317
5.9.3.3	Broadcast MRB establishment	317
5.9.3.4	Broadcast MRB release	318
5.9.4	MBS Interest Indication	318
5.9.4.1	General	318
5.9.4.2	Initiation	318
5.9.4.3	MBS frequencies of interest determination	319
5.9.4.4	MBS services of interest determination	319
5.9.4.5	Setting of the contents of MBS Interest Indication	320
6	Protocol data units, formats and parameters (ASN.1)	321
6.1	General	321

6.1.1	Introduction.....	321
6.1.2	Need codes and conditions for optional downlink fields	321
6.1.3	General rules	324
6.2	RRC messages.....	324
6.2.1	General message structure	324
–	NR-RRC-Definitions.....	324
–	BCCH-BCH-Message	325
–	BCCH-DL-SCH-Message	325
–	DL-CCCH-Message	325
–	DL-DCCH-Message	326
–	MCCH-Message	327
–	PCCH-Message	327
–	UL-CCCH-Message	327
–	UL-CCCH1-Message	328
–	UL-DCCH-Message	329
6.2.2	Message definitions	330
–	CounterCheck.....	330
–	CounterCheckResponse.....	331
–	DedicatedSIBRequest	332
–	DLDedicatedMessageSegment	333
–	DLInformationTransfer	334
–	DLInformationTransferMRDC	335
–	FailureInformation.....	336
–	IABOtherInformation	337
–	LocationMeasurementIndication	340
–	LoggedMeasurementConfiguration	341
–	MBSBroadcastConfiguration	343
–	MBSInterestIndication	344
–	MCGFailureInformation	345
–	MeasurementReport	346
–	MeasurementReportAppLayer	347
–	MIB	348
–	MobilityFromNRCommand	350
–	Paging	352
–	RRCReestablishment	353
–	RRCReestablishmentComplete	354
–	RRCReestablishmentRequest	355
–	RRCReconfiguration	356
–	RRCReconfigurationComplete	362
–	RRCReject	364
–	RRCRelease.....	365
–	RRCResume.....	372
–	RRCResumeComplete	374
–	RRCResumeRequest	376
–	RRCResumeRequest1	377
–	RRCSetup	378
–	RRCSetupComplete	379
–	RRCSetupRequest.....	381
–	RRCSystemInfoRequest	382
–	SCGFailureInformation	383
–	SCGFailureInformationEUTRA.....	385
–	SecurityModeCommand	386
–	SecurityModeComplete	387
–	SecurityModeFailure.....	388
–	SIB1	388
–	SidelinkUEInformationNR	392
–	SystemInformation	397
–	UEAssistanceInformation	398
–	UECapabilityEnquiry.....	407
–	UECapabilityInformation	408
–	UEInformationRequest.....	409
–	UEInformationResponse	410

–	<i>UEPositioningAssistanceInfo</i>	424
–	<i>ULDedicatedMessageSegment</i>	425
–	<i>ULInformationTransfer</i>	426
–	<i>ULInformationTransferIRAT</i>	427
–	<i>ULInformationTransferMRDC</i>	428
6.3	RRC information elements	429
6.3.0	Parameterized types	429
–	<i>SetupRelease</i>	429
6.3.1	System information blocks	429
–	<i>SIB2</i>	429
–	<i>SIB3</i>	434
–	<i>SIB4</i>	436
–	<i>SIB5</i>	441
–	<i>SIB6</i>	444
–	<i>SIB7</i>	444
–	<i>SIB8</i>	445
–	<i>SIB9</i>	446
–	<i>SIB10</i>	447
–	<i>SIB11</i>	448
–	<i>SIB12</i>	448
–	<i>SIB13</i>	450
–	<i>SIB14</i>	451
–	<i>SIB15</i>	452
–	<i>SIB16</i>	452
–	<i>SIB17</i>	453
–	<i>SIB18</i>	455
–	<i>SIB20</i>	457
–	<i>SIB21</i>	458
6.3.1a	Positioning System information blocks	459
–	<i>PosSystemInformation-r16-IEs</i>	459
–	<i>PosSI-SchedulingInfo</i>	460
–	<i>SIBpos</i>	462
6.3.2	Radio resource control information elements	462
–	<i>AdditionalSpectrumEmission</i>	462
–	<i>Alpha</i>	463
–	<i>AMF-Identifier</i>	463
–	<i>ARFCN-ValueEUTRA</i>	463
–	<i>ARFCN-ValueNR</i>	464
–	<i>ARFCN-ValueUTRA-FDD</i>	464
–	<i>AvailabilityCombinationsPerCell</i>	464
–	<i>AvailabilityIndicator</i>	466
–	<i>BAP-RoutingID</i>	466
–	<i>BeamFailureRecoveryConfig</i>	467
–	<i>BeamFailureRecoverySCellConfig</i>	470
–	<i>BeamFailureRecoveryServingCellConfig</i>	471
–	<i>BetaOffsets</i>	471
–	<i>BetaOffsetsCrossPri</i>	472
–	<i>BH-LogicalChannelIdentity</i>	473
–	<i>BH-LogicalChannelIdentity-Ext</i>	473
–	<i>BH-RLC-ChannelConfig</i>	473
–	<i>BH-RLC-ChannelID</i>	474
–	<i>BSR-Config</i>	475
–	<i>BWP</i>	475
–	<i>BWP-Downlink</i>	476
–	<i>BWP-DownlinkCommon</i>	477
–	<i>BWP-DownlinkDedicated</i>	477
–	<i>BWP-Id</i>	480
–	<i>BWP-Uplink</i>	480
–	<i>BWP-UplinkCommon</i>	481
–	<i>BWP-UplinkDedicated</i>	482
–	<i>CandidateBeamRS</i>	485
–	<i>CellAccessRelatedInfo</i>	486

iTech STANDARD
PREVIEW
(standards.iteh.ai)

ETSI TS 138 331 V17.0.0 (2022-05)
<https://standards.iteh.ai/catalog/standards/sist/c7ab1252-8657-4b84-9602-6f900befac5b/etsi-ts-138-331-v17-0-0-2022-05>

CellAccessRelatedInfo-EUTRA-5GC	487
CellAccessRelatedInfo-EUTRA-EPC	488
CellGroupConfig	489
CellGroupId	496
CellIdentity	497
CellReselectionPriority	497
CellReselectionSubPriority	497
CFR-ConfigMulticast	498
CGI-InfoEUTRA	499
CGI-InfoEUTRALogging	499
CGI-InfoNR	500
CGI-Info-Logging	501
CLI-RSSI-Range	501
CodebookConfig	502
CommonLocationInfo	506
CondReconfigId	507
CondReconfigToAddModList	508
ConditionalReconfiguration	509
ConfiguredGrantConfig	509
ConfiguredGrantConfigIndex	518
ConfiguredGrantConfigIndexMAC	518
ConnEstFailureControl	518
ControlResourceSet	519
ControlResourceSetId	522
ControlResourceSetZero	522
CrossCarrierSchedulingConfig	522
CSI-AperiodicTriggerStateList	524
CSI-FrequencyOccupation	527
CSI-IM-Resource	527
CSI-IM-ResourceId	528
CSI-IM-ResourceSet	529
CSI-IM-ResourceSetId	529
CSI-MeasConfig	529
CSI-ReportConfig	531
CSI-ReportConfigId	537
CSI-ResourceConfig	537
CSI-ResourceConfigId	539
CSI-ResourcePeriodicityAndOffset	539
CSI-RS-ResourceConfigMobility	540
CSI-RS-ResourceMapping	542
CSI-SemiPersistentOnPUSCH-TriggerStateList	543
CSI-SSB-ResourceSet	544
CSI-SSB-ResourceSetId	544
DedicatedNAS-Message	545
DL-PRS-ProcessingWindowPreConfig	545
DMRS-BundlingPUCCH-Config	546
DMRS-BundlingPUSCH-Config	547
DMRS-DownlinkConfig	548
DMRS-UplinkConfig	549
DownlinkConfigCommon	551
DownlinkConfigCommonSIB	552
DownlinkPreemption	557
DRB-Identity	558
DRX-Config	558
DRX-ConfigSecondaryGroup	560
DRX-ConfigSL	561
EphemerisInfo	562
FeatureCombination	563
FeatureCombinationPreambles	564
FilterCoefficient	566
FreqBandIndicatorNR	566
FreqPriorityListNRSlicing	566

FrequencyInfoDL	567
FrequencyInfoDL-SIB	568
FrequencyInfoUL	569
FrequencyInfoUL-SIB	570
GapPriority	571
HighSpeedConfig	572
Hysteresis, HysteresisLocation	573
InvalidSymbolPattern	574
I-RNTI-Value	575
LBT-FailureRecoveryConfig	575
LocationInfo	575
LocationMeasurementInfo	576
LogicalChannelConfig	577
LogicalChannelIdentity	580
MAC-CellGroupConfig	580
MeasConfig	584
MeasConfigAppLayerId	586
MeasGapConfig	586
MeasGapId	589
MeasGapSharingConfig	590
MeasId	591
MeasIdleConfig	591
MeasIdToAddModList	595
MeasObjectCLI	595
MeasObjectEUTRA	598
MeasObjectId	600
MeasObjectNR	600
MeasObjectNR-SL	607
MeasObjectRxTxDiff	607
MeasObjectToAddModList	608
MeasObjectUTRA-FDD	609
MeasResultCellListSFTD-NR	610
MeasResultCellListSFTD-EUTRA	610
MeasResults	611
MeasResult2EUTRA	618
MeasResult2NR	618
MeasResultIdleEUTRA	618
MeasResultIdleNR	619
MeasResultRxTxTimeDiff	621
MeasResultSCG-Failure	621
MeasResultsSL	622
MeasTriggerQuantityEUTRA	622
MobilityStateParameters	623
MRB-Identity	624
MsgA-ConfigCommon	624
MsgA-PUSCH-Config	625
MultiFrequencyBandListNR	628
MultiFrequencyBandListNR-SIB	629
MUSIM-GapConfig	629
MUSIM-GapID	631
NeedForGapsConfigNR	631
NeedForNCSG-ConfigEUTRA	633
NeedForNCSG-ConfigNR	633
NeedForNCSG-InfoEUTRA	634
NeedForNCSG-InfoNR	634
NextHopChainingCount	636
NG-5G-S-TMSI	636
NonCellDefiningSSB	636
NPN-Identity	637
NPN-IdentityInfoList	638
NR-DL-PRS-PDC-Info	639
NR-NS-PmaxList	642

iteh STANDARD
PREVIEW
(standards.iteh.ai)

ETSI TS 138 331 V17.0.0 (2022-05)
https://standards.iteh.ai/catalog/standards/sist/c7ab1252-
8957-4b84-9602-6f900befac5b/etsi-ts-138-331-v17-0-
0-2022-05