

ETSI TS 125 331 V17.1.0 (2022-08)



**Universal Mobile Telecommunications System (UMTS);
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 25.331 version 17.1.0 Release 17)**

[ETSI TS 125 331 V17.1.0 \(2022-08\)](https://standards.iteh.ai/catalog/standards/sist/f39302de-aa49-4152-a6b0-ec369e2928dd/etsi-ts-125-331-v17-1-0-2022-08)

<https://standards.iteh.ai/catalog/standards/sist/f39302de-aa49-4152-a6b0-ec369e2928dd/etsi-ts-125-331-v17-1-0-2022-08>



Reference

RTS/TSGR-0025331vh10

Keywords

UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://standards.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2022.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	40
1 Scope	41
2 References	41
3 Definitions and abbreviations.....	44
3.1 Definitions	44
3.2 Abbreviations	47
4 General	50
4.1 Overview of the specification.....	50
4.2 RRC Layer Model	51
4.3 Protocol specification principles	54
5 RRC Functions and Services provided to upper layers	54
5.1 RRC Functions	54
5.2 RRC Services provided to upper layers.....	55
5.3 Primitives between RRC and upper layers.....	55
6 Services expected from lower layers.....	55
6.1 Services expected from Layer 2	55
6.2 Services expected from Layer 1	55
6.3 Signalling Radio Bearers.....	55
7 Protocol states	56
7.1 Overview of RRC States and State Transitions including GSM and E-UTRA	56
7.2 Processes in UE modes/states.....	57
7.2.1 UE Idle mode.....	57
7.2.2 UTRA RRC Connected mode.....	57
7.2.2.1 URA_PCH or CELL_PCH state	57
7.2.2.2 CELL_FACH state.....	58
7.2.2.3 CELL_DCH state.....	60
8 RRC procedures	60
8.1 RRC Connection Management Procedures	61
8.1.1 Broadcast of system information	61
8.1.1.1 General	62
8.1.1.1.1 System information structure.....	62
8.1.1.1.2 System information blocks	62
8.1.1.1.3 Segmentation and concatenation of system information blocks	70
8.1.1.1.4 Re-assembly of segments	71
8.1.1.1.5 Scheduling of system information	72
8.1.1.2 Initiation.....	73
8.1.1.3 Reception of SYSTEM INFORMATION messages by the UE.....	73
8.1.1.4 Void.....	73
8.1.1.5 Actions upon reception of the Master Information Block and Scheduling Block(s).....	73
8.1.1.6 Actions upon reception of system information blocks	78
8.1.1.6.1 System Information Block type 1	80
8.1.1.6.2 System Information Block type 2	80
8.1.1.6.3 System Information Block type 3	81
8.1.1.6.4 System Information Block type 4	86
8.1.1.6.5 System Information Block type 5 and 5bis.....	86
8.1.1.6.6 System Information Block type 6	92
8.1.1.6.7 System Information Block type 7	95
8.1.1.6.8 Void.....	95

8.1.1.6.9	Void.....	95
8.1.1.6.10	Void.....	95
8.1.1.6.11	System Information Block type 11.....	95
8.1.1.6.11a	System Information Block type 11bis.....	97
8.1.1.6.11b	System Information Block type 11ter.....	98
8.1.1.6.12	System Information Block type 12.....	98
8.1.1.6.13	System Information Block type 13.....	100
8.1.1.6.14	System Information Block type 14.....	100
8.1.1.6.15	System Information Block type 15.....	100
8.1.1.6.15.0	System Information Block type 15bis.....	100
8.1.1.6.15.1	System Information Block type 15.1.....	101
8.1.1.6.15.1a	System Information Block type 15.1bis.....	101
8.1.1.6.15.1b	System Information Block type 15.1ter.....	101
8.1.1.6.15.2	System Information Block type 15.2.....	101
8.1.1.6.15.2a	System Information Block type 15.2bis.....	102
8.1.1.6.15.2b	System Information Block type 15.2ter.....	102
8.1.1.6.15.3	System Information Block type 15.3.....	102
8.1.1.6.15.3a	System Information Block type 15.3bis.....	103
8.1.1.6.15.4	System Information Block type 15.4.....	104
8.1.1.6.15.5	System Information Block type 15.5.....	104
8.1.1.6.15.6	System Information Block type 15.6.....	104
8.1.1.6.15.7	System Information Block type 15.7.....	104
8.1.1.6.15.8	System Information Block type 15.8.....	104
8.1.1.6.16	System Information Block type 16.....	105
8.1.1.6.17	System Information Block type 17.....	105
8.1.1.6.18	System Information Block type 18.....	105
8.1.1.6.19	System Information Block type 19.....	107
8.1.1.6.20	System Information Block type 20.....	107
8.1.1.6.21	System Information Block type 21.....	108
8.1.1.6.22	System Information Block type 22.....	108
8.1.1.6.23	System Information Block type 23.....	108
8.1.1.6.24	System Information Block type 24.....	109
8.1.1.6.25	System Information Block type 25.....	109
8.1.1.7	Modification of system information.....	110
8.1.1.7.1	Modification of system information blocks using a value tag.....	110
8.1.1.7.2	Synchronised modification of system information blocks.....	111
8.1.1.7.3	Actions upon system information change.....	111
8.1.1.7.4	Actions upon expiry of a system information expiry timer.....	112
8.1.1.8	Reception of System Information Container by the UE.....	113
8.1.2	Paging.....	113
8.1.2.1	General.....	113
8.1.2.2	Initiation.....	114
8.1.2.3	Reception of a PAGING TYPE 1 message by the UE.....	114
8.1.3	RRC connection establishment.....	116
8.1.3.1	General.....	116
8.1.3.2	Initiation.....	116
8.1.3.3	RRC CONNECTION REQUEST message contents to set.....	117
8.1.3.4	Reception of an RRC CONNECTION REQUEST message by the UTRAN.....	120
8.1.3.5	Cell re-selection, T300 or T318 timeout.....	121
8.1.3.5a	Abortion of RRC connection establishment.....	122
8.1.3.6	Reception of an RRC CONNECTION SETUP message by the UE.....	122
8.1.3.7	Physical channel failure or cell re-selection.....	129
8.1.3.8	Invalid RRC CONNECTION SETUP message, unsupported configuration or invalid configuration.....	129
8.1.3.9	Reception of an RRC CONNECTION REJECT message by the UE.....	130
8.1.3.10	Invalid RRC CONNECTION REJECT message.....	134
8.1.3.11	Logging of failed RRC Connection Establishment.....	134
8.1.4	RRC connection release.....	135
8.1.4.1	General.....	136
8.1.4.2	Initiation.....	136
8.1.4.3	Reception of an RRC CONNECTION RELEASE message by the UE.....	136
8.1.4.4	Invalid RRC CONNECTION RELEASE message.....	138

8.1.4.5	Cell re-selection or radio link failure	138
8.1.4.6	Expiry of timer T308, unacknowledged mode transmission	139
8.1.4.7	Void.....	139
8.1.4.8	Reception of an RRC CONNECTION RELEASE COMPLETE message by UTRAN	140
8.1.4.9	Unsuccessful transmission of the RRC CONNECTION RELEASE COMPLETE message, acknowledged mode transmission	140
8.1.4.10	Detection of loss of dedicated physical channel by UTRAN in CELL_DCH state	140
8.1.4.11	Failure to receive RRC CONNECTION RELEASE COMPLETE message by UTRAN.....	140
8.1.4a	RRC connection release requested by upper layers	140
8.1.4a.1	General	140
8.1.4a.2	Initiation.....	140
8.1.5	Void	141
8.1.6	Transmission of UE capability information.....	141
8.1.6.1	General	141
8.1.6.2	Initiation.....	141
8.1.6.3	Reception of a UE CAPABILITY INFORMATION message by the UTRAN.....	144
8.1.6.4	Reception of the UE CAPABILITY INFORMATION CONFIRM message by the UE	145
8.1.6.5	Invalid UE CAPABILITY INFORMATION CONFIRM message	145
8.1.6.6	T304 timeout.....	146
8.1.7	UE capability enquiry	146
8.1.7.1	General	146
8.1.7.2	Initiation.....	146
8.1.7.3	Reception of a UE CAPABILITY ENQUIRY message by the UE	146
8.1.7.4	Invalid UE CAPABILITY ENQUIRY message	147
8.1.8	Initial Direct transfer.....	147
8.1.8.1	General	147
8.1.8.2	Initiation of Initial direct transfer procedure in the UE	147
8.1.8.2a	RLC re-establishment or inter-RAT change	150
8.1.8.2ab	Inter-RAT handover from UTRAN to GERAN <i>Iu mode</i>	150
8.1.8.2b	Abortion of signalling connection establishment	150
8.1.8.2c	Inter-RAT handover from UTRAN to E-UTRAN	150
8.1.8.3	Reception of INITIAL DIRECT TRANSFER message by the UTRAN	150
8.1.9	Downlink Direct transfer	151
8.1.9.1	General	151
8.1.9.2	Initiation of downlink direct transfer procedure in the UTRAN	151
8.1.9.3	Reception of a DOWNLINK DIRECT TRANSFER message by the UE	151
8.1.9.3a	No signalling connection exists.....	151
8.1.9.4	Invalid DOWNLINK DIRECT TRANSFER message	152
8.1.10	Uplink Direct transfer	152
8.1.10.1	General	152
8.1.10.2	Initiation of uplink direct transfer procedure in the UE	153
8.1.10.2a	RLC re-establishment or inter-RAT change	153
8.1.10.2b	Inter-RAT handover from UTRAN to GERAN <i>Iu mode</i>	154
8.1.10.2c	Inter-RAT handover from UTRAN to E-UTRAN	154
8.1.10.3	Reception of UPLINK DIRECT TRANSFER message by the UTRAN	154
8.1.11	UE dedicated paging.....	154
8.1.11.1	General	154
8.1.11.2	Initiation.....	154
8.1.11.3	Reception of a PAGING TYPE 2 message by the UE	155
8.1.11.4	Invalid PAGING TYPE 2 message.....	155
8.1.12	Security mode control.....	155
8.1.12.1	General	156
8.1.12.2	Initiation.....	156
8.1.12.2.1	Ciphering configuration change	156
8.1.12.2.2	Integrity protection configuration change.....	157
8.1.12.3	Reception of SECURITY MODE COMMAND message by the UE	159
8.1.12.3.1	New ciphering and integrity protection keys.....	163
8.1.12.4	Void.....	164
8.1.12.4a	Incompatible simultaneous security reconfiguration.....	164
8.1.12.4b	Cell update procedure during security reconfiguration	165
8.1.12.4c	Invalid configuration.....	166
8.1.12.5	Reception of SECURITY MODE COMPLETE message by the UTRAN	166

8.1.12.6	Invalid SECURITY MODE COMMAND message.....	168
8.1.13	Signalling connection release procedure.....	169
8.1.13.1	General.....	169
8.1.13.2	Initiation of SIGNALLING CONNECTION RELEASE by the UTRAN.....	169
8.1.13.3	Reception of SIGNALLING CONNECTION RELEASE by the UE.....	169
8.1.13.4	Invalid SIGNALLING CONNECTION RELEASE message.....	169
8.1.13.5	Invalid configuration.....	170
8.1.14	Signalling connection release indication procedure.....	170
8.1.14.1	General.....	170
8.1.14.2	Initiation.....	170
8.1.14.2a	RLC re-establishment or inter-RAT change.....	173
8.1.14.3	Reception of SIGNALLING CONNECTION RELEASE INDICATION by the UTRAN.....	173
8.1.14.4	Expiry of timer T323.....	173
8.1.15	Counter check procedure.....	173
8.1.15.1	General.....	174
8.1.15.2	Initiation.....	174
8.1.15.3	Reception of a COUNTER CHECK message by the UE.....	174
8.1.15.4	Reception of the COUNTER CHECK RESPONSE message by UTRAN.....	175
8.1.15.5	Cell re-selection.....	175
8.1.15.6	Invalid COUNTER CHECK message.....	175
8.1.16	Inter RAT handover information transfer.....	175
8.1.16.1	General.....	176
8.1.16.2	Initiation.....	176
8.1.16.3	INTER RAT HANDOVER INFO message contents to set.....	176
8.1.17	ETWS primary notification with security procedure.....	178
8.1.17.1	General.....	178
8.1.17.2	Initiation.....	178
8.1.17.3	Void.....	178
8.1.17.4	Reception of the ETWS PRIMARY NOTIFICATION WITH SECURITY message.....	178
8.1.17.5	Forward of the ETWS primary notification to the upper layers.....	178
8.1.17.6	Void.....	178
8.2	Radio Bearer control procedures.....	179
8.2.1	Radio bearer establishment.....	179
8.2.2	Reconfiguration procedures.....	179
8.2.2.1	General.....	181
8.2.2.2	Initiation.....	182
8.2.2.2a	Initiation of handover from GERAN <i>Iu mode</i>	183
8.2.2.3	Reception of RADIO BEARER SETUP or RADIO BEARER RECONFIGURATION or RADIO BEARER RELEASE or TRANSPORT CHANNEL RECONFIGURATION or PHYSICAL CHANNEL RECONFIGURATION message, TTI switch HS-SCCH order or Target cell HS-SCCH order by the UE.....	184
8.2.2.3a	Reception of RADIO BEARER RECONFIGURATION message by the UE performing handover from GERAN <i>Iu mode</i>	204
8.2.2.4	Transmission of a response message by the UE, normal case.....	205
8.2.2.5	Reception of a response message by the UTRAN, normal case.....	208
8.2.2.5a	Rejection by the UE.....	209
8.2.2.6	Unsupported configuration in the UE.....	209
8.2.2.7	Physical channel failure.....	210
8.2.2.8	Cell re-selection.....	211
8.2.2.9	Transmission of a response message by the UE, failure case.....	211
8.2.2.10	Reception of a response message by the UTRAN, failure case.....	212
8.2.2.11	Invalid configuration.....	212
8.2.2.12	Incompatible simultaneous reconfiguration.....	212
8.2.2.12a	Incompatible simultaneous security reconfiguration.....	213
8.2.2.12b	Cell update procedure during security reconfiguration.....	213
8.2.2.13	Invalid received message.....	214
8.2.2.14	Radio link failure.....	214
8.2.3	Radio bearer release.....	215
8.2.4	Transport channel reconfiguration.....	215
8.2.5	Transport format combination control.....	216
8.2.5.1	General.....	216
8.2.5.2	Initiation.....	216

8.2.5.3	Reception of a TRANSPORT FORMAT COMBINATION CONTROL message by the UE	216
8.2.5.4	Invalid configuration	218
8.2.5.5	Invalid TRANSPORT FORMAT COMBINATION CONTROL message	219
8.2.6	Physical channel reconfiguration	219
8.2.7	Physical Shared Channel Allocation [TDD only]	220
8.2.7.1	General	220
8.2.7.2	Initiation	220
8.2.7.3	Reception of a PHYSICAL SHARED CHANNEL ALLOCATION message by the UE	220
8.2.7.4	Invalid PHYSICAL SHARED CHANNEL ALLOCATION message	222
8.2.8	PUSCH capacity request [TDD only]	223
8.2.8.1	General	223
8.2.8.2	Initiation	223
8.2.8.3	PUSCH CAPACITY REQUEST message contents to set	224
8.2.8.4	Reception of a PUSCH CAPACITY REQUEST message by the UTRAN	225
8.2.8.5	T310 expiry	225
8.2.9	Void	225
8.2.10	Uplink Physical Channel Control [TDD only]	225
8.2.10.1	General	225
8.2.10.2	Initiation	225
8.2.10.3	Reception of UPLINK PHYSICAL CHANNEL CONTROL message by the UE	225
8.2.10.4	Invalid UPLINK PHYSICAL CHANNEL CONTROL message	226
8.2.11	Physical channel reconfiguration failure	226
8.2.11.1	General	227
8.2.11.2	Runtime error due to overlapping compressed mode configurations	227
8.2.11.3	Void	227
8.3	RRC connection mobility procedures	227
8.3.1	Cell and URA update procedures	227
8.3.1.1	General	230
8.3.1.2	Initiation	231
8.3.1.3	CELL UPDATE / URA UPDATE message contents to set	240
8.3.1.4	T305 expiry and the UE detects "out of service area"	245
8.3.1.4.1	Re-entering "in service area"	245
8.3.1.4.2	Expiry of timer T307	246
8.3.1.5	Reception of an CELL UPDATE/URA UPDATE message by the UTRAN	246
8.3.1.6	Reception of the CELL UPDATE CONFIRM/URA UPDATE CONFIRM message by the UE	247
8.3.1.7	Transmission of a response message to UTRAN	257
8.3.1.7a	Physical channel failure	261
8.3.1.8	Unsupported configuration by the UE	262
8.3.1.9	Invalid configuration	263
8.3.1.9a	Incompatible simultaneous reconfiguration	264
8.3.1.9b	Security reconfiguration during Cell update procedure	266
8.3.1.10	Confirmation error of URA ID list	266
8.3.1.11	Invalid CELL UPDATE CONFIRM/URA UPDATE CONFIRM message	267
8.3.1.12	T302 expiry or cell reselection	268
8.3.1.13	T314 expiry	271
8.3.1.14	T315 expiry	272
8.3.1.15	Reception of the UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN	273
8.3.1.16	T320 Expiry	273
8.3.2	URA update	273
8.3.3	UTRAN mobility information	274
8.3.3.1	General	274
8.3.3.2	Initiation	274
8.3.3.3	Reception of UTRAN MOBILITY INFORMATION message by the UE	274
8.3.3.4	Reception of an UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN	279
8.3.3.5	Cell re-selection	279
8.3.3.5a	Incompatible simultaneous security reconfiguration	280
8.3.3.6	Invalid UTRAN MOBILITY INFORMATION message	280
8.3.3.7	T322 expiry	281
8.3.4	Active set update	281
8.3.4.1	General	281
8.3.4.2	Initiation	282
8.3.4.3	Reception of an ACTIVE SET UPDATE message by the UE	283

8.3.4.3a	Handling of ACTIVE SET UPDATE message on secondary uplink frequency (FDD only)	285
8.3.4.4	Unsupported configuration in the UE	287
8.3.4.5	Invalid configuration	287
8.3.4.5a	Void	288
8.3.4.5b	Incompatible simultaneous reconfiguration	288
8.3.4.6	Reception of the ACTIVE SET UPDATE COMPLETE message by the UTRAN	289
8.3.4.7	Reception of the ACTIVE SET UPDATE FAILURE message by the UTRAN	289
8.3.4.8	Invalid ACTIVE SET UPDATE message	289
8.3.4.9	Reception of an ACTIVE SET UPDATE message in wrong state	290
8.3.5	Hard handover	290
8.3.5.1	Timing re-initialised hard handover	290
8.3.5.1.1	General	290
8.3.5.1.2	Initiation (FDD only)	290
8.3.5.2	Timing-maintained hard handover	292
8.3.5.2.1	General	292
8.3.5.2.2	Initiation (FDD only)	292
8.3.6	Inter-RAT handover to UTRAN	292
8.3.6.1	General	292
8.3.6.2	Initiation	293
8.3.6.3	Reception of HANDOVER TO UTRAN COMMAND message by the UE	293
8.3.6.4	Invalid Handover to UTRAN command message	299
8.3.6.4a	Unsupported configuration in HANDOVER TO UTRAN COMMAND message	300
8.3.6.5	UE fails to perform handover	300
8.3.6.6	Reception of message HANDOVER TO UTRAN COMPLETE by the UTRAN	300
8.3.7	Inter-RAT handover from UTRAN	300
8.3.7.1	General	300
8.3.7.2	Initiation	301
8.3.7.3	Reception of a HANDOVER FROM UTRAN COMMAND message by the UE	301
8.3.7.4	Successful completion of the inter-RAT handover	303
8.3.7.5	UE fails to complete requested handover	303
8.3.7.6	Invalid HANDOVER FROM UTRAN COMMAND message	304
8.3.7.7	Reception of an HANDOVER FROM UTRAN FAILURE message by UTRAN	305
8.3.7.8	Unsupported configuration in HANDOVER FROM UTRAN COMMAND message	305
8.3.7.8a	Reception of HANDOVER FROM UTRAN COMMAND message by UE in CELL_FACH	305
8.3.8	Inter-RAT cell reselection to UTRAN	306
8.3.8.1	General	306
8.3.8.2	Initiation	306
8.3.8.2a	Initiation of inter-RAT cell reselection from GERAN <i>Iu mode</i>	306
8.3.8.3	UE fails to complete an inter-RAT cell reselection	307
8.3.8.3a	UE fails to complete an inter-RAT cell reselection from GERAN <i>Iu mode</i>	307
8.3.9	Inter-RAT cell reselection from UTRAN	307
8.3.9.1	General	307
8.3.9.2	Initiation	307
8.3.9.2a	Initiation of inter-RAT cell reselection to GERAN <i>Iu mode</i>	308
8.3.9.3	Successful cell reselection	308
8.3.9.4	UE fails to complete an inter-RAT cell reselection	308
8.3.10	Inter-RAT cell change order to UTRAN	308
8.3.10.1	General	308
8.3.10.2	Initiation	308
8.3.10.3	UE fails to complete an inter-RAT cell change order	309
8.3.11	Inter-RAT cell change order from UTRAN	309
8.3.11.1	General	309
8.3.11.2	Initiation	309
8.3.11.3	Reception of an CELL CHANGE ORDER FROM UTRAN message by the UE	309
8.3.11.4	Successful completion of the cell change order	310
8.3.11.5	Expiry of timer T309 or UE fails to complete requested cell change order	310
8.3.11.6	Unsupported configuration in CELL CHANGE ORDER FROM UTRAN message	312
8.3.11.7	Invalid CELL CHANGE ORDER FROM UTRAN message	312
8.4	Measurement procedures	313
8.4.0	Measurement related definitions	313
8.4.1	Measurement control	315
8.4.1.1	General	315

8.4.1.2	Initiation.....	315
8.4.1.3	Reception of MEASUREMENT CONTROL by the UE.....	316
8.4.1.4	Unsupported measurement in the UE.....	328
8.4.1.4a	Configuration Incomplete.....	329
8.4.1.5	Invalid MEASUREMENT CONTROL message.....	329
8.4.1.6	Measurements after transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state ...	330
8.4.1.6.1	Intra-frequency measurement.....	330
8.4.1.6.2	Inter-frequency measurement.....	330
8.4.1.6.3	Inter-RAT measurement.....	331
8.4.1.6.4	Quality measurement.....	332
8.4.1.6.5	UE internal measurement.....	332
8.4.1.6.6	Traffic volume measurement.....	333
8.4.1.6.7	UE positioning measurement.....	334
8.4.1.6.8	CSG Proximity detection measurement.....	335
8.4.1.6a	Actions in CELL_FACH/CELL_PCH/URA/PCH state upon cell re-selection.....	336
8.4.1.7	Measurements after transition from CELL_FACH to CELL_DCH state.....	336
8.4.1.7.1	Intra-frequency measurement.....	336
8.4.1.7.2	Inter-frequency measurement.....	336
8.4.1.7.3	Inter-RAT measurement.....	337
8.4.1.7.4	Traffic volume measurement.....	337
8.4.1.7.5	UE positioning measurement.....	338
8.4.1.7.6	CSG Proximity detection measurement.....	338
8.4.1.7.7	E-UTRA measurement for CELL_FACH.....	338
8.4.1.8	Measurements after transition from idle mode to CELL_DCH state.....	339
8.4.1.8.1	Intra-frequency measurement.....	339
8.4.1.8.2	Inter-frequency measurement.....	339
8.4.1.8.3	Inter-RAT measurement.....	339
8.4.1.8.4	Traffic volume measurement.....	339
8.4.1.8.5	UE positioning measurement.....	339
8.4.1.9	Measurements after transition from idle mode to CELL_FACH state.....	339
8.4.1.9.1	Intra-frequency measurement.....	340
8.4.1.9.2	Inter-frequency measurement.....	340
8.4.1.9.3	Inter-RAT measurement.....	340
8.4.1.9.4	Traffic volume measurement.....	341
8.4.1.9.5	UE positioning measurement.....	341
8.4.1.9a	Measurements after transition from connected mode to idle mode.....	341
8.4.1.9a.1	Intra-frequency measurement.....	342
8.4.1.9a.2	Inter-frequency measurement.....	342
8.4.1.9a.3	Inter-RAT measurement.....	342
8.4.1.9a.4	UE positioning measurement.....	342
8.4.1.9b	Measurements after transition from CELL_FACH to CELL_PCH/URA_PCH.....	342
8.4.1.9b.1	Traffic volume measurement.....	342
8.4.1.9b.2	UE positioning measurement.....	343
8.4.1.9b.3	Inter-RAT measurement.....	343
8.4.1.9b.4	Intra-frequency measurement.....	343
8.4.1.9b.5	Inter-frequency measurement.....	343
8.4.1.9b.6	E-UTRA measurement for CELL_FACH.....	344
8.4.1.9c	Measurements after transition from CELL_PCH/URA_PCH to CELL_FACH.....	344
8.4.1.9c.1	Traffic volume measurement.....	344
8.4.1.9c.2	UE positioning measurement.....	344
8.4.1.9c.3	Inter-RAT measurement.....	344
8.4.1.10	Changes in measurement objects.....	345
8.4.1.10.1	Traffic volume measurement.....	345
8.4.1.10.2	Quality measurement.....	346
8.4.1.10.3	Intra-frequency, Inter-frequency and Inter-RAT measurements.....	346
8.4.1.11	Cell Reselection (FDD only and 1.28 Mcps TDD only).....	346
8.4.1.11.1	Traffic volume measurement.....	346
8.4.2	Measurement report.....	347
8.4.2.1	General.....	347
8.4.2.2	Initiation.....	347
8.4.3	Assistance Data Delivery.....	350
8.4.3.1	General.....	350

8.4.3.2	Initiation.....	350
8.4.3.3	Reception of ASSISTANCE DATA DELIVERY message by the UE.....	350
8.4.3.4	Invalid ASSISTANCE DATA DELIVERY message.....	351
8.5	General procedures.....	351
8.5.1	Selection of initial UE identity.....	351
8.5.2	Actions when entering idle mode from connected mode.....	352
8.5.3	Open loop power control upon establishment of DPCCCH.....	354
8.5.4	Physical channel establishment criteria in CELL_DCH state.....	354
8.5.4A	Physical channel establishment criteria for Enhanced Uplink in CELL_FACH state and Idle mode.....	354
8.5.4B	Physical channel establishment criteria in CELL_DCH state on the secondary uplink frequency (FDD only).....	355
8.5.5	Actions in "out of service area" and "in service area".....	355
8.5.5.1	Detection of "out of service" area.....	355
8.5.5.1.1	Actions following detection of "out of service" area in URA_PCH or CELL_PCH state.....	355
8.5.5.1.2	Actions following detection of "out of service" area in CELL_FACH state.....	355
8.5.5.1.3	Actions following detection of "out of service" area on transition from CELL_DCH to URA_PCH or CELL_PCH.....	355
8.5.5.1.4	Actions following detection of "out of service" area on transition from CELL_DCH to CELL_FACH.....	356
8.5.5.2	Detection of "in service" area.....	356
8.5.5.2.1	Actions following Re-entry into "in service area" in URA_PCH or CELL_PCH state.....	356
8.5.5.2.2	Actions following re-entry into "in service area" in CELL_FACH state.....	356
8.5.5.3	T316 expiry.....	357
8.5.5.4	T317 expiry.....	357
8.5.6	Radio link failure criteria and actions upon radio link failure.....	357
8.5.6a	Radio link failure criteria and actions upon radio link failure on the secondary uplink frequency (FDD only).....	358
8.5.7	Open loop power control.....	358
8.5.8	Maintenance of Hyper Frame Numbers.....	363
8.5.9	START value calculation.....	363
8.5.10	Integrity protection.....	364
8.5.10.1	Integrity protection in downlink.....	365
8.5.10.2	Integrity protection in uplink.....	366
8.5.10.3	Calculation of message authentication code.....	367
8.5.11	FACH measurement occasion calculation.....	367
8.5.11a	CELL_DCH measurement occasion calculation (1.28 Mcps TDD only).....	369
8.5.12	Establishment of Access Service Classes.....	369
8.5.13	Mapping of Access Classes to Access Service Classes.....	370
8.5.14	PLMN Type Selection.....	370
8.5.14a	Neighbour cells list narrowing for cell reselection.....	371
8.5.15	CFN calculation.....	371
8.5.15.1	Initialisation for CELL_DCH state after state transition.....	371
8.5.15.2	Initialisation in CELL_DCH state at hard handover.....	371
8.5.15.3	Initialisation for CELL_FACH.....	372
8.5.15.4	Initialisation after intersystem handover to UTRAN.....	372
8.5.15.5	Initialisation for MTCH and/or MSCH carried on S-CCPCH that may be soft combined.....	372
8.5.16	Configuration of CTCH occasions.....	372
8.5.17	PRACH selection.....	373
8.5.18	Selection of RACH TTI.....	374
8.5.18.1	FDD.....	374
8.5.18.2	1.28 Mcps TDD.....	375
8.5.19	Secondary CCPCH selection.....	375
8.5.19a	Secondary CCPCH and FACH selection for MCCH reception.....	376
8.5.20	Unsupported configuration.....	376
8.5.21	Actions related to Radio Bearer mapping.....	376
8.5.22	Actions when entering another RAT from connected mode.....	384
8.5.23	Measured results on RACH.....	385
8.5.24	Change of PLMN while in RRC connected mode.....	388
8.5.25	Actions related to HS_DSCH_RECEPTION variable.....	389
8.5.26	Service prioritisation.....	391
8.5.27	MBMS frequency selection.....	391
8.5.28	Actions related to E_DCH_TRANSMISSION variable.....	393

8.5.29	MBMS modification period identity calculation	396
8.5.30	Detecting MBMS service reception inability.....	396
8.5.31	Actions related to DEFERRED_MEASUREMENT_STATUS variable	397
8.5.32	Actions related to MIMO_PARAMS variable.....	397
8.5.33	Actions related to MIMO_STATUS variable	398
8.5.34	Actions related to DTX_DRX_STATUS variable (FDD only)	399
8.5.35	Actions related to HS_SCCH_LESS_STATUS variable (FDD only).....	400
8.5.36	Actions related to HS_DSCH_RECEPTION_CELL_FACH_STATE variable (FDD and 1.28 Mcps TDD only).....	401
8.5.37	Actions related to HS_DSCH_RECEPTION_OF_CCCH_ENABLED variable (FDD and 1.28 Mcps TDD only).....	403
8.5.37a	Actions related to HS_DSCH_RECEPTION_GENERAL.....	403
8.5.38	Common H-RNTI selection (FDD and 1.28 Mcps TDD only).....	404
8.5.39	PICH selection for HSDPA based paging (FDD and 1.28 Mcps TDD only)	404
8.5.40	HS_DSCH Reception in CELL_PCH and URA_PCH (FDD only)	405
8.5.40a	HS_DSCH Reception in CELL_PCH and URA_PCH (1.28 Mcps TDD only)	406
8.5.41	HS-PDSCH channelisation codes selection for paging reception (FDD and 1.28 Mcps TDD only)	407
8.5.42	Autonomous UTRAN DRX Cycle length coefficient change	408
8.5.43	Reception of MBMS from a cell operating in MBSFN mode	408
8.5.44	HS-DSCH CQI reporting tables.....	408
8.5.45	Enhanced Uplink in CELL_FACH state and Idle mode (FDD only)	408
8.5.45a	Enhanced Uplink in CELL_FACH state and Idle mode (1.28 Mcps TDD only)	411
8.5.46	Actions related to COMMON_E_DCH_TRANSMISSION variable (FDD and 1.28 Mcps TDD only).....	411
8.5.47	Actions related to READY_FOR_COMMON_EDCH variable (FDD and 1.28 Mcps TDD only)	414
8.5.48	Actions related to HS_DSCH_DRX_CELL_FACH_STATUS variable (FDD and 1.28 Mcps TDD only) and HS_DSCH_DRX_CELL_FACH_2CYCLE_STATUS variable (FDD only)	416
8.5.49	CELL_FACH HS-DSCH DRX operation (FDD only).....	417
8.5.49a	CELL_FACH HS-DSCH DRX operation (1.28Mcps TDD only).....	418
8.5.49b	CELL_FACH HS-DSCH DRX operation with second DRX cycle (FDD only).....	418
8.5.50	Common E-RNTI selection (1.28 Mcps TDD only).....	420
8.5.51	Actions related to SECONDARY_CELL_HS_DSCH_RECEPTION variable (FDD only).....	421
8.5.52	Actions related to TARGET_CELL_PRECONFIGURATION variable (FDD only).....	422
8.5.53	Actions related to CONTROL_CHANNEL_DRX_STATUS variable (1.28 Mcps TDD only).....	423
8.5.54	Actions related to E_DCH_SPS_STATUS variable (1.28 Mcps TDD only)	424
8.5.55	Actions related to HS_DSCH_SPS_STATUS variable (1.28 Mcps TDD only)	424
8.5.56	Actions related to HSPA_RNTI_STORED_PCH variable (FDD and 1.28 Mcps TDD only)	425
8.5.57	Actions related to SECONDARY_CELL_MIMO_STATUS variable.....	426
8.5.58	Actions related to SECONDARY_CELL_E_DCH_TRANSMISSION variable (FDD only)	428
8.5.59	Actions related to reception of a HS-SCCH order for secondary uplink frequency activation/deactivation (FDD only)	430
8.5.60	Configuration of "TSN field extension" for MAC-ehs entity	430
8.5.61	Actions related to MU_MIMO_STATUS variable (1.28 Mcps TDD only).....	431
8.5.62	Actions related to MULTI_CARRIER_E_DCH_TRANSMISSION variable (1.28Mcps TDD only)....	431
8.5.63	Logged Measurements Configuration.....	432
8.5.63.1	General	432
8.5.63.2	Initiation.....	433
8.5.63.3	Reception of LOGGING MEASUREMENT CONFIGURATION by the UE	433
8.5.63.4	T326 Expiry	433
8.5.63.5	T327 Expiry	433
8.5.64	UE INFORMATION	434
8.5.64.1	General	434
8.5.64.2	Initiation.....	434
8.5.64.3	Reception of the UE INFORMATION REQUEST message by the UE.....	434
8.5.64.4	Reception of the UE INFORMATION RESPONSE message by the UTRAN	435
8.5.65	Measurements logging.....	435
8.5.65.1	General	435
8.5.65.2	Initiation.....	435
8.5.66Release of Logged Measurements Configuration.....	436
8.5.66.1	General	436
8.5.66.2	Initiation.....	437

8.5.67	Measurements logging for ANR.....	437
8.5.67.1	General.....	437
8.5.67.2	Initiation.....	437
8.5.68	Release of ANR Logging Measurements Configuration	439
8.5.68.1	General.....	439
8.5.68.2	Initiation.....	439
8.5.69	Actions related to UPLINK_CLTD_TRANSMISSION variable (FDD only)	439
8.5.70	Actions related to UPLINK_OLTD_TRANSMISSION variable (FDD only)	440
8.5.71	Actions related to MULTIFLOW_STATUS variable (FDD only).....	440
8.5.72	Selection of common E-DCH TTI (FDD only)	441
8.5.73	PRACH preamble control parameters selection with Concurrent Deployment of 2ms and 10ms TTI (for Enhanced Uplink, FDD only)	442
8.5.74	PRACH preamble control parameters selection without Concurrent Deployment of 2ms and 10ms TTI (for Enhanced Uplink, FDD only)	444
8.5.75	Actions related to READY_FOR_COMMON_ERGCH variable (FDD only)	445
8.5.76	Actions related to FALLBACK_R99_PRACH_ENABLED variable (FDD only)	446
8.5.77	Actions related to READY_FOR_FALLBACK_R99_PRACH variable (FDD only)	446
8.5.78	Actions related to MIMO_MODE_WITH_FOUR_TRANSMIT_ANTENNAS_PARAMS variable (FDD only).....	447
8.5.79	Actions related to MIMO_MODE_WITH_FOUR_TRANSMIT_ANTENNAS_STATUS variable(FDD only).....	448
8.5.80	Actions related to SECONDARY_CELL_MIMO_MODE_WITH_FOUR_TRANSMIT_ANTENNAS_STATUS variable (FDD only).....	449
8.5.81	Actions related to UPLINK_MIMO_TRANSMISSION variable (FDD only)	450
8.5.82	Actions related to NON_RECTANGULAR_RESOURCE_ALLOCATION_STATUS variable (1.28 Mcps TDD only).....	451
8.5.83	Actions related to DPCCH2_TRANSMISSION variable (FDD only).....	451
8.5.84	Actions related to DCH_ENHANCEMENTS_STATUS variable (FDD only).....	452
8.5.85	Actions related to IMPLICIT_GRANT variable (FDD only).....	453
8.5.86	Actions related to reception of a HS-SCCH order for TTI switching (FDD only)	453
8.5.87	Actions related to BLIND_HARQ_HSDPA variable (FDD only)	454
8.5.88	Actions related to HS_SCCH_DRX_CELL_FACH_STATUS variable (FDD only)	454
8.5.89	HS-SCCH DRX operation in CELL_FACH state (FDD only).....	455
8.6	Generic actions on receipt and absence of an information element.....	456
8.6.1	CN information elements.....	456
8.6.1.1	Void.....	456
8.6.1.2	CN information info.....	456
8.6.1.3	Signalling connection release indication.....	456
8.6.1.4	Extended DRX in Idle mode	457
8.6.1.4.1	T331 expiry	457
8.6.1.4.2	T332 expiry	457
8.6.2	UTRAN mobility information elements	457
8.6.2.1	URA identity.....	457
8.6.2.2	Mapping info.....	458
8.6.2.3	RNC support for change of UE capability	458
8.6.2.4	CSG PSC Split Information	458
8.6.2.5	E-UTRA detection	459
8.6.3	UE information elements	459
8.6.3.1	Activation time.....	459
8.6.3.1a	CN domain specific DRX cycle length coefficient	460
8.6.3.1b	H-RNTI.....	460
8.6.3.2	UTRAN DRX Cycle length coefficient	461
8.6.3.3	Generic state transition rules depending on received information elements	462
8.6.3.4	Ciphering mode info	462
8.6.3.5	Integrity protection mode info.....	465
8.6.3.5.1	Initialisation of Integrity Protection.....	466
8.6.3.5.2	Integrity Protection Re-configuration for SRNS Relocation, intra-RAT SR-VCC and handover from GERAN Iu mode.....	467
8.6.3.5.3	Integrity Protection modification in case of new keys or initialisation of signalling connection ..	468
8.6.3.6	Void.....	469
8.6.3.7	Void.....	469

8.6.3.8	Integrity check info	469
8.6.3.9	New C-RNTI.....	469
8.6.3.9a	New DSCH-RNTI.....	469
8.6.3.10	New U-RNTI.....	470
8.6.3.11	RRC transaction identifier.....	470
8.6.3.12	Capability Update Requirement	475
8.6.3.13	Group release information.....	476
8.6.3.14	New E-RNTI.....	477
8.6.3.15	SR-VCC Info.....	478
8.6.3.16	rSR-VCC Info	478
8.6.3.17	Access Group identity	479
8.6.3.18	RNTI handling at cell re-selection	479
8.6.3.19	Actions related to dynamic activation time determination (FDD only)	479
8.6.4	Radio bearer information elements	480
8.6.4.1	Signalling RB information to setup list.....	480
8.6.4.2	RAB information for setup.....	481
8.6.4.2a	RAB information to reconfigure	483
8.6.4.3	RB information to setup	483
8.6.4.4	RB information to be affected.....	485
8.6.4.4a	Void.....	485
8.6.4.5	RB information to reconfigure	485
8.6.4.6	RB information to release	486
8.6.4.7	RB with PDCP information	487
8.6.4.8	RB mapping info	487
8.6.4.9	RLC Info	490
8.6.4.10	PDCP Info	493
8.6.4.11	PDCP SN Info.....	495
8.6.4.12	NAS Synchronisation Indicator	495
8.6.4.13	PDCP context relocation info.....	495
8.6.4.14	RLC Info MBMS	495
8.6.4.15	RAB information for MBMS ptp bearer	495
8.6.4.16	Retrievable configuration info	496
8.6.4.17	Other state configuration info	496
8.6.5	Transport channel information elements	497
8.6.5.1	Transport Format Set.....	497
8.6.5.2	Transport format combination set	499
8.6.5.3	Transport format combination subset.....	501
8.6.5.4	DCH quality target	502
8.6.5.5	Added or Reconfigured UL TrCH information.....	503
8.6.5.5a	Added or reconfigured MAC-d flow.....	503
8.6.5.6	Added or Reconfigured DL TrCH information.....	504
8.6.5.6a	Void.....	505
8.6.5.6b	HARQ Info.....	505
8.6.5.6c	Void.....	508
8.6.5.7	Deleted UL TrCH information.....	508
8.6.5.8	Deleted DL TrCH information.....	508
8.6.5.9	UL Transport channel information common for all transport channels	508
8.6.5.10	DL Transport channel information common for all transport channels	509
8.6.5.11	Void.....	510
8.6.5.12	TFCS Reconfiguration/Addition Information	510
8.6.5.12a	Additional RACH TFCS for CCCH.....	510
8.6.5.13	TFCS Removal Information.....	510
8.6.5.14	Void.....	511
8.6.5.15	TFCS Explicit Configuration	511
8.6.5.16	E-DCH Transmission Time Interval (FDD only).....	511
8.6.5.17	HARQ Info for E-DCH	511
8.6.5.18	Added or reconfigured E-DCH MAC-d flow.....	511
8.6.5.19	SRB1 mapping info (FDD and 1.28 Mcps TDD only)	513
8.6.5.20	HARQ System Info (FDD and 1.28 Mcps TDD only).....	513
8.6.5.21	CCCH mapping info (FDD and 1.28 Mcps TDD only)	514
8.6.5.22	Common MAC-ehs reordering queue (FDD and 1.28 Mcps TDD only).....	514
8.6.5.23	Added or reconfigured MAC-ehs reordering queue.....	514

8.6.5.24	Common E-DCH MAC-d flows (FDD and 1.28 Mcps TDD only)	514
8.6.5.25	Early DCH quality target	515
8.6.6	Physical channel information elements.....	515
8.6.6.1	Frequency info	515
8.6.6.2	Void.....	516
8.6.6.2a	PNBSCH allocation	517
8.6.6.3	Void.....	517
8.6.6.3a	Downlink information per radio link list.....	517
8.6.6.3b	Downlink information per radio link list on secondary UL frequency (FDD only).....	518
8.6.6.4	Downlink information for each radio link.....	519
8.6.6.4a	Downlink information for each radio link on secondary UL frequency (FDD only).....	522
8.6.6.5	Void.....	523
8.6.6.6	Uplink DPCH info	523
8.6.6.7	Void.....	524
8.6.6.8	Maximum allowed UL TX power	524
8.6.6.9	Void.....	524
8.6.6.10	Void.....	525
8.6.6.11	Uplink DPCH power control info	525
8.6.6.12	Secondary CPICH info.....	526
8.6.6.13	Primary CPICH usage for channel estimation	526
8.6.6.14	DPCH frame offset (FDD Only)	527
8.6.6.15	DPCH Compressed mode info	528
8.6.6.16	Repetition period, Repetition length, Offset (TDD only).....	532
8.6.6.16a	Repetition period, Repetition length, Offset _{sub} (1.28 Mcps TDD only).....	532
8.6.6.17	Primary CCPCH info	533
8.6.6.18	Primary CPICH info.....	533
8.6.6.19	Void.....	533
8.6.6.20	Void.....	533
8.6.6.21	Void.....	534
8.6.6.22	Secondary Scrambling Code, Code Number.....	534
8.6.6.23	PDSCH Power Control info	534
8.6.6.24	Tx Diversity Mode	534
8.6.6.25	Void.....	535
8.6.6.26	UL Timing Advance Control (TDD only)	535
8.6.6.26a	Uplink synchronisation parameters (TDD only)	536
8.6.6.27	Downlink information common for all radio links.....	536
8.6.6.28	Downlink DPCH info common for all radio links	537
8.6.6.28a	Downlink F-DPCH info common for all radio links.....	539
8.6.6.29	ASC setting	539
8.6.6.30	SRB delay, PC preamble (FDD only)	541
8.6.6.31	Void.....	541
8.6.6.32	Void.....	541
8.6.6.33	HS-SCCH Info	541
8.6.6.34	Measurement Feedback Info	543
8.6.6.35	DPC Mode.....	543
8.6.6.36	Downlink HS-PDSCH Information	543
8.6.6.36a	DL Multi-carrier information (1.28 Mcps TDD only)	544
8.6.6.37	E-DCH Info.....	545
8.6.6.38	DTX-DRX timing information (FDD only).....	546
8.6.6.39	DTX-DRX information (FDD only)	547
8.6.6.40	HS-SCCH less information (FDD only)	548
8.6.6.41	MIMO parameters	548
8.6.6.42	UL 16QAM settings.....	549
8.6.6.42b	UL 64QAM settings.....	549
8.6.6.43	Multi-frequency Info (1.28 Mcps TDD only)	549
8.6.6.44	Void.....	549
8.6.6.45	Downlink Secondary Cell Info FDD.....	549
8.6.6.46	Control Channel DRX information (1.28 Mcps TDD only)	551
8.6.6.47	SPS information (1.28 Mcps TDD only).....	551
8.6.6.48	Secondary cell MIMO parameters	553
8.6.6.49	Uplink Secondary Cell Info FDD (FDD only).....	553
8.6.6.50	Additional downlink secondary cell info list FDD.....	554