

ETSI TS 138 331 V17.1.0 (2022-08)



5G;
NR;
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 38.331 version 17.1.0 Release 17)

<https://standards.iteh.ai/catalog/standards/sist/ec0bc057-82da-422a-8a2b-ce250e176cab/etsi-ts-138-331-v17-1-0-2022-08>



ReferenceRTS/TSGR-0238331vh10

Keywords5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<http://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://standards-portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2022.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <http://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document **"shall"**, **"shall not"**, **"should"**, **"should not"**, **"may"**, **"need not"**, **"will"**, **"will not"**, **"can"** and **"cannot"** are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"must" and **"must not"** are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	24
1 Scope	25
2 References	25
3 Definitions, symbols and abbreviations	28
3.1 Definitions	28
3.2 Abbreviations	29
4 General	32
4.1 Introduction	32
4.2 Architecture	32
4.2.1 UE states and state transitions including inter RAT	32
4.2.2 Signalling radio bearers	36
4.3 Services	36
4.3.1 Services provided to upper layers	36
4.3.2 Services expected from lower layers	37
4.4 Functions	37
5 Procedures	38
5.1 General	38
5.1.1 Introduction.....	38
5.1.2 General requirements.....	38
5.1.3 Requirements for UE in MR-DC	39
5.2 System information	39
5.2.1 Introduction.....	39
5.2.2 System information acquisition	40
5.2.2.1 General UE requirements.....	40
5.2.2.2 SIB validity and need to (re)-acquire SIB	41
5.2.2.2.1 SIB validity.....	41
5.2.2.2.2 SI change indication and PWS notification	42
5.2.2.3 Acquisition of System Information	43
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i>	43
5.2.2.3.2 Acquisition of an SI message	44
5.2.2.3.3 Request for on demand system information	46
5.2.2.3.3a Request for on demand positioning system information	47
5.2.2.3.4 Actions related to transmission of <i>RRCSystemInfoRequest</i> message	48
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in <i>RRC_CONNECTED</i>	48
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message	49
5.2.2.4 Actions upon receipt of System Information	50
5.2.2.4.1 Actions upon reception of the <i>MIB</i>	50
5.2.2.4.2 Actions upon reception of the <i>SIB1</i>	50
5.2.2.4.3 Actions upon reception of <i>SIB2</i>	54
5.2.2.4.4 Actions upon reception of <i>SIB3</i>	55
5.2.2.4.5 Actions upon reception of <i>SIB4</i>	55
5.2.2.4.6 Actions upon reception of <i>SIB5</i>	56
5.2.2.4.7 Actions upon reception of <i>SIB6</i>	56
5.2.2.4.8 Actions upon reception of <i>SIB7</i>	56
5.2.2.4.9 Actions upon reception of <i>SIB8</i>	57
5.2.2.4.10 Actions upon reception of <i>SIB9</i>	57
5.2.2.4.11 Actions upon reception of <i>SIB10</i>	57
5.2.2.4.12 Actions upon reception of <i>SIB11</i>	58
5.2.2.4.13 Actions upon reception of <i>SIB12</i>	58
5.2.2.4.14 Actions upon reception of <i>SIB13</i>	59

5.2.2.4.15	Actions upon reception of <i>SIB14</i>	59
5.2.2.4.16	Actions upon reception of <i>SIBpos</i>	59
5.2.2.4.17	Actions upon reception of <i>SIB15</i>	59
5.2.2.4.18	Actions upon reception of <i>SIB16</i>	59
5.2.2.4.19	Actions upon reception of <i>SIB17</i>	59
5.2.2.4.20	Actions upon reception of <i>SIB18</i>	60
5.2.2.4.21	Actions upon reception of <i>SIB19</i>	60
5.2.2.4.22	Actions upon reception of <i>SIB20</i>	60
5.2.2.4.23	Actions upon reception of <i>SIB21</i>	60
5.2.2.5	Essential system information missing	60
5.2.2.6	T430 expiry	60
5.3	Connection control	61
5.3.1	Introduction	61
5.3.1.1	RRC connection control	61
5.3.1.2	AS Security	62
5.3.2	Paging	63
5.3.2.1	General	63
5.3.2.2	Initiation	63
5.3.2.3	Reception of the <i>Paging message</i> by the UE or <i>PagingRecord</i> by the L2 U2N Remote UE	63
5.3.3	RRC connection establishment	65
5.3.3.1	General	65
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	65
5.3.3.2	Initiation	66
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message	66
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE	67
5.3.3.5	Reception of the <i>RRCReject</i> by the UE	70
5.3.3.6	Cell re-selection or cell selection while T390, T300 or T302 is running (UE in RRC_IDLE)	70
5.3.3.7	T300 expiry	71
5.3.3.8	Abortion of RRC connection establishment	72
5.3.4	Initial AS security activation	73
5.3.4.1	General	73
5.3.4.2	Initiation	73
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE	73
5.3.5	RRC reconfiguration	74
5.3.5.1	General	74
5.3.5.2	Initiation	75
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE	75
5.3.5.4	Secondary cell group release	86
5.3.5.5	Cell Group configuration	87
5.3.5.5.1	General	87
5.3.5.5.2	Reconfiguration with sync	87
5.3.5.5.3	RLC bearer release	89
5.3.5.5.4	RLC bearer addition/modification	90
5.3.5.5.5	MAC entity configuration	91
5.3.5.5.6	RLF Timers & Constants configuration	91
5.3.5.5.7	SpCell Configuration	92
5.3.5.5.8	SCell Release	93
5.3.5.5.9	SCell Addition/Modification	93
5.3.5.5.10	BH RLC channel release	94
5.3.5.5.11	BH RLC channel addition/modification	94
5.3.5.5.12	Uu Relay RLC channel release	94
5.3.5.5.13	Uu Relay RLC channel addition/modification	94
5.3.5.6	Radio Bearer configuration	95
5.3.5.6.1	General	95
5.3.5.6.2	SRB release	95
5.3.5.6.3	SRB addition/modification	96
5.3.5.6.4	DRB release	97
5.3.5.6.5	DRB addition/modification	98
5.3.5.6.6	Multicast MRB release	101
5.3.5.6.7	Multicast MRB addition/modification	101
5.3.5.7	AS Security key update	102

5.3.5.8	Reconfiguration failure	103
5.3.5.8.1	Void	103
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i>	103
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure) or T420 expiry (Path switch failure)	105
5.3.5.9	Other configuration	107
5.3.5.10	MR-DC release	110
5.3.5.11	Full configuration	111
5.3.5.12	BAP configuration	113
5.3.5.12a	IAB Other Configuration	113
5.3.5.12a.1	IP address management	113
5.3.5.12a.1.1	IP Address Release	113
5.3.5.12a.1.2	IP Address Addition/Modification	113
5.3.5.13	Conditional Reconfiguration	115
5.3.5.13.1	General	115
5.3.5.13.2	Conditional reconfiguration removal	115
5.3.5.13.3	Conditional reconfiguration addition/modification	115
5.3.5.13.4	Conditional reconfiguration evaluation	115
5.3.5.13.4a	Conditional reconfiguration evaluation of SN initiated inter-SN CPC for EN-DC	117
5.3.5.13.5	Conditional reconfiguration execution	117
5.3.5.13a	SCG activation	118
5.3.5.13b	SCG deactivation	118
5.3.5.13b1	SCG activation without SN message	119
5.3.5.13c	FR2 UL gap configuration	119
5.3.5.13d	Application layer measurement configuration	119
5.3.5.14	Sidelink dedicated configuration	120
5.3.5.15	L2 U2N Relay UE configuration	122
5.3.5.15.1	General	122
5.3.5.15.2	L2 U2N Remote UE Release	122
5.3.5.15.3	L2 U2N Remote UE Addition/Modification	123
5.3.5.16	L2 U2N Remote UE configuration	123
5.3.6	Counter check	123
5.3.6.1	General	123
5.3.6.2	Initiation	124
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	124
5.3.7	RRC connection re-establishment	124
5.3.7.1	General	124
5.3.7.2	Initiation	125
5.3.7.3	Actions following cell selection while T311 is running	128
5.3.7.3a	Actions following relay selection while T311 is running	130
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message	130
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE	131
5.3.7.6	T311 expiry	133
5.3.7.7	T301 expiry or selected cell/L2 U2N Relay UE no longer suitable	133
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE	133
5.3.8	RRC connection release	133
5.3.8.1	General	133
5.3.8.2	Initiation	134
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE	134
5.3.8.4	T320 expiry	137
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i>	137
5.3.8.6	T346g expiry	138
5.3.9	RRC connection release requested by upper layers	138
5.3.9.1	General	138
5.3.9.2	Initiation	138
5.3.10	Radio link failure related actions	138
5.3.10.1	Detection of physical layer problems in RRC_CONNECTED	138
5.3.10.2	Recovery of physical layer problems	138
5.3.10.3	Detection of radio link failure	138
5.3.10.4	RLF cause determination	140
5.3.10.5	RLF report content determination	141
5.3.11	UE actions upon going to RRC_IDLE	144
5.3.12	UE actions upon PUCCH/SRS release request	146

5.3.13	RRC connection resume	146
5.3.13.1	General	146
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	147
5.3.13.1b	Conditions for initiating SDT	148
5.3.13.2	Initiation	148
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message	151
5.3.13.4	Reception of the <i>RRCResume</i> by the UE	152
5.3.13.5	Handling of failure to resume RRC Connection	157
5.3.13.6	Cell re-selection or cell selection or L2 U2N relay (re)selection while T390, T319, T319a or T302 is running (UE in RRC_INACTIVE) or SRS transmission in RRC_INACTIVE is configured	158
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE	159
5.3.13.8	RNA update	159
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE	159
5.3.13.10	Reception of the <i>RRCReject</i> by the UE	159
5.3.13.11	Inability to comply with <i>RRCResume</i>	160
5.3.13.12	Inter RAT cell reselection	160
5.3.14	Unified Access Control	160
5.3.14.1	General	160
5.3.14.2	Initiation	160
5.3.14.3	Void	162
5.3.14.4	T302, T390 expiry or stop (Barring alleviation)	162
5.3.14.5	Access barring check	162
5.3.15	RRC connection reject	163
5.3.15.1	Initiation	163
5.3.15.2	Reception of the <i>RRCReject</i> by the UE	163
5.4	Inter-RAT mobility	164
5.4.1	Introduction	164
5.4.2	Handover to NR	165
5.4.2.1	General	165
5.4.2.2	Initiation	165
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE	165
5.4.3	Mobility from NR	166
5.4.3.1	General	166
5.4.3.2	Initiation	166
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE	166
5.4.3.4	Successful completion of the mobility from NR	167
5.4.3.5	Mobility from NR failure	167
5.5	Measurements	168
5.5.1	Introduction	168
5.5.2	Measurement configuration	171
5.5.2.1	General	171
5.5.2.2	Measurement identity removal	172
5.5.2.3	Measurement identity addition/modification	172
5.5.2.4	Measurement object removal	174
5.5.2.5	Measurement object addition/modification	174
5.5.2.6	Reporting configuration removal	176
5.5.2.7	Reporting configuration addition/modification	176
5.5.2.8	Quantity configuration	176
5.5.2.9	Measurement gap configuration	177
5.5.2.10	Reference signal measurement timing configuration	179
5.5.2.10a	RSSI measurement timing configuration	180
5.5.2.11	Measurement gap sharing configuration	180
5.5.3	Performing measurements	181
5.5.3.1	General	181
5.5.3.2	Layer 3 filtering	186
5.5.3.3	Derivation of cell measurement results	186
5.5.3.3a	Derivation of layer 3 beam filtered measurement	187
5.5.3.4	Derivation of L2 U2N Relay UE measurement results	187
5.5.4	Measurement report triggering	188
5.5.4.1	General	188

5.5.4.2	Event A1 (Serving becomes better than threshold)	194
5.5.4.3	Event A2 (Serving becomes worse than threshold)	195
5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell)	195
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	196
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2)	197
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell)	198
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold)	198
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	199
5.5.4.10	Event I1 (Interference becomes higher than threshold)	200
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold)	200
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold)	201
5.5.4.13	Void	201
5.5.4.14	Void	201
5.5.4.15	Event D1	201
5.5.4.16	CondEvent T1	202
5.5.4.17	Event X1 (Serving L2 U2N Relay UE becomes worse than threshold1 and NR Cell becomes better than threshold2)	203
5.5.4.18	Event X2 (Serving L2 U2N Relay UE becomes worse than threshold)	203
5.5.4.19	Event Y1 (PCell becomes worse than threshold1 and candidate L2 U2N Relay UE becomes better than threshold2)	204
5.5.4.20	Event Y2 (Candidate L2 U2N Relay UE becomes better than threshold)	205
5.5.5	Measurement reporting	205
5.5.5.1	General	205
5.5.5.2	Reporting of beam measurement information	213
5.5.5.3	Sorting of cell measurement results	214
5.5.6	Location measurement indication	215
5.5.6.1	General	215
5.5.6.2	Initiation	215
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message	216
5.5a	Logged Measurements	216
5.5a.1	Logged Measurement Configuration	216
5.5a.1.1	General	216
5.5a.1.2	Initiation	217
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE	217
5.5a.1.4	T330 expiry	217
5.5a.2	Release of Logged Measurement Configuration	217
5.5a.2.1	General	217
5.5a.2.2	Initiation	217
5.5a.3	Measurements logging	218
5.5a.3.1	General	218
5.5a.3.2	Initiation	218
5.6	UE capabilities	220
5.6.1	UE capability transfer	220
5.6.1.1	General	220
5.6.1.2	Initiation	221
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	221
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE	222
5.6.1.5	Void	224
5.7	Other	224
5.7.1	DL information transfer	224
5.7.1.1	General	224
5.7.1.2	Initiation	225
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	225
5.7.1a	DL information transfer for MR-DC	225
5.7.1a.1	General	225
5.7.1a.2	Initiation	226
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message	226
5.7.2	UL information transfer	226
5.7.2.1	General	226
5.7.2.2	Initiation	226

5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message	227
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message	227
5.7.2a	UL information transfer for MR-DC	227
5.7.2a.1	General	227
5.7.2a.2	Initiation	227
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message	227
5.7.2b	UL transfer of IRAT information	228
5.7.2b.1	General	228
5.7.2b.2	Initiation	228
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	228
5.7.3	SCG failure information	229
5.7.3.1	General	229
5.7.3.2	Initiation	229
5.7.3.3	Failure type determination for (NG)EN-DC	229
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i>	230
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message	231
5.7.3a	EUTRA SCG failure information	233
5.7.3a.1	General	233
5.7.3a.2	Initiation	233
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message	234
5.7.3b	MCG failure information	234
5.7.3b.1	General	234
5.7.3b.2	Initiation	234
5.7.3b.3	Failure type determination	235
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message	235
5.7.3b.5	T316 expiry	237
5.7.4	UE Assistance Information	237
5.7.4.1	General	237
5.7.4.2	Initiation	238
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	244
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE	252
5.7.4.4	Relaxed measurement criterion for a stationary UE	253
5.7.4a	Void	253
5.7.5	Failure information	253
5.7.5.1	General	253
5.7.5.2	Initiation	254
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message	254
5.7.6	DL message segment transfer	254
5.7.6.1	General	254
5.7.6.2	Initiation	255
5.7.6.3	Reception of <i>DLDEDICATEDMESSAGESEGMENT</i> by the UE	255
5.7.7	UL message segment transfer	255
5.7.7.1	General	255
5.7.7.2	Initiation	255
5.7.7.3	Actions related to transmission of <i>ULDEDICATEDMESSAGESEGMENT</i> message	256
5.7.8	Idle/inactive Measurements	256
5.7.8.1	General	256
5.7.8.1a	Measurement configuration	256
5.7.8.2	Void	257
5.7.8.2a	Performing measurements	257
5.7.8.3	T331 expiry or stop	260
5.7.8.4	Cell re-selection or cell selection while T331 is running	260
5.7.9	Mobility history information	260
5.7.9.1	General	260
5.7.9.2	Initiation	260
5.7.10	UE Information	263
5.7.10.1	General	263
5.7.10.2	Initiation	263
5.7.10.3	Reception of the <i>UEInformationRequest</i> message	263
5.7.10.4	Actions upon successful completion of a random-access procedure or on completion of a request of on-demand system information	266
5.7.10.5	RA information determination for RA report and RLF report	267

5.7.10.6	Actions for the successful handover report determination	270
5.7.12	IAB Other Information	273
5.7.12.1	General	273
5.7.12.2	Initiation	273
5.7.12.3	Actions related to transmission of <i>IABOtherInformation</i> message	273
5.7.13	RLM/BFD relaxation	275
5.7.13.1	Relaxed measurement criterion for low mobility	275
5.7.13.2	Relaxed measurement criterion for good serving cell quality	275
5.7.14	UE Positioning Assistance Information	276
5.7.14.1	General	276
5.7.14.2	Initiation	276
5.7.14.3	Actions related to transmission of <i>UEPositioningAssistanceInfo</i> message	276
5.7.15	Void	277
5.7.17	Derivation of pathloss reference for TA validation of SRS for Positioning transmission and CG-SDT in RRC_INACTIVE	278
5.8	Sidelink	278
5.8.1	General	278
5.8.2	Conditions for NR sidelink communication operation	279
5.8.3	Sidelink UE information for NR sidelink communication	279
5.8.3.1	General	279
5.8.3.2	Initiation	280
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message	284
5.8.4	Void	288
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication	288
5.8.5.1	General	288
5.8.5.2	Initiation	288
5.8.5.3	Transmission of SLSS	289
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication	290
5.8.5a.1	General	290
5.8.5a.2	Initiation	291
5.8.6	Sidelink synchronisation reference	291
5.8.6.1	General	291
5.8.6.2	Selection and reselection of synchronisation reference	291
5.8.6.3	Sidelink communication transmission reference cell selection	294
5.8.7	Sidelink communication reception	294
5.8.8	Sidelink communication transmission	294
5.8.9	Sidelink RRC procedure	296
5.8.9.1	Sidelink RRC reconfiguration	296
5.8.9.1.1	General	296
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message	297
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE	298
5.8.9.1.4	Void	300
5.8.9.1.5	Void	300
5.8.9.1.6	Void	300
5.8.9.1.7	Void	300
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE	300
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE	300
5.8.9.1a	Sidelink radio bearer management	301
5.8.9.1a.1	Sidelink DRB release	301
5.8.9.1a.2	Sidelink DRB addition/modification	302
5.8.9.1a.3	Sidelink SRB release	303
5.8.9.1a.4	Sidelink SRB addition	304
5.8.9.2	Sidelink UE capability transfer	304
5.8.9.2.1	General	304
5.8.9.2.2	Initiation	304
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE	304
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE	305
5.8.9.3	Sidelink radio link failure related actions	305
5.8.9.4	Sidelink common control information	306
5.8.9.4.1	General	306
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message	306
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message	306

5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers or AS layer	307
5.8.9.6	Sidelink UE assistance information	308
5.8.9.6.1	General	308
5.8.9.6.2	Initiation	308
5.8.9.6.3	Actions related to reception of <i>UEAssistanceInformationSidelink</i> message	308
5.8.9.8	Remote UE information	309
5.8.9.8.1	General	309
5.8.9.8.2	Actions related to transmission of <i>RemoteUEInformationSidelink</i> message	310
5.8.9.8.3	Reception of <i>RemoteUEInformationSidelink</i> message by the L2 U2N Relay UE	310
5.8.9.9	Uu message transfer in sidelink	311
5.8.9.9.1	General	311
5.8.9.9.2	Actions related to transmission of <i>UuMessageTransferSidelink</i> message	311
5.8.9.9.3	Reception of the <i>UuMessageTransferSidelink</i>	312
5.8.9.10	Notification Message	312
5.8.9.10.1	General	312
5.8.9.10.2	Initiation	312
5.8.9.10.3	Actions related to transmission of <i>NotificationMessageSidelink</i> message	312
5.8.9.10.4	Actions related to reception of <i>NotificationMessageSidelink</i> message	313
5.8.10	Sidelink measurement	313
5.8.10.1	Introduction	313
5.8.10.2	Sidelink measurement configuration	314
5.8.10.2.1	General	314
5.8.10.2.2	Sidelink measurement identity removal	314
5.8.10.2.3	Sidelink measurement identity addition/modification	315
5.8.10.2.4	Sidelink measurement object removal	315
5.8.10.2.5	Sidelink measurement object addition/modification	315
5.8.10.2.6	Sidelink reporting configuration removal	316
5.8.10.2.7	Sidelink reporting configuration addition/modification	316
5.8.10.2.8	Sidelink quantity configuration	316
5.8.10.3	Performing NR sidelink measurements	317
5.8.10.3.1	General	317
5.8.10.3.2	Derivation of NR sidelink measurement results	317
5.8.10.4	Sidelink measurement report triggering	317
5.8.10.4.1	General	317
5.8.10.4.2	Event S1 (Serving becomes better than threshold)	318
5.8.10.4.3	Event S2 (Serving becomes worse than threshold)	319
5.8.10.5	Sidelink measurement reporting	319
5.8.10.5.1	General	319
5.8.11	Zone identity calculation	320
5.8.12	DFN derivation from GNSS	320
5.9	MBS Broadcast	326
5.9.1	Introduction	326
5.9.1.1	General	326
5.9.1.2	MCCH scheduling	326
5.9.1.3	MCCH information validity and notification of changes	327
5.9.2	MCCH information acquisition	327
5.9.2.1	General	327
5.9.2.2	Initiation	327
5.9.2.3	MCCH information acquisition by the UE	327
5.9.2.4	Actions upon reception of the <i>MBSBroadcastConfiguration</i> message	328
5.9.3	Broadcast MRB configuration	328
5.9.3.1	General	328
5.9.3.2	Initiation	328
5.9.3.3	Broadcast MRB establishment	328
5.9.3.4	Broadcast MRB release	329
5.9.4	MBS Interest Indication	329
5.9.4.1	General	329
5.9.4.2	Initiation	329
5.9.4.3	MBS frequencies of interest determination	330
5.9.4.4	MBS services of interest determination	330
5.9.4.5	Setting of the contents of MBS Interest Indication	330

6	Protocol data units, formats and parameters (ASN.1)	332
6.1	General	332
6.1.1	Introduction	332
6.1.2	Need codes and conditions for optional fields	332
6.1.3	General rules	335
6.2	RRC messages	335
6.2.1	General message structure	335
–	NR-RRC-Definitions	335
–	BCCH-BCH-Message	335
–	BCCH-DL-SCH-Message	336
–	DL-CCCH-Message	336
–	DL-DCCH-Message	337
–	MCCH-Message	337
–	PCCH-Message	338
–	UL-CCCH-Message	338
–	UL-CCCH1-Message	339
–	UL-DCCH-Message	339
6.2.2	Message definitions	341
–	CounterCheck	341
–	CounterCheckResponse	342
–	DedicatedSIBRequest	343
–	DLDedicatedMessageSegment	344
–	DLInformationTransfer	345
–	DLInformationTransferMRDC	346
–	FailureInformation	347
–	IABOtherInformation	348
–	LocationMeasurementIndication	351
–	LoggedMeasurementConfiguration	352
–	MBSBroadcastConfiguration	354
–	MBSInterestIndication	355
–	MCGFailureInformation	356
–	MeasurementReport	358
–	MeasurementReportAppLayer	358
–	MIB	360
–	MobilityFromNRCommand	361
–	Paging	363
–	RRCReestablishment	364
–	RRCReestablishmentComplete	365
–	RRCReestablishmentRequest	366
–	RRCReconfiguration	367
–	RRCReconfigurationComplete	374
–	RRCReject	376
–	RRCRelease	377
–	RRCResume	384
–	RRCResumeComplete	386
–	RRCResumeRequest	388
–	RRCResumeRequest1	389
–	RRCSetup	390
–	RRCSetupComplete	391
–	RRCSetupRequest	393
–	RRCSystemInfoRequest	394
–	SCGFailureInformation	395
–	SCGFailureInformationEUTRA	397
–	SecurityModeCommand	398
–	SecurityModeComplete	399
–	SecurityModeFailure	400
–	SIB1	400
–	SidelinkUEInformationNR	405
–	SystemInformation	410
–	UEAssistanceInformation	411
–	UECapabilityEnquiry	420
–	UECapabilityInformation	421

–	<i>UEInformationRequest</i>	422
–	<i>UEInformationResponse</i>	423
–	<i>UEPositioningAssistanceInfo</i>	438
–	<i>ULDedicatedMessageSegment</i>	439
–	<i>ULInformationTransfer</i>	440
–	<i>ULInformationTransferIRAT</i>	441
–	<i>ULInformationTransferMRDC</i>	442
6.3	RRC information elements	443
6.3.0	Parameterized types	443
–	<i>SetupRelease</i>	443
6.3.1	System information blocks	444
–	<i>SIB2</i>	444
–	<i>SIB3</i>	449
–	<i>SIB4</i>	451
–	<i>SIB5</i>	456
–	<i>SIB6</i>	459
–	<i>SIB7</i>	459
–	<i>SIB8</i>	460
–	<i>SIB9</i>	461
–	<i>SIB10</i>	462
–	<i>SIB11</i>	463
–	<i>SIB12</i>	463
–	<i>SIB13</i>	465
–	<i>SIB14</i>	466
–	<i>SIB15</i>	467
–	<i>SIB16</i>	467
–	<i>SIB17</i>	468
–	<i>SIB18</i>	470
–	<i>SIB20</i>	472
–	<i>SIB21</i>	473
6.3.1a	Positioning System information blocks	474
–	<i>PosSystemInformation-r16-IEs</i>	474
–	<i>PosSI-SchedulingInfo</i>	475
–	<i>SIBpos</i>	477
6.3.2	Radio resource control information elements	478
–	<i>AdditionalSpectrumEmission</i>	478
–	<i>Alpha</i>	478
–	<i>AMF-Identifier</i>	479
–	<i>ARFCN-ValueEUTRA</i>	479
–	<i>ARFCN-ValueNR</i>	479
–	<i>ARFCN-ValueUTRA-FDD</i>	480
–	<i>AvailabilityCombinationsPerCell</i>	480
–	<i>AvailabilityIndicator</i>	481
–	<i>BAP-RoutingID</i>	482
–	<i>BeamFailureRecoveryConfig</i>	483
–	<i>BeamFailureRecoveryRSConfig</i>	485
–	<i>BetaOffsets</i>	486
–	<i>BetaOffsetsCrossPri</i>	487
–	<i>BH-LogicalChannelIdentity</i>	487
–	<i>BH-LogicalChannelIdentity-Ext</i>	488
–	<i>BH-RLC-ChannelConfig</i>	488
–	<i>BH-RLC-ChannelID</i>	489
–	<i>BSR-Config</i>	489
–	<i>BWP</i>	490
–	<i>BWP-Downlink</i>	491
–	<i>BWP-DownlinkCommon</i>	492
–	<i>BWP-DownlinkDedicated</i>	492
–	<i>BWP-Id</i>	495
–	<i>BWP-Uplink</i>	495
–	<i>BWP-UplinkCommon</i>	496
–	<i>BWP-UplinkDedicated</i>	499
–	<i>CandidateBeamRS</i>	502

–	<i>CellAccessRelatedInfo</i>	503
–	<i>CellAccessRelatedInfo-EUTRA-5GC</i>	504
–	<i>CellAccessRelatedInfo-EUTRA-EPC</i>	505
–	<i>CellGroupConfig</i>	506
–	<i>CellGroupId</i>	514
–	<i>CellIdentity</i>	514
–	<i>CellReselectionPriority</i>	514
–	<i>CellReselectionSubPriority</i>	515
–	<i>CFR-ConfigMulticast</i>	515
–	<i>CGI-InfoEUTRA</i>	516
–	<i>CGI-InfoEUTRALogging</i>	516
–	<i>CGI-InfoNR</i>	517
–	<i>CGI-Info-Logging</i>	518
–	<i>CLI-RSSI-Range</i>	519
–	<i>CodebookConfig</i>	519
–	<i>CommonLocationInfo</i>	524
–	<i>CondReconfigId</i>	524
–	<i>CondReconfigToAddModList</i>	525
–	<i>ConditionalReconfiguration</i>	526
–	<i>ConfiguredGrantConfig</i>	526
–	<i>ConfiguredGrantConfigIndex</i>	535
–	<i>ConfiguredGrantConfigIndexMAC</i>	536
–	<i>ConnEstFailureControl</i>	536
–	<i>ControlResourceSet</i>	537
–	<i>ControlResourceSetId</i>	539
–	<i>ControlResourceSetZero</i>	539
–	<i>CrossCarrierSchedulingConfig</i>	540
–	<i>CSI-AperiodicTriggerStateList</i>	541
–	<i>CSI-FrequencyOccupation</i>	544
–	<i>CSI-IM-Resource</i>	544
–	<i>CSI-IM-ResourceId</i>	545
–	<i>CSI-IM-ResourceSet</i>	546
–	<i>CSI-IM-ResourceSetId</i>	546
–	<i>CSI-MeasConfig</i>	546
–	<i>CSI-ReportConfig</i>	548
–	<i>CSI-ReportConfigId</i>	554
–	<i>CSI-ResourceConfig</i>	554
–	<i>CSI-ResourceConfigId</i>	556
–	<i>CSI-ResourcePeriodicityAndOffset</i>	557
–	<i>CSI-RS-ResourceConfigMobility</i>	557
–	<i>CSI-RS-ResourceMapping</i>	559
–	<i>CSI-SemiPersistentOnPUSCH-TriggerStateList</i>	561
–	<i>CSI-SSB-ResourceSet</i>	562
–	<i>CSI-SSB-ResourceSetId</i>	562
–	<i>DedicatedNAS-Message</i>	563
–	<i>DL-PPW-PreConfig</i>	563
–	<i>DMRS-BundlingPUCCH-Config</i>	566
–	<i>DMRS-BundlingPUSCH-Config</i>	566
–	<i>DMRS-DownlinkConfig</i>	567
–	<i>DMRS-UplinkConfig</i>	568
–	<i>DownlinkConfigCommon</i>	570
–	<i>DownlinkConfigCommonSIB</i>	571
–	<i>DownlinkPreemption</i>	575
–	<i>DRB-Identity</i>	576
–	<i>DRX-Config</i>	576
–	<i>DRX-ConfigSecondaryGroup</i>	578
–	<i>DRX-ConfigSL</i>	579
–	<i>EphemerisInfo</i>	579
–	<i>FeatureCombination</i>	581
–	<i>FeatureCombinationPreambles</i>	582
–	<i>FilterCoefficient</i>	584
–	<i>FreqBandIndicatorNR</i>	584

–	<i>FreqPriorityListDedicatedSlicing</i>	584
–	<i>FreqPriorityListSlicing</i>	585
–	<i>FrequencyInfoDL</i>	586
–	<i>FrequencyInfoDL-SIB</i>	587
–	<i>FrequencyInfoUL</i>	588
–	<i>FrequencyInfoUL-SIB</i>	589
–	<i>GapPriority</i>	590
–	<i>HighSpeedConfig</i>	591
–	<i>Hysteresis</i>	592
–	<i>HysteresisLocation</i>	593
–	<i>InvalidSymbolPattern</i>	593
–	<i>I-RNTI-Value</i>	594
–	<i>LBT-FailureRecoveryConfig</i>	594
–	<i>LocationInfo</i>	595
–	<i>LocationMeasurementInfo</i>	595
–	<i>LogicalChannelConfig</i>	597
–	<i>LogicalChannelIdentity</i>	599
–	<i>LTE-NeighCellsCRS-AssistInfoList</i>	599
–	<i>MAC-CellGroupConfig</i>	601
–	<i>MeasConfig</i>	604
–	<i>MeasGapConfig</i>	606
–	<i>MeasGapId</i>	610
–	<i>MeasGapSharingConfig</i>	611
–	<i>MeasId</i>	612
–	<i>MeasIdleConfig</i>	612
–	<i>MeasIdToAddModList</i>	615
–	<i>MeasObjectCLI</i>	615
–	<i>MeasObjectEUTRA</i>	618
–	<i>MeasObjectId</i>	620
–	<i>MeasObjectNR</i>	620
–	<i>MeasObjectNR-SL</i>	627
–	<i>MeasObjectRxTxDiff</i>	628
–	<i>MeasObjectToAddModList</i>	628
–	<i>MeasObjectUTRA-FDD</i>	629
–	<i>MeasResultCellListSFTD-NR</i>	630
–	<i>MeasResultCellListSFTD-EUTRA</i>	631
–	<i>MeasResults</i>	631
–	<i>MeasResult2EUTRA</i>	638
–	<i>MeasResult2NR</i>	638
–	<i>MeasResultIdleEUTRA</i>	639
–	<i>MeasResultIdleNR</i>	640
–	<i>MeasResultRxTxTimeDiff</i>	641
–	<i>MeasResultSCG-Failure</i>	642
–	<i>MeasResultsSL</i>	642
–	<i>MeasTriggerQuantityEUTRA</i>	643
–	<i>MobilityStateParameters</i>	643
–	<i>MRB-Identity</i>	644
–	<i>MsgA-ConfigCommon</i>	644
–	<i>MsgA-PUSCH-Config</i>	645
–	<i>MultiFrequencyBandListNR</i>	648
–	<i>MultiFrequencyBandListNR-SIB</i>	649
–	<i>MUSIM-GapConfig</i>	649
–	<i>MUSIM-GapID</i>	650
–	<i>MUSIM-GapInfo</i>	651
–	<i>NeedForGapsConfigNR</i>	652
–	<i>NeedForGapNCSG-ConfigEUTRA</i>	653
–	<i>NeedForGapNCSG-ConfigNR</i>	654
–	<i>NeedForGapNCSG-InfoEUTRA</i>	654
–	<i>NeedForGapNCSG-InfoNR</i>	655
–	<i>NextHopChainingCount</i>	656
–	<i>NG-5G-S-TMSI</i>	657
–	<i>NonCellDefiningSSB</i>	657