

ISO/TC 45/SC 2

Secretariat: JISC

Voting begins
on: **2015-06-23**

Voting terminates
on: **2015-08-23**

Rubber — Guide to the use of curemeters

Caoutchouc — Guide pour l'emploi des rhéomètres

ITeH STANDARD PREVIEW
(standards.iteh.ai)
Full standard:
<https://standards.iteh.ai/catalog/standards/sist/1fe7ec37-fbce-4fcc-8d6e-b885e5a05f2f/iso-6502-2016>

RECIPIENTS OF THIS DRAFT ARE INVITED TO SUBMIT, WITH THEIR COMMENTS, NOTIFICATION OF ANY RELEVANT PATENT RIGHTS OF WHICH THEY ARE AWARE AND TO PROVIDE SUPPORTING DOCUMENTATION.

IN ADDITION TO THEIR EVALUATION AS BEING ACCEPTABLE FOR INDUSTRIAL, TECHNOLOGICAL, COMMERCIAL AND USER PURPOSES, DRAFT INTERNATIONAL STANDARDS MAY ON OCCASION HAVE TO BE CONSIDERED IN THE LIGHT OF THEIR POTENTIAL TO BECOME STANDARDS TO WHICH REFERENCE MAY BE MADE IN NATIONAL REGULATIONS.



Reference number
ISO/FDIS 6502:2015(E)

iTeh STANDARD PREVIEW
(standards.iteh.ai)
Full standard:
<https://standards.iteh.ai/catalog/standards/sist/1fe7ec37-fbce-4fcc-8d6e-b885e5a05f2f/iso-6502-2016>



COPYRIGHT PROTECTED DOCUMENT

© ISO 2015, Published in Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Ch. de Blandonnet 8 • CP 401
CH-1214 Vernier, Geneva, Switzerland
Tel. +41 22 749 01 11
Fax +41 22 749 09 47
copyright@iso.org
www.iso.org

Contents

	Page
Foreword.....	iv
Introduction.....	v
1 Scope.....	1
2 Normative references.....	1
3 Terms and definitions.....	1
4 Basic principles.....	2
5 Types of curemeter.....	4
6 Apparatus.....	4
6.1 General.....	4
6.2 Die cavity.....	4
6.3 Die closure.....	5
6.4 Moving member.....	5
6.5 Movement.....	5
6.6 Stiffness measurement.....	6
6.7 Heating and temperature control.....	6
6.8 Calibration.....	6
7 Test piece.....	6
8 Vulcanization temperature.....	6
9 Conditioning.....	6
10 Test procedure.....	7
10.1 Preparation for the test.....	7
10.2 Loading the curemeter.....	7
11 Expression of results.....	7
12 Test report.....	8
Annex A (informative) Effect of thermal parameters on measured cure properties.....	15
Annex B (informative) Particular requirements for oscillating-disc curemeters.....	18
Annex C (informative) Particular requirements for rotorless curemeters.....	19
Bibliography.....	20

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see www.iso.org/patents).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation on the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the WTO principles in the Technical Barriers to Trade (TBT) see the following URL: [Foreword - Supplementary information](#)

The committee responsible for this document is ISO/TC45, *Rubber and rubber products*, Subcommittee SC 2, *Testing and analysis*.

This fourth edition cancels and replaces the third edition (ISO 6502:1999), of which it constitutes a minor revision. The references have been updated.

Introduction

In this International Standard, it became clear that a number of different curemeters were available and that significant developments had taken place, especially with the rotorless types. Rather than specify individual rotorless instruments, possibly restricting future developments, it was felt that a more general document was required. Accordingly, it was decided to provide guidance and assistance in the design and use of curemeters generally.

iTeh STANDARD PREVIEW
(standards.iteh.ai)
Full standard:
<https://standards.iteh.ai/catalog/standards/sist/1fe7ec37-fbce-4fcc-8d6e-b885e5a05f2f/iso-6502-2016>

iTeh STANDARD PREVIEW
(standards.iteh.ai)

Full standard:
<https://standards.iteh.ai/catalog/standards/sist/1fe7ec37-fbce-4fcc-8d6e-b885e5a0592f/iso-6502-2016>

Rubber — Guide to the use of curemeters

WARNING — Persons using this International Standard should be familiar with normal laboratory practice. This International Standard does not purport to address all of the safety problems, if any, associated with its use. It is the responsibility of the user to establish appropriate safety and health practices and to ensure compliance with any national regulatory conditions.

1 Scope

This International Standard provides guidance on the determination of vulcanization characteristics of rubber compounds by means of curemeters.

2 Normative references

The following documents, in whole or in part, are normatively referenced in this document and are indispensable for its application. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 1382, *Rubber — Vocabulary*

3 Terms and definitions

For the purposes of this document, the terms and definitions given in ISO 1382 and the following apply.

3.1 oscillating-disc curemeter ODC

curemeter consisting of a biconical disc oscillated within a temperature-controlled die cavity containing the test piece

Note 1 to entry: An oscillating-disc curemeter is also known as an oscillating disc rheometer (ODR).

3.2 rotorless curemeter RCM

curemeter consisting of two dies forming a temperature-controlled cavity, one of which is moved relative to the other to apply a stress or strain to the test piece

Note 1 to entry: A rotorless curemeter is also known as a moving die rheometer (MDR).

Note 2 to entry: Types of rotorless curemeter are listed in [Clause 5](#) and illustrated in [Figure 3](#) to [Figure 7](#).

3.3 marching-modulus cure

type of vulcanization during which the modulus does not reach a maximum value but, after a rapid rise, continues to rise slowly at the vulcanization temperature

3.4 vulcanization characteristics

characteristics which may be taken from a vulcanization curve

Note 1 to entry: See [Figure 1](#).

Note 2 to entry: More explanations are given in [Clause 4](#).

**3.5
stiffness**

measure of the resistance offered by rubber to deformation

Note 1 to entry: Force and torque have not been defined since they have a generally accepted scientific meaning.

4 Basic principles

The properties of a rubber compound change during the course of vulcanization, and the vulcanization characteristics can be determined by measuring properties as a function of time and temperature. Vulcanization characteristics are most commonly determined using instruments known as curemeters in which a cyclic stress or strain is applied to a test piece and the associated strain or force is measured. Normally, the test is carried out at a predetermined constant temperature and the measure of stiffness recorded continuously as a function of time.

The stiffness of the rubber increases as vulcanization proceeds. Vulcanization is complete when the recorded stiffness rises to a plateau value or to a maximum and then declines (see [Figure 1](#)). In the latter case, the decrease in stiffness is caused by reversion. In cases where the recorded stiffness continues to rise (marching-modulus cure), vulcanization is deemed to be complete after a specified time. The time required to obtain a vulcanization curve is a function of the test temperature and the characteristics of the rubber compound. Curves analogous to [Figure 1](#) are obtained for a curemeter in which strain is measured.

The following vulcanization characteristics can be taken from the measure of stiffness against time curve ([Figure 1](#)):

Minimum force or torque	F_L or M_L
Force or torque at a specified time t	F_t or M_t
Scorch time (time to incipient cure)	t_{sx}
Time to a percentage y of full cure from minimum force or torque	$t'_c(y)$
Plateau force or torque	F_{HF} or M_{HF}
Maximum force or torque (reverting cure)	F_{HR} or M_{HR}
Force or torque value attained after a specified time (marching-modulus cure)	F_H or M_H


The minimum force or torque F_L or M_L characterizes the stiffness of the unvulcanized compound at the curing temperature.

The scorch time (time to incipient cure) t_{sx} is a measure of the processing safety of the compound.


The time $t'_c(y)$ and the corresponding forces or torques give information on the progress of cure. The optimum cure is often taken as $t'_c(90)$.

The highest force or torque is a measure of the stiffness of the vulcanized rubber at the curing temperature.

NOTE The term F denotes force and the term M denotes torque.



a) Vulcanization curve F or $M = f(t)$



b) Method of evaluation

Key

- 1 sinusoidal curve
- 2 envelope curve
- 3 vulcanization curve with steady increase to F_H or M_H at time t_e at end of test (marching-modulus cure)
- 4 vulcanization curve with plateau at F_{HF} or M_{HF} (plateau cure)
- 5 vulcanization curve with maximum F_{HR} or M_{HR} at time t_{max} (reverting cure)

Figure 1 — Typical vulcanization curve and method of evaluation

5 Types of curemeter

Three types of curemeters have found widespread use:

- oscillating-disc;
- reciprocating-paddle;
- rotorless.

The reciprocating-paddle type was popular, but is now much less used and is not considered further in this International Standard.

Rotorless curemeters can be subdivided into three forms:

- reciprocating (linear strain);
- oscillating (torsion) unsealed cavity;
- oscillating (torsion) sealed cavity.

Oscillating types may have a biconical die, a flat-plate die or be of top-hat section.

Other geometries are possible, for example with a vibrating probe or needle.

The oscillating-disc curemeter has for many years been the most widely used type of instrument, recently the rotorless type of curemeter has increased greatly in popularity. The principal advantages of the rotorless type are that the specified temperature is reached in a shorter time after insertion of the test piece into the die cavity and there is better temperature distribution in the test piece (see [Annex A](#)).

6 Apparatus

6.1 General

A curemeter consists of two heated dies with means of closing them under a specified force to form a die cavity containing the test piece, a means of oscillating a rotor within the cavity, or alternatively oscillating or reciprocating one of the dies relative to the other, and a means of measuring and recording the force or torque required to produce the relative movement, or the movement produced by a given applied force or torque. In addition, with sealed rotorless torsion systems, reaction torque on the stationary die opposite the moving die may be measured.

The general arrangements for oscillating-disc and rotorless curemeters are shown in [Figure 2](#) to [Figure 7](#).

6.2 Die cavity

The dies should be manufactured from a non-deforming material. The surface of the dies should minimize the effect of contamination and be hard so as to prevent wear. A minimum Rockwell hardness of 50 HRC, or equivalent, is recommended. The tolerances necessary on the dimensions of the dies will depend on the particular design, but as a general guide the dimensions of the cavity should be controlled to $\pm 0,2\%$.

The top and bottom surfaces of the cavity should have a pattern of grooves of dimensions sufficient to prevent slippage of the rubber test piece.

Holes should be provided in both the upper and lower dies to accommodate temperature sensors. The positions of the sensors relative to the cavity should be controlled to ensure reproducible response.

In the case of oscillating-disc instruments, one die requires a central hole to allow insertion of the die stem. A seal of suitable low, constant friction should be provided in this hole to prevent material leaking from the cavity.