

ETSI TS 138 331 V17.4.0 (2023-05)



5G;
NR;
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 38.331 version 17.4.0 Release 17)

<https://standards.iteh.ai/catalog/standards/sist/d585f820-3853-4a9b-9cau-852ed3c0f927/etsi-ts-138-331-v17-4-0-2023-05>



ReferenceRTS/TSGR-0238331vh40

Keywords5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<https://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://standards-portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2023.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found under <https://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	24
1 Scope	25
2 References	25
3 Definitions, symbols and abbreviations	28
3.1 Definitions	28
3.2 Abbreviations	30
4 General	32
4.1 Introduction	32
4.2 Architecture	33
4.2.1 UE states and state transitions including inter RAT	33
4.2.2 Signalling radio bearers	36
4.3 Services	36
4.3.1 Services provided to upper layers	36
4.3.2 Services expected from lower layers	37
4.4 Functions	37
5 Procedures	38
5.1 General	38
5.1.1 Introduction.....	38
5.1.2 General requirements.....	38
5.1.3 Requirements for UE in MR-DC	39
5.2 System information	39
5.2.1 Introduction.....	39
5.2.2 System information acquisition	40
5.2.2.1 General UE requirements	40
5.2.2.2 SIB validity and need to (re)-acquire SIB	41
5.2.2.2.1 SIB validity.....	41
5.2.2.2.2 SI change indication and PWS notification	42
5.2.2.3 Acquisition of System Information	43
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i>	43
5.2.2.3.2 Acquisition of an SI message	44
5.2.2.3.3 Request for on demand system information	46
5.2.2.3.3a Request for on demand positioning system information	47
5.2.2.3.4 Actions related to transmission of <i>RRCSystemInfoRequest</i> message	48
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in <i>RRC_CONNECTED</i>	49
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message	49
5.2.2.4 Actions upon receipt of System Information	50
5.2.2.4.1 Actions upon reception of the <i>MIB</i>	50
5.2.2.4.2 Actions upon reception of the <i>SIB1</i>	50
5.2.2.4.3 Actions upon reception of <i>SIB2</i>	54
5.2.2.4.4 Actions upon reception of <i>SIB3</i>	55
5.2.2.4.5 Actions upon reception of <i>SIB4</i>	55
5.2.2.4.6 Actions upon reception of <i>SIB5</i>	56
5.2.2.4.7 Actions upon reception of <i>SIB6</i>	56
5.2.2.4.8 Actions upon reception of <i>SIB7</i>	56
5.2.2.4.9 Actions upon reception of <i>SIB8</i>	57
5.2.2.4.10 Actions upon reception of <i>SIB9</i>	58
5.2.2.4.11 Actions upon reception of <i>SIB10</i>	58
5.2.2.4.12 Actions upon reception of <i>SIB11</i>	58
5.2.2.4.13 Actions upon reception of <i>SIB12</i>	58
5.2.2.4.14 Actions upon reception of <i>SIB13</i>	59

5.2.2.4.15	Actions upon reception of <i>SIB14</i>	59
5.2.2.4.16	Actions upon reception of <i>SIBpos</i>	59
5.2.2.4.17	Actions upon reception of <i>SIB15</i>	59
5.2.2.4.18	Actions upon reception of <i>SIB16</i>	60
5.2.2.4.19	Actions upon reception of <i>SIB17</i>	60
5.2.2.4.20	Actions upon reception of <i>SIB18</i>	60
5.2.2.4.21	Actions upon reception of <i>SIB19</i>	60
5.2.2.4.22	Actions upon reception of <i>SIB20</i>	60
5.2.2.4.23	Actions upon reception of <i>SIB21</i>	60
5.2.2.5	Essential system information missing	60
5.2.2.6	T430 expiry	61
5.3	Connection control	61
5.3.1	Introduction	61
5.3.1.1	RRC connection control	61
5.3.1.2	AS Security	62
5.3.2	Paging	63
5.3.2.1	General	63
5.3.2.2	Initiation	63
5.3.2.3	Reception of the <i>Paging message</i> by the UE or <i>PagingRecord</i> by the L2 U2N Remote UE	64
5.3.3	RRC connection establishment	65
5.3.3.1	General	65
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	66
5.3.3.2	Initiation	66
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message	67
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE	68
5.3.3.5	Reception of the <i>RRCReject</i> by the UE	71
5.3.3.6	Cell re-selection or cell selection or relay (re)selection while T390, T300 or T302 is running (UE in RRC_IDLE)	71
5.3.3.7	T300 expiry	72
5.3.3.8	Abortion of RRC connection establishment	73
5.3.4	Initial AS security activation	74
5.3.4.1	General	74
5.3.4.2	Initiation	74
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE	74
5.3.5	RRC reconfiguration	75
5.3.5.1	General	75
5.3.5.2	Initiation	76
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE	77
5.3.5.4	Secondary cell group release	88
5.3.5.5	Cell Group configuration	89
5.3.5.5.1	General	89
5.3.5.5.2	Reconfiguration with sync	90
5.3.5.5.3	RLC bearer release	92
5.3.5.5.4	RLC bearer addition/modification	92
5.3.5.5.5	MAC entity configuration	93
5.3.5.5.6	RLF Timers & Constants configuration	93
5.3.5.5.7	SpCell Configuration	94
5.3.5.5.8	SCell Release	95
5.3.5.5.9	SCell Addition/Modification	95
5.3.5.5.10	BH RLC channel release	96
5.3.5.5.11	BH RLC channel addition/modification	96
5.3.5.5.12	Uu Relay RLC channel release	96
5.3.5.5.13	Uu Relay RLC channel addition/modification	97
5.3.5.6	Radio Bearer configuration	97
5.3.5.6.1	General	97
5.3.5.6.2	SRB release	97
5.3.5.6.3	SRB addition/modification	98
5.3.5.6.4	DRB release	100
5.3.5.6.5	DRB addition/modification	100
5.3.5.6.6	Multicast MRB release	103
5.3.5.6.7	Multicast MRB addition/modification	103

5.3.5.7	AS Security key update	104
5.3.5.8	Reconfiguration failure	105
5.3.5.8.1	Void	105
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i>	105
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure) or T420 expiry (Path switch failure)	107
5.3.5.9	Other configuration	109
5.3.5.9a	MUSIM gap configuration	113
5.3.5.10	MR-DC release	113
5.3.5.11	Full configuration	114
5.3.5.12	BAP configuration	116
5.3.5.12a	IAB Other Configuration	116
5.3.5.12a.1	IP address management	116
5.3.5.12a.1.1	IP Address Release	116
5.3.5.12a.1.2	IP Address Addition/Modification	116
5.3.5.13	Conditional Reconfiguration	118
5.3.5.13.1	General	118
5.3.5.13.2	Conditional reconfiguration removal	118
5.3.5.13.3	Conditional reconfiguration addition/modification	118
5.3.5.13.4	Conditional reconfiguration evaluation	119
5.3.5.13.4a	Conditional reconfiguration evaluation of SN initiated inter-SN CPC for EN-DC	120
5.3.5.13.5	Conditional reconfiguration execution	121
5.3.5.13a	SCG activation	121
5.3.5.13b	SCG deactivation	121
5.3.5.13b1	SCG activation without SN message	122
5.3.5.13c	FR2 UL gap configuration	122
5.3.5.13d	Application layer measurement configuration	123
5.3.5.14	Sidelink dedicated configuration	124
5.3.5.15	L2 U2N Relay UE configuration	126
5.3.5.15.1	General	126
5.3.5.15.2	L2 U2N Remote UE Release	126
5.3.5.15.3	L2 U2N Remote UE Addition/Modification	126
5.3.5.16	L2 U2N Remote UE configuration	127
5.3.6	Counter check	127
5.3.6.1	General	127
5.3.6.2	Initiation	127
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	128
5.3.7	RRC connection re-establishment	128
5.3.7.1	General	128
5.3.7.2	Initiation	129
5.3.7.3	Actions following cell selection while T311 is running	132
5.3.7.3a	Actions following relay selection while T311 is running	134
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message	135
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE	136
5.3.7.6	T311 expiry	137
5.3.7.7	T301 expiry or selected cell/L2 U2N Relay UE no longer suitable	138
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE	138
5.3.8	RRC connection release	138
5.3.8.1	General	138
5.3.8.2	Initiation	138
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE	138
5.3.8.4	T320 expiry	142
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i>	142
5.3.8.6	T346g expiry	142
5.3.9	RRC connection release requested by upper layers	143
5.3.9.1	General	143
5.3.9.2	Initiation	143
5.3.10	Radio link failure related actions	143
5.3.10.1	Detection of physical layer problems in RRC_CONNECTED	143
5.3.10.2	Recovery of physical layer problems	143
5.3.10.3	Detection of radio link failure	143
5.3.10.4	RLF cause determination	145
5.3.10.5	RLF report content determination	146

5.3.11	UE actions upon going to RRC_IDLE.....	150
5.3.12	UE actions upon PUCCH/SRS release request.....	151
5.3.13	RRC connection resume	152
5.3.13.1	General	152
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	153
5.3.13.1b	Conditions for initiating SDT.....	153
5.3.13.2	Initiation.....	154
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message	157
5.3.13.4	Reception of the <i>RRCResume</i> by the UE	158
5.3.13.5	Handling of failure to resume RRC Connection	163
5.3.13.6	Cell re-selection or cell selection or L2 U2N relay (re)selection while T390, T319 or T302 is running or SDT procedure is ongoing (UE in RRC_INACTIVE) or SRS transmission in RRC_INACTIVE is configured	165
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE.....	165
5.3.13.8	RNA update.....	165
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE	166
5.3.13.10	Reception of the <i>RRCReject</i> by the UE.....	166
5.3.13.11	Inability to comply with <i>RRCResume</i>	166
5.3.13.12	Inter RAT cell reselection	166
5.3.14	Unified Access Control.....	166
5.3.14.1	General	166
5.3.14.2	Initiation.....	167
5.3.14.3	Void.....	168
5.3.14.4	T302, T390 expiry or stop (Barring alleviation)	168
5.3.14.5	Access barring check.....	169
5.3.15	RRC connection reject.....	170
5.3.15.1	Initiation.....	170
5.3.15.2	Reception of the <i>RRCReject</i> by the UE.....	170
5.4	Inter-RAT mobility.....	171
5.4.1	Introduction.....	171
5.4.2	Handover to NR.....	171
5.4.2.1	General	171
5.4.2.2	Initiation.....	171
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE.....	172
5.4.3	Mobility from NR.....	172
5.4.3.1	General	172
5.4.3.2	Initiation.....	172
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE.....	172
5.4.3.4	Successful completion of the mobility from NR.....	173
5.4.3.5	Mobility from NR failure	173
5.5	Measurements.....	174
5.5.1	Introduction.....	174
5.5.2	Measurement configuration	177
5.5.2.1	General	177
5.5.2.2	Measurement identity removal.....	179
5.5.2.3	Measurement identity addition/modification	179
5.5.2.4	Measurement object removal	180
5.5.2.5	Measurement object addition/modification.....	180
5.5.2.6	Reporting configuration removal	182
5.5.2.7	Reporting configuration addition/modification.....	183
5.5.2.8	Quantity configuration	183
5.5.2.9	Measurement gap configuration.....	183
5.5.2.10	Reference signal measurement timing configuration	186
5.5.2.10a	RSSI measurement timing configuration	186
5.5.2.11	Measurement gap sharing configuration	187
5.5.3	Performing measurements	188
5.5.3.1	General	188
5.5.3.2	Layer 3 filtering	193
5.5.3.3	Derivation of cell measurement results.....	193
5.5.3.3a	Derivation of layer 3 beam filtered measurement	194
5.5.3.4	Derivation of L2 U2N Relay UE measurement results	194

5.5.4	Measurement report triggering	195
5.5.4.1	General	195
5.5.4.2	Event A1 (Serving becomes better than threshold)	201
5.5.4.3	Event A2 (Serving becomes worse than threshold)	202
5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell)	202
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	203
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2)	204
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell)	205
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold)	205
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	206
5.5.4.10	Event I1 (Interference becomes higher than threshold)	207
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold)	207
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold)	208
5.5.4.13	Void	208
5.5.4.14	Void	208
5.5.4.15	Event D1 (Distance between UE and referenceLocation1 is above threshold1 and distance between UE and referenceLocation2 is below threshold2)	208
5.5.4.16	CondEvent T1 (Time measured at UE is within a duration from threshold)	209
5.5.4.17	Event X1 (Serving L2 U2N Relay UE becomes worse than threshold1 and NR Cell becomes better than threshold2)	210
5.5.4.18	Event X2 (Serving L2 U2N Relay UE becomes worse than threshold)	210
5.5.4.19	Event Y1 (PCell becomes worse than threshold1 and candidate L2 U2N Relay UE becomes better than threshold2)	211
5.5.4.20	Event Y2 (Candidate L2 U2N Relay UE becomes better than threshold)	212
5.5.5	Measurement reporting	212
5.5.5.1	General	212
5.5.5.2	Reporting of beam measurement information	221
5.5.5.3	Sorting of cell measurement results	221
5.5.6	Location measurement indication	222
5.5.6.1	General	222
5.5.6.2	Initiation	222
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message	223
5.5a	Logged Measurements	224
5.5a.1	Logged Measurement Configuration	224
5.5a.1.1	General	224
5.5a.1.2	Initiation	224
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE	224
5.5a.1.4	T330 expiry	225
5.5a.2	Release of Logged Measurement Configuration	225
5.5a.2.1	General	225
5.5a.2.2	Initiation	225
5.5a.3	Measurements logging	225
5.5a.3.1	General	225
5.5a.3.2	Initiation	225
5.6	UE capabilities	228
5.6.1	UE capability transfer	228
5.6.1.1	General	228
5.6.1.2	Initiation	228
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	228
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE	229
5.6.1.5	Void	232
5.7	Other	232
5.7.1	DL information transfer	232
5.7.1.1	General	232
5.7.1.2	Initiation	232
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	232
5.7.1a	DL information transfer for MR-DC	233
5.7.1a.1	General	233
5.7.1a.2	Initiation	233
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message	233

5.7.2	UL information transfer	234
5.7.2.1	General	234
5.7.2.2	Initiation	234
5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message	234
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message	234
5.7.2a	UL information transfer for MR-DC	235
5.7.2a.1	General	235
5.7.2a.2	Initiation	235
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message	235
5.7.2b	UL transfer of IRAT information	235
5.7.2b.1	General	235
5.7.2b.2	Initiation	236
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	236
5.7.3	SCG failure information	236
5.7.3.1	General	236
5.7.3.2	Initiation	236
5.7.3.3	Failure type determination for (NG)EN-DC	237
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i>	238
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message	238
5.7.3a	EUTRA SCG failure information	241
5.7.3a.1	General	241
5.7.3a.2	Initiation	241
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message	241
5.7.3b	MCG failure information	242
5.7.3b.1	General	242
5.7.3b.2	Initiation	242
5.7.3b.3	Failure type determination	242
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message	243
5.7.3b.5	T316 expiry	244
5.7.4	UE Assistance Information	245
5.7.4.1	General	245
5.7.4.2	Initiation	245
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	252
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE	260
5.7.4.4	Relaxed measurement criterion for a stationary RedCap UE	261
5.7.4a	Void	261
5.7.5	Failure information	261
5.7.5.1	General	261
5.7.5.2	Initiation	262
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message	262
5.7.6	DL message segment transfer	262
5.7.6.1	General	262
5.7.6.2	Initiation	263
5.7.6.3	Reception of <i>DLDedicatedMessageSegment</i> by the UE	263
5.7.7	UL message segment transfer	263
5.7.7.1	General	263
5.7.7.2	Initiation	263
5.7.7.3	Actions related to transmission of <i>ULDedicatedMessageSegment</i> message	264
5.7.8	Idle/inactive Measurements	264
5.7.8.1	General	264
5.7.8.1a	Measurement configuration	264
5.7.8.2	Void	265
5.7.8.2a	Performing measurements	265
5.7.8.3	T331 expiry or stop	268
5.7.8.4	Cell re-selection or cell selection while T331 is running	268
5.7.9	Mobility history information	268
5.7.9.1	General	268
5.7.9.2	Initiation	268
5.7.10	UE Information	272
5.7.10.1	General	272
5.7.10.2	Initiation	272
5.7.10.3	Reception of the <i>UEInformationRequest</i> message	272

5.7.10.4	Actions upon successful completion of a random-access procedure or on completion of a request of on-demand system information.....	275
5.7.10.5	RA information determination	276
5.7.10.6	Actions for the successful handover report determination	279
5.7.12	IAB Other Information	282
5.7.12.1	General	282
5.7.12.2	Initiation	282
5.7.12.3	Actions related to transmission of <i>IABOtherInformation</i> message	282
5.7.13	RLM/BFD relaxation.....	284
5.7.13.1	Relaxed measurement criterion for low mobility	284
5.7.13.2	Relaxed measurement criterion for good serving cell quality	284
5.7.14	UE Positioning Assistance Information.....	285
5.7.14.1	General	285
5.7.14.2	Initiation.....	285
5.7.14.3	Actions related to transmission of <i>UEPositioningAssistanceInfo</i> message.....	285
5.7.15	Void	286
5.7.17	Derivation of pathloss reference for TA validation of SRS for Positioning transmission and CG-SDT in RRC_INACTIVE	287
5.8	Sidelink	287
5.8.1	General.....	287
5.8.2	Conditions for NR sidelink communication/discovery operation.....	288
5.8.3	Sidelink UE information for NR sidelink communication/discovery	289
5.8.3.1	General	289
5.8.3.2	Initiation.....	289
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message	294
5.8.4	Void	298
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication/discovery	298
5.8.5.1	General	298
5.8.5.2	Initiation.....	299
5.8.5.3	Transmission of SLSS.....	299
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication	301
5.8.5a.1	General	301
5.8.5a.2	Initiation.....	301
5.8.6	Sidelink synchronisation reference	301
5.8.6.1	General	301
5.8.6.2	Selection and reselection of synchronisation reference.....	302
5.8.6.3	Sidelink communication transmission reference cell selection	304
5.8.7	Sidelink communication reception	304
5.8.8	Sidelink communication transmission	305
5.8.9	Sidelink RRC procedure	307
5.8.9.1	Sidelink RRC reconfiguration.....	307
5.8.9.1.1	General	307
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message.....	308
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE.....	309
5.8.9.1.4	Void	311
5.8.9.1.5	Void	311
5.8.9.1.6	Void	311
5.8.9.1.7	Void	311
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE.....	311
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE	311
5.8.9.1a	Sidelink radio bearer management.....	312
5.8.9.1a.1	Sidelink DRB release	312
5.8.9.1a.2	Sidelink DRB addition/modification	313
5.8.9.1a.3	Sidelink SRB release	314
5.8.9.1a.4	Sidelink SRB addition	315
5.8.9.2	Sidelink UE capability transfer	315
5.8.9.2.1	General	315
5.8.9.2.2	Initiation.....	315
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE	315
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE.....	316
5.8.9.3	Sidelink radio link failure related actions.....	316
5.8.9.4	Sidelink common control information	317

5.8.9.4.1	General	317
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message	317
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message	317
5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers	318
5.8.9.6	Sidelink UE assistance information	319
5.8.9.6.1	General	319
5.8.9.6.2	Initiation	319
5.8.9.6.3	Actions related to reception of <i>UEAssistanceInformationSidelink</i> message	319
5.8.9.8	Remote UE information	320
5.8.9.8.1	General	320
5.8.9.8.2	Actions related to transmission of <i>RemoteUEInformationSidelink</i> message	321
5.8.9.8.3	Reception of <i>RemoteUEInformationSidelink</i> message by the L2 U2N Relay UE	321
5.8.9.9	Uu message transfer in sidelink	322
5.8.9.9.1	General	322
5.8.9.9.2	Actions related to transmission of <i>UuMessageTransferSidelink</i> message	322
5.8.9.9.3	Reception of the <i>UuMessageTransferSidelink</i>	323
5.8.9.10	Notification Message	323
5.8.9.10.1	General	323
5.8.9.10.2	Initiation	323
5.8.9.10.3	Actions related to transmission of <i>NotificationMessageSidelink</i> message	323
5.8.9.10.4	Actions related to reception of <i>NotificationMessageSidelink</i> message	324
5.8.10	Sidelink measurement	324
5.8.10.1	Introduction	324
5.8.10.2	Sidelink measurement configuration	325
5.8.10.2.1	General	325
5.8.10.2.2	Sidelink measurement identity removal	325
5.8.10.2.3	Sidelink measurement identity addition/modification	326
5.8.10.2.4	Sidelink measurement object removal	326
5.8.10.2.5	Sidelink measurement object addition/modification	326
5.8.10.2.6	Sidelink reporting configuration removal	327
5.8.10.2.7	Sidelink reporting configuration addition/modification	327
5.8.10.2.8	Sidelink quantity configuration	327
5.8.10.3	Performing NR sidelink measurements	328
5.8.10.3.1	General	328
5.8.10.3.2	Derivation of NR sidelink measurement results	328
5.8.10.4	Sidelink measurement report triggering	328
5.8.10.4.1	General	328
5.8.10.4.2	Event S1 (Serving becomes better than threshold)	329
5.8.10.4.3	Event S2 (Serving becomes worse than threshold)	330
5.8.10.5	Sidelink measurement reporting	330
5.8.10.5.1	General	330
5.8.11	Zone identity calculation	331
5.8.12	DFN derivation from GNSS	331
5.9	MBS Broadcast	337
5.9.1	Introduction	337
5.9.1.1	General	337
5.9.1.2	MCCH scheduling	337
5.9.1.3	MCCH information validity and notification of changes	338
5.9.2	MCCH information acquisition	338
5.9.2.1	General	338
5.9.2.2	Initiation	338
5.9.2.3	MCCH information acquisition by the UE	339
5.9.2.4	Actions upon reception of the <i>MBSBroadcastConfiguration</i> message	339
5.9.3	Broadcast MRB configuration	339
5.9.3.1	General	339
5.9.3.2	Initiation	339
5.9.3.3	Broadcast MRB establishment	340
5.9.3.4	Broadcast MRB release	340
5.9.4	MBS Interest Indication	340
5.9.4.1	General	340
5.9.4.2	Initiation	340
5.9.4.3	MBS frequencies of interest determination	341

5.9.4.4	MBS services of interest determination	342
5.9.4.5	Setting of the contents of MBS Interest Indication	342
6	Protocol data units, formats and parameters (ASN.1)	343
6.1	General	343
6.1.1	Introduction.....	343
6.1.2	Need codes and conditions for optional fields.....	343
6.1.3	General rules.....	346
6.2	RRC messages	346
6.2.1	General message structure	346
–	NR-RRC-Definitions.....	346
–	BCCH-BCH-Message	346
–	BCCH-DL-SCH-Message	347
–	DL-CCCH-Message	347
–	DL-DCCH-Message	348
–	MCCH-Message	348
–	PCCH-Message.....	349
–	UL-CCCH-Message	349
–	UL-CCCH1-Message	350
–	UL-DCCH-Message.....	350
6.2.2	Message definitions	352
–	CounterCheck.....	352
–	CounterCheckResponse.....	353
–	DedicatedSIBRequest.....	354
–	DLDedicatedMessageSegment.....	355
–	DLInformationTransfer	356
–	DLInformationTransferMRDC.....	357
–	FailureInformation.....	358
–	IABOtherInformation	359
–	LocationMeasurementIndication	362
–	LoggedMeasurementConfiguration	363
–	MBSBroadcastConfiguration	365
–	MBSInterestIndication	366
–	MCGFailureInformation.....	367
–	MeasurementReport	369
–	MeasurementReportAppLayer	369
–	MIB	371
–	MobilityFromNRCommand.....	372
–	Paging	374
–	RRCReestablishment	375
–	RRCReestablishmentComplete	376
–	RRCReestablishmentRequest	377
–	RRCReconfiguration	378
–	RRCReconfigurationComplete	385
–	RRCReject	387
–	RRCRelease.....	388
–	RRCResume.....	397
–	RRCResumeComplete	400
–	RRCResumeRequest	401
–	RRCResumeRequest1	402
–	RRCSetup	403
–	RRCSetupComplete	404
–	RRCSetupRequest.....	406
–	RRCSystemInfoRequest.....	407
–	SCGFailureInformation	409
–	SCGFailureInformationEUTRA.....	410
–	SecurityModeCommand	411
–	SecurityModeComplete	412
–	SecurityModeFailure.....	413
–	SIB1	414
–	SidelinkUEInformationNR	419
–	SystemInformation	424

–	<i>UEAssistanceInformation</i>	425
–	<i>UECapabilityEnquiry</i>	434
–	<i>UECapabilityInformation</i>	435
–	<i>UEInformationRequest</i>	436
–	<i>UEInformationResponse</i>	437
–	<i>UEPositioningAssistanceInfo</i>	452
–	<i>ULDedicatedMessageSegment</i>	454
–	<i>ULInformationTransfer</i>	455
–	<i>ULInformationTransferIRAT</i>	455
–	<i>ULInformationTransferMRDC</i>	456
6.3	RRC information elements	457
6.3.0	Parameterized types	457
–	<i>SetupRelease</i>	457
6.3.1	System information blocks	458
–	<i>SIB2</i>	458
–	<i>SIB3</i>	463
–	<i>SIB4</i>	465
–	<i>SIB5</i>	471
–	<i>SIB6</i>	474
–	<i>SIB7</i>	474
–	<i>SIB8</i>	475
–	<i>SIB9</i>	476
–	<i>SIB10</i>	477
–	<i>SIB11</i>	478
–	<i>SIB12</i>	478
–	<i>SIB13</i>	480
–	<i>SIB14</i>	481
–	<i>SIB15</i>	482
–	<i>SIB16</i>	482
–	<i>SIB17</i>	483
–	<i>SIB18</i>	485
–	<i>SIB20</i>	487
–	<i>SIB21</i>	488
6.3.1a	Positioning System information blocks	489
–	<i>PosSystemInformation-r16-IEs</i>	489
–	<i>PosSI-SchedulingInfo</i>	490
–	<i>SIBpos</i>	493
6.3.2	Radio resource control information elements	493
–	<i>AdditionalSpectrumEmission</i>	493
–	<i>Alpha</i>	493
–	<i>AMF-Identifier</i>	494
–	<i>ARFCN-ValueEUTRA</i>	494
–	<i>ARFCN-ValueNR</i>	494
–	<i>ARFCN-ValueUTRA-FDD</i>	495
–	<i>AvailabilityCombinationsPerCell</i>	495
–	<i>AvailabilityIndicator</i>	497
–	<i>BAP-RoutingID</i>	497
–	<i>BeamFailureRecoveryConfig</i>	498
–	<i>BeamFailureRecoveryRSConfig</i>	501
–	<i>BetaOffsets</i>	502
–	<i>BetaOffsetsCrossPri</i>	503
–	<i>BH-LogicalChannelIdentity</i>	503
–	<i>BH-LogicalChannelIdentity-Ext</i>	504
–	<i>BH-RLC-ChannelConfig</i>	504
–	<i>BH-RLC-ChannelID</i>	505
–	<i>BSR-Config</i>	505
–	<i>BWP</i>	506
–	<i>BWP-Downlink</i>	507
–	<i>BWP-DownlinkCommon</i>	508
–	<i>BWP-DownlinkDedicated</i>	508
–	<i>BWP-Id</i>	511
–	<i>BWP-Uplink</i>	511

–	BWP-UplinkCommon	512
–	BWP-UplinkDedicated	515
–	CandidateBeamRS	518
–	CellAccessRelatedInfo	519
–	CellAccessRelatedInfo-EUTRA-5GC	521
–	CellAccessRelatedInfo-EUTRA-EPC	521
–	CellGroupConfig	522
–	CellGroupId	532
–	CellIdentity	532
–	CellReselectionPriority	532
–	CellReselectionSubPriority	533
–	CFR-ConfigMulticast	533
–	CGI-InfoEUTRA	534
–	CGI-InfoEUTRALogging	534
–	CGI-InfoNR	535
–	CGI-Info-Logging	536
–	CLI-RSSI-Range	537
–	CodebookConfig	537
–	CommonLocationInfo	543
–	CondReconfigId	543
–	CondReconfigToAddModList	544
–	ConditionalReconfiguration	545
–	ConfiguredGrantConfig	545
–	ConfiguredGrantConfigIndex	554
–	ConfiguredGrantConfigIndexMAC	555
–	ConnEstFailureControl	555
–	ControlResourceSet	556
–	ControlResourceSetId	558
–	ControlResourceSetZero	558
–	CrossCarrierSchedulingConfig	559
–	CSI-AperiodicTriggerStateList	560
–	CSI-FrequencyOccupation	563
–	CSI-IM-Resource	563
–	CSI-IM-ResourceId	564
–	CSI-IM-ResourceSet	565
–	CSI-IM-ResourceSetId	565
–	CSI-MeasConfig	565
–	CSI-ReportConfig	567
–	CSI-ReportConfigId	574
–	CSI-ResourceConfig	575
–	CSI-ResourceConfigId	576
–	CSI-ResourcePeriodicityAndOffset	577
–	CSI-RS-ResourceConfigMobility	577
–	CSI-RS-ResourceMapping	580
–	CSI-SemiPersistentOnPUSCH-TriggerStateList	581
–	CSI-SSB-ResourceSet	582
–	CSI-SSB-ResourceSetId	583
–	DedicatedNAS-Message	583
–	DL-PPW-PreConfig	583
–	DMRS-BundlingPUCCH-Config	586
–	DMRS-BundlingPUSCH-Config	587
–	DMRS-DownlinkConfig	588
–	DMRS-UplinkConfig	589
–	DownlinkConfigCommon	591
–	DownlinkConfigCommonSIB	592
–	DownlinkPreemption	596
–	DRB-Identity	597
–	DRX-Config	597
–	DRX-ConfigSecondaryGroup	599
–	DRX-ConfigSL	600
–	EphemerisInfo	601
–	FeatureCombination	602

FeatureCombinationPreambles	603
FilterCoefficient	606
FreqBandIndicatorNR.....	606
FreqPriorityListDedicatedSlicing	606
FreqPriorityListSlicing	607
FrequencyInfoDL	608
FrequencyInfoDL-SIB.....	609
FrequencyInfoUL	610
FrequencyInfoUL-SIB.....	611
GapPriority	612
HighSpeedConfig	613
Hysteresis	614
HysteresisLocation.....	615
InvalidSymbolPattern.....	615
I-RNTI-Value.....	616
LBT-FailureRecoveryConfig	616
LocationInfo	617
LocationMeasurementInfo	617
LogicalChannelConfig	619
LogicalChannelIdentity.....	622
LTE-NeighCellsCRS-AssistInfoList.....	622
MAC-CellGroupConfig	624
MeasConfig	627
MeasGapConfig	629
MeasGapId.....	633
MeasGapSharingConfig.....	634
MeasId.....	635
MeasIdleConfig.....	635
MeasIdToAddModList.....	638
MeasObjectCLI	638
MeasObjectEUTRA	641
MeasObjectId	643
MeasObjectNR	643
MeasObjectNR-SL	651
MeasObjectRxTxDiff.....	651
MeasObjectToAddModList	652
MeasObjectUTRA-FDD.....	652
MeasResultCellListSFTD-NR.....	653
MeasResultCellListSFTD-EUTRA	654
MeasResults	654
MeasResult2EUTRA.....	661
MeasResult2NR.....	661
MeasResultIdleEUTRA	662
MeasResultIdleNR.....	663
MeasResultRxTxTimeDiff.....	664
MeasResultSCG-Failure	665
MeasResultsSL	665
MeasTriggerQuantityEUTRA.....	666
MobilityStateParameters.....	666
MRB-Identity.....	667
MsgA-ConfigCommon.....	667
MsgA-PUSCH-Config.....	668
MultiFrequencyBandListNR.....	671
MultiFrequencyBandListNR-SIB	672
MUSIM-GapConfig.....	672
MUSIM-GapId	673
MUSIM-GapInfo	674
NeedForGapsConfigNR	675
NeedForGapNCSG-ConfigEUTRA.....	676
NeedForGapNCSG-ConfigNR	677
NeedForGapNCSG-InfoEUTRA	677
NeedForGapNCSG-InfoNR.....	678