

ETSI TS 138 331 V17.8.0 (2024-05)



**5G;
NR;
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 38.331 version 17.8.0 Release 17)**

[ETSI TS 138 331 V17.8.0 \(2024-05\)](https://standards.iteh.ai/catalog/standards/etsi/894a5efe-8d29-4faf-8f1e-58d39477f3cb/etsi-ts-138-331-v17-8-0-2024-05)

<https://standards.iteh.ai/catalog/standards/etsi/894a5efe-8d29-4faf-8f1e-58d39477f3cb/etsi-ts-138-331-v17-8-0-2024-05>



ReferenceRTS/TSGR-0238331vh80

Keywords5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from:

<https://www.etsi.org/standards-search>

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format at www.etsi.org/deliver.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<https://portal.etsi.org/TB/ETSIDeliverableStatus.aspx>

If you find errors in the present document, please send your comment to one of the following services:

<https://portal.etsi.org/People/CommitteeSupportStaff.aspx>

If you find a security vulnerability in the present document, please report it through our

Coordinated Vulnerability Disclosure Program:

<https://www.etsi.org/standards/coordinated-vulnerability-disclosure>

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2024.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (<https://ipr.etsi.org/>).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™** and **LTE™** are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables. (2024-05)

The cross reference between 3GPP and ETSI identities can be found under <https://webapp.etsi.org/key/queryform.asp>.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	24
1 Scope	25
2 References	25
3 Definitions, symbols and abbreviations	28
3.1 Definitions	28
3.2 Abbreviations	30
4 General	32
4.1 Introduction	32
4.2 Architecture	33
4.2.1 UE states and state transitions including inter RAT	33
4.2.2 Signalling radio bearers	36
4.3 Services	36
4.3.1 Services provided to upper layers.....	36
4.3.2 Services expected from lower layers	37
4.4 Functions	37
5 Procedures	38
5.1 General	38
5.1.1 Introduction.....	38
5.1.2 General requirements.....	38
5.1.3 Requirements for UE in MR-DC	39
5.2 System information	39
5.2.1 Introduction.....	39
5.2.2 System information acquisition	40
5.2.2.1 General UE requirements.....	40
5.2.2.2 SIB validity and need to (re)-acquire SIB	41
5.2.2.2.1 SIB validity.....	41
5.2.2.2.2 SI change indication and PWS notification	42
5.2.2.3 Acquisition of System Information	43
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i>	43
5.2.2.3.2 Acquisition of an SI message	44
5.2.2.3.3 Request for on demand system information	46
5.2.2.3.3a Request for on demand positioning system information	47
5.2.2.3.4 Actions related to transmission of <i>RRCSystemInfoRequest</i> message	48
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in <i>RRC_CONNECTED</i>	49
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message	49
5.2.2.4 Actions upon receipt of System Information	50
5.2.2.4.1 Actions upon reception of the <i>MIB</i>	50
5.2.2.4.2 Actions upon reception of the <i>SIB1</i>	50
5.2.2.4.3 Actions upon reception of <i>SIB2</i>	55
5.2.2.4.4 Actions upon reception of <i>SIB3</i>	55
5.2.2.4.5 Actions upon reception of <i>SIB4</i>	55
5.2.2.4.6 Actions upon reception of <i>SIB5</i>	56
5.2.2.4.7 Actions upon reception of <i>SIB6</i>	56
5.2.2.4.8 Actions upon reception of <i>SIB7</i>	57
5.2.2.4.9 Actions upon reception of <i>SIB8</i>	57
5.2.2.4.10 Actions upon reception of <i>SIB9</i>	58
5.2.2.4.11 Actions upon reception of <i>SIB10</i>	58
5.2.2.4.12 Actions upon reception of <i>SIB11</i>	58
5.2.2.4.13 Actions upon reception of <i>SIB12</i>	58
5.2.2.4.14 Actions upon reception of <i>SIB13</i>	60

5.2.2.4.15	Actions upon reception of <i>SIB14</i>	60
5.2.2.4.16	Actions upon reception of <i>SIBpos</i>	60
5.2.2.4.17	Actions upon reception of <i>SIB15</i>	60
5.2.2.4.18	Actions upon reception of <i>SIB16</i>	60
5.2.2.4.19	Actions upon reception of <i>SIB17</i>	60
5.2.2.4.20	Actions upon reception of <i>SIB18</i>	61
5.2.2.4.21	Actions upon reception of <i>SIB19</i>	61
5.2.2.4.22	Actions upon reception of <i>SIB20</i>	61
5.2.2.4.23	Actions upon reception of <i>SIB21</i>	61
5.2.2.5	Essential system information missing	61
5.2.2.6	T430 expiry	61
5.3	Connection control	62
5.3.1	Introduction	62
5.3.1.1	RRC connection control	62
5.3.1.2	AS Security	63
5.3.2	Paging	64
5.3.2.1	General	64
5.3.2.2	Initiation	64
5.3.2.3	Reception of the <i>Paging message</i> by the UE or <i>PagingRecord</i> by the L2 U2N Remote UE	64
5.3.3	RRC connection establishment	66
5.3.3.1	General	66
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	67
5.3.3.2	Initiation	67
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message	68
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE	69
5.3.3.5	Reception of the <i>RRCReject</i> by the UE	72
5.3.3.6	Cell re-selection or cell selection or relay (re)selection while T390, T300 or T302 is running (UE in RRC_IDLE)	72
5.3.3.7	T300 expiry	73
5.3.3.8	Abortion of RRC connection establishment	74
5.3.4	Initial AS security activation	75
5.3.4.1	General	75
5.3.4.2	Initiation	75
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE	75
5.3.5	RRC reconfiguration	76
5.3.5.1	General	76
5.3.5.2	Initiation	77
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE	77
5.3.5.4	Secondary cell group release	89
5.3.5.5	Cell Group configuration	89
5.3.5.5.1	General	89
5.3.5.5.2	Reconfiguration with sync	90
5.3.5.5.3	RLC bearer release	92
5.3.5.5.4	RLC bearer addition/modification	92
5.3.5.5.5	MAC entity configuration	94
5.3.5.5.6	RLF Timers & Constants configuration	94
5.3.5.5.7	SpCell Configuration	95
5.3.5.5.8	SCell Release	96
5.3.5.5.9	SCell Addition/Modification	96
5.3.5.5.10	BH RLC channel release	97
5.3.5.5.11	BH RLC channel addition/modification	97
5.3.5.5.12	Uu Relay RLC channel release	97
5.3.5.5.13	Uu Relay RLC channel addition/modification	98
5.3.5.6	Radio Bearer configuration	98
5.3.5.6.1	General	98
5.3.5.6.2	SRB release	98
5.3.5.6.3	SRB addition/modification	99
5.3.5.6.4	DRB release	101
5.3.5.6.5	DRB addition/modification	101
5.3.5.6.6	Multicast MRB release	104
5.3.5.6.7	Multicast MRB addition/modification	104

5.3.5.7	AS Security key update	105
5.3.5.8	Reconfiguration failure	106
5.3.5.8.1	Void	106
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i>	106
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure) or T420 expiry (Path switch failure)	108
5.3.5.9	Other configuration	110
5.3.5.9a	MUSIM gap configuration	114
5.3.5.10	MR-DC release	114
5.3.5.11	Full configuration	115
5.3.5.12	BAP configuration	117
5.3.5.12a	IAB Other Configuration	117
5.3.5.12a.1	IP address management	117
5.3.5.12a.1.1	IP Address Release	117
5.3.5.12a.1.2	IP Address Addition/Modification	117
5.3.5.13	Conditional Reconfiguration	119
5.3.5.13.1	General	119
5.3.5.13.2	Conditional reconfiguration removal	119
5.3.5.13.3	Conditional reconfiguration addition/modification	119
5.3.5.13.4	Conditional reconfiguration evaluation	120
5.3.5.13.4a	Conditional reconfiguration evaluation of SN initiated inter-SN CPC for EN-DC	121
5.3.5.13.5	Conditional reconfiguration execution	122
5.3.5.13a	SCG activation	122
5.3.5.13b	SCG deactivation	122
5.3.5.13b1	SCG activation without SN message	123
5.3.5.13c	FR2 UL gap configuration	123
5.3.5.13d	Application layer measurement configuration	124
5.3.5.14	Sidelink dedicated configuration	125
5.3.5.15	L2 U2N Relay UE configuration	127
5.3.5.15.1	General	127
5.3.5.15.2	L2 U2N Remote UE Release	127
5.3.5.15.3	L2 U2N Remote UE Addition/Modification	127
5.3.5.16	L2 U2N Remote UE Configuration	128
5.3.6	Counter check	128
5.3.6.1	General	128
5.3.6.2	Initiation	129
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	129
5.3.7	RRC connection re-establishment	129
5.3.7.1	General	129
5.3.7.2	Initiation	130
5.3.7.3	Actions following cell selection while T311 is running	133
5.3.7.3a	Actions following relay selection while T311 is running	135
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message	136
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE	137
5.3.7.6	T311 expiry	138
5.3.7.7	T301 expiry or selected cell/L2 U2N Relay UE no longer suitable	139
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE	139
5.3.8	RRC connection release	139
5.3.8.1	General	139
5.3.8.2	Initiation	139
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE	140
5.3.8.4	T320 expiry	144
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i>	144
5.3.8.6	T346g expiry	144
5.3.9	RRC connection release requested by upper layers	144
5.3.9.1	General	144
5.3.9.2	Initiation	144
5.3.10	Radio link failure related actions	144
5.3.10.1	Detection of physical layer problems in <i>RRC_CONNECTED</i>	144
5.3.10.2	Recovery of physical layer problems	145
5.3.10.3	Detection of radio link failure	145
5.3.10.4	RLF cause determination	147
5.3.10.5	RLF report content determination	147

5.3.11	UE actions upon going to RRC_IDLE.....	151
5.3.12	UE actions upon PUCCH/SRS release request.....	153
5.3.13	RRC connection resume	153
5.3.13.1	General	153
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/discovery/V2X sidelink communication	154
5.3.13.1b	Conditions for initiating SDT.....	155
5.3.13.2	Initiation.....	155
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message	159
5.3.13.4	Reception of the <i>RRCResume</i> by the UE	160
5.3.13.5	Handling of failure to resume RRC Connection	165
5.3.13.6	Cell re-selection or cell selection or L2 U2N relay (re)selection while T390, T319 or T302 is running or SDT procedure is ongoing (UE in RRC_INACTIVE) or SRS transmission in RRC_INACTIVE is configured	167
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE.....	167
5.3.13.8	RNA update.....	167
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE	168
5.3.13.10	Reception of the <i>RRCReject</i> by the UE.....	168
5.3.13.11	Inability to comply with <i>RRCResume</i>	168
5.3.13.12	Inter RAT cell reselection	168
5.3.14	Unified Access Control.....	168
5.3.14.1	General	168
5.3.14.2	Initiation.....	168
5.3.14.3	Void.....	170
5.3.14.4	T302, T390 expiry or stop (Barring alleviation)	170
5.3.14.5	Access barring check.....	171
5.3.15	RRC connection reject.....	172
5.3.15.1	Initiation.....	172
5.3.15.2	Reception of the <i>RRCReject</i> by the UE.....	172
5.4	Inter-RAT mobility.....	173
5.4.1	Introduction.....	173
5.4.2	Handover to NR.....	173
5.4.2.1	General	173
5.4.2.2	Initiation.....	173
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE	173
5.4.3	Mobility from NR.....	174
5.4.3.1	General	174
5.4.3.2	Initiation.....	174
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE.....	174
5.4.3.4	Successful completion of the mobility from NR.....	175
5.4.3.5	Mobility from NR failure	175
5.5	Measurements.....	176
5.5.1	Introduction.....	176
5.5.2	Measurement configuration	179
5.5.2.1	General	179
5.5.2.2	Measurement identity removal.....	180
5.5.2.3	Measurement identity addition/modification	181
5.5.2.4	Measurement object removal	182
5.5.2.5	Measurement object addition/modification.....	182
5.5.2.6	Reporting configuration removal	184
5.5.2.7	Reporting configuration addition/modification.....	185
5.5.2.8	Quantity configuration	185
5.5.2.9	Measurement gap configuration.....	185
5.5.2.10	Reference signal measurement timing configuration	187
5.5.2.10a	RSSI measurement timing configuration	188
5.5.2.11	Measurement gap sharing configuration	189
5.5.3	Performing measurements	189
5.5.3.1	General	189
5.5.3.2	Layer 3 filtering	194
5.5.3.3	Derivation of cell measurement results.....	195
5.5.3.3a	Derivation of layer 3 beam filtered measurement	196
5.5.3.4	Derivation of L2 U2N Relay UE measurement results	196

5.5.4	Measurement report triggering	196
5.5.4.1	General	196
5.5.4.2	Event A1 (Serving becomes better than threshold)	203
5.5.4.3	Event A2 (Serving becomes worse than threshold)	204
5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell)	204
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	205
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2)	205
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell)	206
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold)	207
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	208
5.5.4.10	Event I1 (Interference becomes higher than threshold)	208
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold)	209
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold)	209
5.5.4.13	Void	210
5.5.4.14	Void	210
5.5.4.15	Event D1 (Distance between UE and referenceLocation1 is above threshold1 and distance between UE and referenceLocation2 is below threshold2)	210
5.5.4.16	CondEvent T1 (Time measured at UE is within a duration from threshold)	211
5.5.4.17	Event X1 (Serving L2 U2N Relay UE becomes worse than threshold1 and NR Cell becomes better than threshold2)	211
5.5.4.18	Event X2 (Serving L2 U2N Relay UE becomes worse than threshold)	212
5.5.4.19	Event Y1 (PCell becomes worse than threshold1 and candidate L2 U2N Relay UE becomes better than threshold2)	213
5.5.4.20	Event Y2 (Candidate L2 U2N Relay UE becomes better than threshold)	213
5.5.5	Measurement reporting	214
5.5.5.1	General	214
5.5.5.2	Reporting of beam measurement information	222
5.5.5.3	Sorting of cell measurement results	223
5.5.6	Location measurement indication	224
5.5.6.1	General	224
5.5.6.2	Initiation	224
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message	225
5.5a	Logged Measurements	225
5.5a.1	Logged Measurement Configuration	225
5.5a.1.1	General	225
5.5a.1.2	Initiation	226
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE	226
5.5a.1.4	T330 expiry	226
5.5a.2	Release of Logged Measurement Configuration	227
5.5a.2.1	General	227
5.5a.2.2	Initiation	227
5.5a.3	Measurements logging	227
5.5a.3.1	General	227
5.5a.3.2	Initiation	227
5.6	UE capabilities	230
5.6.1	UE capability transfer	230
5.6.1.1	General	230
5.6.1.2	Initiation	230
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	230
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE	231
5.6.1.5	Void	234
5.7	Other	234
5.7.1	DL information transfer	234
5.7.1.1	General	234
5.7.1.2	Initiation	234
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	234
5.7.1a	DL information transfer for MR-DC	235
5.7.1a.1	General	235
5.7.1a.2	Initiation	235
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message	235

5.7.2	UL information transfer	236
5.7.2.1	General	236
5.7.2.2	Initiation	236
5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message	236
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message	236
5.7.2a	UL information transfer for MR-DC	237
5.7.2a.1	General	237
5.7.2a.2	Initiation	237
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message	237
5.7.2b	UL transfer of IRAT information	237
5.7.2b.1	General	237
5.7.2b.2	Initiation	238
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	238
5.7.3	SCG failure information	238
5.7.3.1	General	238
5.7.3.2	Initiation	238
5.7.3.3	Failure type determination for (NG)EN-DC	239
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i>	240
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message	240
5.7.3a	EUTRA SCG failure information	243
5.7.3a.1	General	243
5.7.3a.2	Initiation	243
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message	243
5.7.3b	MCG failure information	244
5.7.3b.1	General	244
5.7.3b.2	Initiation	244
5.7.3b.3	Failure type determination	244
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message	245
5.7.3b.5	T316 expiry	246
5.7.4	UE Assistance Information	247
5.7.4.1	General	247
5.7.4.2	Initiation	247
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	254
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE	262
5.7.4.4	Relaxed measurement criterion for a stationary RedCap UE	263
5.7.4a	Void	263
5.7.5	Failure information	263
5.7.5.1	General	263
5.7.5.2	Initiation	264
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message	264
5.7.6	DL message segment transfer	264
5.7.6.1	General	264
5.7.6.2	Initiation	265
5.7.6.3	Reception of <i>DLDedicatedMessageSegment</i> by the UE	265
5.7.7	UL message segment transfer	265
5.7.7.1	General	265
5.7.7.2	Initiation	265
5.7.7.3	Actions related to transmission of <i>ULDedicatedMessageSegment</i> message	266
5.7.8	Idle/inactive Measurements	266
5.7.8.1	General	266
5.7.8.1a	Measurement configuration	266
5.7.8.2	Void	267
5.7.8.2a	Performing measurements	267
5.7.8.3	T331 expiry or stop	270
5.7.8.4	Cell re-selection or cell selection while T331 is running	270
5.7.9	Mobility history information	270
5.7.9.1	General	270
5.7.9.2	Initiation	270
5.7.10	UE Information	274
5.7.10.1	General	274
5.7.10.2	Initiation	274
5.7.10.3	Reception of the <i>UEInformationRequest</i> message	274

5.7.10.4	Actions upon successful completion of a random-access procedure or on completion of a request of on-demand system information.....	277
5.7.10.5	RA information determination	278
5.7.10.6	Actions for the successful handover report determination	281
5.7.11	Void	284
5.7.12	IAB Other Information	284
5.7.12.1	General	284
5.7.12.2	Initiation	284
5.7.12.3	Actions related to transmission of <i>IABOtherInformation</i> message	284
5.7.13	RLM/BFD relaxation	286
5.7.13.1	Relaxed measurement criterion for low mobility	286
5.7.13.2	Relaxed measurement criterion for good serving cell quality	286
5.7.14	UE Positioning Assistance Information	287
5.7.14.1	General	287
5.7.14.2	Initiation	287
5.7.14.3	Actions related to transmission of <i>UEPositioningAssistanceInfo</i> message	287
5.7.15	Void	288
5.7.17	Derivation of pathloss reference for TA validation of SRS for Positioning transmission and CG-SDT in RRC_INACTIVE	289
5.8	Sidelink	289
5.8.1	General	289
5.8.2	Conditions for NR sidelink communication/discovery operation	290
5.8.3	Sidelink UE information for NR sidelink communication/discovery	291
5.8.3.1	General	291
5.8.3.2	Initiation	291
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message	296
5.8.4	Void	301
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication/discovery	301
5.8.5.1	General	301
5.8.5.2	Initiation	301
5.8.5.3	Transmission of SLSS	302
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication	303
5.8.5a.1	General	303
5.8.5a.2	Initiation	304
5.8.6	Sidelink synchronisation reference	304
5.8.6.1	General	304
5.8.6.2	Selection and reselection of synchronisation reference	304
5.8.6.3	Sidelink communication transmission reference cell selection	307
5.8.7	Sidelink communication reception	307
5.8.8	Sidelink communication transmission	307
5.8.9	Sidelink RRC procedure	310
5.8.9.1	Sidelink RRC reconfiguration	310
5.8.9.1.1	General	310
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message	311
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE	312
5.8.9.1.4	Void	314
5.8.9.1.5	Void	314
5.8.9.1.6	Void	314
5.8.9.1.7	Void	314
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE	314
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE	314
5.8.9.1a	Sidelink radio bearer management	315
5.8.9.1a.1	Sidelink DRB release	315
5.8.9.1a.2	Sidelink DRB addition/modification	316
5.8.9.1a.3	Sidelink SRB release	317
5.8.9.1a.4	Sidelink SRB addition	318
5.8.9.2	Sidelink UE capability transfer	318
5.8.9.2.1	General	318
5.8.9.2.2	Initiation	318
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE	318
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE	319
5.8.9.3	Sidelink radio link failure related actions	319

5.8.9.4	Sidelink common control information	320
5.8.9.4.1	General	320
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message	320
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message	320
5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers	321
5.8.9.6	Sidelink UE assistance information	322
5.8.9.6.1	General	322
5.8.9.6.2	Initiation	322
5.8.9.6.3	Actions related to reception of <i>UEAssistanceInformationSidelink</i> message	322
5.8.9.8	Remote UE information	323
5.8.9.8.1	General	323
5.8.9.8.2	Actions related to transmission of <i>RemoteUEInformationSidelink</i> message	324
5.8.9.8.3	Reception of <i>RemoteUEInformationSidelink</i> message by the L2 U2N Relay UE	324
5.8.9.9	Uu message transfer in sidelink	325
5.8.9.9.1	General	325
5.8.9.9.2	Actions related to transmission of <i>UuMessageTransferSidelink</i> message	325
5.8.9.9.3	Reception of the <i>UuMessageTransferSidelink</i>	326
5.8.9.10	Notification Message	326
5.8.9.10.1	General	326
5.8.9.10.2	Initiation	326
5.8.9.10.3	Actions related to transmission of <i>NotificationMessageSidelink</i> message	326
5.8.9.10.4	Actions related to reception of <i>NotificationMessageSidelink</i> message	327
5.8.10	Sidelink measurement	327
5.8.10.1	Introduction	327
5.8.10.2	Sidelink measurement configuration	328
5.8.10.2.1	General	328
5.8.10.2.2	Sidelink measurement identity removal	328
5.8.10.2.3	Sidelink measurement identity addition/modification	329
5.8.10.2.4	Sidelink measurement object removal	329
5.8.10.2.5	Sidelink measurement object addition/modification	329
5.8.10.2.6	Sidelink reporting configuration removal	330
5.8.10.2.7	Sidelink reporting configuration addition/modification	330
5.8.10.2.8	Sidelink quantity configuration	330
5.8.10.3	Performing NR sidelink measurements	331
5.8.10.3.1	General	331
5.8.10.3.2	Derivation of NR sidelink measurement results	331
5.8.10.4	Sidelink measurement report triggering	331
5.8.10.4.1	General	331
5.8.10.4.2	Event S1 (Serving becomes better than threshold)	332
5.8.10.4.3	Event S2 (Serving becomes worse than threshold)	333
5.8.10.5	Sidelink measurement reporting	333
5.8.10.5.1	General	333
5.8.11	Zone identity calculation	334
5.8.12	DFN derivation from GNSS	334
5.8.13	NR sidelink discovery	335
5.8.13.1	General	335
5.8.13.2	NR sidelink discovery monitoring	335
5.8.13.3	NR sidelink discovery transmission	336
5.8.14	NR sidelink U2N Relay UE operation	338
5.8.14.1	General	338
5.8.15	NR sidelink U2N Remote UE operation	339
5.8.15.1	General	339
5.8.15.2	NR Sidelink U2N Remote UE threshold conditions	339
5.8.15.3	Selection and reselection of NR sidelink U2N Relay UE	339
5.9	MBS Broadcast	340
5.9.1	Introduction	340
5.9.1.1	General	340
5.9.1.2	MCCH scheduling	341
5.9.1.3	MCCH information validity and notification of changes	341
5.9.2	MCCH information acquisition	341
5.9.2.1	General	341
5.9.2.2	Initiation	342

5.9.2.3	MCCH information acquisition by the UE.....	342
5.9.2.4	Actions upon reception of the <i>MBSBroadcastConfiguration</i> message	342
5.9.3	Broadcast MRB configuration	342
5.9.3.1	General	342
5.9.3.2	Initiation	343
5.9.3.3	Broadcast MRB establishment	343
5.9.3.4	Broadcast MRB release	343
5.9.4	MBS Interest Indication	343
5.9.4.1	General	343
5.9.4.2	Initiation	344
5.9.4.3	MBS frequencies of interest determination	344
5.9.4.4	MBS services of interest determination	345
5.9.4.5	Setting of the contents of MBS Interest Indication	345
6	Protocol data units, formats and parameters (ASN.1)	346
6.1	General	346
6.1.1	Introduction	346
6.1.2	Need codes and conditions for optional fields	346
6.1.3	General rules	349
6.2	RRC messages	349
6.2.1	General message structure	349
–	<i>NR-RRC-Definitions</i>	349
–	<i>BCCH-BCH-Message</i>	349
–	<i>BCCH-DL-SCH-Message</i>	350
–	<i>DL-CCCH-Message</i>	350
–	<i>DL-DCCH-Message</i>	351
–	<i>MCCH-Message</i>	351
–	<i>PCCH-Message</i>	352
–	<i>UL-CCCH-Message</i>	352
–	<i>UL-CCCH1-Message</i>	353
–	<i>UL-DCCH-Message</i>	353
6.2.2	Message definitions	355
–	<i>CounterCheck</i>	355
–	<i>CounterCheckResponse</i>	356
–	<i>DedicatedSIBRequest</i>	357
–	<i>DLDedicatedMessageSegment</i>	358
–	<i>DLInformationTransfer</i>	359
–	<i>DLInformationTransferMRDC</i>	361
–	<i>FailureInformation</i>	362
–	<i>IABOtherInformation</i>	363
–	<i>LocationMeasurementIndication</i>	365
–	<i>LoggedMeasurementConfiguration</i>	366
–	<i>MBSBroadcastConfiguration</i>	368
–	<i>MBSInterestIndication</i>	369
–	<i>MCGFailureInformation</i>	370
–	<i>MeasurementReport</i>	372
–	<i>MeasurementReportAppLayer</i>	372
–	<i>MIB</i>	374
–	<i>MobilityFromNRCommand</i>	375
–	<i>Paging</i>	377
–	<i>RRCReestablishment</i>	378
–	<i>RRCReestablishmentComplete</i>	379
–	<i>RRCReestablishmentRequest</i>	380
–	<i>RRCReconfiguration</i>	381
–	<i>RRCReconfigurationComplete</i>	388
–	<i>RRCReject</i>	390
–	<i>RRCRelease</i>	391
–	<i>RRCResume</i>	400
–	<i>RRCResumeComplete</i>	403
–	<i>RRCResumeRequest</i>	404
–	<i>RRCResumeRequest1</i>	405
–	<i>RRCSetup</i>	406

–	<i>RRCSetupComplete</i>	407
–	<i>RRCSetupRequest</i>	409
–	<i>RRCSystemInfoRequest</i>	410
–	<i>SCGFailureInformation</i>	412
–	<i>SCGFailureInformationEUTRA</i>	413
–	<i>SecurityModeCommand</i>	414
–	<i>SecurityModeComplete</i>	415
–	<i>SecurityModeFailure</i>	416
–	<i>SIB1</i>	417
–	<i>SidelinkUEInformationNR</i>	422
–	<i>SystemInformation</i>	427
–	<i>UEAssistanceInformation</i>	428
–	<i>UECapabilityEnquiry</i>	437
–	<i>UECapabilityInformation</i>	438
–	<i>UEInformationRequest</i>	439
–	<i>UEInformationResponse</i>	440
–	<i>UEPositioningAssistanceInfo</i>	455
–	<i>ULDedicatedMessageSegment</i>	457
–	<i>ULInformationTransfer</i>	458
–	<i>ULInformationTransferIRAT</i>	458
–	<i>ULInformationTransferMRDC</i>	459
6.3	RRC information elements	460
6.3.0	Parameterized types	460
–	<i>SetupRelease</i>	460
6.3.1	System information blocks	461
–	<i>SIB2</i>	461
–	<i>SIB3</i>	466
–	<i>SIB4</i>	468
–	<i>SIB5</i>	474
–	<i>SIB6</i>	477
–	<i>SIB7</i>	477
–	<i>SIB8</i>	478
–	<i>SIB9</i>	479
–	<i>SIB10</i>	480
–	<i>SIB11</i>	481
–	<i>SIB12</i>	481
–	<i>SIB13</i>	483
–	<i>SIB14</i>	484
–	<i>SIB15</i>	485
–	<i>SIB16</i>	485
–	<i>SIB17</i>	486
–	<i>SIB18</i>	488
–	<i>SIB19</i>	489
–	<i>SIB20</i>	490
–	<i>SIB21</i>	491
6.3.1a	Positioning System information blocks	492
–	<i>PosSystemInformation-r16-IEs</i>	492
–	<i>PosSI-SchedulingInfo</i>	494
–	<i>SIBpos</i>	496
6.3.2	Radio resource control information elements	496
–	<i>AdditionalSpectrumEmission</i>	496
–	<i>Alpha</i>	497
–	<i>AMF-Identifier</i>	497
–	<i>ARFCN-ValueEUTRA</i>	497
–	<i>ARFCN-ValueNR</i>	498
–	<i>ARFCN-ValueUTRA-FDD</i>	498
–	<i>AvailabilityCombinationsPerCell</i>	498
–	<i>AvailabilityIndicator</i>	500
–	<i>BAP-RoutingID</i>	500
–	<i>BeamFailureRecoveryConfig</i>	501
–	<i>BeamFailureRecoveryRSConfig</i>	504
–	<i>BetaOffsets</i>	505

–	BetaOffsetsCrossPri	506
–	BH-LogicalChannelIdentity	506
–	BH-LogicalChannelIdentity-Ext	507
–	BH-RLC-ChannelConfig	507
–	BH-RLC-ChannelID	508
–	BSR-Config	508
–	BWP	509
–	BWP-Downlink	510
–	BWP-DownlinkCommon	511
–	BWP-DownlinkDedicated	511
–	BWP-Id	514
–	BWP-Uplink	514
–	BWP-UplinkCommon	515
–	BWP-UplinkDedicated	518
–	CandidateBeamRS	521
–	CellAccessRelatedInfo	522
–	CellAccessRelatedInfo-EUTRA-5GC	524
–	CellAccessRelatedInfo-EUTRA-EPC	524
–	CellGroupConfig	525
–	CellGroupId	536
–	CellIdentity	536
–	CellReselectionPriority	536
–	CellReselectionSubPriority	537
–	CFR-ConfigMulticast	537
–	CGI-InfoEUTRA	538
–	CGI-InfoEUTRALogging	538
–	CGI-InfoNR	539
–	CGI-Info-Logging	540
–	CLI-RSSI-Range	541
–	CodebookConfig	541
–	CommonLocationInfo	547
–	CondReconfigId	547
–	CondReconfigToAddModList	548
–	ConditionalReconfiguration	549
–	ConfiguredGrantConfig	549
–	ConfiguredGrantConfigIndex	558
–	ConfiguredGrantConfigIndexMAC	559
–	ConnEstFailureControl	559
–	ControlResourceSet	560
–	ControlResourceSetId	563
–	ControlResourceSetZero	563
–	CrossCarrierSchedulingConfig	564
–	CSI-AperiodicTriggerStateList	565
–	CSI-FrequencyOccupation	568
–	CSI-IM-Resource	568
–	CSI-IM-ResourceId	569
–	CSI-IM-ResourceSet	570
–	CSI-IM-ResourceSetId	570
–	CSI-MeasConfig	570
–	CSI-ReportConfig	572
–	CSI-ReportConfigId	579
–	CSI-ResourceConfig	580
–	CSI-ResourceConfigId	581
–	CSI-ResourcePeriodicityAndOffset	581
–	CSI-RS-ResourceConfigMobility	582
–	CSI-RS-ResourceMapping	584
–	CSI-SemiPersistentOnPUSCH-TriggerStateList	586
–	CSI-SSB-ResourceSet	587
–	CSI-SSB-ResourceSetId	587
–	DedicatedNAS-Message	588
–	DL-PPW-PreConfig	588
–	DMRS-BundlingPUCCH-Config	591