

ETSI TS 138 331 V18.4.0 (2025-01)



**5G;
NR;
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 38.331 version 18.4.0 Release 18)**

[ETSI TS 138 331 V18.4.0 \(2025-01\)](https://standards.iteh.ai/catalog/standards/etsi/86c0604a-bff8-458f-bb0d-ccc636a370f1/etsi-ts-138-331-v18-4-0-2025-01)

<https://standards.iteh.ai/catalog/standards/etsi/86c0604a-bff8-458f-bb0d-ccc636a370f1/etsi-ts-138-331-v18-4-0-2025-01>



ReferenceRTS/TSGR-0238331v140

Keywords5G

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from the
[ETSI Search & Browse Standards application](#).

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format on [ETSI deliver repository](#).

Users should be aware that the present document may be revised or have its status changed,
this information is available in the [Milestones listing](#).

If you find errors in the present document, please send your comments to
the relevant service listed under [Committee Support Staff](#).

If you find a security vulnerability in the present document, please report it through our
[Coordinated Vulnerability Disclosure \(CVD\)](#) program.

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2025.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the [ETSI IPR online database](#).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™**, **LTE™** and **5G™** logo are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables. (2025-01)

The cross reference between 3GPP and ETSI identities can be found at [3GPP to ETSI numbering cross-referencing](#).

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	27
1 Scope	28
2 References	28
3 Definitions, symbols and abbreviations	31
3.1 Definitions	31
3.2 Abbreviations	34
4 General	37
4.1 Introduction	37
4.2 Architecture	38
4.2.1 UE states and state transitions including inter RAT	38
4.2.2 Signalling radio bearers	41
4.3 Services	42
4.3.1 Services provided to upper layers	42
4.3.2 Services expected from lower layers	42
4.4 Functions	42
5 Procedures	43
5.1 General	43
5.1.1 Introduction.....	43
5.1.2 General requirements.....	43
5.1.3 Requirements for UE in MR-DC	44
5.2 System information	44
5.2.1 Introduction.....	44
5.2.2 System information acquisition	46
5.2.2.1 General UE requirements.....	46
5.2.2.2 SIB validity and need to (re)-acquire SIB	46
5.2.2.2.1 SIB validity.....	46
5.2.2.2.2 SI change indication and PWS notification	48
5.2.2.3 Acquisition of System Information	49
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i>	49
5.2.2.3.2 Acquisition of an SI message	50
5.2.2.3.3 Request for on demand system information	52
5.2.2.3.3a Request for on demand positioning system information	54
5.2.2.3.4 Actions related to transmission of <i>RRCSystemInfoRequest</i> message	56
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in <i>RRC_CONNECTED</i>	56
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message	57
5.2.2.4 Actions upon receipt of System Information	57
5.2.2.4.1 Actions upon reception of the <i>MIB</i>	57
5.2.2.4.2 Actions upon reception of the <i>SIB1</i>	58
5.2.2.4.3 Actions upon reception of <i>SIB2</i>	65
5.2.2.4.4 Actions upon reception of <i>SIB3</i>	66
5.2.2.4.5 Actions upon reception of <i>SIB4</i>	66
5.2.2.4.6 Actions upon reception of <i>SIB5</i>	67
5.2.2.4.7 Actions upon reception of <i>SIB6</i>	67
5.2.2.4.8 Actions upon reception of <i>SIB7</i>	67
5.2.2.4.9 Actions upon reception of <i>SIB8</i>	68
5.2.2.4.10 Actions upon reception of <i>SIB9</i>	69
5.2.2.4.11 Actions upon reception of <i>SIB10</i>	69
5.2.2.4.12 Actions upon reception of <i>SIB11</i>	69
5.2.2.4.13 Actions upon reception of <i>SIB12</i>	70
5.2.2.4.14 Actions upon reception of <i>SIB13</i>	71

5.2.2.4.15	Actions upon reception of <i>SIB14</i>	71
5.2.2.4.16	Actions upon reception of <i>SIBpos</i>	71
5.2.2.4.17	Actions upon reception of <i>SIB15</i>	72
5.2.2.4.18	Actions upon reception of <i>SIB16</i>	72
5.2.2.4.19	Actions upon reception of <i>SIB17</i>	72
5.2.2.4.19a	Actions upon reception of <i>SIB17bis</i>	72
5.2.2.4.20	Actions upon reception of <i>SIB18</i>	72
5.2.2.4.21	Actions upon reception of <i>SIB19</i>	72
5.2.2.4.22	Actions upon reception of <i>SIB20</i>	73
5.2.2.4.23	Actions upon reception of <i>SIB21</i>	73
5.2.2.4.24	Actions upon reception of <i>SIB22</i>	73
5.2.2.4.26	Actions upon reception of <i>SIB24</i>	73
5.2.2.4.27	Actions upon reception of <i>SIB25</i>	73
5.2.2.5	Essential system information missing	74
5.2.2.6	T430 expiry	74
5.3	Connection control	74
5.3.1	Introduction	74
5.3.1.1	RRC connection control	74
5.3.1.2	AS Security	75
5.3.2	Paging	76
5.3.2.1	General	76
5.3.2.2	Initiation	76
5.3.2.3	Reception of the <i>Paging message</i> by the UE or <i>PagingRecord</i> by the L2 U2N Remote UE	77
5.3.3	RRC connection establishment	79
5.3.3.1	General	79
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/discovery/V2X sidelink communication/MP operation	80
5.3.3.1b	Void	80
5.3.3.2	Initiation	80
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message	81
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE	82
5.3.3.5	Reception of the <i>RRCReject</i> by the UE	87
5.3.3.6	Cell re-selection or cell selection or relay (re)selection while T390, T300 or T302 is running (UE in RRC_IDLE)	87
5.3.3.7	T300 expiry	87
5.3.3.8	Abortion of RRC connection establishment	89
5.3.4	Initial AS security activation	90
5.3.4.1	General	90
5.3.4.2	Initiation	90
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE	90
5.3.5	RRC reconfiguration	91
5.3.5.1	General	91
5.3.5.2	Initiation	92
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE	93
5.3.5.4	Secondary cell group release	109
5.3.5.5	Cell Group configuration	110
5.3.5.5.1	General	110
5.3.5.5.2	Reconfiguration with sync	112
5.3.5.5.3	RLC bearer release	114
5.3.5.5.4	RLC bearer addition/modification	114
5.3.5.5.5	MAC entity configuration	115
5.3.5.5.6	RLF Timers & Constants configuration	116
5.3.5.5.7	SpCell Configuration	116
5.3.5.5.8	SCell Release	118
5.3.5.5.9	SCell Addition/Modification	118
5.3.5.5.10	BH RLC channel release	119
5.3.5.5.11	BH RLC channel addition/modification	119
5.3.5.5.12	Uu Relay RLC channel release	119
5.3.5.5.13	Uu Relay RLC channel addition/modification	119
5.3.5.5.14	NCR-Fwd configuration	120
5.3.5.6	Radio Bearer configuration	120
5.3.5.6.1	General	120

5.3.5.6.2	SRB release	120
5.3.5.6.3	SRB addition/modification	121
5.3.5.6.4	DRB release	123
5.3.5.6.5	DRB addition/modification	123
5.3.5.6.6	Multicast MRB release	126
5.3.5.6.7	Multicast MRB addition/modification	126
5.3.5.7	AS Security key update	127
5.3.5.8	Reconfiguration failure	128
5.3.5.8.1	Void	128
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i>	128
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure) or T420 expiry (Path switch failure)	131
5.3.5.9	Other configuration	132
5.3.5.9a	MUSIM gap configuration	137
5.3.5.10	MR-DC release	138
5.3.5.11	Full configuration	139
5.3.5.12	BAP configuration	141
5.3.5.12a	IAB Other Configuration	141
5.3.5.12a.1	IP address management	141
5.3.5.12a.1.1	IP Address Release	141
5.3.5.12a.1.2	IP Address Addition/Modification	141
5.3.5.13	Conditional Reconfiguration	143
5.3.5.13.1	General	143
5.3.5.13.2	Conditional reconfiguration removal	144
5.3.5.13.3	Conditional reconfiguration addition/modification	144
5.3.5.13.4	Conditional reconfiguration evaluation	145
5.3.5.13.4a	Conditional reconfiguration evaluation of SN initiated inter-SN CPC for EN-DC	148
5.3.5.13.5	Conditional reconfiguration execution	148
5.3.5.13.6	Subsequent CPAC reference configuration addition/removal	149
5.3.5.13.7	sk-Counter configuration addition/modification/removal	149
5.3.5.13.8	Subsequent CPAC execution	149
5.3.5.13a	SCG activation	152
5.3.5.13b	SCG deactivation	153
5.3.5.13b1	SCG activation without SN message	153
5.3.5.13c	FR2 UL gap configuration	154
5.3.5.13d	Application layer measurement configuration	154
5.3.5.14	Sidelink dedicated configuration	156
5.3.5.15	L2 U2N or U2U Relay UE configuration	158
5.3.5.15.1	General	158
5.3.5.15.2	L2 U2N or U2U Remote UE Release	159
5.3.5.15.3	L2 U2N or U2U Remote UE Addition/Modification	159
5.3.5.16	L2 U2N or U2U Remote UE configuration	160
5.3.5.16.1	L2 U2U Relay UE Release	161
5.3.5.16.2	L2 U2U Relay UE Addition/Modification	161
5.3.5.17	MP configuration	162
5.3.5.17.1	Introduction	162
5.3.5.17.2	Configuration of SL indirect path	162
5.3.5.17.2.1	General	162
5.3.5.17.2.2	SL indirect path specific configuration	162
5.3.5.17.2.3	T421 expiry (Indirect path addition/change failure)	162
5.3.5.17.3	Configuration of N3C indirect path	163
5.3.5.17.3.1	General	163
5.3.5.17.3.2	N3C remote UE configuration	163
5.3.5.17.3.2a	N3C Indirect path addition/change failure	163
5.3.5.17.3.3	N3C relay UE configuration	164
5.3.5.17.3.4	Bearer mapping management on N3C indirect path	164
5.3.5.17.3.4.1	Bearer mapping release	164
5.3.5.17.3.4.2	Bearer mapping addition and modification	164
5.3.5.18	LTM configuration and execution	164
5.3.5.18.1	LTM configuration	164
5.3.5.18.2	LTM candidate configuration release	165
5.3.5.18.3	LTM candidate configuration addition/modification	165
5.3.5.18.4	Void	166

5.3.5.18.5	Void	166
5.3.5.18.6	LTM cell switch execution	166
5.3.5.18.7	LTM configuration release	169
5.3.5.19	T348 expiry	169
5.3.6	Counter check	169
5.3.6.1	General	169
5.3.6.2	Initiation	169
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE	170
5.3.7	RRC connection re-establishment	170
5.3.7.1	General	170
5.3.7.2	Initiation	171
5.3.7.3	Actions following cell selection while T311 is running	175
5.3.7.3a	Actions following relay selection while T311 is running	178
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message	178
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE	179
5.3.7.6	T311 expiry	182
5.3.7.7	T301 expiry or selected cell/L2 U2N Relay UE no longer suitable	182
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE	182
5.3.8	RRC connection release	183
5.3.8.1	General	183
5.3.8.2	Initiation	183
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE	183
5.3.8.4	T320 expiry	189
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i>	189
5.3.8.6	T346g expiry	189
5.3.9	RRC connection release requested by upper layers	189
5.3.9.1	General	189
5.3.9.2	Initiation	189
5.3.10	Radio link failure related actions	189
5.3.10.1	Detection of physical layer problems in RRC_CONNECTED	189
5.3.10.2	Recovery of physical layer problems	190
5.3.10.3	Detection of radio link failure	190
5.3.10.4	RLF cause determination	193
5.3.10.5	RLF report content determination	193
5.3.11	UE actions upon going to RRC_IDLE	197
5.3.12	UE actions upon PUCCH/SRS release request	200
5.3.13	RRC connection resume	200
5.3.13.1	General	200
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/positioning/discovery/V2X sidelink communication	201
5.3.13.1b	Conditions for initiating SDT	202
5.3.13.1c	Void	202
5.3.13.1d	Conditions for resuming RRC connection for multicast reception	202
5.3.13.2	Initiation	203
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message	207
5.3.13.4	Reception of the <i>RRCResume</i> by the UE	209
5.3.13.5	Handling of failure to resume RRC Connection	217
5.3.13.6	Cell re-selection or cell selection or L2 U2N relay (re)selection while T390, T319 or T302 is running or SDT procedure is ongoing (UE in RRC_INACTIVE) or SRS transmission in RRC_INACTIVE is configured	218
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE	219
5.3.13.8	RNA update	219
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE	220
5.3.13.10	Reception of the <i>RRCReject</i> by the UE	220
5.3.13.11	Inability to comply with <i>RRCResume</i>	220
5.3.13.12	Inter RAT cell reselection	220
5.3.14	Unified Access Control	220
5.3.14.1	General	220
5.3.14.2	Initiation	221
5.3.14.3	Void	223
5.3.14.4	T302, T390 expiry or stop (Barring alleviation)	223
5.3.14.5	Access barring check	223

5.3.15	RRC connection reject	224
5.3.15.1	Initiation	224
5.3.15.2	Reception of the <i>RRCReject</i> by the UE	224
5.4	Inter-RAT mobility	225
5.4.1	Introduction	225
5.4.2	Handover to NR	225
5.4.2.1	General	225
5.4.2.2	Initiation	226
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE	226
5.4.3	Mobility from NR	226
5.4.3.1	General	226
5.4.3.2	Initiation	227
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE	227
5.4.3.4	Successful completion of the mobility from NR	227
5.4.3.5	Mobility from NR failure	228
5.5	Measurements	229
5.5.1	Introduction	229
5.5.2	Measurement configuration	232
5.5.2.1	General	232
5.5.2.2	Measurement identity removal	233
5.5.2.3	Measurement identity addition/modification	234
5.5.2.4	Measurement object removal	235
5.5.2.5	Measurement object addition/modification	235
5.5.2.6	Reporting configuration removal	237
5.5.2.7	Reporting configuration addition/modification	238
5.5.2.8	Quantity configuration	238
5.5.2.9	Measurement gap configuration	238
5.5.2.10	Reference signal measurement timing configuration	241
5.5.2.10a	RSSI measurement timing configuration	241
5.5.2.11	Measurement gap sharing configuration	242
5.5.2.12	Effective measurement window configuration	242
5.5.3	Performing measurements	243
5.5.3.1	General	243
5.5.3.2	Layer 3 filtering	248
5.5.3.3	Derivation of cell measurement results	249
5.5.3.3a	Derivation of layer 3 beam filtered measurement	250
5.5.3.4	Derivation of L2 U2N Relay UE measurement results	250
5.5.4	Measurement report triggering	250
5.5.4.1	General	250
5.5.4.2	Event A1 (Serving becomes better than threshold)	259
5.5.4.3	Event A2 (Serving becomes worse than threshold)	259
5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell)	260
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	260
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2)	261
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell)	262
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold)	263
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	263
5.5.4.10	Event I1 (Interference becomes higher than threshold)	264
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold)	265
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold)	265
5.5.4.13	Void	266
5.5.4.14	Void	266
5.5.4.15	Event D1 (Distance between UE and referenceLocation1 is above threshold1 and distance between UE and referenceLocation2 is below threshold2)	266
5.5.4.15a	Event D2 (Distance between UE and the serving cell moving reference location is above threshold1 and distance between UE and a moving reference location is below threshold2)	267
5.5.4.16	CondEvent T1 (Time measured at UE is within a duration from threshold)	267
5.5.4.17	Event X1 (Serving L2 U2N Relay UE becomes worse than threshold1 and NR Cell becomes better than threshold2)	268
5.5.4.18	Event X2 (Serving L2 U2N Relay UE becomes worse than threshold)	269

5.5.4.19	Event Y1 (PCell becomes worse than threshold1 and candidate L2 U2N Relay UE becomes better than threshold2).....	269
5.5.4.20	Event Y2 (Candidate L2 U2N Relay UE becomes better than threshold)	270
5.5.4.20b	Event Z1 (Serving L2 U2N Relay UE becomes worse than threshold1 and Candidate L2 U2N Relay UE becomes better than threshold2)	270
5.5.4.21	Event H1 (The Aerial UE altitude becomes higher than a threshold)	271
5.5.4.22	Event H2 (The Aerial UE altitude becomes lower than a threshold)	272
5.5.4.23	Event A3H1 (Neighbour becomes offset better than SpCell and the Aerial UE altitude becomes higher than a threshold).....	272
5.5.4.24	Event A3H2 (Neighbour becomes offset better than SpCell and the Aerial UE altitude becomes lower than a threshold).....	273
5.5.4.25	Event A4H1 (Neighbour becomes better than threshold1 and the Aerial UE altitude becomes higher than a threshold2).....	274
5.5.4.26	Event A4H2 (Neighbour becomes better than threshold1 and the Aerial UE altitude becomes lower than a threshold2).....	275
5.5.4.27	Event A5H1 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2 and the Aerial UE altitude becomes higher than a threshold3)	276
5.5.4.28	Event A5H2 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2 and the Aerial UE altitude becomes lower than a threshold3).....	277
5.5.5	Measurement reporting	278
5.5.5.1	General	278
5.5.5.2	Reporting of beam measurement information	288
5.5.5.3	Sorting of cell measurement results	288
5.5.6	Location measurement indication	289
5.5.6.1	General	289
5.5.6.2	Initiation.....	289
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message	290
5.5a	Logged Measurements	291
5.5a.1	Logged Measurement Configuration	291
5.5a.1.1	General	291
5.5a.1.2	Initiation.....	291
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE	291
5.5a.1.4	T330 expiry	292
5.5a.2	Release of Logged Measurement Configuration.....	292
5.5a.2.1	General	292
5.5a.2.2	Initiation.....	292
5.5a.3	Measurements logging.....	292
5.5a.3.1	General	292
5.5a.3.2	Initiation.....	293
5.5b	Application Layer Measurements in RRC_IDLE/RRC_INACTIVE.....	296
5.5b.1	Handling of Application Layer Measurements in RRC_IDLE/RRC_INACTIVE	296
5.5b.1.1	General	296
5.5b.1.2	Initiation.....	296
5.6	UE capabilities	297
5.6.1	UE capability transfer	297
5.6.1.1	General	297
5.6.1.2	Initiation.....	297
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	297
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE	298
5.6.1.5	Void.....	301
5.7	Other.....	301
5.7.1	DL information transfer	301
5.7.1.1	General	301
5.7.1.2	Initiation.....	301
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	302
5.7.1a	DL information transfer for MR-DC	303
5.7.1a.1	General	303
5.7.1a.2	Initiation.....	303
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message	303
5.7.2	UL information transfer	304
5.7.2.1	General	304
5.7.2.2	Initiation.....	304

5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message	304
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message	304
5.7.2a	UL information transfer for MR-DC	305
5.7.2a.1	General	305
5.7.2a.2	Initiation	305
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message	305
5.7.2b	UL transfer of IRAT information	305
5.7.2b.1	General	305
5.7.2b.2	Initiation	306
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	306
5.7.3	SCG failure information	306
5.7.3.1	General	306
5.7.3.2	Initiation	306
5.7.3.3	Failure type determination for (NG)EN-DC	307
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i>	308
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message	309
5.7.3a	EUTRA SCG failure information	312
5.7.3a.1	General	312
5.7.3a.2	Initiation	312
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message	312
5.7.3b	MCG failure information	313
5.7.3b.1	General	313
5.7.3b.2	Initiation	313
5.7.3b.3	Failure type determination	313
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message	314
5.7.3b.5	T316 expiry	315
5.7.3c	Indirect path failure information	316
5.7.3c.1	General	316
5.7.3c.2	Initiation	316
5.7.3c.3	Failure type determination	316
5.7.3c.4	Actions related to transmission of <i>IndirectPathFailureInformation</i> message	317
5.7.4	UE Assistance Information	318
5.7.4.1	General	318
5.7.4.2	Initiation	319
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	328
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE	340
5.7.4.4	Relaxed measurement criterion for a stationary (e)RedCap UE	341
5.7.4a	Void	341
5.7.5	Failure information	341
5.7.5.1	General	341
5.7.5.2	Initiation	341
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message	342
5.7.6	DL message segment transfer	342
5.7.6.1	General	342
5.7.6.2	Initiation	343
5.7.6.3	Reception of <i>DLDedicatedMessageSegment</i> by the UE	343
5.7.7	UL message segment transfer	343
5.7.7.1	General	343
5.7.7.2	Initiation	343
5.7.7.3	Actions related to transmission of <i>ULDedicatedMessageSegment</i> message	343
5.7.8	Idle/inactive Measurements	344
5.7.8.1	General	344
5.7.8.1a	Measurement configuration	344
5.7.8.1b	Measurement configuration (reselection measurements)	345
5.7.8.2	Void	346
5.7.8.2a	Performing measurements	346
5.7.8.3	T331 expiry or stop	348
5.7.8.4	Cell re-selection or cell selection while T331 is running	349
5.7.9	Mobility history information	349
5.7.9.1	General	349
5.7.9.2	Initiation	349
5.7.9.3	Release of Mobility History Information	352

5.7.10	UE Information	353
5.7.10.1	General	353
5.7.10.2	Initiation	353
5.7.10.3	Reception of the <i>UEInformationRequest</i> message	353
5.7.10.4	Actions for the Random Access report determination	358
5.7.10.5	RA information determination	359
5.7.10.6	Actions for the successful handover report determination	364
5.7.10.7	Actions for the successful PSCell change or addition report determination	368
5.7.11	Void	371
5.7.12	IAB Other Information	371
5.7.12.1	General	371
5.7.12.2	Initiation	371
5.7.12.3	Actions related to transmission of <i>IABOtherInformation</i> message	371
5.7.13	RLM/BFD relaxation	373
5.7.13.0	General	373
5.7.13.1	Relaxed measurement criterion for low mobility	373
5.7.13.2	Relaxed measurement criterion for good serving cell quality	373
5.7.14	UE Positioning Assistance Information	374
5.7.14.1	General	374
5.7.14.2	Initiation	374
5.7.14.3	Actions related to transmission of <i>UEPositioningAssistanceInfo</i> message	374
5.7.15	Void	375
5.7.17	Derivation of pathloss reference for TA validation of SRS for Positioning transmission and CG-SDT in RRC_INACTIVE	377
5.7.18	Void	378
5.7.19	Satellite switch with resynchronization	378
5.7.20	Actions related to Transmission of SRS for Positioning in a validity area in RRC_INACTIVE	378
5.8	Sidelink	379
5.8.1	General	379
5.8.2	Conditions for NR sidelink communication/discovery/positioning operation	379
5.8.3	Sidelink UE information for NR sidelink communication/discovery/positioning	380
5.8.3.1	General	380
5.8.3.2	Initiation	381
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message	387
5.8.4	Void	394
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication/discovery/positioning	394
5.8.5.1	General	394
5.8.5.2	Initiation	394
5.8.5.3	Transmission of SLSS	395
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication	397
5.8.5a.1	General	397
5.8.5a.2	Initiation	397
5.8.6	Sidelink synchronisation reference	398
5.8.6.1	General	398
5.8.6.2	Selection and reselection of synchronisation reference	398
5.8.6.2a	Sidelink synchronization reference priority group order	399
5.8.6.2b	Sidelink synchronization reference search	400
5.8.6.3	Sidelink communication transmission reference cell selection	401
5.8.7	Sidelink communication reception	402
5.8.8	Sidelink communication transmission	402
5.8.9	Sidelink RRC procedure	405
5.8.9.1	Sidelink RRC reconfiguration	405
5.8.9.1.1	General	405
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message	406
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE	409
5.8.9.1.4	Void	412
5.8.9.1.5	Void	412
5.8.9.1.6	Void	412
5.8.9.1.7	Void	412
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE	412
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE	412

5.8.9.1a	Sidelink radio bearer management	413
5.8.9.1a.1	Sidelink DRB release	413
5.8.9.1a.2	Sidelink DRB addition/modification	414
5.8.9.1a.3	Sidelink SRB release	416
5.8.9.1a.4	Sidelink SRB addition	416
5.8.9.1a.5	Additional Sidelink RLC Bearer release	417
5.8.9.1a.5.1	Additional Sidelink RLC Bearer release conditions	417
5.8.9.1a.5.2	Additional Sidelink RLC Bearer release operation	417
5.8.9.1a.6	Additional Sidelink RLC Bearer addition/modification	418
5.8.9.1a.6.1	Additional Sidelink RLC Bearer addition/modification conditions	418
5.8.9.1a.6.2	Additional Sidelink RLC Bearer addition/modification operation	418
5.8.9.1b	Sidelink Carrier Configuration	420
5.8.9.1b.1	Sidelink Carrier Release	420
5.8.9.1b.1.1	Sidelink Carrier Release Condition	420
5.8.9.1b.1.2	Sidelink Carrier Release Operation	420
5.8.9.1b.2	Sidelink Carrier Addition	421
5.8.9.1b.2.1	Sidelink Carrier Addition Condition	421
5.8.9.1b.2.2	Sidelink Carrier Addition Operation	421
5.8.9.2	Sidelink UE capability transfer	421
5.8.9.2.1	General	421
5.8.9.2.2	Initiation	422
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE	422
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE	422
5.8.9.3	Sidelink radio link failure related actions	422
5.8.9.3a	End-to-end PC5 connection failure related actions performed by L2 U2U Remote UE	424
5.8.9.3b	End-to-end PC5 connection failure/release related actions performed by L2 U2U Relay UE	424
5.8.9.4	Sidelink common control information	425
5.8.9.4.1	General	425
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message	425
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message	425
5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers	426
5.8.9.5a	Actions related to end-to-end PC5-RRC connection release performed by L2 U2U Remote UE	427
5.8.9.6	Sidelink UE assistance information	427
5.8.9.6.1	General	427
5.8.9.6.2	Initiation	427
5.8.9.6.3	Actions related to reception of <i>UEAssistanceInformationSidelink</i> message	428
5.8.9.7	PC5 Relay RLC channel management for L2 U2N or U2U relay	428
5.8.9.7.1	PC5 Relay RLC channel release	428
5.8.9.7.2	PC5 Relay RLC channel addition/modification	428
5.8.9.8	Remote UE information	430
5.8.9.8.1	General	430
5.8.9.8.2	Actions related to transmission of <i>RemoteUEInformationSidelink</i> message	430
5.8.9.8.3	Reception of <i>RemoteUEInformationSidelink</i> message by the L2 U2N/U2U Relay UE	431
5.8.9.9	Uu message transfer in sidelink	433
5.8.9.9.1	General	433
5.8.9.9.2	Actions related to transmission of <i>UuMessageTransferSidelink</i> message	433
5.8.9.9.3	Reception of the <i>UuMessageTransferSidelink</i>	433
5.8.9.10	Notification Message	434
5.8.9.10.1	General	434
5.8.9.10.2	Initiation	434
5.8.9.10.3	Actions related to transmission of <i>NotificationMessageSidelink</i> message	434
5.8.9.10.4	Actions related to reception of <i>NotificationMessageSidelink</i> message	435
5.8.9.11	UE information transfer on sidelink	436
5.8.9.11.1	General	436
5.8.9.11.2	Actions related to transmission of the <i>UEInformationRequestSidelink</i> by the UE	436
5.8.9.11.3	Actions related to reception of the <i>UEInformationRequestSidelink</i> by the UE	436
5.8.9.11.4	Actions related to reception of the <i>UEInformationResponseSidelink</i> by the UE	437
5.8.10	Sidelink measurement	437
5.8.10.1	Introduction	437
5.8.10.2	Sidelink measurement configuration	438
5.8.10.2.1	General	438
5.8.10.2.2	Sidelink measurement identity removal	439

5.8.10.2.3	Sidelink measurement identity addition/modification	439
5.8.10.2.4	Sidelink measurement object removal	439
5.8.10.2.5	Sidelink measurement object addition/modification	440
5.8.10.2.6	Sidelink reporting configuration removal	440
5.8.10.2.7	Sidelink reporting configuration addition/modification	440
5.8.10.2.8	Sidelink quantity configuration	441
5.8.10.3	Performing NR sidelink measurements	441
5.8.10.3.1	General	441
5.8.10.3.2	Derivation of NR sidelink measurement results	441
5.8.10.4	Sidelink measurement report triggering	441
5.8.10.4.1	General	441
5.8.10.4.2	Event S1 (Serving becomes better than threshold)	442
5.8.10.4.3	Event S2 (Serving becomes worse than threshold)	443
5.8.10.5	Sidelink measurement reporting	444
5.8.10.5.1	General	444
5.8.11	Zone identity calculation	444
5.8.12	DFN derivation from GNSS	445
5.8.13	NR sidelink discovery	445
5.8.13.1	General	445
5.8.13.2	NR sidelink discovery monitoring	445
5.8.13.3	NR sidelink discovery transmission	446
5.8.14	NR sidelink U2N Relay UE operation	450
5.8.14.1	General	450
5.8.15	NR sidelink U2N Remote UE operation	450
5.8.15.1	General	450
5.8.15.2	NR Sidelink U2N Remote UE threshold conditions	450
5.8.15.3	Selection and reselection of NR sidelink U2N Relay UE	451
5.8.16	NR sidelink U2U Relay UE operation	452
5.8.16.1	General	452
5.8.16.2	NR sidelink U2U Relay UE threshold conditions	452
5.8.16.3	Neighbor UE(s) in proximity conditions	452
5.8.17	NR sidelink U2U Remote UE operation	453
5.8.17.1	General	453
5.8.17.2	NR Sidelink U2U Remote UE threshold conditions	453
5.8.17.3	Conditions for selection and reselection of NR sidelink U2U Relay UE	454
5.8.17.4	Actions related to selection and reselection of NR sidelink U2U Relay UE	454
5.8.18	NR sidelink positioning	455
5.8.18.1	General	455
5.8.18.2	NR sidelink positioning measurement	455
5.8.18.3	NR sidelink positioning transmission	455
5.9	MBS Broadcast	458
5.9.1	Introduction	458
5.9.1.1	General	458
5.9.1.2	MCCH scheduling	458
5.9.1.3	MCCH information validity and notification of changes	458
5.9.2	MCCH information acquisition	459
5.9.2.1	General	459
5.9.2.2	Initiation	459
5.9.2.3	MCCH information acquisition by the UE	459
5.9.2.4	Actions upon reception of the <i>MBSBroadcastConfiguration</i> message	459
5.9.3	Broadcast MRB configuration	460
5.9.3.1	General	460
5.9.3.2	Initiation	460
5.9.3.3	Broadcast MRB establishment	460
5.9.3.4	Broadcast MRB release	460
5.9.4	MBS Interest Indication	461
5.9.4.1	General	461
5.9.4.2	Initiation	461
5.9.4.3	MBS frequencies of interest determination	462
5.9.4.4	MBS services of interest determination	462
5.9.4.5	Setting of the contents of MBS Interest Indication	463
5.10	MBS multicast reception in RRC_INACTIVE	463

5.10.1	Introduction.....	463
5.10.1.1	General	463
5.10.1.2	Multicast MCCH scheduling.....	464
5.10.1.3	Multicast MCCH information validity and notification of changes.....	464
5.10.2	Multicast MCCH information acquisition	465
5.10.2.1	General	465
5.10.2.2	Initiation.....	465
5.10.2.3	Multicast MCCH information acquisition by the UE.....	465
5.10.2.4	Actions upon reception of the <i>MBSMulticastConfiguration</i> message.....	465
5.10.3	MRB configuration	466
5.10.3.1	General	466
5.10.3.2	Multicast MRB establishment.....	466
5.10.3.3	Multicast MRB release.....	466
6	Protocol data units, formats and parameters (ASN.1)	467
6.1	General	467
6.1.1	Introduction.....	467
6.1.2	Need codes and conditions for optional fields.....	467
6.1.3	General rules.....	470
6.2	RRC messages.....	470
6.2.1	General message structure	470
–	<i>NR-RRC-Definitions</i>	470
–	<i>BCCH-BCH-Message</i>	470
–	<i>BCCH-DL-SCH-Message</i>	471
–	<i>DL-CCCH-Message</i>	471
–	<i>DL-DCCH-Message</i>	472
–	<i>MCCH-Message</i>	472
–	<i>MulticastMCCH-Message</i>	473
–	<i>PCCH-Message</i>	473
–	<i>UL-CCCH-Message</i>	474
–	<i>UL-CCCH1-Message</i>	474
–	<i>UL-DCCH-Message</i>	475
6.2.2	Message definitions	477
–	<i>CounterCheck</i>	477
–	<i>CounterCheckResponse</i>	478
–	<i>DedicatedSIBRequest</i>	479
–	<i>DL DedicatedMessageSegment</i>	480
–	<i>DLInformationTransfer</i>	481
–	<i>DLInformationTransferMRDC</i>	483
–	<i>FailureInformation</i>	484
–	<i>IABOtherInformation</i>	485
–	<i>IndirectPathFailureInformation</i>	488
–	<i>LocationMeasurementIndication</i>	489
–	<i>LoggedMeasurementConfiguration</i>	490
–	<i>MBSBroadcastConfiguration</i>	492
–	<i>MBSInterestIndication</i>	494
–	<i>MBSMulticastConfiguration</i>	495
–	<i>MCGFailureInformation</i>	496
–	<i>MeasurementReport</i>	498
–	<i>MeasurementReportAppLayer</i>	498
–	<i>MIB</i>	500
–	<i>MobilityFromNRCommand</i>	502
–	<i>Paging</i>	504
–	<i>RRCReestablishment</i>	506
–	<i>RRCReestablishmentComplete</i>	507
–	<i>RRCReestablishmentRequest</i>	508
–	<i>RRCReconfiguration</i>	509
–	<i>RRCReconfigurationComplete</i>	517
–	<i>RRCReject</i>	519
–	<i>RRCRelease</i>	520
–	<i>RRCResume</i>	533
–	<i>RRCResumeComplete</i>	536