2553

International Standard

INTERNATIONAL ORGANIZATION FOR STANDARDIZATION-MEXCHAPOCHAR OPPAHUSALUH TO CTAHDAPTUSALUH-ORGANISATION INTERNATIONALE DE NORMALISATION

Welds — Symbolic representation on drawings

Soudures - Représentation/symbolique/sur les dessins

Second edition - 1984-11-15

iTeh STANDARD PREVIEW (standards.iteh.ai)

ISO 2553:1984 https://standards.iteh.ai/catalog/standards/sist/bc24fc95-a885-429b-b2d3a1b2bcb33dc3/iso-2553-1984

UDC 621.791 : 744.4

Ref. No. ISO 2553-1984 (E)

Descriptors : drawings, technical drawings, welded joints, symbols, graphic symbols.

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work.

Draft International Standards, adopted by the technical committees are circulated to the member bodies for approval before their acceptance as International Standards by the ISO Council. They are approved in accordance with ISO procedures requiring at least 75 % approval by the member bodies voting. TANDARD PREVIEW

International Standard ISO 2553 was prepared by Jechnical Committee ISO/TC 44,1) Welding and allied processes.

ISO 2553 was first published in 1974. This second edition cancels and replaces the first edition, of which it constitutes a technical revision chai/catalog/standards/sist/bc24fc95-a885-429b-b2d3a1b2bcb33dc3/iso-2553-1984

© International Organization for Standardization, 1984 •

(Co	ntents	Page
1	1 5	Scope and field of application	1
2	2 F	References	1
3	3 (General	1
4	1 9	Symbols	1
	2	.1 Elementary symbols	1
	4	.2 Combinations of elementary symbols	3
iTeh S	S	Supplementary symbols	3
E	5 (\$	osition of the symbols on drawings	4
	Ę	6.1 Gene <u>ral 2553:1984</u>	4
https://standards	.itel	nai/catalog/standards/sist/bc24fc95-a885-429b-b2d3- .211Belation between the arrow line and the joint	5
	ę	i.3 Position of the arrow line	6
	ŧ	i.4 Position of the reference line	6
	Į	5.5 Position of the symbol with regard to the reference line	6
(6	Dimensioning of welds	8
	(i.1 General rules	8
	(5.2 Main dimensions to be shown	8
7	7	Complementary indications	11
		7.1 Peripheral welds	11
	-	7.2 Field or site welds	11
	-	7.3 Indication of the welding process	11
	Annexes		
	A	Examples of use of symbols	12
	в	Guidance for converting drawings made according to ISO 2553-1974 into the new system according to ISO 2553-1984	27

()

R

iTeh STANDARD PREVIEW (standards.iteh.ai)

•

ISO 2553:1984 https://standards.iteh.ai/catalog/standards/sist/bc24fc95-a885-429b-b2d3a1b2bcb33dc3/iso-2553-1984

Welds – Symbolic representation on drawings

iTeh STANDARD PREVIEW (standards.iteh.ai)

1 Scope and field of application

3.3 This symbolic representation includes an elementary [SO 2553:1symbol which may be completed by:

a means of showing dimensions;

This International Standard prescribes the tules to be applied ndards/sist/bc24fc95-a885-429b-b2d3for the symbolic representation of welds on drawings 2bcb33dc3/iso-2553-1984

2 References

ISO 128, Technical drawings — General principles of presentation.

ISO 3098/1, Technical drawings — Lettering — Part 1: Currently used characters.

ISO 4063, Welding, brazing, braze welding and soldering of metals — List of processes, for symbolic representation on drawings.

3 General

3.1 Welds may be indicated with the general recommendations for technical drawings. However, for the purpose of simplification, it is advisable to adopt, for usual welds, the symbolic representation described in this International Standard.

3.2 The symbolic representation shall give clearly all necesary indications regarding the specific weld to be obtained without over-burdening the drawing with notes or showing an additional view.

some complementary indications (particularly for workshop drawings).

3.4 In order to simplify the drawings as much as possible, it is recommended that references be made to specific instructions or particular specifications giving all details of the preparation of edges to be welded and/or welding procedures, rather than showing these indications on the drawings of the welded parts.

If there are no such instructions, the dimensions relating to the preparation of the edges to be welded and/or the welding procedures can be close to the symbol.

4 Symbols

4.1 Elementary symbols

The various categories of welds are characterized by a symbol which, in general, is similar to the shape of the weld to be made.

The symbol shall not be taken to pre-judge the process to be employed.

The elementary symbols are shown in table 1.

No.	Designation	Illustration	Symbol
1	Butt weld between plates with raised edges ¹⁾ ; edge flanged weld /USA/ (the raised edges being melted down completely)		ノ
2	Square butt weld		[]
3	Single-V butt weld		\vee
4	Single-bevel butt weld		V
5	Single-V butt weld with broad root face (standards.iteh. ISO 2553:1984		Y
6	https://standards.iteh.ai/catalog/standards/sist/bc24fc a1b2bcb33dc3/iso-2553-198 Single-bevel butt weld with broad root face	4 4	٢
7	Single-U butt weld (parallel or sloping sides)		Y
8	Single-J butt weld		٢
9	Backing run; back or backing weld /USA/		D
10	Fillet weld		

Table 1 - Elementary symbols

1) Butt welds between plates with raised edges (symbol 1) not completely penetrated are symbolized as square butt welds (symbol 2) with the weld thickness *s* shown (see table 4).




Table 1 — Elementary symbols (concluded)

https://standards.iteh.ai/catalog/standards/sist/bc24fc95-a885-429b-b2d3a1b2bcb33dc3/iso-2553-1984

4.2 Combinations of elementary symbols

When required, combinations of elementary symbols can be used.

Typical examples are given in table 6.

4.3 Supplementary symbols

Elementary symbols may be completed by a symbol characterizing the shape of the external surface of the weld.

The recommended supplementary symbols are given in table 2.

The absence of a supplementary symbol means that the shape of the weld surface does not need to be indicated precisely.

Examples of combinations of elementary and supplementary symbols are given in tables 3 and 7.

NOTE — Though it is not forbidden to associate several symbols, it is better to represent the weld on a separate sketch, when symbolization becomes too difficult.

Shape of weld surface	Symbol	
a) flat (usually finished flush)		
b) convex		
c) concave		

Table 2 - Supplementary symbols

Table 3 gives examples of application of the supplementary symbols.

Designation	Illustration	Symbol
Flat (flush) single-V butt weld		$\overline{\nabla}$
Convex double-V butt weld		χ
Concave fillet weld		6
Flat (flush) single-V butt weld with flat (flush) backing run		Σ

Table 3 - Examples of application of supplementary symbols

5 Position of the symbols on drawings

General iTeh STANDARD PREVIEW

The symbols covered by these rules form only part of the complete method of representation (figure 1), which comprises in addition to the symbol (3) itself:

- an arrow line (1) per joint (see figures 2 and 3); ISO 2553:1984
- a dual reference line, consisting of two parallel lines, one continuous and one dashed (2) (exception, see note 1);
- a certain number of dimensions and conventional signs.

NOTES

5.1


1 The dashed line can be drawn either above or beneath the continuous line ______ (see also 5.5 and annex B).

For symmetrical welds, the dashed line is unnecessary and should be omitted.

2 The thickness of lines for arrow line, reference line, symbol and lettering shall be in accordance with the thickness of line for dimensioning according to ISO 128 and ISO 3098/1, respectively.

The purpose of the following rules is to define the location of welds by specifying:

- the position of the arrow line;
- the position of the reference line;
- the position of the symbol.



1 = arrow line
2a = reference line (continuous line)
2b = identification line (dashed line)
3 = welding symbol

Figure 1 – Method of representation

5.2 Relation between the arrow line and the joint

The examples given in figures 2 and 3 explain the meaning of the terms

- "arrow side" of the joint;
- "other side" of the joint.




Figure 3 - Cruciform joint with two fillet welds

5.3 Position of the arrow line

The position of the arrow line with respect to the weld is generally of no special significance [{see figure 4 a) and b}]. However, in the case of welds of types 4, 6 and 8 (see table 1), the arrow line shall point towards the plate which is prepared [(see figure 4 c) and d)].

The arrow line

- $-\,$ joins one end of the continuous reference line such that it forms an angle with it
- shall be completed by an arrow head.

5.4 Position of the reference line


The reference line shall preferably be drawn parallel to the bottom edge of the drawing, or if impossible perpendicular.


5.5 Position of the symbol with regard to the reference line


The symbol is to be placed either above or beneath the reference line, in accordance with the following regulation:

- The symbol is placed on the continuous line side of the reference line if the weld (weld face) is on the arrow side of the joint [see 5 a)].

- The symbol is placed on the dashed line side if the weld (weld face) is on the other side of the joint [see figure 5 b)].








d)

c)

Figure 4 – Position of the arrow line

NOTE - In the case of spot welds made by projection welding, the projection surface is to be considered as the external surface of the weld.





6 Dimensioning of welds

6.1 General rules

Each weld symbol may be accompanied by a certain number of dimensions.

These dimensions are written as follows, in accordance with figure 6:

1) the main dimensions relative to the cross-section are written on the left-hand side (that means before) of the symbol.

2) longitudinal dimensions are written on the right-hand side (that means after) of the symbol.




Figure 6 - Examples of the principle

The method of indicating the main dimensions is defined in

table 4. The rules for setting down these dimensions are also

6.2 Main dimensions to be shown

The dimension that locates the weld in relation to the edge of the sheet shall not appear in the symbolization but on the drawing.

6.2.1 The absence of any indication following the symbol signifies that the weld is to be continuous over the whole length of the workpiece.

6.2.2 In the absence of any indication to the contrary, butt welds are to have complete penetration.

6.2.3 For the fillet welds, there are two methods to indicate dimensions (see figure 7). Therefore, the letters a or z shall always be placed in front of the value of the corresponding dimension.



given in this table. (Standard.2.4 the case of plug or slot welds with bevelled edges, it is the dimensional the bottom of the hole which shall be taken necessary. ISO 2553:1984

https://standards.iteh.ai/catalog/standards/sist/bc24fc95-a885-429b-b2d3a1b2bcb33dc3/iso-2553-1984




Figure 7 – Methods of indicating dimensions for fillet welds