



SLOVENSKI STANDARD SIST ETS 300 974 E8:2003

01-december-2003

8 [[[HJb]`W] b]`h`Y_ca i b]_UW`g_]`g]ghYa `fZuU&ŽL`E`GdYWZ_UW`UXYUnUa cV]`bY
Ud`]_UW`Y`fA5 DŁf} GA `\$- '\$&žfUh`]]WJ) '%&%'ž]nXUU%- * Ł

Digital cellular telecommunications system (Phase 2+) (GSM); Mobile Application Part (MAP) specification (GSM 09.02 version 5.12.1 Release 1996)

iteh STANDARD PREVIEW
(standards.iteh.ai)

Ta slovenski standard je istoveten z: ^{SIST ETS 300 974 E8:2003} **ETS 300 974 Edition 8**
<https://standards.iteh.ai/catalog/standards/sist/b7195c68-9a86-450c-a625-b8b258d13d47/sist-ets-300-974-e8-2003>

ICS:

33.070.50	Globalni sistem za mobilno telekomunikacijo (GSM)	Global System for Mobile Communication (GSM)
-----------	---	--


SIST ETS 300 974 E8:2003

en

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ETS 300 974 E8:2003

<https://standards.iteh.ai/catalog/standards/sist/b7195c68-9a86-450c-a625-b8b258d13d47/sist-ets-300-974-e8-2003>



EUROPEAN
TELECOMMUNICATION
STANDARD

ETS 300 974

August 1999

Eighth Edition

Source: SMG

Reference: RE/SMG-030902QR7

ICS: 33.020

Key words: Digital cellular telecommunications system, Global System for Mobile communications (GSM)



**Digital cellular telecommunications system (Phase 2+);
Mobile Application Part (MAP) specification
(GSM 09.02 version 5.12.1 Release 1996)**

ETSI

European Telecommunications Standards Institute

ETSI Secretariat

Postal address: F-06921 Sophia Antipolis CEDEX - FRANCE

Office address: 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

Internet: secretariat@etsi.fr - <http://www.etsi.org>

Tel.: +33 4 92 94 42 00 - Fax: +33 4 93 65 47 16

Copyright Notification: No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 1999. All rights reserved.

iTeh STANDARD PREVIEW (standards.iteh.ai)

[SIST ETS 300 974 E8:2003](https://standards.iteh.ai/catalog/standards/sist/b7195c68-9a86-450c-a625-b8b258d13d47/sist-ets-300-974-e8-2003)

<https://standards.iteh.ai/catalog/standards/sist/b7195c68-9a86-450c-a625-b8b258d13d47/sist-ets-300-974-e8-2003>

Contents

Intellectual Property Rights	19
Foreword	19
1 Scope	21
1.1 Normative references	21
1.2 Abbreviations	27
2 Configuration of the mobile network.....	27
2.1 The entities of the mobile system	27
2.1.1 The Home Location Register (HLR).....	27
2.1.2 The Visitor Location Register (VLR).....	27
2.1.3 The Mobile-services Switching Centre (MSC).....	28
2.1.4 The Base Station System (BSS)	28
2.1.5 The Gateway MSC (GMSC).....	28
2.1.6 The SMS Gateway MSC	28
2.1.7 The SMS Interworking MSC.....	28
2.1.8 The VBS/VGCS Anchor MSC	29
2.1.9 The Equipment Identity Register (EIR).....	29
2.1.10 The GSM Service Control Function (gsmSCF).....	29
2.1.11 The Group Call Register (GCR)	29
2.2 Configuration of a Public Land Mobile Network (PLMN)	29
2.3 Interconnection between PLMNs.....	29
2.4 The interfaces within the mobile service.....	29
2.4.1 Interface between the HLR and the VLR (D-interface)	29
2.4.2 Interface between the HLR and the gsmSCF (J-interface)	30
2.4.3 Interface between the VLR and its associated MSC(s) (B-interface).....	30
2.4.4 Interface between VLRs (G-interface).....	30
2.4.5 Interface between the HLR and the MSC (C-interface)	30
2.4.6 Interface between MSCs (E-interface)	30
2.4.7 Interface between the MSC and Base Station Systems (A-interface).....	30
2.4.8 Interface between MSC and EIR (F-interface)	30
2.4.9 Interface between VBS/VGCS Anchor MSC and GCR (I-interface)	30
2.5 Splitting of the data storage	31
3 Overload and compatibility overview	33
3.1 Overload control.....	33
3.1.1 Overload control for MSC (outside MAP).....	33
3.1.2 Overload control for MAP entities.....	33
3.1.3 Congestion control for Signalling System No. 7	36
3.2 Compatibility	36
3.2.1 General.....	36
3.2.2 Strategy for selecting the Application Context (AC) version.....	36
3.2.2.1 Proposed method	36
3.2.2.2 Managing the version look-up table.....	37
3.2.2.3 Optimizing the method.....	38
4 Requirements concerning the use of SCCP and TC.....	39
4.1 Use of SCCP.....	39
4.1.1 SCCP Class	39
4.1.2 Sub-System Number (SSN)	39
4.1.3 SCCP addressing.....	39
4.1.3.1 Introduction	39
4.1.3.2 The Mobile-services Switching Centre (MSC).....	40
4.1.3.2.1 MSC interaction during handover	40
4.1.3.2.2 MSC for short message routing.....	40
4.1.3.3 The Home Location Register (HLR)	40

	4.1.3.3.1	During call set-up	40
	4.1.3.3.2	Before location updating completion	41
	4.1.3.3.3	After location updating completion	41
	4.1.3.3.4	VLR restoration	41
	4.1.3.4	The Visitor Location Register (VLR)	42
	4.1.3.4.1	Inter-VLR information retrieval	42
	4.1.3.4.2	HLR request	42
	4.1.3.5	The Interworking MSC (IWMSC) for Short Message Service	42
	4.1.3.6	The Equipment Identity Register (EIR)	42
	4.1.3.7	Summary table	42
4.2	Use of TC		43
5	General on MAP services		45
5.1	Terminology and definitions		45
5.2	Modelling principles		45
5.3	Common MAP services		45
	5.3.1	MAP-OPEN service	46
	5.3.2	MAP-CLOSE service	48
	5.3.3	MAP-DELIMITER service	49
	5.3.4	MAP-U-ABORT service	49
	5.3.5	MAP-P-ABORT service	50
	5.3.6	MAP-NOTICE service	51
5.4	Sequencing of services		51
5.5	General rules for mapping of services onto TC		53
	5.5.1	Mapping of common services	53
	5.5.2	Mapping of user specific services	54
5.6	Definition of parameters		55
	5.6.1	Common parameters	57
	5.6.1.1	Invoke Id	57
	5.6.1.2	Linked Id	57
	5.6.1.3	Provider error	57
	5.6.1.4	User error	57
	5.6.2	Numbering and identification parameter	59
	5.6.2.1	IMSI	59
	5.6.2.2	TMSI	59
	5.6.2.3	IMEI	59
	5.6.2.4	Previous location area Id	59
	5.6.2.5	Stored location area Id	60
	5.6.2.6	Current location area Id	60
	5.6.2.7	Target location area Id	60
	5.6.2.8	Target cell Id	60
	5.6.2.9	[Spare]	60
	5.6.2.10	Originating entity number	60
	5.6.2.11	MSC number	60
	5.6.2.12	Target MSC number	60
	5.6.2.13	HLR number	60
	5.6.2.14	VLR number	60
	5.6.2.15	HLR Id	60
	5.6.2.16	LMSI	60
	5.6.2.17	MS ISDN	60
	5.6.2.18	OMC Id	60
	5.6.2.19	Roaming number	60
	5.6.2.20	[Spare]	61
	5.6.2.21	Handover number	61
	5.6.2.22	Forwarded-to number	61
	5.6.2.23	Forwarded-to subaddress	61
	5.6.2.24	Called number	61
	5.6.2.25	Calling number	61
	5.6.2.26	Originally dialled number	61
	5.6.2.27	Service centre address	61
	5.6.2.28	Zone Code	61
	5.6.2.29	MSISdn-Alert	61

ETS 300 974 (GSM 09.02 version 5.12.1 Release 1996): August 1999

	5.6.2.30	Location Information	61
	5.6.2.31	GMSC Address	61
	5.6.2.32	VMSC Address	61
	5.6.2.33	Group Id	61
5.6.3		Subscriber management parameters	62
	5.6.3.1	Category	62
	5.6.3.2	Equipment status	62
	5.6.3.3	Extensible Bearer service	62
	5.6.3.4	Extensible Teleservice	62
	5.6.3.5	Extensible Basic Service Group	62
	5.6.3.6	GSM bearer capability	62
	5.6.3.7	Subscriber Status	62
	5.6.3.8	CUG Outgoing Access indicator	62
	5.6.3.9	Operator Determined Barring General Data	62
	5.6.3.10	ODB HPLMN Specific Data	63
	5.6.3.11	Regional Subscription Data	63
	5.6.3.12	Regional Subscription Response	63
	5.6.3.13	Roaming Restriction Due To Unsupported Feature	63
	5.6.3.14	Extensible SS-Info	63
	5.6.3.15	Extensible Forwarding information	63
	5.6.3.16	Extensible Forwarding feature	63
	5.6.3.17	Extensible SS-Status	64
	5.6.3.18	Extensible Forwarding Options	64
	5.6.3.19	Extensible No reply condition timer	64
	5.6.3.20	Extensible Call barring information	64
	5.6.3.21	Extensible Call barring feature	64
	5.6.3.22	CUG info	64
	5.6.3.23	CUG subscription	64
	5.6.3.24	CUG interlock	64
	5.6.3.25	CUG index	64
	5.6.3.26	CUG feature	65
	5.6.3.27	Inter CUG options	65
	5.6.3.28	Intra CUG restrictions	65
	5.6.3.29	Extensible SS-Data	65
	5.6.3.30	Subscriber State	65
	5.6.3.31	Requested Info	65
	5.6.3.32	Suppression of Announcement	65
	5.6.3.33	Suppress T-CSI	66
	5.6.3.34	GMSC CAMEL Subscription Info	66
	5.6.3.35	VLR CAMEL Subscription Info	66
	5.6.3.36	Supported CAMEL Phases	66
	5.6.3.37	CUG Subscription Flag	66
	5.6.3.38	CAMEL Subscription Info Withdraw	66
	5.6.3.39	Voice Group Call Service (VGCS) Data	66
	5.6.3.40	Voice Broadcast Service (VBS) Data	66
5.6.4		Supplementary services parameters	66
	5.6.4.1	SS-Code	66
	5.6.4.2	SS-Status	67
	5.6.4.3	SS-Data	67
	5.6.4.4	Override Category	67
	5.6.4.5	CLI Restriction Option	67
	5.6.4.6	Forwarding Options	67
	5.6.4.7	No reply condition timer	67
	5.6.4.8	- 5.6.4.14 [Spare]	67
	5.6.4.15	Forwarding information	67
	5.6.4.16	Forwarding feature	68
	5.6.4.17	[Spare]	68
	5.6.4.18	Call barring information	68
	5.6.4.19	Call barring feature	68
	5.6.4.20	New password	68
	5.6.4.21	Current password	68
	5.6.4.22	Guidance information	68
	5.6.4.23	[Spare]	69

iTeh STANDARD PREVIEW
(standardsiteh.ai)

https://standardsiteh.ai/catalog/standards/sist/300-974-e8-2003/sist/300-974-e8-2003-2003
https://standardsiteh.ai/catalog/standards/sist/300-974-e8-2003/sist/300-974-e8-2003-2003

	5.6.4.24	SS-Info	69
	5.6.4.25	- 5.6.4.35 [Spare]	69
	5.6.4.36	USSD Data Coding Scheme	69
	5.6.4.37	USSD String	69
	5.6.4.38	Bearer service	69
	5.6.4.39	Teleservice	69
	5.6.4.40	Basic Service Group	69
	5.6.4.41	eMLPP information	69
5.6.5	Call parameters		69
	5.6.5.1	Call reference number	69
	5.6.5.2	Interrogation type	70
	5.6.5.3	OR interrogation	70
	5.6.5.4	OR capability	70
	5.6.5.5	Forwarding reason	70
	5.6.5.6	Forwarding interrogation required	70
	5.6.5.7	O-CSI	70
5.6.6	Radio parameters		70
	5.6.6.1	- 5.6.6.6 [Spare]	70
	5.6.6.7	HO-Number Not Required	70
5.6.7	Authentication parameters		70
	5.6.7.1	Authentication set list	70
	5.6.7.2	Rand	70
	5.6.7.3	Sres	70
	5.6.7.4	Kc	71
	5.6.7.5	[Spare]	71
	5.6.7.6	Cksn	71
	5.6.7.7	Ciphering mode	71
5.6.8	Short message parameters		71
	5.6.8.1	SM-RP-DA	71
	5.6.8.2	SM-RP-OA	71
	5.6.8.3	MWD status	71
	5.6.8.4	SM-RP-UI	71
	5.6.8.5	SM-RP-PR	71
	5.6.8.6	SM Delivery Outcome	71
	5.6.8.7	More Messages To Send	72
	5.6.8.8	Alert Reason	72
	5.6.8.9	Absent Subscriber Diagnostic SM	72
5.6.9	Access and signalling system related parameters		72
	5.6.9.1	BSS-apdu	72
	5.6.9.2	CM service type	72
	5.6.9.3	Access connection status	72
	5.6.9.4	External Signal Information	72
	5.6.9.5	Access signalling information	72
	5.6.9.6	Location update type	73
	5.6.9.7	Protocol ID	73
	5.6.9.8	Network signal information	73
5.6.10	System operations parameters		73
	5.6.10.1	Network resources	73
	5.6.10.2	Trace reference	74
	5.6.10.3	Trace type	74
5.7	Representation of a list of a basic parameter in service-primitives		74
6	Mobility services		75
6.1	Location management services		75
6.1.1	MAP_UPDATE_LOCATION_AREA service		75
	6.1.1.1	Definition	75
	6.1.1.2	Service primitives	75
	6.1.1.3	parameter definitions and use	75
6.1.2	MAP_UPDATE_LOCATION service		76
	6.1.2.1	Definition	76
	6.1.2.2	Service primitives	76
	6.1.2.3	Parameter definitions and use	76
6.1.3	MAP_CANCEL_LOCATION service		77

ETS 300 974 (GSM 09.02 version 5.12.1 Release 1996): August 1999

	6.1.3.1	Definition.....	77
	6.1.3.2	Service primitives.....	77
	6.1.3.3	Parameter definitions and use.....	78
6.1.4		MAP_SEND_IDENTIFICATION service	78
	6.1.4.1	Definition.....	78
	6.1.4.2	Service primitives.....	78
	6.1.4.3	Parameter definitions and use.....	78
6.1.5		MAP_DETACH_IMSI service	79
	6.1.5.1	Definition.....	79
	6.1.5.2	Service primitives.....	79
	6.1.5.3	Parameter definitions and use.....	79
6.1.6		MAP_PURGE_MS service	80
	6.1.6.1	Definition.....	80
	6.1.6.2	Service primitives.....	80
	6.1.6.3	Parameter definitions and use.....	80
6.2		Paging and search	80
	6.2.1	MAP_PAGE service	80
	6.2.1.1	Definition.....	80
	6.2.1.2	Service primitives.....	81
	6.2.1.3	Parameter definitions and use.....	81
	6.2.2	MAP_SEARCH_FOR_MS service	81
	6.2.2.1	Definition.....	81
	6.2.2.2	Service primitives.....	82
	6.2.2.3	Parameter definitions and use.....	82
6.3		Access management services.....	82
	6.3.1	MAP_PROCESS_ACCESS_REQUEST service	82
	6.3.1.1	Definition.....	82
	6.3.1.2	Service primitives.....	83
	6.3.1.3	Parameter definitions and use.....	83
6.4		Handover services	84
	6.4.1	MAP_PREPARE_HANDOVER service.....	84
	6.4.1.1	Definition.....	84
	6.4.1.2	Service primitives.....	84
	6.4.1.3	Parameter use	84
	6.4.2	MAP_SEND_END_SIGNAL service	85
	6.4.2.1	Definition.....	85
	6.4.2.2	Service primitives.....	85
	6.4.2.3	Parameter use	85
	6.4.3	MAP_PROCESS_ACCESS_SIGNALLING service	86
	6.4.3.1	Definition.....	86
	6.4.3.2	Service primitives.....	86
	6.4.3.3	Parameter use	86
	6.4.4	MAP_FORWARD_ACCESS_SIGNALLING service.....	86
	6.4.4.1	Definition.....	86
	6.4.4.2	Service primitives.....	86
	6.4.4.3	Parameter use	87
	6.4.5	MAP_PREPARE_SUBSEQUENT_HANDOVER service.....	87
	6.4.5.1	Definition.....	87
	6.4.5.2	Service primitives.....	87
	6.4.5.3	Parameter use	87
	6.4.6	MAP_ALLOCATE_HANDOVER_NUMBER service	88
	6.4.6.1	Definition.....	88
	6.4.6.2	Service primitives.....	88
	6.4.6.3	Parameter use	88
	6.4.7	MAP_SEND_HANDOVER_REPORT service.....	88
	6.4.7.1	Definition.....	88
	6.4.7.2	Service primitives.....	88
	6.4.7.3	Parameter use	89
6.5		Authentication management services.....	89
	6.5.1	MAP_AUTHENTICATE service	89
	6.5.1.1	Definition.....	89
	6.5.1.2	Service primitives.....	89
	6.5.1.3	Parameter use	89

6.5.2	MAP_SEND_AUTHENTICATION_INFO service	90
6.5.2.1	Definition	90
6.5.2.2	Service primitives	90
6.5.2.3	Parameter use	90
6.6	Security management services	91
6.6.1	MAP_SET_CIPHERING_MODE service	91
6.6.1.1	Definitions	91
6.6.1.2	Service primitives	91
6.6.1.3	Parameter use	91
6.7	International mobile equipment identities management services	91
6.7.1	MAP_CHECK_IMEI service	91
6.7.1.1	Definition	91
6.7.1.2	Service primitives	91
6.7.1.3	Parameter use	92
6.7.2	MAP_OBTAIN_IMEI service	92
6.7.2.1	Definition	92
6.7.2.2	Service primitives	93
6.7.2.3	Parameter use	93
6.8	Subscriber management services	93
6.8.1	MAP-INSERT-SUBSCRIBER-DATA service	93
6.8.1.1	Definition	93
6.8.1.2	Service primitives	94
6.8.1.3	Parameter use	94
6.8.1.4	Basic service information related to supplementary services	100
6.8.2	MAP-DELETE-SUBSCRIBER-DATA service	100
6.8.2.1	Definition	100
6.8.2.2	Service primitives	101
6.8.2.3	Parameter use	101
6.9	Identity management services	102
6.9.1	MAP-PROVIDE-TMSI service	102
6.9.1.1	Definition	102
6.9.1.2	Service primitives	103
6.9.1.3	Parameter use	103
6.9.2	MAP-FORWARD-NEW-TMSI service	103
6.9.2.1	Definition	103
6.9.2.2	Service primitives	103
6.9.2.3	Parameter use	103
6.10	Fault recovery services	103
6.10.1	MAP_RESET service	103
6.10.1.1	Definition	103
6.10.1.2	Service primitives	104
6.10.1.3	Parameter definition and use	104
6.10.2	MAP_FORWARD_CHECK_SS_INDICATION service	104
6.10.2.1	Definition	104
6.10.2.2	Service primitives	104
6.10.2.3	Parameter definition and use	104
6.10.3	MAP_RESTORE_DATA service	104
6.10.3.1	Definition	104
6.10.3.2	Service primitives	105
6.10.3.3	Parameter definitions and use	105
6.11	Subscriber Information services	106
6.11.1	MAP-ANY-TIME-INTERROGATION service	106
6.11.1.1	Definition	106
6.11.1.2	Service primitives	106
6.11.1.3	Parameter definition and use	106
6.11.2	MAP-PROVIDE-SUBSCRIBER-Info service	107
6.11.2.1	Definition	107
6.11.2.2	Service primitives	107
6.11.2.3	Parameter definition and use	107
7	Operation and maintenance services	108
7.1	Subscriber tracing services	108

ETS 300 974 (GSM 09.02 version 5.12.1 Release 1996): August 1999

7.1.1	MAP-ACTIVATE-TRACE-MODE service	108
7.1.1.1	Definition	108
7.1.1.2	Service primitives	108
7.1.1.3	Parameter use	108
7.1.2	MAP-DEACTIVATE-TRACE-MODE service	109
7.1.2.1	Definition	109
7.1.2.2	Service primitives	109
7.1.2.3	Parameter use	109
7.1.3	MAP-TRACE-SUBSCRIBER-ACTIVITY service	109
7.1.3.1	Definition	109
7.1.3.2	Service primitives	110
7.1.3.3	Parameter use	110
7.2	Other operation and maintenance services	110
7.2.1	MAP-SEND-IMSI service	110
7.2.1.1	Definition	110
7.2.1.2	Service primitives	110
7.2.1.3	Parameter use	111
8	Call handling services	111
8.1	MAP_SEND_ROUTING_INFORMATION service	111
8.1.1	Definition	111
8.1.2	Service primitives	111
8.1.3	Parameter use	112
8.2	MAP_PROVIDE_ROAMING_NUMBER service	115
8.2.1	Definition	115
8.2.2	Service primitives	115
8.2.3	Parameter use	115
8.3	MAP_RESUME_CALL_HANDLING service	117
8.3.1	Definition	117
8.3.2	Service primitives	117
8.3.3	Parameter use	117
9	Supplementary services related services	118
9.1	MAP_REGISTER_SS service	118
9.1.1	Definition	118
9.1.2	Service primitives	118
9.1.3	Parameter use	118
9.2	MAP_ERASE_SS service	119
9.2.1	Definition	119
9.2.2	Service primitives	120
9.2.3	Parameter use	120
9.3	MAP_ACTIVATE_SS service	121
9.3.1	Definition	121
9.3.2	Service primitives	121
9.3.3	Parameter use	121
9.4	MAP_DEACTIVATE_SS service	122
9.4.1	Definitions	122
9.4.2	Service primitives	123
9.4.3	Parameter use	123
9.5	MAP_INTERROGATE_SS service	124
9.5.1	Definitions	124
9.5.2	Service primitives	124
9.5.3	Parameter use	124
9.6	MAP_INVOKE_SS service	127
9.6.1	Definitions	127
9.6.2	Service primitives	127
9.6.3	Parameter use	127
9.7	MAP_REGISTER_PASSWORD service	128
9.7.1	Definitions	128
9.7.2	Service primitives	128
9.7.3	Parameter use	128
9.8	MAP_GET_PASSWORD service	128
9.8.1	Definitions	128

	9.8.2	Service primitives.....	129
	9.8.3	Parameter use	129
9.9		MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service	129
	9.9.1	Definitions	129
	9.9.2	Service primitives.....	129
	9.9.3	Parameter use	130
9.10		MAP_UNSTRUCTURED_SS_REQUEST service.....	130
	9.10.1	Definitions	130
	9.10.2	Service primitives.....	130
	9.10.3	Parameter use	131
9.11		MAP_UNSTRUCTURED_SS_NOTIFY service.....	131
	9.11.1	Definitions	131
	9.11.2	Service primitives.....	131
	9.11.3	Parameter use	132
10		Short message service management services.....	132
10.1		MAP-SEND-ROUTING-INFO-FOR-SM service.....	132
	10.1.1	Definition.....	132
	10.1.2	Service primitives.....	133
	10.1.3	Parameter use	133
10.2		MAP-MO-FORWARD-SHORT-MESSAGE service	134
	10.2.1	Definition.....	134
	10.2.2	Service primitives.....	134
	10.2.3	Parameter use	134
10.3		MAP-REPORT-SM-DELIVERY-STATUS service.....	135
	10.3.1	Definition.....	135
	10.3.2	Service primitives.....	135
	10.3.3	Parameter use	135
10.4		MAP-READY-FOR-SM service.....	136
	10.4.1	Definition.....	136
	10.4.2	Service primitives.....	137
	10.4.3	Parameter use	137
10.5		MAP-ALERT-SERVICE-CENTRE service.....	137
	10.5.1	Definition.....	137
	10.5.2	Service primitives.....	138
	10.5.3	Parameter use	138
10.6		MAP-INFORM-SERVICE-CENTRE service.....	138
	10.6.1	Definition.....	138
	10.6.2	Service primitives.....	139
	10.6.3	Parameter use	139
10.7		MAP-SEND-INFO-FOR-MT-SMS service.....	139
	10.7.1	Definition.....	139
	10.7.2	Service primitives.....	139
	10.7.3	Parameter use	139
10.8		MAP-SEND-INFO-FOR-MO-SMS service	140
	10.8.1	Definition.....	140
	10.8.2	Service primitives.....	140
	10.8.3	Parameter use	140
10.9		MAP-MT-FORWARD-SHORT-MESSAGE service.....	141
	10.9.1	Definition.....	141
	10.9.2	Service primitives.....	141
	10.9.3	Parameter use	141
11		General.....	143
	11.1	Overview	143
	11.2	Underlying services	143
	11.3	Model.....	143
	11.4	Conventions	143
12		Elements of procedure	144
	12.1	Dialogue establishment.....	144
	12.1.1	Handling of unknown operations	144
	12.1.2	Receipt of a MAP-OPEN request primitive.....	145

12.1.3	Receipt of a TC-BEGIN indication.....	145
12.1.4	Receipt of a MAP-OPEN response	148
12.1.5	Receipt of the first TC-CONTINUE ind.....	148
12.1.6	Receipt of a TC-END ind.....	148
12.1.7	Receipt of a TC-U-ABORT ind	148
12.1.8	Receipt of a TC-P-ABORT ind	149
12.2	Dialogue continuation	149
12.2.1	Sending entity.....	149
12.2.2	Receiving entity	149
12.3	Dialogue termination	149
12.3.1	Receipt of a MAP-CLOSE request.....	149
12.3.2	Receipt of a TC-END indication	150
12.4	User Abort.....	150
12.4.1	MAP-U-ABORT request	150
12.4.2	TC-U-ABORT ind	150
12.5	Provider Abort.....	150
12.5.1	MAP PM error situation	150
12.5.2	TC-P-ABORT ind.....	150
12.5.3	TC-U-ABORT ind	151
12.6	Procedures for MAP specific services	151
12.6.1	Service invocation	151
12.6.2	Service invocation receipt	151
12.6.3	Service response.....	152
12.6.4	Receipt of a response	153
12.6.4.1	Receipt of a TC-RESULT-NL indication	153
12.6.4.2	Receipt of a TC-RESULT-L indication.....	153
12.6.4.3	Receipt of a TC-U-ERROR indication	153
12.6.4.4	Receipt of a TC-INVOKE indication.....	154
12.6.4.5	Receipt of a TC-U-REJECT indication	154
12.6.4.6	Receipt of a TC-L-REJECT indication	154
12.6.4.7	Receipt of a TC-L-CANCEL indication	155
12.6.4.8	Receipt of a TC-NOTICE indication.....	155
12.6.5	Other events.....	155
12.6.5.1	Receipt of a TC-U-REJECT	155
12.6.5.2	Receipt of a TC-R-REJECT indication	156
12.6.5.3	Receipt of a TC-L-REJECT indication	156
12.6.6	Parameter checks	156
12.6.7	Returning state machines to idle	156
12.6.8	Load control.....	157
13	Mapping on to TC services.....	157
13.1	Dialogue control.....	157
13.1.1	Directly mapped parameters	157
13.1.2	Use of other parameters of dialogue handling primitives	157
13.1.2.1	Dialogue Id.....	157
13.1.2.2	Application-context-name	157
13.1.2.3	User information	157
13.1.2.4	Component present	157
13.1.2.5	Termination.....	157
13.1.2.6	P-Abort-Cause	157
13.1.2.7	Quality of service	158
13.2	Service specific procedures.....	158
13.2.1	Directly mapped parameters	158
13.2.2	Use of other parameters of component handling primitives.....	158
13.2.2.1	Dialogue Id.....	158
13.2.2.2	Class.....	158
13.2.2.3	Linked Id	159
13.2.2.4	Operation	159
13.2.2.5	Error.....	160
13.2.2.6	Parameters	160
13.2.2.7	Time out.....	160
13.2.2.8	Last component	160
13.2.2.9	Problem code	160

		13.2.2.9.1	Mapping to MAP User Error	160
		13.2.2.9.2	Mapping to MAP Provider Error parameter	160
		13.2.2.9.3	Mapping to diagnostic parameter	161
13.3	SDL descriptions			161
14	Abstract syntax of the MAP protocol			187
14.1	General			187
	14.1.1	Encoding rules		187
	14.1.2	Use of TC		187
		14.1.2.1	Use of Global Operation and Error codes defined outside MAP	188
	14.1.3	Use of information elements defined outside MAP		188
	14.1.4	Compatibility considerations		189
	14.1.5	Structure of the Abstract Syntax of MAP		189
	14.1.6	Application Contexts		190
14.2	Operation packages			192
	14.2.1	General aspects		192
	14.2.2	Packages specifications		193
		14.2.2.1	Location updating	193
		14.2.2.2	Location cancellation	193
		14.2.2.3	Roaming number enquiry	193
		14.2.2.4	Information retrieval	193
		14.2.2.5	Inter-VLR information retrieval	193
		14.2.2.6	IMSI retrieval	194
		14.2.2.7	Call control transfer	194
		14.2.2.8	- 14.2.2.9 [Spare]	194
		14.2.2.10	Interrogation	194
		14.2.2.11	[Spare]	194
		14.2.2.12	Handover Control	194
		14.2.2.13	Subscriber Data management stand alone	195
		14.2.2.14	Equipment management	195
		14.2.2.15	Subscriber data management	195
		14.2.2.16	Location register restart	195
		14.2.2.17	Tracing stand-alone	196
		14.2.2.18	Functional SS handling	196
		14.2.2.19	Tracing	196
		14.2.2.20	Binding	196
		14.2.2.21	Unstructured SS handling	196
		14.2.2.22	MO Short message relay services	197
		14.2.2.23	Short message gateway services	197
		14.2.2.24	MT Short message relay services	197
		14.2.2.25	[Spare]	198
		14.2.2.26	Message waiting data management	198
		14.2.2.27	Alerting	198
		14.2.2.28	Data restoration	198
		14.2.2.29	Purging	198
		14.2.2.30	Subscriber information enquiry	198
		14.2.2.31	Any time information enquiry	199
14.3	Application contexts			200
	14.3.1	General aspects		200
	14.3.2	Application context definitions		201
		14.3.2.1	[Spare]	201
		14.3.2.2	Location Updating	201
		14.3.2.3	Location Cancellation	201
		14.3.2.4	Roaming number enquiry	201
		14.3.2.5	[Spare]	202
		14.3.2.6	Location Information Retrieval	202
		14.3.2.7	Call control transfer	202
		14.3.2.8	- 14.3.2.10 [Spare]	202
		14.3.2.11	Location registers restart	202
		14.3.2.12	Handover control	202
		14.3.2.13	IMSI Retrieval	203

ETS 300 974 (GSM 09.02 version 5.12.1 Release 1996): August 1999

	14.3.2.14	Equipment Management	203
	14.3.2.15	Information retrieval.....	203
	14.3.2.16	Inter-VLR information retrieval.....	203
	14.3.2.17	Stand Alone Subscriber Data Management	203
	14.3.2.18	Tracing.....	204
	14.3.2.19	Network functional SS handling.....	204
	14.3.2.20	Network unstructured SS handling	204
	14.3.2.21	Short Message Gateway	204
	14.3.2.22	Mobile originating Short Message Relay	205
	14.3.2.23	[Spare]	205
	14.3.2.24	Short message alert	205
	14.3.2.25	Short message waiting data management	205
	14.3.2.26	Mobile terminating Short Message Relay	205
	14.3.2.27	MS purging	206
	14.3.2.28	Subscriber information enquiry	206
	14.3.2.29	Any time information enquiry	206
	14.3.3	ASN.1 Module for application-context-names	207
14.4		MAP Dialogue Information	209
14.5		MAP operation and error codes	211
14.6		MAP operation and error types	216
	14.6.1	Mobile Service Operations	216
	14.6.2	Operation and Maintenance Operations	220
	14.6.3	Call Handling Operations	222
	14.6.4	Supplementary service operations	224
	14.6.5	Short message service operations	228
	14.6.6	Errors.....	231
14.7		MAP constants and data types	236
	14.7.1	Mobile Service data types	236
	14.7.2	Operation and maintenance data types	246
	14.7.3	Call handling data types	247
	14.7.4	Supplementary service data types	250
	14.7.5	Supplementary service codes	253
	14.7.6	Short message data types	255
	14.7.7	Error data types	257
	14.7.8	Common data types	261
	14.7.9	Teleservice Codes.....	265
	14.7.10	Bearer Service Codes	267
	14.7.11	Extension data types	269
15		General on MAP user procedures.....	270
	15.1	Introduction	270
	15.2	Common aspects of user procedure descriptions	270
		15.2.1 General conventions	270
		15.2.2 Naming conventions.....	270
		15.2.3 Convention on primitives parameters.....	272
		15.2.3.1 Open service.....	272
		15.2.3.2 Close service	272
		15.2.4 Version handling at dialogue establishment.....	272
		15.2.4.1 Behaviour at the initiating side.....	272
		15.2.4.2 Behaviour at the responding side	272
		15.2.5 Abort Handling.....	273
		15.2.6 SDL conventions	273
	15.3	Interaction between MAP Provider and MAP Users	273
16		Mobility procedures	274
	16.1	Location management Procedures.....	274
		16.1.1 Location updating	279
		16.1.1.1 General.....	279
		16.1.1.2 Detailed procedure in the MSC.....	283
		16.1.1.3 Detailed procedure in the VLR.....	287
		16.1.1.4 Detailed procedure in the HLR	299
		16.1.1.5 Send Identification	302
		16.1.1.5.1 General	302