
**Tools for pressing — Gas springs —
Part 5:
Safety instructions for gas springs**

Outillage de presse — Ressorts à gaz —

Partie 5: Instructions de sécurité pour les ressorts à gaz

iTeh Standards
(<https://standards.iteh.ai>)
Document Preview

ISO 11901-5:2021

<https://standards.iteh.ai/catalog/standards/iso/14483045-273e-46b6-b9d2-16d337e925d6/iso-11901-5-2021>



iTeh Standards
(<https://standards.iteh.ai>)
Document Preview

ISO 11901-5:2021

<https://standards.iteh.ai/catalog/standards/iso/14483045-273e-46b6-b9d2-16d337e925d6/iso-11901-5-2021>



COPYRIGHT PROTECTED DOCUMENT

© ISO 2021

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
CP 401 • Ch. de Blandonnet 8
CH-1214 Vernier, Geneva
Phone: +41 22 749 01 11
Email: copyright@iso.org
Website: www.iso.org

Published in Switzerland

Contents

	Page
Foreword	iv
Introduction	v
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 Safety protection for nitrogen gas springs	1
4.1 General	1
4.2 Uncontrolled return stroke safety protection	1
4.3 Overstroke safety protection	2
4.4 Overpressure safety protection	2
Annex A (informative) Instructions for use	3
Bibliography	16

iTeh Standards
(<https://standards.iteh.ai>)
Document Preview

ISO 11901-5:2021

<https://standards.iteh.ai/catalog/standards/iso/14483045-273e-46b6-b9d2-16d337e925d6/iso-11901-5-2021>

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular, the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see www.iso.org/patents).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT), see www.iso.org/iso/foreword.html.

This document was prepared by Technical Committee ISO/TC 29, *Small tools*, Subcommittee SC 8, *Tools for pressing and moulding*.

A list of all parts in the ISO 11901 series can be found on the ISO website.

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at www.iso.org/members.html.

Introduction

This document was developed to align the ISO standard with the most commonly used gas springs safety standard, and to give some recommendations about instructions for use.

iTeh Standards
(<https://standards.iteh.ai>)
Document Preview

ISO 11901-5:2021

<https://standards.iteh.ai/catalog/standards/iso/14483045-273e-46b6-b9d2-16d337e925d6/iso-11901-5-2021>

Tools for pressing — Gas springs —

Part 5: Safety instructions for gas springs

1 Scope

This document describes the safety requirements for gas springs in accordance with ISO 11901-1, ISO 11901-3 and ISO 11901-4 intended for use in press tool and their correct installation instructions.

The instructions and operating conditions described in [Annex A](#) help to maximise lifetime and ensure the safe operation of nitrogen gas springs.

2 Normative references

There are no normative references in this document.

3 Terms and definitions

No terms and definitions are listed in this document

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- ISO Online browsing platform: available at <https://www.iso.org/obp>
- IEC Electropedia: available at <http://www.electropedia.org/>

4 Safety protection for nitrogen gas springs

4.1 General

Incorrect use of nitrogen gas springs can pose a risk to people and the machine/die.

Some potential causes of damage and the mode of operation of the protection equipment used to avoid them are described in [4.2](#) to [4.4](#).

4.2 Uncontrolled return stroke safety protection

It is possible that the piston rod of the nitrogen gas spring does not immediately follow the return stroke of the press: this can be caused by a jammed tool part or cam (see [Figure 1](#)). As a result, when the jammed part is released, the piston rod of the nitrogen gas spring exceeds the permitted speed during the return stroke and the piston rod slams unchecked onto the final stop (return stroke of the rod pushing out the jammed part without stamping counterforce). This can seriously damage the nitrogen gas spring or cause it to fail. To avoid this, nitrogen gas springs shall be designed to vent the gas to the atmosphere – thereby depressurizing the spring – in the event that the maximum permitted piston rod speed is exceeded. This reduces the risk of injuries caused by the ejection of gas spring parts.




Figure 1 — Return stroke of nitrogen gas spring without counterforce

4.3 Overstroke safety protection

Overstroke occurs when the piston rod is pushed deeper into the gas spring body than nominal stroke. This could damage the gas spring (see Figure 2) and cause sudden dislocation of spring body (e.g. the spring base). Therefore, gas springs shall be designed to vent the gas to the atmosphere in a controlled manner in the event of overstroke.




Figure 2 — Damaging of the gas spring due to overstroke

4.4 Overpressure safety protection

If the pressure inside gas springs rises above the permitted limit, due to fluid penetration or incorrect charging, gas springs can break away. Therefore, gas springs shall include overpressure protection.

When the overpressure protection system is triggered, the gas is vented to the atmosphere.

Annex A (informative)

Instructions for use

A.1 General

Nitrogen gas springs use should comply with the following instructions to ensure their safe operation. Moreover, compliance with the operating instructions of the nitrogen gas springs manufacturer is also required.

A.2 Symbols

The symbols in [Table A.1](#) are used throughout this annex.

Table A.1 — Symbols used in this annex

Symbol	Designation	Unit
d_1	cylinder body outside diameter of nitrogen gas spring	mm
d_2	diameter of holes and pockets	mm
d_3	drill diameter	mm
F	force	N
h_1	safeguard gap	mm
l_1	cylinder body length of nitrogen gas spring	mm
p_{\max}	maximum charging pressure	bar
T_{\max}	maximum operating temperature	°C
T_{\min}	minimum operating temperature	°C
v	piston rod speed	m/s

A.3 Operating conditions

Nitrogen gas springs for installation in stamping dies should be designed for

- at least two million full strokes at maximum charging pressure, and
- maximum operating temperature.

Furthermore, they should be designed for all permitted mounting options listed in [A.10](#).

Ideally, nitrogen gas springs should be mounted within the die (see [A.10](#)).

CAUTION — For mounting and demounting operations the gas spring rod should be fully extended and free of any outside load.

Dies fitted with nitrogen gas springs should carry an appropriate warning and caution sign. [Figure A.1](#) shows an example.

Caution				
This die is fitted with ___ nitrogen gas springs with a maximum charging pressure of 150 bar and/or 180 bar.				
No	Quantity	Spring type	Charging pressure in bar	Total force in daN
1	_____	_____	_____	_____
2	_____	_____	_____	_____
3	_____	_____	_____	_____
4	_____	_____	_____	_____
5	_____	_____	_____	_____

Figure A.1 — Example of a caution sign to affix to dies containing nitrogen gas springs

A.4 Piston rod speed

To avoid the high-speed return of the rod and thus prevent internal damage, the piston rod should not be released suddenly from a pressurized position. A maximum permitted piston rod speed v_{\max} should be specified. See [Figure A.2](#).




Figure A.2 — Specification of the permitted piston rod speed

A.5 Operating temperature

The specified permitted operating temperature range should be from 0 °C to 80 °C. The operating temperature can rise either due to external warming (e.g. thermoforming or drop forging) or internal warming (frictional energy, compression energy). Exceedance of the temperature range can reduce spring life ([Figure A.3](#)).