This document is not an ASTM standard and is intended only to provide the user of an ASTM standard an indication of what changes have been made to the previous version. Because it may not be technically possible to adequately depict all changes accurately, ASTM recommends that users consult prior editions as appropriate. In all cases only the current version of the standard as published by ASTM is to be considered the official document.



Designation: F739 - 07 F739 - 12

# Standard Test Method for Permeation of Liquids and Gases through Protective Clothing Materials under Conditions of Continuous Contact<sup>1</sup>

This standard is issued under the fixed designation F739; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon ( $\epsilon$ ) indicates an editorial change since the last revision or reapproval.

### INTRODUCTION

Workers involved in the production, use, and transportation of liquid and gaseous chemicals can be exposed to numerous compounds capable of causing harm upon contact with the human body. The deleterious effects of these chemicals can range from acute trauma such as skin irritation and burn, to chronic degenerative disease such as cancer. Since engineering controls may not eliminate all possible exposures, attention is often placed on reducing the potential for direct skin contact through the use of protective clothing that resists permeation, penetration, and degradation.

This test method is used to measure the permeation of liquids and gases through protective clothing materials under the conditions of continuous contact of the clothing material by the <u>ehallengetest</u> chemical. Resistance to permeation under the condition of intermittent contact with the <u>ehallengetest</u> chemical should be determined by Test Method F1383. In certain situations, the permeation of liquids through protective clothing materials can be measured using a permeation cup following Test Method F1407. Penetration of liquids should be determined by Test Method F903. An undesirable change in the physical properties of protective clothing materials is called degradation. Procedures for measuring the degradation of rubbers, plastics, and coated fabrics are found in Test Method D471, Test Method D543, and Test Method D751, respectively. A starting point for selecting the chemicals to be used in assessing the chemical resistance of clothing materials is Guide F1001.

### 1. Scope

1.1 This test method measures the permeation of liquids and gases through protective clothing materials under the condition of continuous contact.  $\frac{AS IM + 739 - 12}{AS IM + 739 - 12}$ 

1.2 This test method is designed for use when the <u>challengetest</u> chemical is a gas or a liquid, where the liquid is either volatile (that is, having a vapor pressure greater than 1 mm Hg at 25°C) or soluble in water or another liquid that does not interact with the clothing material.

<u>1.3</u> Values states in SI units are to be regarded as standard. Values given in parentheses are not exact equivalents and are given for information only.

1.4 This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use. Specific precautionary statements are given in Section 7.

## 2. Referenced Documents

2.1 ASTM Standards:<sup>2</sup>

- D471 Test Method for Rubber Property—Effect of Liquids
- D543 Practices for Evaluating the Resistance of Plastics to Chemical Reagents

D751 Test Methods for Coated Fabrics

<sup>&</sup>lt;sup>1</sup> This test method is under the jurisdiction of ASTM Committee F23 on Personal Protective Clothing and Equipment and is the direct responsibility of Subcommittee F23.30 on Chemicals.

Current edition approved July 1, 2007Sept. 1, 2012. Published October 2007October 2012. Originally approved in 1981. Last previous edition approved in 19992007 as F739 – 99a.F739 – 07. DOI: 10.1520/F0739-07.10.1520/F0739-12.

<sup>&</sup>lt;sup>2</sup> For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For Annual Book of ASTM Standards volume information, refer to the standard's Document Summary page on the ASTM website.



FIG. 1 ASTM Permeation Test Cell

D1777 Test Method for Thickness of Textile Materials

E105 Practice for Probability Sampling of Materials

E171 Practice for Conditioning and Testing Flexible Barrier Packaging

E177 Practice for Use of the Terms Precision and Bias in ASTM Test Methods

E691 Practice for Conducting an Interlaboratory Study to Determine the Precision of a Test Method

F903 Test Method for Resistance of Materials Used in Protective Clothing to Penetration by Liquids

F1001 Guide for Selection of Chemicals to Evaluate Protective Clothing Materials

F1194 Guide for Documenting the Results of Chemical Permeation Testing of Materials Used in Protective Clothing

F1383 Test Method for Permeation of Liquids and Gases through Protective Clothing Materials under Conditions of Intermittent Contact

F1407 Test Method for Resistance of Chemical Protective Clothing Materials to Liquid Permeation—Permeation Cup Method F1494 Terminology Relating to Protective Clothing ACTIVE 7200 10

F2815 Practice for Chemical Permeation through Protective Clothing Materials: Testing Data Analysis by Use of a Computer Program

2.2 ISO Standard:

ISO 6529 Protective Clothing—Determination of Resistance of Protective Clothing Materials to Permeation by Liquids and Gases<sup>3</sup>

# 3. Terminology

3.1 *Definitions*:

3.1.1 *analytical technique, n*—a procedure whereby the concentration of the <u>ehallengetest</u> chemical in a collection medium is quantitatively determined.

<sup>3</sup> Available from American National Standards Institute (ANSI), 25 W. 43<sup>rd</sup> St., 4th Floor, New York, NY 10036, http://www.ansi.org.

3.1.1.1 Discussion-

These techniques are often specific to individual chemical and collection medium combinations. Applicable techniques include, but are not limited to, flame ionization, photo ionization, electro-chemical, ultraviolet and infrared spectrophotometry, gas and liquid chromatography, colorimetry, length-of-stain detector tubes, and radionuclide tagging/detection counting.

3.1.2 *breakthrough detection time, n*—the elapsed time measured from the start of initial exposure to the test chemical to the sampling time that immediately precedes the sampling time at which the challengetest chemical is first detected.

3.1.2.1 Discussion—

(See Fig. 6.) The breakthrough detection time is dependent on the sensitivity of the method (see Appendix X1).



FIG. 3 Example Set-up for Continuous Collecting Medium Sample Withdrawal, Analysis, and Return

3.1.3 challenge chemical, n—the liquid or gas that is used to challenge the protective clothing material specimen.

# 3.1.3.1 Discussion—

The liquid or gas may be either one component (for example, a neat liquid or gas) or have several components (for example, a mixture).

3.1.3 *closed-loop, adj*—refers to a testing mode in which the collection medium volume is fixed. there is no change in the volume of the collection medium except for sampling.

3.1.4 collection medium, n—a liquid, gas, or solid that absorbs, adsorbs, dissolves, suspends, or otherwise captures the <u>challengetest</u> chemical and does not affect the measured permeation.

3.1.5 *cumulative permeation*, *n*—the total mass of chemical that permeates a specific area of protective clothing material during a specified time from when the material is first contacted by the test chemical.

3.1.6 *degradation*, *n*—a deleterious change in one or more properties of a material.

3.1.6.1 Discussion-



FIG. 4 Example Set-up for Continuous Flow of Fresh Collecting Medium

For protective clothing materials, changes in physical properties are typically of most interest.

3.1.7 *minimum detectable mass permeated, n*—the smallest mass of <u>permeant test chemical</u> that is detectable with the complete permeation test system.



https://standards.it/h.ai/catalog/standards/sist/811f2b78-c296-41c8-80b1-1dd32efb6bf5/astm-f739-12



# ∰ F739 – 12

NOTE 1—Fig. 5 shows five types of permeation behavior. Type A, the most typical, where the permeation rate stabilizes at a "steady state" value. Type B behavior is due to the material specimen being structurally modified by the chemical resulting in an increase or decrease in permeation rate. Type C behavior occurs when the material specimen exhibits a sudden, very large increase in rate. Type D response happens when there is moderate to heavy swelling of the material specimen although the permeation rate eventually stabilizes. Type E response can occur when there is a high degree of swelling. (Reprinted with permission by *American Industrial Hygiene Association Journal* Vol 42:217–225 (1981).)

#### FIG. 5 Five Types of Permeation Behavior



FIG. 6 The Breakthrough Detection Time for a method sensitivity of 0.05 μg/cm<sup>2</sup>/min is 23 minutes. The Standardized Breakthrough Detection Time is 33 minutes. The Steady State Permeation Rate is approximately 0.15 μg/cm<sup>2</sup>/min.

This value is not necessarily the sensitivity of the analytical instrument.

3.1.8 *minimum detectable permeation rate, n*—the lowest rate of permeation that is measurable with the complete permeation test system.

### ASTM F739-12

3.1.8.1 Discussion—s, iteh ai/catalog/standards/sist/811f2b78-c296-41c8-80b1-1dd32efb6bf5/astm-f739-12

This value is not necessarily the sensitivity of the analytical instrument.

3.1.9 open loop, adj-refers to a testing mode in which fresh collection medium flows continuously through the collection chamber of the test cell.

3.1.10 penetration, n—for a protective clothing material or item, the process by which a substance moves through closures, seams, interstices, and pinholes or other imperfections chemical protective clothing, the movement of substances through voids in protective clothing materials or items on a non-molecular level.

3.1.10.1 Discussion—

The substance may be a solid, liquid, gas, or biological species. Voids include gaps, pores, holes and imperfections in closures, seams, interfaces and protective clothing materials. Penetration does not require a change if state; solid chemicals move through voids in materials as solids, liquids as liquids and gases as gases. Penetration is a distinctly different mechanism from permeation.

3.1.11 permeation, n—the process by which a chemical moves through a protective clothing material on a molecular level. for chemical protective clothing, the movements of chemicals as molecules through protective clothing materials by the processes of (1) absorption of the chemical into the contact surface of the materials, (2) diffusion of the absorbed molecules throughout the material, and (3) desorption of the chemical from the opposite surface of the material.

3.1.11.1 Discussion—

Permeation involves the following: (is a distinctly different1) sorption of molecules of the chemical into the contacted (challenge

side) surface of the material, (mechanism 2) diffusion of the sorbed molecules in the material, and (3) desorption of the molecules from the opposite (collection side) surface of the material.from penetration.

🖽 F739 – 12

3.1.12 protective clothing material, <u>clothing</u>, <u>n</u>—any element, constituent, or substance from which protective clothing is composed or can be made.item of clothing that is specifically designed and constructed for the intended purpose of isolating all or part of the body from a potential hazard; or, isolating the external environment from contamination by the wearer of the clothing.

3.1.13 standardized breakthrough time, n-the time at which the permeation rate reaches 0.1 µg/cm<sup>2</sup>/min.

3.1.14 *steady-state permeation, n*—the constant rate of permeation that occurs after breakthrough when the chemical contact is continuous and all forces affecting permeation have reached equilibrium.

3.1.15 test chemical, n—the solid, liquid, gas or mixture thereof, used to evaluate the performance of a protective clothing material.

## 3.1.15.1 Discussion—

The liquid or gas may be either one component (for example, a neat liquid or gas) or have several components (for example, a mixture).

# 4. Summary of Test Method

4.1 The permeation of chemical(s) through a protective clothing material is assessed by measuring the breakthrough detection time, standardized breakthrough time, and subsequent permeation rate subsequent permeation rate, and cumulative permeation over a period of time through replicate specimens of the material.

4.2 In the permeation test apparatus, the protective clothing material specimen partitions the challengetest chemical from the collection medium.

4.2.1 The collection medium is analyzed quantitatively for its concentration of the <u>challengetest</u> chemical and thereby the amount of that chemical that has permeated the barrier as a function of time after its initial contact with the material.

4.2.2 By either graphical representation or representation, appropriate calculations, or both, the breakthrough detection time, standardized breakthrough time, and the permeation rate of the challengetest chemical are determined.

### 5. Significance and Use

5.1 This test method is normally used to evaluate flat specimens from finished items of protective clothing and from materials that are candidates for items of protective clothing.

5.1.1 Finished items of protective clothing include gloves, arm shields, aprons, suits, hats, boots, respirators, and the like.

5.1.2 The phrase "specimens from finished items" encompasses seamed or other discontinuous regions as well as the usual continuous regions of protective clothing items.

5.2 The breakthrough detection time, standardized breakthrough time, <u>permeation rate</u>, and <u>cumulative</u> permeation <del>rate</del> are key measures of the effectiveness of a clothing material as a barrier to the <u>challengetest</u> chemical. Such information is used in the comparison of clothing materials during the process of selecting clothing for protection from hazardous chemicals. Long breakthrough detection <u>times</u> and <u>times</u>, long standardized breakthrough detection <u>times</u>, low amounts of cumulative permeation, and low permeation rates are characteristics of better barriers.

NOTE 1—At present, no-only limited quantitative information exists about acceptable levels of dermal contact. contact with most chemicals. Therefore, the data obtained using this test method cannot be used to infer safe exposure levels.

5.2.1 The reporting of a standardized breakthrough time greater than a specific time period means that the test chemical has not permeated the specimen at a rate exceeding  $0.1 \,\mu\text{g/cm}^2/\text{min}$  in the designated time. Permeation may or may not have occurred at a lower rate during this time interval.

5.3 The sensitivity of the test method in detecting low permeation rates or amounts of the <u>challengetest</u> chemical that permeate is determined by the combination of the analytical technique and collection system selected, and the ratio of material specimen area to collection medium volume or flow rate.

5.3.1 The analytical technique employed should be capable of measuring the concentration of the ehallengetest chemical in the collection medium at, or below, levels consistent with the standardized breakthrough time value specified in 3.1.13 and at, or above, the steady-state permeation rate.

5.3.2 Often permeation tests will require measurement of the <u>challengetest</u> chemical over several orders of magnitude in concentration, requiring adjustments in either the sample collection volume or concentration/dilution, or the analytical instrument settings over the course of the test.

5.3.3 Higher ratios of material specimen area to collection medium volume or flow rate permit earlier detection of breakthrough and detection of lower permeation rates <u>and levels of cumulative permeation</u> because higher concentrations of the <u>challengetest</u> chemical in the collection medium will develop in a given time period, relative to those that would occur at lower ratios.