



SLOVENSKI STANDARD SIST ETS 300 974 E9:2003

01-december-2003

8 [[[HJb]`W] b]`hY`_ca i b]_UW`g_]`g]ghYa `fZuU&Zk/`E`GdYWZ]_UW`UXY`UnU
a cV]`bY`Ud`]_UW`Y`fA5 DL`f] GA `\$-`\$&zfUn`] JWJ) "%`%Z]nXUJ%-`* Ł

Digital cellular telecommunications system (Phase 2+) (GSM); Mobile Application Part (MAP) specification (GSM 09.02 version 5.13.1 Release 1996)

iteh STANDARD PREVIEW
(standards.iteh.ai)

Ta slovenski standard je istoveten z: ^{SIST ETS 300 974 E9:2003} **ETS 300 974 Edition 9**
<https://standards.iteh.ai/catalog/standards/sist/17655e0b-a598-4441-a953-c0953edc5000/sist-ets-300-974-e9-2003>

ICS:

33.070.50	Globalni sistem za mobilno telekomunikacijo (GSM)	Global System for Mobile Communication (GSM)
-----------	---------------------------------------------------	----------------------------------------------


SIST ETS 300 974 E9:2003

en

iTeh STANDARD PREVIEW
(standards.iteh.ai)

SIST ETS 300 974 E9:2003

<https://standards.iteh.ai/catalog/standards/sist/17655e0b-a398-4441-a953-c0953edc5000/sist-ets-300-974-e9-2003>



EUROPEAN
TELECOMMUNICATION
STANDARD

ETS 300 974

December 1999

Ninth Edition

Source: SMG

Reference: RE/SMG-030902QR8

ICS: 33.020

Key words: Digital cellular telecommunications system, Global System for Mobile communications (GSM)



**Digital cellular telecommunications system (Phase 2+);
Mobile Application Part (MAP) specification
(GSM 09.02 version 5.13.1 Release 1996)**

ETSI

European Telecommunications Standards Institute

ETSI Secretariat

Postal address: F-06921 Sophia Antipolis CEDEX - FRANCE

Office address: 650 Route des Lucioles - Sophia Antipolis - Valbonne - FRANCE

Internet: secretariat@etsi.fr - <http://www.etsi.org>

Tel.: +33 4 92 94 42 00 - Fax: +33 4 93 65 47 16

Copyright Notification: No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 1999. All rights reserved.

iTeh STANDARD PREVIEW
(standards.iteh.ai)

[SIST ETS 300 974 E9:2003](https://standards.iteh.ai/catalog/standards/sist/17655e0b-a398-4441-a953-c0953edc5000/sist-ets-300-974-e9-2003)

<https://standards.iteh.ai/catalog/standards/sist/17655e0b-a398-4441-a953-c0953edc5000/sist-ets-300-974-e9-2003>

Contents

Intellectual Property Rights	19
Foreword.....	19
1 Scope	21
1.1 Normative references	21
1.2 Abbreviations	27
2 Configuration of the mobile network.....	27
2.1 The entities of the mobile system	27
2.1.1 The Home Location Register (HLR)	27
2.1.2 The Visitor Location Register (VLR)	27
2.1.3 The Mobile-services Switching Centre (MSC).....	28
2.1.4 The Base Station System (BSS)	28
2.1.5 The Gateway MSC (GMSC).....	28
2.1.6 The SMS Gateway MSC	28
2.1.7 The SMS Interworking MSC.....	28
2.1.8 The VBS/VGCS Anchor MSC	29
2.1.9 The Equipment Identity Register (EIR).....	29
2.1.10 The GSM Service Control Function (gsmSCF)	29
2.1.11 The Group Call Register (GCR)	29
2.2 Configuration of a Public Land Mobile Network (PLMN).....	29
2.3 Interconnection between PLMNs	29
2.4 The interfaces within the mobile service.....	29
2.4.1 Interface between the HLR and the VLR (D-interface).....	29
2.4.2 Interface between the HLR and the gsmSCF (J-interface)	30
2.4.3 Interface between the VLR and its associated MSC(s) (B-interface)	30
2.4.4 Interface between VLRs (G-interface)	30
2.4.5 Interface between the HLR and the MSC (C-interface).....	30
2.4.6 Interface between MSCs (E-interface)	30
2.4.7 Interface between the MSC and Base Station Systems (A-interface).....	30
2.4.8 Interface between MSC and EIR (F-interface)	30
2.4.9 Interface between VBS/VGCS Anchor MSC and GCR (I-interface).....	30
2.5 Splitting of the data storage	31
3 Overload and compatibility overview	33
3.1 Overload control.....	33
3.1.1 Overload control for MSC (outside MAP)	33
3.1.2 Overload control for MAP entities.....	33
3.1.3 Congestion control for Signalling System No. 7	36
3.2 Compatibility.....	36
3.2.1 General.....	36
3.2.2 Strategy for selecting the Application Context (AC) version.....	36
3.2.2.1 Proposed method	36
3.2.2.2 Managing the version look-up table.....	37
3.2.2.3 Optimizing the method.....	38
4 Requirements concerning the use of SCCP and TC.....	39
4.1 Use of SCCP.....	39
4.1.1 SCCP Class.....	39
4.1.2 Sub-System Number (SSN)	39
4.1.3 SCCP addressing	39
4.1.3.1 Introduction	39
4.1.3.2 The Mobile-services Switching Centre (MSC)	40
4.1.3.2.1 MSC interaction during handover	40
4.1.3.2.2 MSC for short message routing	40
4.1.3.3 The Home Location Register (HLR)	40

	4.1.3.3.1	During call set-up	40
	4.1.3.3.2	Before location updating completion	41
	4.1.3.3.3	After location updating completion	41
	4.1.3.3.4	VLR restoration	41
	4.1.3.4	The Visitor Location Register (VLR).....	42
	4.1.3.4.1	Inter-VLR information retrieval	42
	4.1.3.4.2	HLR request	42
	4.1.3.5	The Interworking MSC (IWMSC) for Short Message Service	42
	4.1.3.6	The Equipment Identity Register (EIR)	42
	4.1.3.7	Summary table	42
4.2	Use of TC		43
5	General on MAP services		45
5.1	Terminology and definitions		45
5.2	Modelling principles		45
5.3	Common MAP services.....		45
	5.3.1	MAP-OPEN service	46
	5.3.2	MAP-CLOSE service	48
	5.3.3	MAP-DELIMITER service	49
	5.3.4	MAP-U-ABORT service	49
	5.3.5	MAP-P-ABORT service	50
	5.3.6	MAP-NOTICE service.....	51
5.4	Sequencing of services		51
5.5	General rules for mapping of services onto TC.....		53
	5.5.1	Mapping of common services.....	53
	5.5.2	Mapping of user specific services.....	54
5.6	Definition of parameters.....		55
	5.6.1	Common parameters.....	57
	5.6.1.1	Invoke Id.....	57
	5.6.1.2	Linked Id.....	57
	5.6.1.3	Provider error	57
	5.6.1.4	User error	57
	5.6.2	Numbering and identification parameter.....	59
	5.6.2.1	MSI.....	59
	5.6.2.2	TMSI.....	59
	5.6.2.3	IMEI.....	59
	5.6.2.4	Previous location area Id.....	59
	5.6.2.5	Stored location area Id.....	60
	5.6.2.6	Current location area Id.....	60
	5.6.2.7	Target location area Id	60
	5.6.2.8	Target cell Id	60
	5.6.2.9	[Spare].....	60
	5.6.2.10	Originating entity number	60
	5.6.2.11	MSC number	60
	5.6.2.12	Target MSC number	60
	5.6.2.13	HLR number.....	60
	5.6.2.14	VLR number	60
	5.6.2.15	HLR Id	60
	5.6.2.16	LMSI.....	60
	5.6.2.17	MS ISDN	60
	5.6.2.18	OMC Id.....	60
	5.6.2.19	Roaming number	60
	5.6.2.20	[Spare].....	61
	5.6.2.21	Handover number	61
	5.6.2.22	Forwarded-to number.....	61
	5.6.2.23	Forwarded-to subaddress	61
	5.6.2.24	Called number.....	61
	5.6.2.25	Calling number	61
	5.6.2.26	Originally dialled number.....	61
	5.6.2.27	Service centre address	61
	5.6.2.28	Zone Code	61
	5.6.2.29	MSISdn-Alert	61

ETS 300 974 (GSM 09.02 version 5.13.1 Release 1996): December 1999

	5.6.2.30	Location Information	61
	5.6.2.31	GMSC Address	61
	5.6.2.32	VMSC Address	61
	5.6.2.33	Group Id	61
5.6.3		Subscriber management parameters	62
	5.6.3.1	Category	62
	5.6.3.2	Equipment status	62
	5.6.3.3	Extensible Bearer service	62
	5.6.3.4	Extensible Teleservice	62
	5.6.3.5	Extensible Basic Service Group	62
	5.6.3.6	GSM bearer capability	62
	5.6.3.7	Subscriber Status	62
	5.6.3.8	CUG Outgoing Access indicator	62
	5.6.3.9	Operator Determined Barring General Data	62
	5.6.3.10	ODB HPLMN Specific Data	63
	5.6.3.11	Regional Subscription Data	63
	5.6.3.12	Regional Subscription Response	63
	5.6.3.13	Roaming Restriction Due To Unsupported Feature	63
	5.6.3.14	Extensible SS-Info	63
	5.6.3.15	Extensible Forwarding information	63
	5.6.3.16	Extensible Forwarding feature	63
	5.6.3.17	Extensible SS-Status	64
	5.6.3.18	Extensible Forwarding Options	64
	5.6.3.19	Extensible No reply condition timer	64
	5.6.3.20	Extensible Call barring information	64
	5.6.3.21	Extensible Call barring feature	64
	5.6.3.22	CUG info	64
	5.6.3.23	CUG subscription	64
	5.6.3.24	CUG interlock	64
	5.6.3.25	CUG index	64
	5.6.3.26	CUG feature	65
	5.6.3.27	Inter CUG options	65
	5.6.3.28	Intra CUG restrictions	65
	5.6.3.29	Extensible SS-Data	65
	5.6.3.30	Subscriber State	65
	5.6.3.31	Requested Info	65
	5.6.3.32	Suppression of Announcement	65
	5.6.3.33	Suppress T-CSI	66
	5.6.3.34	GMSC CAMEL Subscription Info	66
	5.6.3.35	VLR CAMEL Subscription Info	66
	5.6.3.36	Supported CAMEL Phases	66
	5.6.3.37	CUG Subscription Flag	66
	5.6.3.38	CAMEL Subscription Info Withdraw	66
	5.6.3.39	Voice Group Call Service (VGCS) Data	66
	5.6.3.40	Voice Broadcast Service (VBS) Data	66
5.6.4		Supplementary services parameters	66
	5.6.4.1	SS-Code	66
	5.6.4.2	SS-Status	66
	5.6.4.3	SS-Data	67
	5.6.4.4	Override Category	67
	5.6.4.5	CLI Restriction Option	67
	5.6.4.6	Forwarding Options	67
	5.6.4.7	No reply condition timer	67
	5.6.4.8 - 5.6.4.14	[Spare]
	5.6.4.15	Forwarding information	67
	5.6.4.16	Forwarding feature	67
	5.6.4.17	[Spare]	68
	5.6.4.18	Call barring information	68
	5.6.4.19	Call barring feature	68
	5.6.4.20	New password	68
	5.6.4.21	Current password	68
	5.6.4.22	Guidance information	68
	5.6.4.23	[Spare]	68

iTeh STANDARDS REVIEW
(standards.itteh.ai)

https://standards.cer.in/catalog/standards/sist/ets-300-974/e9-2003-4441-a953-495-edc5000/sist-ets-300-974-e9-2003

	5.6.4.24	SS-Info	68	
	5.6.4.25 - 5.6.4.35.....	[Spare]	69	69
	5.6.4.36	USSD Data Coding Scheme	69	
	5.6.4.37	USSD String	69	
	5.6.4.38	Bearer service	69	
	5.6.4.39	Teleservice	69	
	5.6.4.40	Basic Service Group	69	
	5.6.4.41	eMLPP information.....	69	
5.6.5	Call parameters		69	
	5.6.5.1	Call reference number	69	
	5.6.5.2	Interrogation type	69	
	5.6.5.3	OR interrogation.....	70	
	5.6.5.4	OR capability.....	70	
	5.6.5.5	Forwarding reason	70	
	5.6.5.6	Forwarding interrogation required	70	
	5.6.5.7	O-CSI	70	
5.6.6	Radio parameters		70	
	5.6.6.1 - 5.6.6.6[Spare].....		70	
	5.6.6.7	HO-Number Not Required	70	
5.6.7	Authentication parameters		70	
	5.6.7.1	Authentication set list	70	
	5.6.7.2	Rand.....	70	
	5.6.7.3	Sres.....	70	
	5.6.7.4	Kc	70	
	5.6.7.5	[Spare].....	71	
	5.6.7.6	Cksn	71	
	5.6.7.7	Ciphering mode.....	71	
5.6.8	Short message parameters		71	
	5.6.8.1	SM-RP-DA	71	
	5.6.8.2	SM-RP-OA	71	
	5.6.8.3	MWD status	71	
	5.6.8.4	SM-RP-UI	71	
	5.6.8.5	SM-RP-PR	71	
	5.6.8.6	SM Delivery Outcome	71	
	5.6.8.7	More Messages To Send	72	
	5.6.8.8	Alert Reason	72	
	5.6.8.9	Absent Subscriber Diagnostic SM.....	72	
5.6.9	Access and signalling system related parameters.....		72	
	5.6.9.1	BSS-apdu	72	
	5.6.9.2	CM service type.....	72	
	5.6.9.3	Access connection status	72	
	5.6.9.4	External Signal Information	72	
	5.6.9.5	Access signalling information.....	72	
	5.6.9.6	Location update type	72	
	5.6.9.7	Protocol ID	73	
	5.6.9.8	Network signal information.....	73	
5.6.10	System operations parameters.....		73	
	5.6.10.1	Network resources	73	
	5.6.10.2	Trace reference.....	74	
	5.6.10.3	Trace type	74	
5.7	Representation of a list of a basic parameter in service-primitives		74	
6	Mobility services.....		75	
6.1	Location management services		75	
6.1.1	MAP_UPDATE_LOCATION_AREA service		75	
	6.1.1.1	Definition	75	
	6.1.1.2	Service primitives	75	
	6.1.1.3	parameter definitions and use.....	75	
6.1.2	MAP_UPDATE_LOCATION service.....		76	
	6.1.2.1	Definition	76	
	6.1.2.2	Service primitives	76	
	6.1.2.3	Parameter definitions and use	76	
6.1.3	MAP_CANCEL_LOCATION service.....		77	

ETS 300 974 (GSM 09.02 version 5.13.1 Release 1996): December 1999

	6.1.3.1	Definition.....	77
	6.1.3.2	Service primitives.....	77
	6.1.3.3	Parameter definitions and use.....	78
6.1.4		MAP_SEND_IDENTIFICATION service.....	78
	6.1.4.1	Definition.....	78
	6.1.4.2	Service primitives.....	78
	6.1.4.3	Parameter definitions and use.....	78
6.1.5		MAP_DETACH_IMSI service.....	79
	6.1.5.1	Definition.....	79
	6.1.5.2	Service primitives.....	79
	6.1.5.3	Parameter definitions and use.....	79
6.1.6		MAP_PURGE_MS service.....	80
	6.1.6.1	Definition.....	80
	6.1.6.2	Service primitives.....	80
	6.1.6.3	Parameter definitions and use.....	80
6.2		Paging and search.....	80
	6.2.1	MAP_PAGE service.....	80
	6.2.1.1	Definition.....	80
	6.2.1.2	Service primitives.....	81
	6.2.1.3	Parameter definitions and use.....	81
	6.2.2	MAP_SEARCH_FOR_MS service.....	81
	6.2.2.1	Definition.....	81
	6.2.2.2	Service primitives.....	82
	6.2.2.3	Parameter definitions and use.....	82
6.3		Access management services.....	82
	6.3.1	MAP_PROCESS_ACCESS_REQUEST service.....	82
	6.3.1.1	Definition.....	82
	6.3.1.2	Service primitives.....	83
	6.3.1.3	Parameter definitions and use.....	83
6.4		Handover services.....	84
	6.4.1	MAP_PREPARE_HANOVER service.....	84
	6.4.1.1	Definition.....	84
	6.4.1.2	Service primitives.....	84
	6.4.1.3	Parameter use.....	84
	6.4.2	MAP_SEND_END_SIGNAL service.....	85
	6.4.2.1	Definition.....	85
	6.4.2.2	Service primitives.....	85
	6.4.2.3	Parameter use.....	85
	6.4.3	MAP_PROCESS_ACCESS_SIGNALLING service.....	86
	6.4.3.1	Definition.....	86
	6.4.3.2	Service primitives.....	86
	6.4.3.3	Parameter use.....	86
	6.4.4	MAP_FORWARD_ACCESS_SIGNALLING service.....	86
	6.4.4.1	Definition.....	86
	6.4.4.2	Service primitives.....	86
	6.4.4.3	Parameter use.....	87
	6.4.5	MAP_PREPARE_SUBSEQUENT_HANOVER service.....	87
	6.4.5.1	Definition.....	87
	6.4.5.2	Service primitives.....	87
	6.4.5.3	Parameter use.....	87
	6.4.6	MAP_ALLOCATE_HANOVER_NUMBER service.....	88
	6.4.6.1	Definition.....	88
	6.4.6.2	Service primitives.....	88
	6.4.6.3	Parameter use.....	88
	6.4.7	MAP_SEND_HANOVER_REPORT service.....	88
	6.4.7.1	Definition.....	88
	6.4.7.2	Service primitives.....	88
	6.4.7.3	Parameter use.....	89
6.5		Authentication management services.....	89
	6.5.1	MAP_AUTHENTICATE service.....	89
	6.5.1.1	Definition.....	89
	6.5.1.2	Service primitives.....	89
	6.5.1.3	Parameter use.....	89

iTech STANDARDS REVIEW
(standards.itech.ai)

SIST ETS 300 974 E9:2003
<https://standards.itech.ai/catalog/standards/sist/6053e01a-3998-4441-a953-c0956dc3009/sist-ets-300-974-e9-2003>

6.5.2	MAP_SEND_AUTHENTICATION_INFO service	90
6.5.2.1	Definition	90
6.5.2.2	Service primitives	90
6.5.2.3	Parameter use.....	90
6.6	Security management services	91
6.6.1	MAP_SET_CIPHERING_MODE service.....	91
6.6.1.1	Definitions	91
6.6.1.2	Service primitives	91
6.6.1.3	Parameter use.....	91
6.7	International mobile equipment identities management services.....	91
6.7.1	MAP_CHECK_IMEI service.....	91
6.7.1.1	Definition	91
6.7.1.2	Service primitives	91
6.7.1.3	Parameter use.....	92
6.7.2	MAP_OBTAIN_IMEI service.....	92
6.7.2.1	Definition	92
6.7.2.2	Service primitives	93
6.7.2.3	Parameter use.....	93
6.8	Subscriber management services.....	93
6.8.1	MAP-INSERT-SUBSCRIBER-DATA service.....	93
6.8.1.1	Definition	93
6.8.1.2	Service primitives	94
6.8.1.3	Parameter use.....	94
6.8.1.4	Basic service information related to supplementary services	100
6.8.2	MAP-DELETE-SUBSCRIBER-DATA service.....	100
6.8.2.1	Definition	100
6.8.2.2	Service primitives	101
6.8.2.3	Parameter use.....	101
6.9	Identity management services.....	102
6.9.1	MAP-PROVIDE-TMSI service.....	102
6.9.1.1	Definition	102
6.9.1.2	Service primitives	103
6.9.1.3	Parameter use.....	103
6.9.2	MAP-FORWARD-NEW-TMSI service.....	103
6.9.2.1	Definition	103
6.9.2.2	Service primitives	103
6.9.2.3	Parameter use.....	103
6.10	Fault recovery services	103
6.10.1	MAP_RESET service.....	103
6.10.1.1	Definition	103
6.10.1.2	Service primitives	104
6.10.1.3	Parameter definition and use	104
6.10.2	MAP_FORWARD_CHECK_SS_INDICATION service.....	104
6.10.2.1	Definition	104
6.10.2.2	Service primitives	104
6.10.2.3	Parameter definition and use	104
6.10.3	MAP_RESTORE_DATA service.....	104
6.10.3.1	Definition	104
6.10.3.2	Service primitives	105
6.10.3.3	Parameter definitions and use	105
6.11	Subscriber Information services.....	106
6.11.1	MAP-ANY-TIME-INTERROGATION service	106
6.11.1.1	Definition	106
6.11.1.2	Service primitives	106
6.11.1.3	Parameter definition and use	106
6.11.2	MAP-PROVIDE-SUBSCRIBER-Info service	107
6.11.2.1	Definition	107
6.11.2.2	Service primitives	107
6.11.2.3	Parameter definition and use	107
7	Operation and maintenance services	108
7.1	Subscriber tracing services	108

ETS 300 974 (GSM 09.02 version 5.13.1 Release 1996): December 1999

7.1.1	MAP-ACTIVATE-TRACE-MODE service	108
7.1.1.1	Definition	108
7.1.1.2	Service primitives	108
7.1.1.3	Parameter use	108
7.1.2	MAP-DEACTIVATE-TRACE-MODE service	109
7.1.2.1	Definition	109
7.1.2.2	Service primitives	109
7.1.2.3	Parameter use	109
7.1.3	MAP-TRACE-SUBSCRIBER-ACTIVITY service	109
7.1.3.1	Definition	109
7.1.3.2	Service primitives	110
7.1.3.3	Parameter use	110
7.2	Other operation and maintenance services	110
7.2.1	MAP-SEND-IMSI service	110
7.2.1.1	Definition	110
7.2.1.2	Service primitives	110
7.2.1.3	Parameter use	111
8	Call handling services	111
8.1	MAP_SEND_ROUTING_INFORMATION service	111
8.1.1	Definition	111
8.1.2	Service primitives	111
8.1.3	Parameter use	112
8.2	MAP_PROVIDE_ROAMING_NUMBER service	115
8.2.1	Definition	115
8.2.2	Service primitives	115
8.2.3	Parameter use	115
8.3	MAP_RESUME_CALL_HANDLING service	117
8.3.1	Definition	117
8.3.2	Service primitives	117
8.3.3	Parameter use	117
9	Supplementary services related services	118
9.1	MAP_REGISTER_SS service	118
9.1.1	Definition	118
9.1.2	Service primitives	118
9.1.3	Parameter use	118
9.2	MAP_ERASE_SS service	119
9.2.1	Definition	119
9.2.2	Service primitives	120
9.2.3	Parameter use	120
9.3	MAP_ACTIVATE_SS service	121
9.3.1	Definition	121
9.3.2	Service primitives	121
9.3.3	Parameter use	121
9.4	MAP_DEACTIVATE_SS service	122
9.4.1	Definitions	122
9.4.2	Service primitives	123
9.4.3	Parameter use	123
9.5	MAP_INTERROGATE_SS service	124
9.5.1	Definitions	124
9.5.2	Service primitives	124
9.5.3	Parameter use	124
9.6	MAP_INVOKE_SS service	127
9.6.1	Definitions	127
9.6.2	Service primitives	127
9.6.3	Parameter use	127
9.7	MAP_REGISTER_PASSWORD service	128
9.7.1	Definitions	128
9.7.2	Service primitives	128
9.7.3	Parameter use	128
9.8	MAP_GET_PASSWORD service	128
9.8.1	Definitions	128

	9.8.2	Service primitives.....	129
	9.8.3	Parameter use	129
9.9		MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service	129
	9.9.1	Definitions	129
	9.9.2	Service primitives.....	129
	9.9.3	Parameter use	130
9.10		MAP_UNSTRUCTURED_SS_REQUEST service.....	130
	9.10.1	Definitions	130
	9.10.2	Service primitives.....	130
	9.10.3	Parameter use	131
9.11		MAP_UNSTRUCTURED_SS_NOTIFY service	131
	9.11.1	Definitions	131
	9.11.2	Service primitives.....	131
	9.11.3	Parameter use	132
10		Short message service management services.....	132
10.1		MAP-SEND-ROUTING-INFO-FOR-SM service.....	132
	10.1.1	Definition	132
	10.1.2	Service primitives.....	133
	10.1.3	Parameter use	133
10.2		MAP-MO-FORWARD-SHORT-MESSAGE service	134
	10.2.1	Definition	134
	10.2.2	Service primitives.....	134
	10.2.3	Parameter use	134
10.3		MAP-REPORT-SM-DELIVERY-STATUS service	135
	10.3.1	Definition	135
	10.3.2	Service primitives.....	135
	10.3.3	Parameter use	135
10.4		MAP-READY-FOR-SM service.....	136
	10.4.1	Definition	136
	10.4.2	Service primitives.....	137
	10.4.3	Parameter use	137
10.5		MAP-ALERT-SERVICE-CENTRE service.....	137
	10.5.1	Definition	137
	10.5.2	Service primitives.....	138
	10.5.3	Parameter use	138
10.6		MAP-INFORM-SERVICE-CENTRE service.....	138
	10.6.1	Definition	138
	10.6.2	Service primitives.....	139
	10.6.3	Parameter use	139
10.7		MAP-SEND-INFO-FOR-MT-SMS service.....	139
	10.7.1	Definition	139
	10.7.2	Service primitives.....	139
	10.7.3	Parameter use	139
10.8		MAP-SEND-INFO-FOR-MO-SMS service	140
	10.8.1	Definition	140
	10.8.2	Service primitives.....	140
	10.8.3	Parameter use	140
10.9		MAP-MT-FORWARD-SHORT-MESSAGE service.....	141
	10.9.1	Definition	141
	10.9.2	Service primitives.....	141
	10.9.3	Parameter use	141
11		General.....	143
	11.1	Overview.....	143
	11.2	Underlying services	143
	11.3	Model.....	143
	11.4	Conventions	143
12		Elements of procedure.....	144
	12.1	Dialogue establishment.....	144
		12.1.1 Handling of unknown operations	144
		12.1.2 Receipt of a MAP-OPEN request primitive	145

ETS 300 974 (GSM 09.02 version 5.13.1 Release 1996): December 1999

12.1.3	Receipt of a TC-BEGIN indication.....	145
12.1.4	Receipt of a MAP-OPEN response	148
12.1.5	Receipt of the first TC-CONTINUE ind.....	148
12.1.6	Receipt of a TC-END ind.....	148
12.1.7	Receipt of a TC-U-ABORT ind	148
12.1.8	Receipt of a TC-P-ABORT ind	149
12.2	Dialogue continuation.....	149
12.2.1	Sending entity	149
12.2.2	Receiving entity	149
12.3	Dialogue termination	149
12.3.1	Receipt of a MAP-CLOSE request	149
12.3.2	Receipt of a TC-END indication	150
12.4	User Abort.....	150
12.4.1	MAP-U-ABORT request	150
12.4.2	TC-U-ABORT ind	150
12.5	Provider Abort.....	150
12.5.1	MAP PM error situation	150
12.5.2	TC-P-ABORT ind.....	150
12.5.3	TC-U-ABORT ind	151
12.6	Procedures for MAP specific services	151
12.6.1	Service invocation	151
12.6.2	Service invocation receipt.....	151
12.6.3	Service response.....	152
12.6.4	Receipt of a response	153
12.6.4.1	Receipt of a TC-RESULT-NL indication	153
12.6.4.2	Receipt of a TC-RESULT-L indication.....	153
12.6.4.3	Receipt of a TC-U-ERROR indication	153
12.6.4.4	Receipt of a TC-INVOKE indication.....	154
12.6.4.5	Receipt of a TC-U-REJECT indication	154
12.6.4.6	Receipt of a TC-L-REJECT indication	154
12.6.4.7	Receipt of a TC-L-CANCEL indication.....	155
12.6.4.8	Receipt of a TC-NOTICE indication.....	155
12.6.5	Other events.....	155
12.6.5.1	Receipt of a TC-U-REJECT	155
12.6.5.2	Receipt of a TC-R-REJECT indication	156
12.6.5.3	Receipt of a TC-L-REJECT indication	156
12.6.6	Parameter checks	156
12.6.7	Returning state machines to idle	156
12.6.8	Load control.....	157
13	Mapping on to TC services.....	157
13.1	Dialogue control.....	157
13.1.1	Directly mapped parameters	157
13.1.2	Use of other parameters of dialogue handling primitives	157
13.1.2.1	Dialogue Id.....	157
13.1.2.2	Application-context-name	157
13.1.2.3	User information	157
13.1.2.4	Component present	157
13.1.2.5	Termination.....	157
13.1.2.6	P-Abort-Cause	157
13.1.2.7	Quality of service	158
13.2	Service specific procedures.....	158
13.2.1	Directly mapped parameters	158
13.2.2	Use of other parameters of component handling primitives.....	158
13.2.2.1	Dialogue Id.....	158
13.2.2.2	Class.....	158
13.2.2.3	Linked Id	159
13.2.2.4	Operation	159
13.2.2.5	Error.....	160
13.2.2.6	Parameters	160
13.2.2.7	Time out.....	160
13.2.2.8	Last component	160
13.2.2.9	Problem code.....	160

		13.2.2.9.1	Mapping to MAP User Error	160	
		13.2.2.9.2	Mapping to MAP Provider Error parameter	160	
		13.2.2.9.3	Mapping to diagnostic parameter	161	
13.3	SDL descriptions			161	
14	Abstract syntax of the MAP protocol			187	
14.1	General			187	
	14.1.1	Encoding rules		187	
	14.1.2	Use of TC		187	
		14.1.2.1	Use of Global Operation and Error codes defined outside MAP	188	
	14.1.3	Use of information elements defined outside MAP		188	
	14.1.4	Compatibility considerations		189	
	14.1.5	Structure of the Abstract Syntax of MAP		189	
	14.1.6	Application Contexts		190	
14.2	Operation packages			192	
	14.2.1	General aspects		192	
	14.2.2	Packages specifications		193	
		14.2.2.1	Location updating	193	
		14.2.2.2	Location cancellation	193	
		14.2.2.3	Roaming number enquiry	193	
		14.2.2.4	Information retrieval	193	
		14.2.2.5	Inter-VLR information retrieval	193	
		14.2.2.6	IMSI retrieval	194	
		14.2.2.7	Call control transfer	194	
		14.2.2.8 - 14.2.2.9 [Spare]	194	
		14.2.2.10	Interrogation	194	
		14.2.2.11	[Spare]	194	
		14.2.2.12	Handover Control	194	
		14.2.2.13	Subscriber Data management stand alone	195	
		14.2.2.14	Equipment management	195	
		14.2.2.15	Subscriber data management	195	
		14.2.2.16	Location register restart	195	
		14.2.2.17	Tracing stand-alone	196	
		14.2.2.18	Functional SS handling	196	
		14.2.2.19	Tracing	196	
		14.2.2.20	Binding	196	
		14.2.2.21	Unstructured SS handling	196	
		14.2.2.22	MO Short message relay services	197	
		14.2.2.23	Short message gateway services	197	
		14.2.2.24	MT Short message relay services	197	
		14.2.2.25	[Spare]	198	
		14.2.2.26	Message waiting data management	198	
		14.2.2.27	Alerting	198	
		14.2.2.28	Data restoration	198	
		14.2.2.29	Purging	198	
		14.2.2.30	Subscriber information enquiry	198	
		14.2.2.31	Any time information enquiry	199	
14.3	Application contexts			200	
	14.3.1	General aspects		200	
	14.3.2	Application context definitions		201	
		14.3.2.1	[Spare]	201	
		14.3.2.2	Location Updating	201	
		14.3.2.3	Location Cancellation	201	
		14.3.2.4	Roaming number enquiry	201	
		14.3.2.5	[Spare]	202	
		14.3.2.6	Location Information Retrieval	202	
		14.3.2.7	Call control transfer	202	
		14.3.2.8 - 14.3.2.10 [Spare]	202	
		14.3.2.11	Location registers restart	202	
		14.3.2.12	Handover control	202	
		14.3.2.13	IMSI Retrieval	203	

ETS 300 974 (GSM 09.02 version 5.13.1 Release 1996): December 1999

	14.3.2.14	Equipment Management.....	203
	14.3.2.15	Information retrieval.....	203
	14.3.2.16	Inter-VLR information retrieval.....	203
	14.3.2.17	Stand Alone Subscriber Data Management	203
	14.3.2.18	Tracing.....	204
	14.3.2.19	Network functional SS handling.....	204
	14.3.2.20	Network unstructured SS handling	204
	14.3.2.21	Short Message Gateway.....	204
	14.3.2.22	Mobile originating Short Message Relay	205
	14.3.2.23	[Spare]	205
	14.3.2.24	Short message alert.....	205
	14.3.2.25	Short message waiting data management	205
	14.3.2.26	Mobile terminating Short Message Relay	205
	14.3.2.27	MS purging	206
	14.3.2.28	Subscriber information enquiry.....	206
	14.3.2.29	Any time information enquiry	206
	14.3.3	ASN.1 Module for application-context-names	206
14.4		MAP Dialogue Information	209
14.5		MAP operation and error codes	211
14.6		MAP operation and error types	216
	14.6.1	Mobile Service Operations	216
	14.6.2	Operation and Maintenance Operations	220
	14.6.3	Call Handling Operations.....	222
	14.6.4	Supplementary service operations	224
	14.6.5	Short message service operations	228
	14.6.6	Errors.....	231
14.7		MAP constants and data types	236
	14.7.1	Mobile Service data types	236
	14.7.2	Operation and maintenance data types.....	246
	14.7.3	Call handling data types	247
	14.7.4	Supplementary service data types	250
	14.7.5	Supplementary service codes	253
	14.7.6	Short message data types.....	255
	14.7.7	Error data types	257
	14.7.8	Common data types	261
	14.7.9	Teleservice Codes.....	265
	14.7.10	Bearer Service Codes	267
	14.7.11	Extension data types	269
15		General on MAP user procedures.....	270
	15.1	Introduction	270
	15.2	Common aspects of user procedure descriptions	270
	15.2.1	General conventions.....	270
	15.2.2	Naming conventions.....	270
	15.2.3	Convention on primitives parameters.....	272
	15.2.3.1	Open service.....	272
	15.2.3.2	Close service	272
	15.2.4	Version handling at dialogue establishment.....	272
	15.2.4.1	Behaviour at the initiating side.....	272
	15.2.4.2	Behaviour at the responding side	272
	15.2.5	Abort Handling.....	273
	15.2.6	SDL conventions	273
	15.3	Interaction between MAP Provider and MAP Users	273
16		Mobility procedures	274
	16.1	Location management Procedures.....	274
	16.1.1	Location updating	279
	16.1.1.1	General	279
	16.1.1.2	Detailed procedure in the MSC.....	283
	16.1.1.3	Detailed procedure in the VLR.....	287
	16.1.1.4	Detailed procedure in the HLR	299
	16.1.1.5	Send Identification	302
	16.1.1.5.1	General	302