Designation: F 1116 – 88 (Reapproved 1995)

Standard Test Method for Determining Dielectric Strength of Overshoe Footwear¹

This standard is issued under the fixed designation F 1116; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This test method covers the determination of the dielectric strength of overshoe footwear. Three procedures are provided, the use of which depends upon the portion of the footwear that it is desired to test.

1.1.1 *Procedure A*—Withstand voltage proof test of the sole portion of the overshoe footwear.

1.1.2 *Procedure B*—Withstand voltage proof test of the sole and foot portion of the overshoe footwear.

1.1.3 *Procedure C*—Withstand voltage proof test of the maximum possible portion of the overshoe footwear without permitting flashover between electrodes.

1.2 The use and maintenance of this equipment is beyond the scope of this test method.

1.3 This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use. Specific hazard statements appear in 5.2.

2. Referenced Documents

2.1 ASTM Standards:

D 149 Test Method for Dielectric Breakdown Voltage and Dielectric Strength of Solid Electrical Insulating Materials at Commercial Power Frequencies²

3. Descriptions of Terms Specific to This Standard

3.1 *sole*—the underside of the boot or rubber that would be in contact with the ground. In this type footwear it is normally one piece and constructed of a molded elastomer.

3.2 *foot portion*—the portion of the footwear below the wearer's ankle bone.

4. Significance and Use

4.1 Electrical contact injuries to workers may involve a current path through the feet of the worker. This test method will determine that overshoe footwear, if provided as additional isolation or insulation, has a particular value of dielectric strength at the time of the test.

TABLE 1	Flashover	Clearances	Between	Electrodes
---------	-----------	------------	---------	------------

A-C Proof Test		D-C Proof Test		
Voltage	mm (in.)	Voltage	mm (in.)	
5 000	76 (3)	20 000	76 (3)	
10 000	76 (3)	40 000	102 (4)	
20 000	127 (5)	50 000	152 (6)	

5. Apparatus

5.1 *Electrodes*:

5.1.1 *Procedure A*—The footwear shall be filled with water or conductive metal shot so that the inner sole is completely covered. The footwear shall then be placed in water to such a depth that the under side of the sole is, to the greatest extent practicable, in contact with the water without the water going above the top of any part of the sole. The water or shot inside the footwear forms one test electrode and shall be connected to one terminal of the voltage source by means of a chain or sliding rod that dips into the electrode. The water in the container outside the footwear forms the other electrode and shall be connected directly to the other terminal of the voltage source (see Figs. 1-4).

5.1.2 *Procedures B and C*—These procedures differ from Procedure A in how much of the overshoe footwear is subjected to the voltage proof test. In Procedure B, the footwear is immersed to a level of the top of the foot, while in Procedure C the footwear is immersed to a depth where the flashover clearance is consistent with the proof test voltage as listed in Table 1. In Procedures B and C, the inner electrode would preferably be water because of the weight of that quantity of shot. Care must therefore be taken to thoroughly dry the inside of the footwear following the proof test and prior to storage or issue.

Note 1—Water used as electrodes should have a minimum conductance of 0.25 mho.

5.2 **Precaution**—It is recommended that the test apparatus be designed to afford the operator full protection in performance of his duties. Reliable means of deenergizing and grounding the high-voltage circuit shall be provided. It is particularly important to incorporate a positive means of grounding the high-voltage section of the d-c test apparatus due to the likely presence of high-voltage capacitance charges at the conclusion of the test.

5.3 Electrical Test Equipment:

5.3.1 The test equipment used in the dielectric strength or proof tests shall be capable of supplying an essentially stepless

¹ This test method is under the jurisdiction of ASTM Committee F-18 on Electrical Protective Equipment for Workers and is the direct responsibility of Subcommittee F18.15 on Worker Personal Equipment.

Current edition approved Feb. 1, 1988. Published May 1988.

² Annual Book of ASTM Standards, Vol 10.01.

Copyright © ASTM, 100 Barr Harbor Drive, West Conshohocken, PA 19428-2959, United States.