

ETSI TS 101 376-4-8 V3.2.1 (2011-02)

Technical Specification

**GEO-Mobile Radio Interface Specifications (Release 3);
Third Generation Satellite Packet Radio Service;
Part 4: Radio interface protocol specifications;
Sub-part 8: Mobile Radio Interface Layer 3 Specifications;
GMR-1 3G 44.008**

iTeh Standards
(<https://standards.iteh.ai>)
Document Preview

ETSI TS 101 376-4-8 V3.2.1 (2011-02)

<https://standards.iteh.ai/catalog/standards/etsi/aecbd058-0c3b-4228-9a2a-e268c58ef7b7/etsi-ts-101-376-4-8-v3-2-1-2011-02>



Reference

RTS/SES-00315-4-8

Keywords

GMPRS, GMR, GPRS, GSM, GSO, interface,
layer 3, management, MES, mobile, mobility,
MSS, radio, satellite, S-PCN

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

(<https://standards.iteh.ai>)
Document Preview

Important notice

Individual copies of the present document can be downloaded from:

<http://www.etsi.org>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at

<http://portal.etsi.org/tb/status/status.asp>

If you find errors in the present document, please send your comment to one of the following services:

http://portal.etsi.org/chaicor/ETSI_support.asp

Copyright Notification

No part may be reproduced except as authorized by written permission.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2011.
All rights reserved.

DECTTM, PLUGTESTSTM, UMTSTM, TIPHONTM, the TIPHON logo and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.

3GPPTM is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

LTETM is a Trade Mark of ETSI currently being registered

for the benefit of its Members and of the 3GPP Organizational Partners.

GSM® and the GSM logo are Trade Marks registered and owned by the GSM Association.

Contents

Intellectual Property Rights	13
Foreword.....	13
Introduction	14
1 Scope	16
1.1 Scope of the present document.....	16
1.2 Application to the interface structures.....	16
1.3 Structure of Layer 3 procedures	16
1.4 Use of logical channels.....	16
1.5 Overview of control procedures	17
1.5.1 List of procedures	17
1.6 Applicability of implementations	19
1.6.1 Packet services.....	19
2 References	20
2.1 Normative references	20
2.2 Informative references.....	22
3 Definitions and abbreviations.....	22
3.1 Definitions.....	22
3.2 Abbreviations	24
3.3 Random values	24
4 Radio resource management procedures.....	24
4.1 Overview/general	24
4.1.1 General (A/Gb mode only)	24
4.1.2 Services provided to upper layers	24
4.1.2.1 Idle mode	24
4.1.2.2 Establishment and release of an RR connection.....	24
4.1.2.3 RR connected mode	25
4.1.2.4 Packet idle mode (A/Gb mode only).....	25
4.1.2.5 Packet transfer mode (A/Gb mode only).....	25
4.1.3 Services required from data link and physical layers.....	25
4.1.4 RR states	25
4.1.5 Change of dedicated channels.....	25
4.1.6 Procedure for service request and contention resolution	25
4.2 Idle mode procedures	25
4.2.1 Mobile Earth Station (MES) side.....	25
4.2.2 Network side.....	25
4.2.2.1 System information broadcasting.....	25
4.2.2.1.1 Classes and segments	26
4.2.2.1.2 Transmission schedules	26
4.2.2.1.3 Change information	26
4.2.2.1.4 Encoding and decoding rules.....	27
4.2.2.1.5 Future extensions.....	29
4.2.2.1.6 Anchored(A) and Temporary(T) BCCH (A/Gb mode only)	29
4.2.2.1.7 Multiplexing of CCCH and PCCCH (A/Gb mode only)	29
4.2.2.1.7a Multiplexing of CCCH and PCCCH (Iu mode only)	30
4.2.2.2 GPS satellite ephemeris data broadcasting.....	30
4.2.2.2a GPS satellite ephemeris data broadcasting on GBCH3.....	30
4.2.2.3 GPS almanac data transmission	31
4.3 RR connection establishment	31
4.3.1 RR connection establishment initiated by the Mobile Earth Station (MES): immediate assignment procedure	31
4.3.1.1 Spot beam selection to access the network	31
4.3.1.2 Permission to access the network.....	31
4.3.1.3 Initiation of the immediate assignment procedure (A/Gb mode only)	32

4.3.1.3a	Initiation of the immediate assignment procedure (Iu mode only).....	33
4.3.1.4	Answer from the network.....	34
4.3.1.4.1	On receipt of a CHANNEL REQUEST message (A/Gb mode only).....	34
4.3.1.4.2	IMMEDIATE ASSIGNMENT from network for MES requesting circuit service (A/Gb mode only)	34
4.3.1.4.3	Immediate Assignment from network for MES requesting packet service	35
4.3.1.4.4	Assignment rejection (IMMEDIATE ASSIGNMENT REJECT from network) (A/Gb mode only)	35
4.3.1.4.4a	Assignment rejection (IMMEDIATE ASSIGNMENT REJECT from network) (Iu mode only)	35
4.3.1.4.5	Extended immediate assignment procedure (A/Gb mode)	38
4.3.1.4.6	Position verification procedure (A/Gb mode only)	39
4.3.1.4.6a	Position verification procedure (Iu mode only)	39
4.3.1.5	Assignment procedure completion (A/Gb mode only).....	40
4.3.1.6	Abnormal cases (A/Gb mode only).....	40
4.3.2	RR connection establishment initiation by the network: paging procedure.....	40
4.4	RR connection transfer phase (A/Gb mode only).....	40
4.5	RR connection release procedure (A/Gb mode only)	40
4.6	Receiving an RR STATUS message by an RR entity	40
4.7	RR procedures on CCCH related to temporary block flow establishment	41
4.7.1	Packet paging procedure using CCCH.....	41
4.7.1.1	Packet paging initiation by the network	41
4.7.1.1a	Packet paging initiation by the network (Iu Mode only).....	42
4.7.1.2	On receipt of a packet paging request	42
4.7.2	Packet access procedure using CCCH	42
4.7.2.1	Entering the packet transfer mode: packet access procedure	42
4.7.2.1.1	Permission to access the network	42
4.7.2.1.2	Initiation of the packet access procedure: channel request (A/Gb mode only).....	43
4.7.2.1.2a	Initiation of the packet access procedure: channel request (Iu mode only)	43
4.7.2.1.3	Packet immediate assignment.....	43
4.7.2.1.4	Packet access completion	46
4.7.2.1.5	Abnormal cases	46
4.7.2.2	Sending an RLC/MAC control message: single block packet access procedure	46
4.7.3	Packet downlink assignment procedure using CCCH (A/Gb mode only)	46
4.7.3.1	Entering the packet transfer mode: packet downlink assignment procedure.....	46
4.7.3.1.1	General	46
4.7.3.1.2	Initiation of the packet downlink assignment procedure	46
4.7.3.1.3	Packet downlink assignment completion.....	47
4.7.3.1.4	Abnormal cases	48
4.7.3.2	Sending an RLC/MAC control message: single block packet downlink assignment procedure.....	48
4.8	GMPRS suspend procedure on CCCH (A/Gb mode only).....	48
4.8.1	Initiation of GMPRS suspend procedure	48
4.8.2	Completion of GMPRS suspend procedure	48
4.8.3	Abnormal cases.....	49
4.9	GMPRS resume procedure on CCCH (A/Gb mode only).....	49
4.9.1	Initiation of GMPRS resume procedure.....	49
4.9.2	Completion of GMPRS resume procedure	49
4.9.3	Abnormal cases.....	50
5	Elementary procedures for mobility management	50
5.1	General	50
5.1.1	MM and GMM procedures	50
5.1.1.1	Types of MM and GMM procedures	50
5.1.1.1.1	Integrity Checking of Signalling Messages in the Mobile Station (Iu mode only).....	50
5.1.1.1.1a	Integrity protection for emergency call (Iu mode only).....	50
5.1.1.2	MM-GMM co-ordination for GMPRS MESs (A/Gb mode only).....	50
5.1.1.2.1	GMPRS MS operating in mode A or B in a network that operates in mode I.....	50
5.1.1.2.2	GPRS MS operating in mode A or B in a network that operates in mode II or III.....	50
5.1.1.3	Core Network System Information for MM (Iu mode only).....	50
5.1.1.4	Core Network System Information for GMM (Iu mode only).....	50
5.1.2	MM sublayer states.....	51
5.1.3	GPRS mobility management (GMM) sublayer states.....	51

5.1.3.1	GMM states in the MES.....	51
5.1.3.1.1	Main states.....	51
5.1.3.1.2	Substates of state GMM-DEREGISTERED.....	52
5.1.3.1.3	Substates of state GMM-REGISTERED.....	53
5.1.3.2	GPRS update status.....	54
5.1.3.3	GMM mobility management states on the network side.....	56
5.1.3.3.1	Main States.....	56
5.1.3.3.2	Substates of state GMM-REGISTERED.....	56
5.2	Behaviour of the MES in MM idle state, GMM-DEREGISTERED state and GMM-REGISTERED state.....	57
5.2.1	Primary service state selection.....	57
5.2.1.1	Selection of the service state after power-on.....	57
5.2.1.2	Other cases.....	57
5.2.2	Detailed description of MES behaviour in MM idle state (A/Gb mode only).....	58
5.2.3	Service state when back to state MM idle from another state (A/Gb mode only).....	58
5.2.4	Service state after position verification.....	58
5.2.5	Behaviour in state GMM-DEREGISTERED.....	58
5.2.5.1	Primary substate selection.....	58
5.2.5.1.1	Selection of the substate after power on or enabling the MESs GPRS capability.....	58
5.2.5.1.2	Other cases.....	59
5.2.5.2	Detailed description of the MES behaviour in state GMM-DEREGISTERED.....	59
5.2.5.2.1	Substate, NORMAL-SERVICE.....	59
5.2.5.2.2	Substate, ATTEMPTING-TO-ATTACH.....	59
5.2.5.2.3	Substate, LIMITED-SERVICE.....	59
5.2.5.2.4	Substate, NO-IMSI.....	59
5.2.5.2.5	Substate, NO-CELL.....	59
5.2.5.2.6	Substate, PLMN-SEARCH.....	60
5.2.5.2.7	Substate, ATTACH-NEEDED.....	60
5.2.5.2.8	Substate, SUSPENDED (A/Gb mode only).....	60
5.2.5.2.9	Substate, INVALID-POSITION (A/Gb mode only).....	60
5.2.5.2.10	Substate, NORMAL-SERVICE-DARK-BEAM (A/Gb mode only).....	60
5.2.5.3	Substate when back to state GMM-DEREGISTERED from another GMM state.....	60
5.2.6	Behaviour in state GMM-REGISTERED.....	61
5.2.6.1	Detailed description of the MES behaviour in state GMM-REGISTERED.....	61
5.2.6.1.1	Substate, NORMAL-SERVICE.....	61
5.2.6.1.2	Substate, SUSPENDED (A/Gb mode only).....	61
5.2.6.1.3	Substate, UPDATE-NEEDED.....	62
5.2.6.1.4	Substate, ATTEMPTING-TO-UPDATE.....	62
5.2.6.1.5	Substate, NO-CELL-AVAILABLE.....	62
5.2.6.1.6	Substate, LIMITED-SERVICE.....	62
5.2.6.1.7	Substate, ATTEMPTING-TO-UPDATE-MM.....	62
5.2.6.1.8	Substate, NORMAL-SERVICE-DARK-BEAM (A/Gb mode only).....	62
5.2.6.1.9	Substate, NORMAL-SERVICE-ILLUMINATION-INITIATED (A/Gb mode only).....	62
5.2.6.1.10	Substate, ROUTING-AREA-UPDATE-DARK-BEAM (A/Gb mode only).....	62
5.2.6.1.11	Substate, ROUTING-AREA-UPDATE-ILLUMINATION-INITIATED (A/Gb mode only).....	63
5.3	MM common procedures.....	63
5.3.1	TMSI reallocation procedure (A/Gb mode only).....	63
5.3.2	Authentication procedure.....	63
5.3.3	Identification procedure.....	63
5.3.4	IMSI detach procedure (A/Gb mode only).....	63
5.3.5	Abort procedure (A/Gb mode only).....	63
5.3.6	MM information procedure (A/Gb mode only).....	63
5.4	MM specific procedures (A/Gb mode only).....	63
5.5	Connection management sublayer service provision (A/Gb mode only).....	63
5.5.1	MM connection establishment.....	63
5.5.1.1	MM connection establishment initiated by the MES.....	63
5.5.1.2	Abnormal cases.....	63
5.5.1.3	MM connection establishment initiated by the network.....	64
5.5.1.4	Abnormal cases.....	64
5.5.1.5	MM connection establishment for emergency calls.....	64
5.5.1.6	Call reestablishment.....	64
5.5.1.7	Forced release during MO MM connection establishment.....	64
5.5.1.8	Optimal routing.....	64

5.5.2	MM connection information transfer phase	65
5.5.3	MM connection release	65
5.6	Receiving an MM STATUS message by an MM entity	65
5.7	Elementary mobility management procedures for GMPRS services	65
5.7.1	General	65
5.7.1.1	Lower layer failure	65
5.7.1.2	Ciphering of messages (A/Gb mode only)	65
5.7.1.3	P-TMSI signature	65
5.7.1.4	Radio resource sublayer address handling	65
5.7.1.4.1	Radio resource sublayer address handling (A/Gb mode only)	66
5.7.1.5	P-TMSI handling	66
5.7.1.6	Change of network mode of operation	66
5.7.1.7	Intersystem change between A/Gb mode and Iu mode	66
5.7.1.8	List of forbidden PLMNs for GPRS service	66
5.7.2	GPRS Mobility management timers and UMTS PS signalling connection control	66
5.7.2.1	READY timer behaviour	66
5.7.2.1.1	READY timer behaviour (A/Gb mode only)	66
5.7.2.1.2	READY timer behaviour (Iu mode only)	66
5.7.2.2	Periodic routing area updating	66
5.7.2.3	PMM-IDLE mode and PMM-CONNECTED mode (Iu mode only)	68
5.7.2.4	Handling of <i>Force to standby</i> in Iu mode (Iu mode only)	68
5.7.2.5	RA Update procedure for Signalling Connection Re-establishment (Iu mode only)	68
5.7.2.6	Cell Update triggered by low layers	68
5.7.3	GPRS attach procedure	68
5.7.3.1	GPRS attach procedure for GMPRS services	69
5.7.3.1.1	GPRS attach procedure initiation	69
5.7.3.1.2	GMM common procedure initiation	69
5.7.3.1.3	GPRS attach accepted by the network	69
5.7.3.1.4	GPRS attach not accepted by the network	69
5.7.3.1.5	Abnormal cases in the MES	69
5.7.3.1.6	Abnormal cases on the network side	70
5.7.3.2	Combined GPRS attach procedure for GMPRS and non-GMPRS services (A/Gb mode only)	70
5.7.4	GPRS detach procedure	70
5.7.4.1	MES initiated GPRS detach procedure	71
5.7.4.1.1	MES initiated GPRS detach procedure initiation	71
5.7.4.1.2	MES initiated GPRS detach procedure completion for GMPRS services only	71
5.7.4.1.3	MES initiated combined GPRS detach procedure completion	71
5.7.4.1.4	Abnormal cases in the MES	71
5.7.4.2	Network initiated GMPRS detach procedure	71
5.7.4.2.1	Network initiated GMPRS detach procedure initiation	71
5.7.4.2.2	Network initiated GMPRS detach procedure completion by the MES	71
5.7.4.2.3	Network initiated GMPRS detach procedure completion by the network	71
5.7.4.2.4	Abnormal cases on the network side	71
5.7.5	Routing area updating procedure	72
5.7.5.1	Normal and periodic routing area updating procedure	74
5.7.5.1.1	Normal and periodic routing area updating procedure initiation	74
5.7.5.1.2	GMM Common procedure initiation	74
5.7.5.1.3	Normal and periodic routing area updating procedure accepted by the network	74
5.7.5.1.4	Normal and periodic routing area updating procedure not accepted by the network	74
5.7.5.1.5	Abnormal cases in the MES	74
5.7.5.1.6	Abnormal cases on the network side	75
5.7.5.2	Combined routing area updating procedure	75
5.7.6	P-TMSI reallocation procedure	75
5.7.7	Authentication and ciphering procedure	76
5.7.8	Identification procedure	76
5.7.9	Paging procedure	76
5.7.9.1	Paging for GMPRS services	76
5.7.9.1.1	Paging for packet services using P-TMSI	76
5.7.9.1.2	Paging for packet services using IMSI	76
5.7.9.2	Paging for non-GMPRS services	76
5.7.10	Receiving a GMM STATUS message by a GMM entity	76
5.7.11	Void	77

5.7.12	GMM Information procedure	77
5.7.13	Service Request procedure (Iu mode only).....	77
6	Elementary procedures for circuit-switched call control (A/Gb mode only)	77
7	Support of packet services.....	77
8	Examples of structured procedures	77
8.1	General	77
8.1.1	Paging and alert request.....	77
8.1.2	Immediate assignment	77
8.1.3	Service request and contention resolution	77
8.1.4	Authentication.....	77
8.1.5	Ciphering mode setting (A/Gb mode only).....	77
8.1.6	Transaction phase (A/Gb mode only)	77
8.1.7	Channel release (A/Gb mode only).....	78
8.2	Abnormal cases (A/Gb mode only)	78
8.3	Selected examples (A/Gb mode only)	78
8.3.1	Location updating	78
8.3.2	Mobile originating call establishment.....	78
8.3.3	Mobile terminating call establishment.....	78
8.3.4	Call clearing.....	78
8.3.5	DTMF protocol control.....	78
8.3.6	Handover	78
8.3.7	In-call modification.....	78
8.3.8	Call reestablishment.....	78
8.3.9	Mobile-to-mobile call establishment	78
8.3.10	Multisatellite optimal routing for call establishment	78
9	Handling of unknown, unforeseen, and erroneous protocol data	79
10	Message functional definitions and contents.....	79
10.1	Messages for radio resources management	80
10.1.1	Additional assignment (A/Gb mode only)	81
10.1.2	Assignment command 1 and assignment command 2 (A/Gb mode only)	81
10.1.2.1	Assignment command 1	81
10.1.2.2	Assignment command 2	81
10.1.3	Assignment complete (A/Gb mode only)	81
10.1.4	Assignment failure (A/Gb mode only).....	81
10.1.5	Channel mode modify (A/Gb mode only)	81
10.1.6	Channel mode modify acknowledge (A/Gb mode only)	81
10.1.7	Channel release (A/Gb mode only).....	81
10.1.8	Channel request	81
10.1.8.1	Extended channel request (A/Gb mode only)	82
10.1.8.2	Channel request Type 1 (A/Gb mode only)	82
10.1.8.3	Channel request Type 2 (A/Gb mode only)	85
10.1.8.4	Channel Request Type 3 (Iu mode only).....	87
10.1.9	Ciphering mode command (A/Gb mode only)	90
10.1.10	Ciphering mode complete (A/Gb mode only).....	90
10.1.11	Classmark change (A/Gb mode only).....	91
10.1.12	Classmark enquiry (A/Gb mode only).....	91
10.1.13	Frequency redefinition (A/Gb mode only).....	91
10.1.14	Handover access (A/Gb mode only)	91
10.1.15	Handover command (A/Gb mode only).....	91
10.1.16	Handover complete (A/Gb mode only).....	91
10.1.17	Handover failure (A/Gb mode only).....	91
10.1.18	Immediate assignment	91
10.1.18.1	Immediate assignment (A/Gb mode only)	91
10.1.18.2	Extended immediate assignment (A/Gb mode only).....	91
10.1.18.3	Immediate assignment Type 2 (A/Gb mode only)	91
10.1.18.3.1	USF.....	92
10.1.18.3.2	TLLI	92
10.1.18.3.3	Packet Power Control Parameters	92
10.1.18.3.4	Timing Advance Index (TAI).....	92