

ETSI TS 136 331 V18.9.0 (2026-04)



TECHNICAL SPECIFICATION

**LTE;
Evolved Universal Terrestrial Radio Access (E-UTRA);
Radio Resource Control (RRC);
Protocol specification
(3GPP TS 36.331 version 18.9.0 Release 18)**



Reference

RTS/TSGR-0236331 vi90

Keywords

LTE

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° w061004871

Important notice

The present document can be downloaded from the
[ETSI Search & Browse Standards](#) application.

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format on [ETSI deliver](#) repository.

Users should be aware that the present document may be revised or have its status changed, this information is available in the [Milestones listing](#).

If you find errors in the present document, please send your comments to the relevant service listed under [Committee Support Staff](#).

If you find a security vulnerability in the present document, please report it through our [Coordinated Vulnerability Disclosure \(CVD\)](#) program.

Notice of disclaimer & limitation of liability

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

Copyright Notification

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2026.
All rights reserved.

Intellectual Property Rights

Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the [ETSI IPR online database](#).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

DECT™, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™**, **LTE™** and **5G™** logo are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found at [3GPP to ETSI numbering cross-referencing](#).

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

Contents

Intellectual Property Rights	2
Legal Notice	2
Modal verbs terminology.....	2
Foreword.....	25
1 Scope	26
2 References	26
3 Definitions, symbols and abbreviations	31
3.1 Definitions	31
3.2 Abbreviations	34
4 General	38
4.1 Introduction	38
4.2 Architecture	39
4.2.1 UE states and state transitions including inter RAT	39
4.2.2 Signalling radio bearers	43
4.3 Services	44
4.3.1 Services provided to upper layers	44
4.3.2 Services expected from lower layers	45
4.4 Functions	45
4.5 Data available for transmission for NB-IoT	46
5 Procedures	46
5.1 General	46
5.1.1 Introduction.....	46
5.1.2 General requirements.....	47
5.1.3 Requirements for UE in MR-DC	48
5.2 System information	48
5.2.1 Introduction.....	48
5.2.1.1 General	48
5.2.1.2 Scheduling.....	49
5.2.1.2a Scheduling for NB-IoT	50
5.2.1.3 System information validity and notification of changes	51
5.2.1.4 Indication of ETWS notification.....	53
5.2.1.5 Indication of CMAS notification.....	53
5.2.1.6 Notification of EAB parameters change	54
5.2.1.7 Access Barring parameters change in NB-IoT.....	54
5.2.1.8 Notification of UAC parameters change	54
5.2.2 System information acquisition	55
5.2.2.1 General	55
5.2.2.2 Initiation.....	55
5.2.2.3 System information required by the UE.....	55
5.2.2.4 System information acquisition by the UE.....	57
5.2.2.5 Essential system information missing	61
5.2.2.6 Actions upon reception of the <i>MasterInformationBlock</i> message.....	62
5.2.2.7 Actions upon reception of the <i>SystemInformationBlockType1</i> message	62
5.2.2.8 Actions upon reception of <i>SystemInformation</i> messages	65
5.2.2.9 Actions upon reception of <i>SystemInformationBlockType2</i>	65
5.2.2.10 Actions upon reception of <i>SystemInformationBlockType3</i>	67
5.2.2.11 Actions upon reception of <i>SystemInformationBlockType4</i>	68
5.2.2.12 Actions upon reception of <i>SystemInformationBlockType5</i>	68
5.2.2.13 Actions upon reception of <i>SystemInformationBlockType6</i>	69
5.2.2.14 Actions upon reception of <i>SystemInformationBlockType7</i>	69
5.2.2.15 Actions upon reception of <i>SystemInformationBlockType8</i>	69
5.2.2.16 Actions upon reception of <i>SystemInformationBlockType9</i>	70
5.2.2.17 Actions upon reception of <i>SystemInformationBlockType10</i>	70

5.2.2.18	Actions upon reception of <i>SystemInformationBlockType11</i>	70
5.2.2.19	Actions upon reception of <i>SystemInformationBlockType12</i>	71
5.2.2.20	Actions upon reception of <i>SystemInformationBlockType13</i>	72
5.2.2.21	Actions upon reception of <i>SystemInformationBlockType14</i>	72
5.2.2.22	Actions upon reception of <i>SystemInformationBlockType15</i>	72
5.2.2.23	Actions upon reception of <i>SystemInformationBlockType16</i>	72
5.2.2.24	Actions upon reception of <i>SystemInformationBlockType17</i>	72
5.2.2.25	Actions upon reception of <i>SystemInformationBlockType18</i>	72
5.2.2.26	Actions upon reception of <i>SystemInformationBlockType19</i>	73
5.2.2.27	Actions upon reception of <i>SystemInformationBlockType20</i>	73
5.2.2.28	Actions upon reception of <i>SystemInformationBlockType21</i>	73
5.2.2.29	Actions upon reception of <i>SystemInformationBlockType22-NB</i>	74
5.2.2.30	Actions upon reception of <i>SystemInformationBlockType23-NB</i>	74
5.2.2.31	Actions upon reception of <i>SystemInformationBlockType24</i>	74
5.2.2.32	Actions upon reception of <i>SystemInformationBlockType25</i>	74
5.2.2.33	Actions upon reception of <i>SystemInformationBlockType26</i>	74
5.2.2.33a	Actions upon reception of <i>SystemInformationBlockType26a</i>	74
5.2.2.34	Actions upon reception of <i>SystemInformationBlockPos</i>	75
5.2.2.35	Actions upon reception of <i>SystemInformationBlockType27</i>	75
5.2.2.36	Actions upon reception of <i>SystemInformationBlockType28</i>	75
5.2.2.37	Actions upon reception of <i>SystemInformationBlockType29</i>	75
5.2.2.38	Actions upon reception of <i>SystemInformationBlockType30</i>	75
5.2.2.39	Actions upon reception of <i>SystemInformationBlockType31</i>	75
5.2.2.40	Actions upon reception of <i>SystemInformationBlockType32</i>	75
5.2.2.41	Actions upon reception of <i>SystemInformationBlockType33</i>	75
5.2.3	Acquisition of an SI message.....	76
5.2.3a	Acquisition of an SI message by BL UE or UE in CE or a NB-IoT UE.....	76
5.2.3b	Acquisition of an SI message from MBMS-dedicated cell.....	77
5.3	Connection control	78
5.3.1	Introduction.....	78
5.3.1.1	RRC connection control.....	78
5.3.1.2	Security	80
5.3.1.2a	RN security	82
5.3.1.3	Connected mode mobility	82
5.3.1.4	Connection control in NB-IoT	83
5.3.2	Paging	84
5.3.2.1	General	84
5.3.2.2	Initiation.....	85
5.3.2.3	Reception of the <i>Paging</i> message by the UE	85
5.3.3	RRC connection establishment	87
5.3.3.1	General	87
5.3.3.1a	Conditions for establishing RRC Connection for sidelink communication/ discovery/ V2X sidelink communication/ NR sidelink communication	90
5.3.3.1b	Conditions for initiating EDT	91
5.3.3.1c	Conditions for initiating transmission using PUR.....	92
5.3.3.1d	Condition for establishing RRC Connection in NTN.....	92
5.3.3.2	Initiation.....	92
5.3.3.3	Actions related to transmission of <i>RRCConnectionRequest</i> message	100
5.3.3.3a	Actions related to transmission of <i>RRCConnectionResumeRequest</i> message.....	101
5.3.3.3b	Actions related to transmission of <i>RRCEarlyDataRequest</i> message.....	105
5.3.3.3c	UE actions upon receiving EDT fallback indication from lower layers.....	105
5.3.3.3d	UE actions upon receiving PUR indications from lower layers	106
5.3.3.4	Reception of the <i>RRCConnectionSetup</i> by the UE.....	106
5.3.3.4a	Reception of the <i>RRCConnectionResume</i> by the UE	112
5.3.3.4b	Reception of the <i>RRCEarlyDataComplete</i> by the UE.....	118
5.3.3.5	Cell re-selection or cell selection while T300, T302, T303, T305, T306, T308 or T309 is running... 119	
5.3.3.6	T300 expiry	120
5.3.3.7	T302, T303, T305, T306, or T308 expiry or stop	122
5.3.3.8	Reception of the <i>RRCConnectionReject</i> by the UE	122
5.3.3.9	Abortion of RRC connection establishment.....	124
5.3.3.9a	Abortion of early security reactivation.....	124
5.3.3.10	Handling of SSAC related parameters	124

5.3.3.11	Access barring check.....	125
5.3.3.12	EAB check	126
5.3.3.13	Access barring check for ACDC	127
5.3.3.14	Access Barring check for NB-IoT.....	127
5.3.3.15	Failure to deliver NAS information in RRCConnectionSetupComplete message	129
5.3.3.16	Integrity check failure from lower layers while T300 is running.....	129
5.3.3.17	Inability to comply with <i>RRCConnectionResume</i>	130
5.3.3.18	Early security reactivation.....	130
5.3.3.19	Timing alignment validation for transmission using PUR	130
5.3.3.20	Maintenance of PUR occasions.....	131
5.3.3.21	UE actions upon indication of out-of-date GNSS position	131
5.3.3.22	Void.....	132
5.3.3.23	UE actions upon detecting discontinuous coverage	132
5.3.3.24	T390 expiry	132
5.3.3.25	UE actions upon receiving UL transmission extension indication.....	132
5.3.4	Initial security activation	133
5.3.4.1	General	133
5.3.4.2	Initiation.....	133
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE.....	133
5.3.5	RRC connection reconfiguration	134
5.3.5.1	General	134
5.3.5.2	Initiation.....	135
5.3.5.3	Reception of an <i>RRCConnectionReconfiguration</i> not including the <i>mobilityControlInfo</i> by the UE	135
5.3.5.4	Reception of an <i>RRCConnectionReconfiguration</i> including the <i>mobilityControlInfo</i> by the UE (handover).....	139
5.3.5.5	Reconfiguration failure	147
5.3.5.6	T304 expiry (handover failure)	147
5.3.5.7	Void.....	150
5.3.5.7a	T307 expiry (SCG change failure).....	150
5.3.5.8	Radio Configuration involving full configuration option.....	150
5.3.5.9	Conditional reconfiguration	153
5.3.5.9.1	General	153
5.3.5.9.2	Conditional reconfiguration removal.....	153
5.3.5.9.3	Conditional reconfiguration addition/modification	153
5.3.5.9.4	Conditional reconfiguration evaluation	153
5.3.5.9.5	Conditional reconfiguration execution	155
5.3.5.9.6	VarConditionalReconfiguration remove.....	155
5.3.5.9.7	VarConditionalReconfiguration CPC remove.....	155
5.3.6	Counter check	156
5.3.6.1	General	156
5.3.6.2	Initiation.....	156
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE.....	156
5.3.7	RRC connection re-establishment.....	157
5.3.7.1	General	157
5.3.7.1a	Condition for re-establishing RRC Connection in NTN	158
5.3.7.2	Initiation.....	158
5.3.7.3	Actions following cell selection while T311 is running.....	160
5.3.7.4	Actions related to transmission of <i>RRCConnectionReestablishmentRequest</i> message	162
5.3.7.5	Reception of the <i>RRCConnectionReestablishment</i> by the UE	164
5.3.7.6	T311 expiry	167
5.3.7.7	T301 expiry or selected cell no longer suitable.....	167
5.3.7.8	Reception of <i>RRCConnectionReestablishmentReject</i> by the UE	167
5.3.8	RRC connection release	168
5.3.8.1	General	168
5.3.8.2	Initiation.....	168
5.3.8.3	Reception of the <i>RRCConnectionRelease</i> by the UE	168
5.3.8.4	T320 expiry	172
5.3.8.5	T322 expiry or stop	172
5.3.8.6	UE actions upon receiving the expiry of <i>DataInactivityTimer</i>	172
5.3.8.7	UE actions upon entering RRC_INACTIVE	172
5.3.8.8	T323 expiry	173

5.3.9	RRC connection release requested by upper layers	174
5.3.9.1	General	174
5.3.9.2	Initiation	174
5.3.10	Radio resource configuration	174
5.3.10.0	General	174
5.3.10.1	SRB addition/ modification	175
5.3.10.1a	SCG RLC bearer addition or reconfiguration for SRBs	176
5.3.10.2	DRB release	177
5.3.10.3	DRB addition/ modification	178
5.3.10.3a1	DC specific DRB addition or reconfiguration	180
5.3.10.3a2	LWA specific DRB addition or reconfiguration	182
5.3.10.3a3	LWIP specific DRB addition or reconfiguration	183
5.3.10.3a4	SCG RLC bearer addition or reconfiguration for DRBs in NE-DC	184
5.3.10.3a	SCell release	184
5.3.10.3b	SCell addition/ modification	184
5.3.10.3c	PSCell addition or modification	185
5.3.10.3d	SCell group release	185
5.3.10.3e	SCell group addition/ modification	186
5.3.10.4	MAC main reconfiguration	186
5.3.10.5	Semi-persistent scheduling reconfiguration	187
5.3.10.6	Physical channel reconfiguration	187
5.3.10.7	Radio Link Failure Timers and Constants reconfiguration	188
5.3.10.8	Time domain measurement resource restriction for serving cell	189
5.3.10.9	Other configuration	189
5.3.10.10	SCG reconfiguration	192
5.3.10.11	SCG dedicated resource configuration	194
5.3.10.12	Reconfiguration SCG or split DRB by <i>drb-ToAddModList</i>	195
5.3.10.13	Neighbour cell information reconfiguration	195
5.3.10.14	Void	195
5.3.10.15	Sidelinek dedicated configuration	195
5.3.10.15a	V2X sidelink Communication dedicated configuration	197
5.3.10.16	T370 expiry	197
5.3.10.17	SRB release	197
5.3.10.18	Scheduling Request Configuration for NB-IoT	198
5.3.10.19	NE-DC release	198
5.3.11	Radio link failure related actions	198
5.3.11.1	Detection of physical layer problems in RRC_CONNECTED	198
5.3.11.1a	Early detection of physical layer problems in RRC_CONNECTED	199
5.3.11.1b	Detection of physical layer improvements in RRC_CONNECTED	199
5.3.11.2	Recovery of physical layer problems	199
5.3.11.2a	Recovery of early detection of physical layer problems	199
5.3.11.2b	Cancellation of physical layer improvements in RRC_CONNECTED	199
5.3.11.3	Detection of radio link failure	199
5.3.11.3a	Detection of early-out-of-sync event	203
5.3.11.3b	Detection of early-in-sync event	203
5.3.12	UE actions upon leaving RRC_CONNECTED or RRC_INACTIVE	203
5.3.13	UE actions upon PUCCH/ SPUCCH/ SRS release request	206
5.3.13a	UE actions upon SR release request for NB-IoT	206
5.3.13b	UE actions upon PUR release request	206
5.3.14	Proximity indication	207
5.3.14.1	General	207
5.3.14.2	Initiation	207
5.3.14.3	Actions related to transmission of <i>ProximityIndication</i> message	207
5.3.15	Void	208
5.3.16	Unified Access Control	208
5.3.16.1	General	208
5.3.16.2	Initiation	208
5.3.16.3	Void	211
5.3.16.4	T302, T309 expiry or stop (Barring alleviation)	211
5.3.16.5	Access barring check	212
5.3.17	RAN notification area update	213
5.3.17.1	General	213

5.3.17.2	Initiation.....	213
5.3.17.3	Inter RAT cell reselection or CN type change	213
5.3.18	T317 expiry.....	214
5.4	Inter-RAT mobility.....	214
5.4.1	Introduction.....	214
5.4.2	Handover to E-UTRA.....	215
5.4.2.1	General.....	215
5.4.2.2	Initiation.....	215
5.4.2.3	Reception of the <i>RRCConnectionReconfiguration</i> by the UE.....	215
5.4.2.4	Reconfiguration failure	219
5.4.2.5	T304 expiry (handover to E-UTRA failure).....	219
5.4.3	Mobility from E-UTRA	219
5.4.3.1	General.....	219
5.4.3.2	Initiation.....	220
5.4.3.3	Reception of the <i>MobilityFromEUTRACommand</i> by the UE	220
5.4.3.4	Successful completion of the mobility from E-UTRA.....	222
5.4.3.5	Mobility from E-UTRA failure.....	223
5.4.4	Handover from E-UTRA preparation request (CDMA2000)	223
5.4.4.1	General.....	223
5.4.4.2	Initiation.....	224
5.4.4.3	Reception of the <i>HandoverFromEUTRAPreparationRequest</i> by the UE	224
5.4.5	UL handover preparation transfer (CDMA2000)	224
5.4.5.1	General.....	224
5.4.5.2	Initiation.....	225
5.4.5.3	Actions related to transmission of the <i>ULHandoverPreparationTransfer</i> message.....	225
5.4.5.4	Failure to deliver the <i>ULHandoverPreparationTransfer</i> message.....	225
5.4.6	Inter-RAT cell change order to E-UTRAN.....	225
5.4.6.1	General.....	225
5.4.6.2	Initiation.....	225
5.4.6.3	UE fails to complete an inter-RAT cell change order	225
5.5	Measurements.....	226
5.5.1	Introduction.....	226
5.5.2	Measurement configuration	228
5.5.2.1	General.....	228
5.5.2.2	Measurement identity removal.....	229
5.5.2.2a	Measurement identity autonomous removal	229
5.5.2.3	Measurement identity addition/ modification	230
5.5.2.4	Measurement object removal	231
5.5.2.5	Measurement object addition/ modification.....	231
5.5.2.6	Reporting configuration removal	234
5.5.2.7	Reporting configuration addition/ modification.....	234
5.5.2.8	Quantity configuration	235
5.5.2.9	Measurement gap configuration.....	235
5.5.2.9a	Measurement gap configuration for RSTD measurements with dense PRS configuration.....	236
5.5.2.10	Discovery signals measurement timing configuration	237
5.5.2.11	RSSI measurement timing configuration	237
5.5.2.12	Measurement gap sharing configuration	237
5.5.2.13	NR measurement timing configuration	238
5.5.3	Performing measurements	238
5.5.3.1	General.....	238
5.5.3.2	Layer 3 filtering	243
5.5.3.3	Derivation of NR cell quality	244
5.5.3.4	Derivation of NR beam quality	244
5.5.4	Measurement report triggering	244
5.5.4.1	General.....	244
5.5.4.2	Event A1 (Serving becomes better than threshold).....	251
5.5.4.3	Event A2 (Serving becomes worse than threshold)	252
5.5.4.4	Event A3 (Neighbour becomes offset better than PCell/ PSCell)	252
5.5.4.5	Event A4 (Neighbour becomes better than threshold)	253
5.5.4.6	Event A5 (PCell/ PSCell becomes worse than threshold1 and neighbour becomes better than threshold2)	253
5.5.4.6a	Event A6 (Neighbour becomes offset better than SCell).....	254

5.5.4.7	Event B1 (Inter RAT neighbour becomes better than threshold).....	255
5.5.4.8	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2)	256
5.5.4.9	Event C1 (CSI-RS resource becomes better than threshold).....	257
5.5.4.10	Event C2 (CSI-RS resource becomes offset better than reference CSI-RS resource).....	257
5.5.4.11	Event W1 (WLAN becomes better than a threshold).....	258
5.5.4.12	Event W2 (All WLAN inside WLAN mobility set becomes worse than threshold1 and a WLAN outside WLAN mobility set becomes better than threshold2)	258
5.5.4.13	Event W3 (All WLAN inside WLAN mobility set becomes worse than a threshold).....	259
5.5.4.14	Event V1 (The channel busy ratio is above a threshold).....	260
5.5.4.15	Event V2 (The channel busy ratio is below a threshold).....	260
5.5.4.16	Event H1 (The Aerial UE height is above a threshold).....	260
5.5.4.17	Event H2 (The Aerial UE height is below a threshold).....	261
5.5.4.18	Void.....	262
5.5.4.19	Void.....	262
5.5.4.20	Event D1 (Distance between UE and referenceLocation1 is above threshold1 and distance between UE and referenceLocation2 is below threshold2).....	262
5.5.4.21	CondEvent T1 (Time measured at UE is within a duration from threshold).....	262
5.5.4.22	Event D2 (Distance between UE and serving cell moving reference location is above threshold1 and distance between UE and neighbour cell moving reference location is below threshold2).....	263
5.5.5	Measurement reporting	264
5.5.5.1	General	264
5.5.5.2	Determination of available NR measurement results	271
5.5.5.3	Selection of NR sorting quality	271
5.5.6	Measurement related actions.....	272
5.5.6.1	Actions upon handover and re-establishment.....	272
5.5.6.2	Speed dependant scaling of measurement related parameters.....	273
5.5.7	Inter-frequency RSTD measurement indication	273
5.5.7.1	General	273
5.5.7.2	Initiation.....	274
5.5.7.3	Actions related to transmission of <i>InterFreqRSTDMeasurementIndication</i> message.....	274
5.5.8	Measurements in NB-IoT	275
5.5.9	GNSS measurement triggering and reporting	276
5.6	Other.....	276
5.6.0	General.....	276
5.6.1	DL information transfer	277
5.6.1.1	General	277
5.6.1.2	Initiation.....	277
5.6.1.3	Reception of the <i>DLInformationTransfer</i> by the UE	277
5.6.2	UL information transfer	278
5.6.2.1	General	278
5.6.2.2	Initiation.....	278
5.6.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message.....	278
5.6.2.4	Failure to deliver <i>ULInformationTransfer</i> message	279
5.6.2a	UL information transfer for MR-DC	279
5.6.2a.1	General	279
5.6.2a.2	Initiation.....	279
5.6.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message.....	279
5.6.2a.4	Void.....	280
5.6.3	UE capability transfer	280
5.6.3.1	General	280
5.6.3.2	Initiation.....	280
5.6.3.3	Reception of the <i>UECapabilityEnquiry</i> by the UE	280
5.6.4	CSFB to 1x Parameter transfer	285
5.6.4.1	General	285
5.6.4.2	Initiation.....	285
5.6.4.3	Actions related to transmission of <i>CSFBParametersRequestCDMA2000</i> message.....	285
5.6.4.4	Reception of the <i>CSFBParametersResponseCDMA2000</i> message.....	285
5.6.5	UE Information.....	286
5.6.5.1	General	286
5.6.5.2	Initiation.....	286
5.6.5.3	Reception of the <i>UEInformationRequest</i> message	286

5.6.6	Logged Measurement Configuration	289
5.6.6.1	General	289
5.6.6.2	Initiation	289
5.6.6.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE	289
5.6.6.4	T330 expiry	290
5.6.7	Release of Logged Measurement Configuration	290
5.6.7.1	General	290
5.6.7.2	Initiation	290
5.6.8	Measurements logging	290
5.6.8.1	General	290
5.6.8.2	Initiation	290
5.6.9	In-device coexistence indication	294
5.6.9.1	General	294
5.6.9.2	Initiation	295
5.6.9.3	Actions related to transmission of <i>InDeviceCoexIndication</i> message	296
5.6.10	UE Assistance Information	297
5.6.10.1	General	297
5.6.10.2	Initiation	297
5.6.10.3	Actions related to transmission of <i>UEAssistanceInformation</i> message	299
5.6.11	Mobility history information	302
5.6.11.1	General	302
5.6.11.2	Initiation	302
5.6.12	RAN-assisted WLAN interworking	302
5.6.12.1	General	302
5.6.12.2	Dedicated WLAN offload configuration	302
5.6.12.3	WLAN offload RAN evaluation	303
5.6.12.4	T350 expiry or stop	303
5.6.12.5	Cell selection/ re-selection while T350 is running	303
5.6.13	SCG failure information	304
5.6.13.1	General	304
5.6.13.2	Initiation	304
5.6.13.3	Actions related to transmission of <i>SCGFailureInformation</i> message	304
5.6.13.4	Failure type determination in NE-DC	305
5.6.13.5	Setting the contents of <i>MeasResultSCG-FailureMRDC</i>	305
5.6.13a	NR SCG failure information	306
5.6.13a.1	General	306
5.6.13a.2	Initiation	306
5.6.13a.3	Actions related to transmission of <i>SCGFailureInformationNR</i> message	306
5.6.14	LTE-WLAN Aggregation	307
5.6.14.1	Introduction	307
5.6.14.2	Reception of LWA configuration	307
5.6.14.3	Release of LWA configuration	308
5.6.15	WLAN connection management	308
5.6.15.1	Introduction	308
5.6.15.2	WLAN connection status reporting	309
5.6.15.2.1	General	309
5.6.15.2.2	Initiation	309
5.6.15.2.3	Actions related to transmission of <i>WLANConnectionStatusReport</i> message	309
5.6.15.3	T351 Expiry (WLAN connection attempt timeout)	309
5.6.15.4	WLAN status monitoring	309
5.6.16	RAN controlled LTE-WLAN interworking	310
5.6.16.1	General	310
5.6.16.2	WLAN traffic steering command	311
5.6.17	LTE-WLAN aggregation with IPsec tunnel	311
5.6.17.1	General	311
5.6.17.2	LWIP reconfiguration	311
5.6.17.3	LWIP release	312
5.6.18	Void	312
5.6.19	Application layer measurement reporting	312
5.6.19.1	General	312
5.6.19.2	Initiation	313
5.6.20	Idle/Inactive Measurements	313

5.6.20.1	General	313
5.6.20.1a	Measurement configuration.....	313
5.6.20.2	Performing measurements.....	314
5.6.20.3	T331 expiry or stop	316
5.6.20.4	Cell re-selection or selection while T331 is running.....	316
5.6.21	Failure information	317
5.6.21.1	General	317
5.6.21.2	Initiation.....	317
5.6.21.3	Actions related to transmission of <i>FailureInformation</i> message.....	317
5.6.22	UL message segment transfer	318
5.6.22.1	General	318
5.6.22.2	Initiation.....	318
5.6.22.3	Actions related to transmission of <i>ULDedicatedMessageSegment</i> message.....	318
5.6.23	PUR Configuration Request	319
5.6.23.1	General	319
5.6.23.2	Initiation.....	319
5.6.23.3	Actions related to transmission of <i>PURConfigurationRequest</i> message.....	319
5.6.24	Neighbour Relation Reporting for SON ANR in NB-IoT	320
5.6.24.0	General	320
5.6.24.1	Initiation.....	320
5.6.25	DL message segment transfer	321
5.6.25.1	General	321
5.6.25.2	Initiation.....	321
5.6.25.3	Reception of <i>DLDedicatedMessageSegment</i> by the UE	321
5.6.26	MCG failure information	322
5.6.26.1	General	322
5.6.26.2	Initiation.....	322
5.6.26.3	Failure type determination	322
5.6.26.4	Actions related to transmission of <i>MCGFailureInformation</i> message.....	323
5.6.26.5	T316 expiry	324
5.6.27	Void	324
5.6.28	UL transfer of IRAT information	324
5.6.28.1	General	324
5.6.28.2	Initiation.....	325
5.6.28.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message	325
5.7	Generic error handling.....	325
5.7.1	General.....	325
5.7.2	ASN.1 violation or encoding error.....	325
5.7.3	Field set to a not comprehended value.....	325
5.7.4	Mandatory field missing	326
5.7.5	Not comprehended field.....	327
5.8	MBMS.....	327
5.8.1	Introduction.....	327
5.8.1.1	General	327
5.8.1.2	Scheduling.....	327
5.8.1.3	MCCH information validity and notification of changes.....	328
5.8.2	MCCH information acquisition	329
5.8.2.1	General	329
5.8.2.2	Initiation.....	329
5.8.2.3	MCCH information acquisition by the UE.....	329
5.8.2.4	Actions upon reception of the <i>MBSFNAreaConfiguration</i> message	330
5.8.2.5	Actions upon reception of the <i>MBMSCountingRequest</i> message.....	330
5.8.3	MBMS PTM radio bearer configuration.....	330
5.8.3.1	General	330
5.8.3.2	Initiation.....	330
5.8.3.3	MRB establishment	330
5.8.3.4	MRB release.....	330
5.8.4	MBMS Counting Procedure	330
5.8.4.1	General	330
5.8.4.2	Initiation.....	331
5.8.4.3	Reception of the <i>MBMSCountingRequest</i> message by the UE	331
5.8.5	MBMS interest indication.....	332

5.8.5.1	General	332
5.8.5.2	Initiation	332
5.8.5.3	Determine MBMS frequencies of interest	333
5.8.5.3a	Determine MBMS services of interest	334
5.8.5.4	Actions related to transmission of <i>MBMSInterestIndication</i> message	334
5.8a	SC-PTM	335
5.8a.1	Introduction	335
5.8a.1.1	General	335
5.8a.1.2	SC-MCCH scheduling	335
5.8a.1.3	SC-MCCH information validity and notification of changes	335
5.8a.1.4	Procedures	336
5.8a.2	SC-MCCH information acquisition	336
5.8a.2.1	General	336
5.8a.2.2	Initiation	336
5.8a.2.3	SC-MCCH information acquisition by the UE	336
5.8a.2.4	Actions upon reception of the <i>SCPTMConfiguration</i> message	337
5.8a.3	SC-PTM radio bearer configuration	337
5.8a.3.1	General	337
5.8a.3.2	Initiation	337
5.8a.3.3	SC-MRB establishment	337
5.8a.3.4	SC-MRB release	338
5.9	RN procedures	338
5.9.1	RN reconfiguration	338
5.9.1.1	General	338
5.9.1.2	Initiation	338
5.9.1.3	Reception of the <i>RNReconfiguration</i> by the RN	338
5.10	Sidelink	339
5.10.1	Introduction	339
5.10.1a	Conditions for sidelink communication operation	339
5.10.1b	Conditions for PS related sidelink discovery operation	340
5.10.1c	Conditions for non-PS related sidelink discovery operation	340
5.10.1d	Conditions for V2X sidelink communication operation	340
5.10.2	Sidelink UE information	340
5.10.2.1	General	340
5.10.2.2	Initiation	341
5.10.2.3	Actions related to transmission of <i>SidelinkUEInformation</i> message	346
5.10.3	Sidelink communication monitoring	348
5.10.4	Sidelink communication transmission	350
5.10.5	Sidelink discovery monitoring	351
5.10.6	Sidelink discovery announcement	352
5.10.6a	Sidelink discovery announcement pool selection	355
5.10.6b	Sidelink discovery announcement reference carrier selection	355
5.10.7	Sidelink synchronisation information transmission	356
5.10.7.1	General	356
5.10.7.2	Initiation	357
5.10.7.3	Transmission of SLSS	359
5.10.7.4	Transmission of <i>MasterInformationBlock-SL</i> or <i>MasterInformationBlock-SL-V2X</i> message	361
5.10.7.5	Void	362
5.10.8	Sidelink synchronisation reference	362
5.10.8.1	General	362
5.10.8.2	Selection and reselection of synchronisation reference	362
5.10.8a	Selection and reselection of synchronisation carrier frequency	365
5.10.9	Sidelink common control information	368
5.10.9.1	General	368
5.10.9.2	Actions related to reception of <i>MasterInformationBlock-SL/ MasterInformationBlock-SL-V2X</i> message	368
5.10.10	Sidelink relay UE operation	368
5.10.10.1	General	368
5.10.10.2	AS-conditions for relay related sidelink communication transmission by sidelink relay UE	369
5.10.10.3	AS-conditions for relay PS related sidelink discovery transmission by sidelink relay UE	369
5.10.10.4	Sidelink relay UE threshold conditions	369
5.10.11	Sidelink remote UE operation	369

5.10.11.1	General	369
5.10.11.2	AS-conditions for relay related sidelink communication transmission by sidelink remote UE	370
5.10.11.3	AS-conditions for relay PS related sidelink discovery transmission by sidelink remote UE	370
5.10.11.4	Selection and reselection of sidelink relay UE	370
5.10.11.5	Sidelink remote UE threshold conditions	371
5.10.12	V2X sidelink communication monitoring	371
5.10.13	V2X sidelink communication transmission	372
5.10.13.1	Transmission of V2X sidelink communication	372
5.10.13.1a	Transmission of P2X related V2X sidelink communication	374
5.10.13.2	V2X sidelink communication transmission pool selection	375
5.10.13.3	V2X sidelink communication transmission reference cell selection	376
5.10.14	DFN derivation from GNSS	377
5.10.15	Void	377
5.10.16	Sidelink synchronisation information transmission for NR sidelink communication	377
6	Protocol data units, formats and parameters (tabular & ASN.1)	378
6.1	General	378
6.2	RRC messages	380
6.2.1	General message structure	380
-	<i>EUTRA-RRC-Definitions</i>	380
-	<i>BCCH-BCH-Message</i>	380
-	<i>BCCH-BCH-Message-MBMS</i>	380
-	<i>BCCH-DL-SCH-Message</i>	381
-	<i>BCCH-DL-SCH-Message-BR</i>	381
-	<i>BCCH-DL-SCH-Message-MBMS</i>	381
-	<i>MCCH-Message</i>	381
-	<i>PCCH-Message</i>	382
-	<i>DL-CCCH-Message</i>	382
-	<i>DL-DCCH-Message</i>	383
-	<i>UL-CCCH-Message</i>	383
-	<i>UL-DCCH-Message</i>	383
-	<i>SC-MCCH-Message</i>	384
6.2.2	Message definitions	385
-	<i>CounterCheck</i>	385
-	<i>CounterCheckResponse</i>	386
-	<i>CSFBParametersRequestCDMA2000</i>	387
-	<i>CSFBParametersResponseCDMA2000</i>	387
-	<i>DLDedicatedMessageSegment</i>	388
-	<i>DLInformationTransfer</i>	388
-	<i>FailureInformation</i>	389
-	<i>HandoverFromEUTRAPreparationRequest (CDMA2000)</i>	390
-	<i>InDeviceCoexIndication</i>	392
-	<i>InterFreqRSTDMeasurementIndication</i>	394
-	<i>LoggedMeasurementConfiguration</i>	396
-	<i>MasterInformationBlock</i>	398
-	<i>MasterInformationBlock-MBMS</i>	399
-	<i>MBMSCountingRequest</i>	400
-	<i>MBMSCountingResponse</i>	400
-	<i>MBMSInterestIndication</i>	401
-	<i>MBSFNAreaConfiguration</i>	402
-	<i>MCGFailureInformation</i>	403
-	<i>MeasReportAppLayer</i>	404
-	<i>MeasurementReport</i>	405
-	<i>MobilityFromEUTRACommand</i>	405
-	<i>Paging</i>	409
-	<i>ProximityIndication</i>	411
-	<i>PURConfigurationRequest</i>	412
-	<i>RNReconfiguration</i>	413
-	<i>RNReconfigurationComplete</i>	413
-	<i>RRCConnectionReconfiguration</i>	414
-	<i>RRCConnectionReconfigurationComplete</i>	424
-	<i>RRCConnectionReestablishment</i>	426

–	<i>RRConnectionReestablishmentComplete</i>	427
–	<i>RRConnectionReestablishmentReject</i>	428
–	<i>RRConnectionReestablishmentRequest</i>	428
–	<i>RRConnectionReject</i>	429
–	<i>RRConnectionRelease</i>	430
–	<i>RRConnectionRequest</i>	437
–	<i>RRConnectionResume</i>	438
–	<i>RRConnectionResumeComplete</i>	441
–	<i>RRConnectionResumeRequest</i>	442
–	<i>RRConnectionSetup</i>	443
–	<i>RRConnectionSetupComplete</i>	443
–	<i>RRCEarlyDataComplete</i>	447
–	<i>RRCEarlyDataRequest</i>	448
–	<i>SCGFailureInformation</i>	448
–	<i>SCGFailureInformationNR</i>	449
–	<i>SCPTMConfiguration</i>	451
–	<i>SCPTMConfiguration-BR</i>	451
–	<i>SecurityModeCommand</i>	452
–	<i>SecurityModeComplete</i>	453
–	<i>SecurityModeFailure</i>	453
–	<i>SidelinkUEInformation</i>	454
–	<i>SystemInformation</i>	457
–	<i>SystemInformationBlockType1</i>	459
–	<i>SystemInformationBlockType1-MBMS</i>	469
–	<i>UEAssistanceInformation</i>	471
–	<i>UECapabilityEnquiry</i>	475
–	<i>UECapabilityInformation</i>	477
–	<i>ULDedicatedMessageSegment</i>	478
–	<i>UEInformationRequest</i>	479
–	<i>UEInformationResponse</i>	480
–	<i>ULHandoverPreparationTransfer (CDMA2000)</i>	488
–	<i>ULInformationTransfer</i>	489
–	<i>ULInformationTransferIRAT</i>	489
–	<i>ULInformationTransferMRDC</i>	490
–	<i>WLANConnectionStatusReport</i>	491
6.3	RRC information elements	491
6.3.0	Parameterized types	491
–	<i>SetupRelease</i>	491
6.3.1	System information blocks	492
–	<i>SystemInformationBlockPos</i>	492
–	<i>SystemInformationBlockType2</i>	492
–	<i>SystemInformationBlockType3</i>	498
–	<i>SystemInformationBlockType4</i>	503
–	<i>SystemInformationBlockType5</i>	504
–	<i>SystemInformationBlockType6</i>	511
–	<i>SystemInformationBlockType7</i>	513
–	<i>SystemInformationBlockType8</i>	514
–	<i>SystemInformationBlockType9</i>	519
–	<i>SystemInformationBlockType10</i>	519
–	<i>SystemInformationBlockType11</i>	519
–	<i>SystemInformationBlockType12</i>	520
–	<i>SystemInformationBlockType13</i>	521
–	<i>SystemInformationBlockType14</i>	522
–	<i>SystemInformationBlockType15</i>	522
–	<i>SystemInformationBlockType16</i>	524
–	<i>SystemInformationBlockType17</i>	524
–	<i>SystemInformationBlockType18</i>	525
–	<i>SystemInformationBlockType19</i>	526
–	<i>SystemInformationBlockType20</i>	529
–	<i>SystemInformationBlockType21</i>	532
–	<i>SystemInformationBlockType24</i>	533
–	<i>SystemInformationBlockType25</i>	537

–	<i>SystemInformationBlockType26</i>	539
–	<i>SystemInformationBlockType26a</i>	540
–	<i>SystemInformationBlockType27</i>	541
–	<i>SystemInformationBlockType28</i>	541
–	<i>SystemInformationBlockType29</i>	542
–	<i>SystemInformationBlockType30</i>	542
–	<i>SystemInformationBlockType31</i>	543
–	<i>SystemInformationBlockType32</i>	544
–	<i>SystemInformationBlockType33</i>	546
6.3.2	Radio resource control information elements	547
–	<i>Alpha</i>	547
–	<i>AntennaInfo</i>	548
–	<i>AntennaInfoUL</i>	551
–	<i>AUL-Config</i>	551
–	<i>CQI-ReportAperiodic</i>	552
–	<i>CQI-ReportBoth</i>	556
–	<i>CQI-ReportConfig</i>	557
–	<i>CQI-ReportPeriodic</i>	560
–	<i>CQI-ReportPeriodicProcExtId</i>	564
–	<i>CrossCarrierSchedulingConfig</i>	564
–	<i>CRS-ChEstMPDCCH-Config</i>	565
–	<i>CSI-IM-Config</i>	566
–	<i>CSI-IM-ConfigId</i>	566
–	<i>CSI-Process</i>	567
–	<i>CSI-ProcessId</i>	568
–	<i>CSI-RS-Config</i>	569
–	<i>CSI-RS-ConfigBeamformed</i>	570
–	<i>CSI-RS-ConfigEMIMO</i>	571
–	<i>CSI-RS-ConfigNonPrecoded</i>	572
–	<i>CSI-RS-ConfigNZP</i>	573
–	<i>CSI-RS-ConfigNZPId</i>	575
–	<i>CSI-RS-ConfigZP</i>	575
–	<i>CSI-RS-ConfigZPId</i>	575
–	<i>DataInactivityTimer</i>	576
–	<i>DMRS-Config</i>	576
–	<i>DRB-Identity</i>	576
–	<i>EPDCCH-Config</i>	576
–	<i>EIMTA-MainConfig</i>	579
–	<i>GWUS-Config</i>	579
–	<i>LogicalChannelConfig</i>	581
–	<i>LWA-Configuration</i>	583
–	<i>LWIP-Configuration</i>	584
–	<i>MAC-MainConfig</i>	584
–	<i>P-C-AndCBSR</i>	591
–	<i>PDCCH-ConfigSCell</i>	592
–	<i>PDCP-Config</i>	593
–	<i>PDSCH-Config</i>	598
–	<i>PDSCH-RE-MappingQCL-ConfigId</i>	602
–	<i>PerCC-GapIndicationList</i>	603
–	<i>PHICH-Config</i>	603
–	<i>PhysicalConfigDedicated</i>	603
–	<i>P-Max</i>	616
–	<i>PRACH-Config</i>	616
–	<i>PresenceAntennaPort1</i>	619
–	<i>PUCCH-Config</i>	619
–	<i>PUR-Config</i>	624
–	<i>PUR-ConfigID</i>	628
–	<i>PUR-PeriodicityAndOffset</i>	628
–	<i>PUSCH-Config</i>	628
–	<i>RACH-ConfigCommon</i>	634
–	<i>RACH-ConfigDedicated</i>	638
–	<i>RadioResourceConfigCommon</i>	638