

# ETSI TS 138 331 V18.9.0 (2026-04)



TECHNICAL SPECIFICATION

**5G;  
NR;  
Radio Resource Control (RRC);  
Protocol specification  
(3GPP TS 38.331 version 18.9.0 Release 18)**



---

**Reference**

RTS/TSGR-0238331 vi90

---

**Keywords**

5G

**ETSI**

650 Route des Lucioles  
F-06921 Sophia Antipolis Cedex - FRANCE

---

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - APE 7112B  
Association à but non lucratif enregistrée à la  
Sous-Préfecture de Grasse (06) N° w061004871

---

**Important notice**

The present document can be downloaded from the  
[ETSI Search & Browse Standards](#) application.

The present document may be made available in electronic versions and/or in print. The content of any electronic and/or print versions of the present document shall not be modified without the prior written authorization of ETSI. In case of any existing or perceived difference in contents between such versions and/or in print, the prevailing version of an ETSI deliverable is the one made publicly available in PDF format on [ETSI deliver](#) repository.

Users should be aware that the present document may be revised or have its status changed, this information is available in the [Milestones listing](#).

If you find errors in the present document, please send your comments to the relevant service listed under [Committee Support Staff](#).

If you find a security vulnerability in the present document, please report it through our [Coordinated Vulnerability Disclosure \(CVD\)](#) program.

---

**Notice of disclaimer & limitation of liability**

The information provided in the present deliverable is directed solely to professionals who have the appropriate degree of experience to understand and interpret its content in accordance with generally accepted engineering or other professional standard and applicable regulations.

No recommendation as to products and services or vendors is made or should be implied.

No representation or warranty is made that this deliverable is technically accurate or sufficient or conforms to any law and/or governmental rule and/or regulation and further, no representation or warranty is made of merchantability or fitness for any particular purpose or against infringement of intellectual property rights.

In no event shall ETSI be held liable for loss of profits or any other incidental or consequential damages.

Any software contained in this deliverable is provided "AS IS" with no warranties, express or implied, including but not limited to, the warranties of merchantability, fitness for a particular purpose and non-infringement of intellectual property rights and ETSI shall not be held liable in any event for any damages whatsoever (including, without limitation, damages for loss of profits, business interruption, loss of information, or any other pecuniary loss) arising out of or related to the use of or inability to use the software.

---

**Copyright Notification**

No part may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm except as authorized by written permission of ETSI.

The content of the PDF version shall not be modified without the written authorization of ETSI.

The copyright and the foregoing restriction extend to reproduction in all media.

© ETSI 2026.  
All rights reserved.

---

# Intellectual Property Rights

## Essential patents

IPRs essential or potentially essential to normative deliverables may have been declared to ETSI. The declarations pertaining to these essential IPRs, if any, are publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "*Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards*", which is available from the ETSI Secretariat. Latest updates are available on the [ETSI IPR online database](#).

Pursuant to the ETSI Directives including the ETSI IPR Policy, no investigation regarding the essentiality of IPRs, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

## Trademarks

The present document may include trademarks and/or tradenames which are asserted and/or registered by their owners. ETSI claims no ownership of these except for any which are indicated as being the property of ETSI, and conveys no right to use or reproduce any trademark and/or tradename. Mention of those trademarks in the present document does not constitute an endorsement by ETSI of products, services or organizations associated with those trademarks.

**DECT™**, **PLUGTESTS™**, **UMTS™** and the ETSI logo are trademarks of ETSI registered for the benefit of its Members. **3GPP™**, **LTE™** and **5G™** logo are trademarks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **oneM2M™** logo is a trademark of ETSI registered for the benefit of its Members and of the oneM2M Partners. **GSM®** and the GSM logo are trademarks registered and owned by the GSM Association.

---

# Legal Notice

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities. These shall be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between 3GPP and ETSI identities can be found at [3GPP to ETSI numbering cross-referencing](#).

---

# Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the [ETSI Drafting Rules](#) (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in ETSI deliverables except when used in direct citation.

# Contents

Intellectual Property Rights .....	2
Legal Notice .....	2
Modal verbs terminology.....	2
Foreword.....	28
1 Scope .....	29
2 References .....	29
3 Definitions, symbols and abbreviations .....	32
3.1 Definitions .....	32
3.2 Abbreviations .....	35
4 General .....	38
4.1 Introduction .....	38
4.2 Architecture .....	39
4.2.1 UE states and state transitions including inter RAT .....	39
4.2.2 Signalling radio bearers .....	42
4.3 Services .....	43
4.3.1 Services provided to upper layers .....	43
4.3.2 Services expected from lower layers .....	43
4.4 Functions .....	43
5 Procedures .....	44
5.1 General .....	44
5.1.1 Introduction.....	44
5.1.2 General requirements.....	44
5.1.3 Requirements for UE in MR-DC .....	45
5.2 System information .....	45
5.2.1 Introduction.....	45
5.2.2 System information acquisition .....	47
5.2.2.1 General UE requirements .....	47
5.2.2.2 SIB validity and need to (re)-acquire SIB .....	47
5.2.2.2.1 SIB validity.....	47
5.2.2.2.2 SI change indication and PWS notification .....	49
5.2.2.3 Acquisition of System Information.....	50
5.2.2.3.1 Acquisition of <i>MIB</i> and <i>SIB1</i> .....	50
5.2.2.3.2 Acquisition of an SI message .....	51
5.2.2.3.3 Request for on demand system information .....	53
5.2.2.3.3a Request for on demand positioning system information .....	55
5.2.2.3.4 Actions related to transmission of <i>RRCSystemInfoRequest</i> message .....	57
5.2.2.3.5 Acquisition of SIB(s) or posSIB(s) in RRC_CONNECTED .....	57
5.2.2.3.6 Actions related to transmission of <i>DedicatedSIBRequest</i> message .....	58
5.2.2.4 Actions upon receipt of System Information .....	58
5.2.2.4.1 Actions upon reception of the <i>MIB</i> .....	58
5.2.2.4.2 Actions upon reception of the <i>SIB1</i> .....	59
5.2.2.4.3 Actions upon reception of <i>SIB2</i> .....	66
5.2.2.4.4 Actions upon reception of <i>SIB3</i> .....	67
5.2.2.4.5 Actions upon reception of <i>SIB4</i> .....	67
5.2.2.4.6 Actions upon reception of <i>SIB5</i> .....	68
5.2.2.4.7 Actions upon reception of <i>SIB6</i> .....	68
5.2.2.4.8 Actions upon reception of <i>SIB7</i> .....	68
5.2.2.4.9 Actions upon reception of <i>SIB8</i> .....	69
5.2.2.4.10 Actions upon reception of <i>SIB9</i> .....	70
5.2.2.4.11 Actions upon reception of <i>SIB10</i> .....	70
5.2.2.4.12 Actions upon reception of <i>SIB11</i> .....	70
5.2.2.4.13 Actions upon reception of <i>SIB12</i> .....	71
5.2.2.4.14 Actions upon reception of <i>SIB13</i> .....	72

5.2.2.4.15	Actions upon reception of <i>SIB14</i> .....	72
5.2.2.4.16	Actions upon reception of <i>SIBpos</i> .....	72
5.2.2.4.17	Actions upon reception of <i>SIB15</i> .....	73
5.2.2.4.18	Actions upon reception of <i>SIB16</i> .....	73
5.2.2.4.19	Actions upon reception of <i>SIB17</i> .....	73
5.2.2.4.19a	Actions upon reception of <i>SIB17bis</i> .....	73
5.2.2.4.20	Actions upon reception of <i>SIB18</i> .....	73
5.2.2.4.21	Actions upon reception of <i>SIB19</i> .....	73
5.2.2.4.22	Actions upon reception of <i>SIB20</i> .....	74
5.2.2.4.23	Actions upon reception of <i>SIB21</i> .....	74
5.2.2.4.24	Actions upon reception of <i>SIB22</i> .....	74
5.2.2.4.25	Actions upon reception of <i>SIB23</i> .....	74
5.2.2.4.26	Actions upon reception of <i>SIB24</i> .....	74
5.2.2.4.27	Actions upon reception of <i>SIB25</i> .....	74
5.2.2.5	Essential system information missing .....	75
5.2.2.6	T430 expiry .....	75
5.3	Connection control .....	75
5.3.1	Introduction .....	75
5.3.1.1	RRC connection control .....	75
5.3.1.2	AS Security .....	76
5.3.2	Paging .....	77
5.3.2.1	General .....	77
5.3.2.2	Initiation .....	77
5.3.2.3	Reception of the <i>Paging message</i> by the UE or <i>PagingRecord</i> by the L2 U2N Remote UE .....	78
5.3.3	RRC connection establishment .....	80
5.3.3.1	General .....	80
5.3.3.1a	Conditions for establishing RRC Connection for NR sidelink communication/discovery/V2X sidelink communication/MP operation .....	81
5.3.3.1b	Void .....	82
5.3.3.2	Initiation .....	82
5.3.3.3	Actions related to transmission of <i>RRCSetupRequest</i> message .....	82
5.3.3.4	Reception of the <i>RRCSetup</i> by the UE .....	83
5.3.3.5	Reception of the <i>RRCReject</i> by the UE .....	88
5.3.3.6	Cell re-selection or cell selection or relay (re)selection while T390, T300 or T302 is running (UE in RRC_IDLE) .....	88
5.3.3.7	T300 expiry .....	89
5.3.3.8	Abortion of RRC connection establishment .....	91
5.3.4	Initial AS security activation .....	91
5.3.4.1	General .....	91
5.3.4.2	Initiation .....	91
5.3.4.3	Reception of the <i>SecurityModeCommand</i> by the UE .....	92
5.3.5	RRC reconfiguration .....	92
5.3.5.1	General .....	92
5.3.5.2	Initiation .....	94
5.3.5.3	Reception of an <i>RRCReconfiguration</i> by the UE .....	94
5.3.5.4	Secondary cell group release .....	111
5.3.5.5	Cell Group configuration .....	112
5.3.5.5.1	General .....	112
5.3.5.5.2	Reconfiguration with sync .....	113
5.3.5.5.3	RLC bearer release .....	116
5.3.5.5.4	RLC bearer addition/modification .....	116
5.3.5.5.5	MAC entity configuration .....	117
5.3.5.5.6	RLF Timers & Constants configuration .....	118
5.3.5.5.7	SpCell Configuration .....	118
5.3.5.5.8	SCell Release .....	119
5.3.5.5.9	SCell Addition/Modification .....	119
5.3.5.5.10	BH RLC channel release .....	120
5.3.5.5.11	BH RLC channel addition/modification .....	120
5.3.5.5.12	Uu Relay RLC channel release .....	121
5.3.5.5.13	Uu Relay RLC channel addition/modification .....	121
5.3.5.5.14	NCR-Fwd configuration .....	121
5.3.5.6	Radio Bearer configuration .....	122

5.3.5.6.1	General .....	122
5.3.5.6.2	SRB release .....	122
5.3.5.6.3	SRB addition/modification .....	122
5.3.5.6.4	DRB release.....	124
5.3.5.6.5	DRB addition/modification .....	125
5.3.5.6.6	Multicast MRB release .....	128
5.3.5.6.7	Multicast MRB addition/modification.....	128
5.3.5.7	AS Security key update.....	129
5.3.5.8	Reconfiguration failure .....	130
5.3.5.8.1	Void.....	130
5.3.5.8.2	Inability to comply with <i>RRCReconfiguration</i> .....	130
5.3.5.8.3	T304 expiry (Reconfiguration with sync Failure) or T420 expiry (Path switch failure) .....	132
5.3.5.9	Other configuration .....	134
5.3.5.9a	MUSIM gap configuration .....	139
5.3.5.10	MR-DC release .....	140
5.3.5.11	Full configuration.....	140
5.3.5.12	BAP configuration .....	143
5.3.5.12a	IAB Other Configuration .....	143
5.3.5.12a.1	IP address management .....	143
5.3.5.12a.1.1	IP Address Release .....	143
5.3.5.12a.1.2	IP Address Addition/Modification .....	143
5.3.5.13	Conditional Reconfiguration .....	145
5.3.5.13.1	General .....	145
5.3.5.13.2	Conditional reconfiguration removal.....	146
5.3.5.13.3	Conditional reconfiguration addition/modification .....	146
5.3.5.13.4	Conditional reconfiguration evaluation .....	147
5.3.5.13.4a	Conditional reconfiguration evaluation of SN initiated inter-SN CPC for EN-DC.....	150
5.3.5.13.5	Conditional reconfiguration execution .....	150
5.3.5.13.6	Subsequent CPAC reference configuration addition/removal .....	151
5.3.5.13.7	sk-Counter configuration addition/modification/removal .....	151
5.3.5.13.8	Subsequent CPAC execution.....	151
5.3.5.13a	SCG activation .....	154
5.3.5.13b	SCG deactivation .....	155
5.3.5.13b1	SCG activation without SN message .....	155
5.3.5.13c	FR2 UL gap configuration .....	156
5.3.5.13d	Application layer measurement configuration .....	156
5.3.5.14	Sidelink dedicated configuration.....	158
5.3.5.15	L2 U2N or U2U Relay UE configuration .....	160
5.3.5.15.1	General .....	160
5.3.5.15.2	L2 U2N or U2U Remote UE Release.....	161
5.3.5.15.3	L2 U2N or U2U Remote UE Addition/Modification .....	161
5.3.5.16	L2 U2N or U2U Remote UE configuration .....	162
5.3.5.16.1	L2 U2U Relay UE Release.....	163
5.3.5.16.2	L2 U2U Relay UE Addition/Modification .....	163
5.3.5.17	MP configuration .....	164
5.3.5.17.1	Introduction .....	164
5.3.5.17.2	Configuration of SL indirect path.....	164
5.3.5.17.2.1	General.....	164
5.3.5.17.2.2	SL indirect path specific configuration .....	164
5.3.5.17.2.3	T421 expiry (Indirect path addition/change failure) .....	164
5.3.5.17.3	Configuration of N3C indirect path.....	165
5.3.5.17.3.1	General.....	165
5.3.5.17.3.2	N3C remote UE configuration .....	165
5.3.5.17.3.2a	N3C Indirect path addition/change failure .....	165
5.3.5.17.3.3	N3C relay UE configuration .....	166
5.3.5.17.3.4	Bearer mapping management on N3C indirect path .....	166
5.3.5.17.3.4.1	Bearer mapping release .....	166
5.3.5.17.3.4.2	Bearer mapping addition and modification .....	166
5.3.5.18	LTM configuration and execution.....	166
5.3.5.18.1	LTM configuration .....	166
5.3.5.18.2	LTM candidate configuration release.....	167
5.3.5.18.3	LTM candidate configuration addition/modification.....	167

5.3.5.18.4	Void .....	168
5.3.5.18.5	Void .....	168
5.3.5.18.6	LTM cell switch execution .....	168
5.3.5.18.7	LTM configuration release .....	171
5.3.5.19	T348 expiry .....	171
5.3.6	Counter check .....	171
5.3.6.1	General .....	171
5.3.6.2	Initiation .....	172
5.3.6.3	Reception of the <i>CounterCheck</i> message by the UE .....	172
5.3.7	RRC connection re-establishment .....	172
5.3.7.1	General .....	172
5.3.7.2	Initiation .....	173
5.3.7.3	Actions following cell selection while T311 is running .....	177
5.3.7.3a	Actions following relay selection while T311 is running .....	180
5.3.7.4	Actions related to transmission of <i>RRCReestablishmentRequest</i> message .....	180
5.3.7.5	Reception of the <i>RRCReestablishment</i> by the UE .....	181
5.3.7.6	T311 expiry .....	184
5.3.7.7	T301 expiry or selected cell/L2 U2N Relay UE no longer suitable .....	184
5.3.7.8	Reception of the <i>RRCSetup</i> by the UE .....	184
5.3.8	RRC connection release .....	185
5.3.8.1	General .....	185
5.3.8.2	Initiation .....	185
5.3.8.3	Reception of the <i>RRCRelease</i> by the UE .....	185
5.3.8.4	T320 expiry .....	191
5.3.8.5	UE actions upon the expiry of <i>DataInactivityTimer</i> .....	191
5.3.8.6	T346g expiry .....	191
5.3.9	RRC connection release requested by upper layers .....	191
5.3.9.1	General .....	191
5.3.9.2	Initiation .....	191
5.3.10	Radio link failure related actions .....	191
5.3.10.1	Detection of physical layer problems in RRC_CONNECTED .....	191
5.3.10.2	Recovery of physical layer problems .....	192
5.3.10.3	Detection of radio link failure .....	192
5.3.10.4	RLF cause determination .....	195
5.3.10.5	RLF report content determination .....	195
5.3.11	UE actions upon going to RRC_IDLE .....	200
5.3.12	UE actions upon PUCCH/SRS release request .....	202
5.3.13	RRC connection resume .....	202
5.3.13.1	General .....	202
5.3.13.1a	Conditions for resuming RRC Connection for NR sidelink communication/positioning/discovery/V2X sidelink communication .....	203
5.3.13.1b	Conditions for initiating SDT .....	204
5.3.13.1c	Void .....	205
5.3.13.1d	Conditions for resuming RRC connection for multicast reception .....	205
5.3.13.2	Initiation .....	205
5.3.13.3	Actions related to transmission of <i>RRCResumeRequest</i> or <i>RRCResumeRequest1</i> message .....	210
5.3.13.4	Reception of the <i>RRCResume</i> by the UE .....	211
5.3.13.5	Handling of failure to resume RRC Connection .....	219
5.3.13.6	Cell re-selection or cell selection or L2 U2N relay (re)selection while T390, T319 or T302 is running or SDT procedure is ongoing (UE in RRC_INACTIVE) or SRS transmission in RRC_INACTIVE is configured .....	221
5.3.13.7	Reception of the <i>RRCSetup</i> by the UE .....	222
5.3.13.8	RNA update .....	222
5.3.13.9	Reception of the <i>RRCRelease</i> by the UE .....	222
5.3.13.10	Reception of the <i>RRCReject</i> by the UE .....	222
5.3.13.11	Inability to comply with <i>RRCResume</i> .....	223
5.3.13.12	Inter RAT cell reselection .....	223
5.3.14	Unified Access Control .....	223
5.3.14.1	General .....	223
5.3.14.2	Initiation .....	223
5.3.14.3	Void .....	225
5.3.14.4	T302, T390 expiry or stop (Barring alleviation) .....	225

5.3.14.5	Access barring check.....	226
5.3.15	RRC connection reject.....	227
5.3.15.1	Initiation.....	227
5.3.15.2	Reception of the <i>RRCReject</i> by the UE.....	227
5.4	Inter-RAT mobility.....	228
5.4.1	Introduction.....	228
5.4.2	Handover to NR.....	228
5.4.2.1	General.....	228
5.4.2.2	Initiation.....	228
5.4.2.3	Reception of the <i>RRCReconfiguration</i> by the UE.....	228
5.4.3	Mobility from NR.....	229
5.4.3.1	General.....	229
5.4.3.2	Initiation.....	229
5.4.3.3	Reception of the <i>MobilityFromNRCommand</i> by the UE.....	229
5.4.3.4	Successful completion of the mobility from NR.....	230
5.4.3.5	Mobility from NR failure.....	231
5.5	Measurements.....	232
5.5.1	Introduction.....	232
5.5.2	Measurement configuration.....	234
5.5.2.1	General.....	234
5.5.2.2	Measurement identity removal.....	236
5.5.2.3	Measurement identity addition/modification.....	236
5.5.2.4	Measurement object removal.....	238
5.5.2.5	Measurement object addition/modification.....	238
5.5.2.6	Reporting configuration removal.....	240
5.5.2.7	Reporting configuration addition/modification.....	240
5.5.2.8	Quantity configuration.....	241
5.5.2.9	Measurement gap configuration.....	241
5.5.2.10	Reference signal measurement timing configuration.....	243
5.5.2.10a	RSSI measurement timing configuration.....	244
5.5.2.11	Measurement gap sharing configuration.....	244
5.5.2.12	Effective measurement window configuration.....	245
5.5.3	Performing measurements.....	245
5.5.3.1	General.....	245
5.5.3.2	Layer 3 filtering.....	251
5.5.3.3	Derivation of cell measurement results.....	252
5.5.3.3a	Derivation of layer 3 beam filtered measurement.....	253
5.5.3.4	Derivation of L2 U2N Relay UE measurement results.....	253
5.5.4	Measurement report triggering.....	253
5.5.4.1	General.....	253
5.5.4.2	Event A1 (Serving becomes better than threshold).....	261
5.5.4.3	Event A2 (Serving becomes worse than threshold).....	262
5.5.4.4	Event A3 (Neighbour becomes offset better than SpCell).....	262
5.5.4.5	Event A4 (Neighbour becomes better than threshold).....	263
5.5.4.6	Event A5 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2).....	264
5.5.4.7	Event A6 (Neighbour becomes offset better than SCell).....	265
5.5.4.8	Event B1 (Inter RAT neighbour becomes better than threshold).....	265
5.5.4.9	Event B2 (PCell becomes worse than threshold1 and inter RAT neighbour becomes better than threshold2).....	266
5.5.4.10	Event I1 (Interference becomes higher than threshold).....	267
5.5.4.11	Event C1 (The NR sidelink channel busy ratio is above a threshold).....	267
5.5.4.12	Event C2 (The NR sidelink channel busy ratio is below a threshold).....	268
5.5.4.13	Void.....	268
5.5.4.14	Void.....	268
5.5.4.15	Event D1 (Distance between UE and referenceLocation1 is above threshold1 and distance between UE and referenceLocation2 is below threshold2).....	268
5.5.4.15a	Event D2 (Distance between UE and the serving cell moving reference location is above threshold1 and distance between UE and a moving reference location is below threshold2).....	269
5.5.4.16	CondEvent T1 (Time measured at UE is within a duration from threshold).....	270
5.5.4.17	Event X1 (Serving L2 U2N Relay UE becomes worse than threshold1 and NR Cell becomes better than threshold2).....	271

5.5.4.18	Event X2 (Serving L2 U2N Relay UE becomes worse than threshold).....	272
5.5.4.19	Event Y1 (PCell becomes worse than threshold1 and candidate L2 U2N Relay UE becomes better than threshold2).....	272
5.5.4.20	Event Y2 (Candidate L2 U2N Relay UE becomes better than threshold) .....	273
5.5.4.20b	Event Z1 (Serving L2 U2N Relay UE becomes worse than threshold1 and Candidate L2 U2N Relay UE becomes better than threshold2) .....	273
5.5.4.21	Event H1 (The Aerial UE altitude becomes higher than a threshold) .....	274
5.5.4.22	Event H2 (The Aerial UE altitude becomes lower than a threshold) .....	274
5.5.4.23	Event A3H1 (Neighbour becomes offset better than SpCell and the Aerial UE altitude becomes higher than a threshold).....	275
5.5.4.24	Event A3H2 (Neighbour becomes offset better than SpCell and the Aerial UE altitude becomes lower than a threshold).....	276
5.5.4.25	Event A4H1 (Neighbour becomes better than threshold1 and the Aerial UE altitude becomes higher than a threshold2).....	277
5.5.4.26	Event A4H2 (Neighbour becomes better than threshold1 and the Aerial UE altitude becomes lower than a threshold2).....	278
5.5.4.27	Event A5H1 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2 and the Aerial UE altitude becomes higher than a threshold3) .....	279
5.5.4.28	Event A5H2 (SpCell becomes worse than threshold1 and neighbour becomes better than threshold2 and the Aerial UE altitude becomes lower than a threshold3).....	280
5.5.5	Measurement reporting .....	281
5.5.5.1	General .....	281
5.5.5.2	Reporting of beam measurement information .....	291
5.5.5.3	Sorting of cell measurement results .....	291
5.5.6	Location measurement indication .....	292
5.5.6.1	General .....	292
5.5.6.2	Initiation.....	292
5.5.6.3	Actions related to transmission of <i>LocationMeasurementIndication</i> message .....	293
5.5a	Logged Measurements .....	294
5.5a.1	Logged Measurement Configuration .....	294
5.5a.1.1	General .....	294
5.5a.1.2	Initiation.....	294
5.5a.1.3	Reception of the <i>LoggedMeasurementConfiguration</i> by the UE .....	294
5.5a.1.4	T330 expiry .....	295
5.5a.2	Release of Logged Measurement Configuration.....	295
5.5a.2.1	General .....	295
5.5a.2.2	Initiation.....	295
5.5a.3	Measurements logging.....	295
5.5a.3.1	General .....	295
5.5a.3.2	Initiation.....	295
5.5b	Application Layer Measurements in RRC_IDLE/RRC_INACTIVE.....	299
5.5b.1	Handling of Application Layer Measurements in RRC_IDLE/RRC_INACTIVE .....	299
5.5b.1.1	General .....	299
5.5b.1.2	Initiation.....	299
5.6	UE capabilities .....	300
5.6.1	UE capability transfer .....	300
5.6.1.1	General .....	300
5.6.1.2	Initiation.....	300
5.6.1.3	Reception of the <i>UECapabilityEnquiry</i> by the UE .....	300
5.6.1.4	Setting band combinations, feature set combinations and feature sets supported by the UE.....	301
5.6.1.5	Void.....	304
5.7	Other.....	304
5.7.1	DL information transfer .....	304
5.7.1.1	General .....	304
5.7.1.2	Initiation.....	304
5.7.1.3	Reception of the <i>DLInformationTransfer</i> by the UE .....	305
5.7.1a	DL information transfer for MR-DC .....	306
5.7.1a.1	General .....	306
5.7.1a.2	Initiation.....	306
5.7.1a.3	Actions related to reception of <i>DLInformationTransferMRDC</i> message.....	306
5.7.2	UL information transfer .....	307
5.7.2.1	General .....	307

5.7.2.2	Initiation.....	307
5.7.2.3	Actions related to transmission of <i>ULInformationTransfer</i> message.....	307
5.7.2.4	Failure to deliver <i>ULInformationTransfer</i> message.....	307
5.7.2a	UL information transfer for MR-DC.....	308
5.7.2a.1	General.....	308
5.7.2a.2	Initiation.....	308
5.7.2a.3	Actions related to transmission of <i>ULInformationTransferMRDC</i> message.....	308
5.7.2b	UL transfer of IRAT information.....	308
5.7.2b.1	General.....	308
5.7.2b.2	Initiation.....	309
5.7.2b.3	Actions related to transmission of <i>ULInformationTransferIRAT</i> message.....	309
5.7.3	SCG failure information.....	309
5.7.3.1	General.....	309
5.7.3.2	Initiation.....	309
5.7.3.3	Failure type determination for (NG)EN-DC.....	310
5.7.3.4	Setting the contents of <i>MeasResultSCG-Failure</i> .....	311
5.7.3.5	Actions related to transmission of <i>SCGFailureInformation</i> message.....	312
5.7.3a	EUTRA SCG failure information.....	315
5.7.3a.1	General.....	315
5.7.3a.2	Initiation.....	315
5.7.3a.3	Actions related to transmission of <i>SCGFailureInformationEUTRA</i> message.....	315
5.7.3b	MCG failure information.....	316
5.7.3b.1	General.....	316
5.7.3b.2	Initiation.....	316
5.7.3b.3	Failure type determination.....	316
5.7.3b.4	Actions related to transmission of <i>MCGFailureInformation</i> message.....	317
5.7.3b.5	T316 expiry.....	318
5.7.3c	Indirect path failure information.....	319
5.7.3c.1	General.....	319
5.7.3c.2	Initiation.....	319
5.7.3c.3	Failure type determination.....	319
5.7.3c.4	Actions related to transmission of <i>IndirectPathFailureInformation</i> message.....	320
5.7.4	UE Assistance Information.....	321
5.7.4.1	General.....	321
5.7.4.2	Initiation.....	322
5.7.4.3	Actions related to transmission of <i>UEAssistanceInformation</i> message.....	331
5.7.4.3a	Setting the contents of <i>OverheatingAssistance</i> IE.....	343
5.7.4.4	Relaxed measurement criterion for a stationary (e)RedCap UE.....	344
5.7.4a	Void.....	344
5.7.5	Failure information.....	344
5.7.5.1	General.....	344
5.7.5.2	Initiation.....	344
5.7.5.3	Actions related to transmission of <i>FailureInformation</i> message.....	345
5.7.6	DL message segment transfer.....	345
5.7.6.1	General.....	345
5.7.6.2	Initiation.....	346
5.7.6.3	Reception of <i>DLDedicatedMessageSegment</i> by the UE.....	346
5.7.7	UL message segment transfer.....	346
5.7.7.1	General.....	346
5.7.7.2	Initiation.....	346
5.7.7.3	Actions related to transmission of <i>ULDedicatedMessageSegment</i> message.....	346
5.7.8	Idle/inactive Measurements.....	347
5.7.8.1	General.....	347
5.7.8.1a	Measurement configuration.....	347
5.7.8.1b	Measurement configuration (reselection measurements).....	348
5.7.8.2	Void.....	349
5.7.8.2a	Performing measurements.....	349
5.7.8.3	T331 expiry or stop.....	352
5.7.8.4	Cell re-selection or cell selection while T331 is running.....	352
5.7.9	Mobility history information.....	352
5.7.9.1	General.....	352
5.7.9.2	Initiation.....	352

5.7.9.3	Release of Mobility History Information .....	356
5.7.10	UE Information .....	356
5.7.10.1	General .....	356
5.7.10.2	Initiation .....	356
5.7.10.3	Reception of the <i>UEInformationRequest</i> message .....	356
5.7.10.4	Actions for the Random Access report determination .....	361
5.7.10.5	RA information determination .....	363
5.7.10.6	Actions for the successful handover report determination .....	367
5.7.10.7	Actions for the successful PSCell change or addition report determination .....	371
5.7.11	Void .....	374
5.7.12	IAB Other Information .....	374
5.7.12.1	General .....	374
5.7.12.2	Initiation .....	374
5.7.12.3	Actions related to transmission of <i>IABOtherInformation</i> message .....	374
5.7.13	RLM/BFD relaxation .....	376
5.7.13.0	General .....	376
5.7.13.1	Relaxed measurement criterion for low mobility .....	376
5.7.13.2	Relaxed measurement criterion for good serving cell quality .....	376
5.7.14	UE Positioning Assistance Information .....	377
5.7.14.1	General .....	377
5.7.14.2	Initiation .....	377
5.7.14.3	Actions related to transmission of <i>UEPositioningAssistanceInfo</i> message .....	377
5.7.15	Void .....	378
5.7.16	Application layer measurement reporting .....	378
5.7.16.1	General .....	378
5.7.16.2	Initiation .....	378
5.7.17	Derivation of pathloss reference for TA validation of SRS for Positioning transmission and CG-SDT in RRC_INACTIVE .....	380
5.7.18	Void .....	381
5.7.19	Satellite switch with resynchronization .....	381
5.7.20	Actions related to Transmission of SRS for Positioning in a validity area in RRC_INACTIVE .....	381
5.8	Sidelink .....	381
5.8.1	General .....	381
5.8.2	Conditions for NR sidelink communication/discovery/positioning operation .....	382
5.8.3	Sidelink UE information for NR sidelink communication/discovery/positioning .....	383
5.8.3.1	General .....	383
5.8.3.2	Initiation .....	383
5.8.3.3	Actions related to transmission of <i>SidelinkUEInformationNR</i> message .....	390
5.8.4	Void .....	397
5.8.5	Sidelink synchronisation information transmission for NR sidelink communication/discovery/positioning .....	397
5.8.5.1	General .....	397
5.8.5.2	Initiation .....	397
5.8.5.3	Transmission of SLSS .....	398
5.8.5a	Sidelink synchronisation information transmission for V2X sidelink communication .....	400
5.8.5a.1	General .....	400
5.8.5a.2	Initiation .....	400
5.8.6	Sidelink synchronisation reference .....	400
5.8.6.1	General .....	400
5.8.6.2	Selection and reselection of synchronisation reference .....	401
5.8.6.2a	Sidelink synchronization reference priority group order .....	402
5.8.6.2b	Sidelink synchronization reference search .....	403
5.8.6.3	Sidelink communication transmission reference cell selection .....	404
5.8.7	Sidelink communication reception .....	404
5.8.8	Sidelink communication transmission .....	405
5.8.9	Sidelink RRC procedure .....	408
5.8.9.1	Sidelink RRC reconfiguration .....	408
5.8.9.1.1	General .....	408
5.8.9.1.2	Actions related to transmission of <i>RRCReconfigurationSidelink</i> message .....	409
5.8.9.1.3	Reception of an <i>RRCReconfigurationSidelink</i> by the UE .....	412
5.8.9.1.4	Void .....	415
5.8.9.1.5	Void .....	415

5.8.9.1.6	Void .....	415
5.8.9.1.7	Void .....	415
5.8.9.1.8	Reception of an <i>RRCReconfigurationFailureSidelink</i> by the UE.....	415
5.8.9.1.9	Reception of an <i>RRCReconfigurationCompleteSidelink</i> by the UE .....	415
5.8.9.1.10	Sidelink reset configuration.....	415
5.8.9.1a	Sidelink radio bearer management.....	416
5.8.9.1a.1	Sidelink DRB release .....	416
5.8.9.1a.2	Sidelink DRB addition/modification .....	417
5.8.9.1a.3	Sidelink SRB release .....	419
5.8.9.1a.4	Sidelink SRB addition .....	419
5.8.9.1a.5	Additional Sidelink RLC Bearer release .....	420
5.8.9.1a.5.1	Additional Sidelink RLC Bearer release conditions .....	420
5.8.9.1a.5.2	Additional Sidelink RLC Bearer release operation.....	420
5.8.9.1a.6	Additional Sidelink RLC Bearer addition/modification.....	421
5.8.9.1a.6.1	Additional Sidelink RLC Bearer addition/modification conditions.....	421
5.8.9.1a.6.2	Additional Sidelink RLC Bearer addition/modification operation .....	421
5.8.9.1b	Sidelink Carrier Configuration.....	423
5.8.9.1b.1	Sidelink Carrier Release .....	423
5.8.9.1b.1.1	Sidelink Carrier Release Condition.....	423
5.8.9.1b.2	Sidelink Carrier Addition .....	424
5.8.9.1b.2.1	Sidelink Carrier Addition Condition.....	424
5.8.9.2	Sidelink UE capability transfer .....	424
5.8.9.2.1	General .....	424
5.8.9.2.2	Initiation .....	425
5.8.9.2.3	Actions related to transmission of the <i>UECapabilityEnquirySidelink</i> by the UE.....	425
5.8.9.2.4	Actions related to reception of the <i>UECapabilityEnquirySidelink</i> by the UE .....	425
5.8.9.3	Sidelink radio link failure related actions.....	425
5.8.9.3a	End-to-end PC5 connection failure related actions performed by L2 U2U Remote UE.....	427
5.8.9.3b	End-to-end PC5 connection failure/release related actions performed by L2 U2U Relay UE.....	427
5.8.9.4	Sidelink common control information .....	428
5.8.9.4.1	General .....	428
5.8.9.4.2	Actions related to reception of <i>MasterInformationBlockSidelink</i> message .....	428
5.8.9.4.3	Transmission of <i>MasterInformationBlockSidelink</i> message .....	428
5.8.9.5	Actions related to PC5-RRC connection release requested by upper layers .....	429
5.8.9.5a	Actions related to end-to-end PC5-RRC connection release performed by L2 U2U Remote UE .....	430
5.8.9.6	Sidelink UE assistance information .....	430
5.8.9.6.1	General .....	430
5.8.9.6.2	Initiation .....	431
5.8.9.6.3	Actions related to reception of <i>UEAssistanceInformationSidelink</i> message .....	431
5.8.9.7	PC5 Relay RLC channel management for L2 U2N or U2U relay .....	431
5.8.9.7.0	Derivation of PC5 Relay RLC channel configuration .....	431
5.8.9.7.1	PC5 Relay RLC channel release.....	431
5.8.9.7.2	PC5 Relay RLC channel addition/modification .....	432
5.8.9.8	Remote UE information .....	433
5.8.9.8.1	General .....	433
5.8.9.8.2	Actions related to transmission of <i>RemoteUEInformationSidelink</i> message.....	433
5.8.9.8.3	Reception of <i>RemoteUEInformationSidelink</i> message by the L2 U2N/U2U Relay UE.....	434
5.8.9.9	Uu message transfer in sidelink .....	436
5.8.9.9.1	General .....	436
5.8.9.9.2	Actions related to transmission of <i>UuMessageTransferSidelink</i> message.....	436
5.8.9.9.3	Reception of the <i>UuMessageTransferSidelink</i> .....	436
5.8.9.10	Notification Message .....	437
5.8.9.10.1	General .....	437
5.8.9.10.2	Initiation .....	437
5.8.9.10.3	Actions related to transmission of <i>NotificationMessageSidelink</i> message .....	437
5.8.9.10.4	Actions related to reception of <i>NotificationMessageSidelink</i> message.....	438
5.8.9.11	UE information transfer on sidelink.....	439
5.8.9.11.1	General .....	439
5.8.9.11.2	Actions related to transmission of the <i>UEInformationRequestSidelink</i> by the UE.....	439
5.8.9.11.3	Actions related to reception of the <i>UEInformationRequestSidelink</i> by the UE .....	439
5.8.9.11.4	Actions related to reception of the <i>UEInformationResponseSidelink</i> by the UE.....	440
5.8.10	Sidelink measurement.....	440

5.8.10.1	Introduction.....	440
5.8.10.2	Sidelink measurement configuration.....	441
5.8.10.2.1	General .....	441
5.8.10.2.2	Sidelink measurement identity removal .....	442
5.8.10.2.3	Sidelink measurement identity addition/modification .....	442
5.8.10.2.4	Sidelink measurement object removal.....	442
5.8.10.2.5	Sidelink measurement object addition/modification .....	442
5.8.10.2.6	Sidelink reporting configuration removal.....	443
5.8.10.2.7	Sidelink reporting configuration addition/modification .....	443
5.8.10.2.8	Sidelink quantity configuration .....	444
5.8.10.3	Performing NR sidelink measurements.....	444
5.8.10.3.1	General .....	444
5.8.10.3.2	Derivation of NR sidelink measurement results .....	444
5.8.10.4	Sidelink measurement report triggering .....	444
5.8.10.4.1	General .....	444
5.8.10.4.2	Event S1 (Serving becomes better than threshold).....	445
5.8.10.4.3	Event S2 (Serving becomes worse than threshold) .....	446
5.8.10.5	Sidelink measurement reporting.....	447
5.8.10.5.1	General .....	447
5.8.11	Zone identity calculation .....	447
5.8.12	DFN derivation from GNSS .....	448
5.8.13	NR sidelink discovery.....	448
5.8.13.1	General .....	448
5.8.13.2	NR sidelink discovery monitoring .....	448
5.8.13.3	NR sidelink discovery transmission .....	449
5.8.14	NR sidelink U2N Relay UE operation.....	453
5.8.14.1	General .....	453
5.8.14.2	NR sidelink U2N Relay UE threshold conditions.....	453
5.8.15	NR sidelink U2N Remote UE operation.....	453
5.8.15.1	General .....	453
5.8.15.2	NR Sidelink U2N Remote UE threshold conditions .....	453
5.8.15.3	Selection and reselection of NR sidelink U2N Relay UE .....	454
5.8.16	NR sidelink U2U Relay UE operation.....	455
5.8.16.1	General .....	455
5.8.16.2	NR sidelink U2U Relay UE threshold conditions.....	455
5.8.16.3	Neighbor UE(s) in proximity conditions.....	455
5.8.17	NR sidelink U2U Remote UE operation.....	456
5.8.17.1	General .....	456
5.8.17.2	NR Sidelink U2U Remote UE threshold conditions .....	456
5.8.17.3	Conditions for selection and reselection of NR sidelink U2U Relay UE .....	457
5.8.17.4	Actions related to selection and reselection of NR sidelink U2U Relay UE.....	457
5.8.18	NR sidelink positioning .....	458
5.8.18.1	General .....	458
5.8.18.2	NR sidelink positioning measurement .....	458
5.8.18.3	NR sidelink positioning transmission.....	458
5.9	MBS Broadcast .....	461
5.9.1	Introduction.....	461
5.9.1.1	General .....	461
5.9.1.2	MCCH scheduling.....	461
5.9.1.3	MCCH information validity and notification of changes.....	461
5.9.2	MCCH information acquisition .....	462
5.9.2.1	General .....	462
5.9.2.2	Initiation.....	462
5.9.2.3	MCCH information acquisition by the UE.....	462
5.9.2.4	Actions upon reception of the <i>MBSBroadcastConfiguration</i> message .....	462
5.9.3	Broadcast MRB configuration .....	463
5.9.3.1	General .....	463
5.9.3.2	Initiation.....	463
5.9.3.3	Broadcast MRB establishment .....	463
5.9.3.4	Broadcast MRB release.....	463
5.9.4	MBS Interest Indication.....	464
5.9.4.1	General .....	464

5.9.4.2	Initiation.....	464
5.9.4.3	MBS frequencies of interest determination.....	465
5.9.4.4	MBS services of interest determination.....	465
5.9.4.5	Setting of the contents of MBS Interest Indication.....	466
5.10	MBS multicast reception in RRC_INACTIVE.....	466
5.10.1	Introduction.....	466
5.10.1.1	General.....	466
5.10.1.2	Multicast MCCH scheduling.....	467
5.10.1.3	Multicast MCCH information validity and notification of changes.....	467
5.10.2	Multicast MCCH information acquisition.....	468
5.10.2.1	General.....	468
5.10.2.2	Initiation.....	468
5.10.2.3	Multicast MCCH information acquisition by the UE.....	468
5.10.2.4	Actions upon reception of the <i>MBSMulticastConfiguration</i> message.....	469
5.10.3	MRB configuration.....	469
5.10.3.1	General.....	469
5.10.3.2	Multicast MRB establishment.....	469
5.10.3.3	Multicast MRB release.....	469
6	Protocol data units, formats and parameters (ASN.1).....	470
6.1	General.....	470
6.1.1	Introduction.....	470
6.1.2	Need codes and conditions for optional fields.....	470
6.1.3	General rules.....	473
6.2	RRC messages.....	473
6.2.1	General message structure.....	473
–	<i>NR-RRC-Definitions</i> .....	473
–	<i>BCCH-BCH-Message</i> .....	473
–	<i>BCCH-DL-SCH-Message</i> .....	474
–	<i>DL-CCCH-Message</i> .....	474
–	<i>DL-DCCH-Message</i> .....	475
–	<i>MCCH-Message</i> .....	475
–	<i>MulticastMCCH-Message</i> .....	476
–	<i>PCCH-Message</i> .....	476
–	<i>UL-CCCH-Message</i> .....	477
–	<i>UL-CCCH1-Message</i> .....	477
–	<i>UL-DCCH-Message</i> .....	478
6.2.2	Message definitions.....	480
–	<i>CounterCheck</i> .....	480
–	<i>CounterCheckResponse</i> .....	481
–	<i>DedicatedSIBRequest</i> .....	482
–	<i>DLDedicatedMessageSegment</i> .....	483
–	<i>DLInformationTransfer</i> .....	484
–	<i>DLInformationTransferMRDC</i> .....	486
–	<i>FailureInformation</i> .....	487
–	<i>IABOtherInformation</i> .....	488
–	<i>IndirectPathFailureInformation</i> .....	491
–	<i>LocationMeasurementIndication</i> .....	492
–	<i>LoggedMeasurementConfiguration</i> .....	493
–	<i>MBSBroadcastConfiguration</i> .....	495
–	<i>MBSInterestIndication</i> .....	496
–	<i>MBSMulticastConfiguration</i> .....	498
–	<i>MCGFailureInformation</i> .....	499
–	<i>MeasurementReport</i> .....	500
–	<i>MeasurementReportAppLayer</i> .....	501
–	<i>MIB</i> .....	503
–	<i>MobilityFromNRCommand</i> .....	504
–	<i>Paging</i> .....	506
–	<i>RRCReestablishment</i> .....	508
–	<i>RRCReestablishmentComplete</i> .....	509
–	<i>RRCReestablishmentRequest</i> .....	510
–	<i>RRCReconfiguration</i> .....	511

–	<i>RRCReconfigurationComplete</i> .....	520
–	<i>RRCReject</i> .....	522
–	<i>RRCRelease</i> .....	523
–	<i>RRCResume</i> .....	536
–	<i>RRCResumeComplete</i> .....	539
–	<i>RRCResumeRequest</i> .....	541
–	<i>RRCResumeRequest1</i> .....	542
–	<i>RRCSetup</i> .....	543
–	<i>RRCSetupComplete</i> .....	544
–	<i>RRCSetupRequest</i> .....	547
–	<i>RRCSystemInfoRequest</i> .....	548
–	<i>SCGFailureInformation</i> .....	550
–	<i>SCGFailureInformationEUTRA</i> .....	552
–	<i>SecurityModeCommand</i> .....	553
–	<i>SecurityModeComplete</i> .....	554
–	<i>SecurityModeFailure</i> .....	555
–	<i>SIB1</i> .....	555
–	<i>SidelinkUEInformationNR</i> .....	562
–	<i>SystemInformation</i> .....	571
–	<i>UEAssistanceInformation</i> .....	573
–	<i>UECapabilityEnquiry</i> .....	587
–	<i>UECapabilityInformation</i> .....	588
–	<i>UEInformationRequest</i> .....	588
–	<i>UEInformationResponse</i> .....	590
–	<i>UEPositioningAssistanceInfo</i> .....	610
–	<i>ULDedicatedMessageSegment</i> .....	612
–	<i>ULInformationTransfer</i> .....	613
–	<i>ULInformationTransferIRAT</i> .....	614
–	<i>ULInformationTransferMRDC</i> .....	615
6.3	RRC information elements .....	616
6.3.0	Parameterized types .....	616
–	<i>SetupRelease</i> .....	616
6.3.1	System information blocks .....	616
–	<i>SIB2</i> .....	616
–	<i>SIB3</i> .....	621
–	<i>SIB4</i> .....	623
–	<i>SIB5</i> .....	629
–	<i>SIB6</i> .....	633
–	<i>SIB7</i> .....	633
–	<i>SIB8</i> .....	634
–	<i>SIB9</i> .....	635
–	<i>SIB10</i> .....	636
–	<i>SIB11</i> .....	637
–	<i>SIB12</i> .....	638
–	<i>SIB13</i> .....	641
–	<i>SIB14</i> .....	642
–	<i>SIB15</i> .....	642
–	<i>SIB16</i> .....	643
–	<i>SIB17</i> .....	644
–	<i>SIB17bis</i> .....	646
–	<i>SIB18</i> .....	649
–	<i>SIB19</i> .....	649
–	<i>SIB20</i> .....	652
–	<i>SIB21</i> .....	653
–	<i>SIB22</i> .....	654
–	<i>SIB23</i> .....	655
–	<i>SIB24</i> .....	656
–	<i>SIB25</i> .....	657
6.3.1a	Positioning System information blocks .....	658
–	<i>PosSystemInformation-r16-IEs</i> .....	658
–	<i>PosSI-SchedulingInfo</i> .....	659
–	<i>SIBpos</i> .....	662